

Service and Maintenance Manual

Models 800S 810SJ 860SJ

Prior to SN 0300182743 & B300001328

P/N-3121139

August 11, 2017

ANSI (E





SECTION A. INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS

A GENERAL

This section contains the general safety precautions which must be observed during maintenance of the aerial platform. It is of utmost importance that maintenance personnel pay strict attention to these warnings and precautions to avoid possible injury to themselves or others, or damage to the equipment. A maintenance program must be followed to ensure that the machine is safe to operate.

A WARNING

MODIFICATION OR ALTERATION OF AN AERIAL WORK PLATFORM SHALL BE MADE ONLY WITH WRITTEN PERMISSION FROM THE MANUFACTURER.

The specific precautions to be observed during maintenance are inserted at the appropriate point in the manual. These precautions are, for the most part, those that apply when servicing hydraulic and larger machine component parts.

Your safety, and that of others, is the first consideration when engaging in the maintenance of equipment. Always be conscious of weight. Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. When raising a portion of the equipment, ensure that adequate support is provided.

M WARNING

SINCE THE MACHINE MANUFACTURER HAS NO DIRECT CONTROL OVER THE FIELD INSPECTION AND MAINTENANCE, SAFETY IN THIS AREA IS THE RESPONSIBILITY OF THE OWNER/OPERATOR.

B HYDRAULIC SYSTEM SAFETY

It should be noted that the machines hydraulic systems operate at extremely high potentially dangerous pressures. Every effort should be made to relieve any system pressure prior to disconnecting or removing any portion of the system.

Do not use your hand to check for leaks. Use a piece of cardboard or paper to search for leaks. Wear gloves to help protect hands from spraying fluid.



C MAINTENANCE

M WARNING

FAILURE TO COMPLY WITH SAFETY PRECAUTIONS LISTED IN THIS SECTION COULD RESULT IN MACHINE DAMAGE, PERSONNEL INJURY OR DEATH AND IS A SAFETY VIOLATION.

- ENSURE REPLACEMENT PARTS OR COMPONENTS ARE IDEN-TICAL OR EQUIVALENT TO ORIGINAL PARTS OR COMPO-NENTS.
- NO SMOKING IS MANDATORY. NEVER REFUEL DURING ELEC-TRICAL STORMS. ENSURE THAT FUEL CAP IS CLOSED AND SECURE AT ALL OTHER TIMES.
- REMOVE ALL RINGS, WATCHES AND JEWELRY WHEN PER-FORMING ANY MAINTENANCE.
- DO NOT WEAR LONG HAIR UNRESTRAINED, OR LOOSE-FIT-TING CLOTHING AND NECKTIES WHICH ARE APT TO BECOME CAUGHT ON OR ENTANGLED IN EOUIPMENT.
- OBSERVE AND OBEY ALL WARNINGS AND CAUTIONS ON MACHINE AND IN SERVICE MANUAL.
- KEEP OIL, GREASE, WATER, ETC. WIPED FROM STANDING SURFACES AND HAND HOLDS.
- USE CAUTION WHEN CHECKING A HOT, PRESSURIZED COOL-ANT SYSTEM.
- NEVER WORK UNDER AN ELEVATED BOOM UNTIL BOOM HAS BEEN SAFELY RESTRAINED FROM ANY MOVEMENT BY BLOCKING OR OVERHEAD SLING, OR BOOM SAFETY PROP HAS BEEN ENGAGED.
- BEFORE MAKING ADJUSTMENTS, LUBRICATING OR PERFORMING ANY OTHER MAINTENANCE, SHUT OFF ALL POWER CONTROLS.
- BATTERY SHOULD ALWAYS BE DISCONNECTED DURING REPLACEMENT OF ELECTRICAL COMPONENTS.
- KEEP ALL SUPPORT EQUIPMENT AND ATTACHMENTS STOWED IN THEIR PROPER PLACE.
- USE ONLY APPROVED, NONFLAMMABLE CLEANING SOL-VENTS.

3121139 A-1

REVISON LOG

Original Issue - October 31, 2001 Revised - January 16, 2002 Revised - February 4, 2002 Revised - May 10, 2002 Revised - July 2, 2003 - July 14, 2005 Revised - November 17, 2005 Revised Revised - March 6, 2006 - November 21, 2007 Revised - July 25, 2008 Revised Revised - November 16, 2012 - November 8, 2016 -Revised Revised August 11, 2017

A-2 3121139

| SECTION N | 10. | TITLE | PAGE NO |
|------------------|-----|--|---------|
| SECTION | Α | - INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS | |
| Α | | General | Δ-1 |
| В | | Hydraulic System Safety | |
| C | | Maintenance. | |
| | | | |
| SECTION | 1 | - SPECIFICATIONS | |
| 1.1 | | Operating Specifications | 1-1 |
| 1.2 | | Specifications and Performance Data | 1-2 |
| 1.3 | | Capacities | 1-2 |
| 1.4 | | Component Data | 1-2 |
| | | Engine Data | 1-2 |
| | | Battery | |
| 1.5 | | Tires | 1-4 |
| 1.6 | | Torque Requirements | |
| 1.7 | | Major Component Weights | |
| 1.8 | | Lubrication | |
| | | Hydraulic Oil | |
| 1.9 | | Operator Maintenance | |
| | | Draining Oil Build Up From The Propane Regulator (Prior to S/N 0300134626) | |
| | | Propane Fuel Filter Replacement | |
| | | Propane Fuel System Pressure Relief | |
| 1.10 | า | Serial Number Location | |
| | | | |
| SECTION | 2 | - GENERAL | |
| 2.1 | | Machine Preparation, Inspection, and Maintenance | 2-1 |
| | | General | 2-1 |
| | | Preparation, Inspection, and Maintenance | 2-1 |
| | | Pre-Start Inspection | 2-1 |
| | | Pre-Delivery Inspection and Frequent Inspection | 2-1 |
| | | Annual Machine Inspection | 2-1 |
| | | Preventative Maintenance | 2-1 |
| 2.2 | | Service and Guidelines | 2-2 |
| | | General | 2-2 |
| | | Safety and Workmanship | 2-2 |
| | | Cleanliness | |
| | | Components Removal and Installation | |
| | | Component Disassembly and Reassembly | |
| | | Pressure-Fit Parts | |
| | | Bearings | |
| | | Gaskets | |
| | | Bolt Usage and Torque Application | |
| | | Hydraulic Lines and Electrical Wiring | |
| | | Hydraulic System | |
| | | Lubrication | |
| | | Battery | |
| | | Lubrication and Servicing | |
| 2.3 | | Lubrication and Information. | |
| 2.5 | | Hydraulic System | |
| | | Hydraulic Oil | |
| | | , | |
| | | Changing Hydraulic Oil | |
| 2.4 | | Lubrication Specifications | |
| 2.4 | | Cylinder Drift | |
| | | Theory | |
| | | Cylinder Leakage Test | |
| <u> </u> | | Cylinder Thermal Drift | |
| 2.5 | | Pins and Composite Rearing Repair Guidelines | 2-6 |

3121139 i

| SECTION NO. | TITLE | PAGE NO |
|-------------|---|---------|
| 2.6 | Welding on JLG Equipment | 2-6 |
| | Do the Following When Welding on JLG Equipment | |
| | Do NOT Do the Following When Welding on JLG Equipment | 2-6 |
| SECTION 3 | - CHASSIS & TURNTABLE | |
| 3.1 | Tires & Wheels | 3-1 |
| | Tire Inflation | 3-1 |
| | Tire Damage | 3-1 |
| | Tire Replacement | 3-1 |
| | Wheel Replacement | 3-1 |
| | Wheel Installation | |
| 3.2 | Lockout Cylinder Bleeding | 3-2 |
| 3.3 | Oscillating Axle Lockout Test | |
| 3.4 | Free Wheeling Option | |
| | To Disengage Drive Motors and Brakes (Free Wheel) for Emergency Towing | |
| | To Engage Drive Motors and Brakes (Normal Operation) | |
| 3.5 | Wheel Drive Assembly, 2WD (Prior to SN 0300083331) | |
| 5.5 | Removal | |
| | Installation | |
| 3.6 | Wheel Drive Assembly, 2WD & 4WD (SN 0300083331 through 0300182743, | 5 10 |
| 5.0 | B30000100 through B300001091) | 3-11 |
| | Removal | |
| | Installation | |
| 3.7 | Wheel Drive Assembly, 4WD (Prior to SN 0300083331) | |
| 5.7 | Removal | |
| | Installation | |
| 3.8 | Drive Hub - 2WD (All Machines), 4WD (SN 0300083331 to SN 0300182743, | J-12 |
| 3.0 | | 2 12 |
| | B300000100 through B300001091) | |
| | Disassembly | |
| | Cleaning and Inspection | |
| | Repair | |
| 2.0 | Assembly | |
| 3.9 | Drive Brake, 2WD - Mico (Prior to SN 0300083331) | |
| | Disassembly | |
| | Assembly | |
| 2.10 | Bleeding | |
| 3.10 | Drive Brake (SN 0300083331 to SN 0300182743, B300000100 through B300001091) | |
| | Disassembly | |
| | Inspection | |
| 2.11 | Assembly | |
| 3.11 | Drive Motor - 2WD (Prior to SN 0300083331) | |
| | Spare Parts Kits | |
| | Replacing the Drive Shaft Seal | |
| | Disassembly | |
| | Assembly | |
| | Testing and Setup | |
| | Drive Motor Adjustment Procedure | |
| 3.12 | Drive Motor | |
| | Description | |
| | Shaft Seal Replacement | |
| | Loop Flushing Valve | |
| | Troubleshooting | |
| | Disassembly | |
| | Inspection | 3-44 |
| | Assembly | |
| | Initial Start-up Procedures | 3-51 |

ii 3121139

| SECTION NO. | TITLE | PAGE NO. |
|-------------|---|----------|
| 3.13 | Drive Hub (4WD Machines W/ Integral Brake) (Prior to SN 0300083331) | 3-52 |
| | Roll, Leak and Brake Testing | |
| | Tightening and Torquing Bolts | |
| | Main Disassembly | |
| | Input Carrier Disassembly | |
| | Output Carrier Disassembly | |
| | Housing-Spindle Disassembly | |
| | Spindle-Brake Disassembly | |
| | Input Carrier Sub-Assembly | |
| | Output Carrier Sub-Assembly | |
| | Spindle Brake Sub-Assembly | |
| | Housing-Spindle Sub-Assembly | |
| | DW2B Integral Brake Check | |
| | Main Assembly | |
| 3.14 | Re-Aligning Drive Hub Input Coupling | |
| | Equipment Required | |
| | Procedure | |
| 3.15 | Swing Drive (Prior to SN 0300066417) | |
| | Disassembly | |
| | Main Assembly Procedure | |
| | Hub Shaft Sub-Assembly | |
| | Carrier Sub-Assembly | |
| 3.16 | Swing Drive Brake - Mico (Prior to SN 0300066417) | |
| | Disassembly | |
| | Assembly | |
| | Bleeding | |
| 3.17 | Swing Motor (Prior to SN 0300066417) | |
| | Disassembly | |
| | Inspection and Cleaning | |
| | Assembly | |
| | Timing Procedure | |
| 3.18 | Swing Drive (SN 0300066417 through 0300182743, B300000100 through B300001091) | |
| | Roll, Leak And Brake Testing | 3-100 |
| | Tightening and Torquing Bolts | 3-100 |
| | Motor Control Valve Disassembly | 3-101 |
| | Motor and Brake Disassembly | 3-102 |
| | Main Drive Disassembly | 3-103 |
| | Hub-Shaft Disassembly | 3-104 |
| | Carrier Disassembly | 3-105 |
| | Hub-Shaft Assembly | 3-106 |
| | Carrier Assembly | 3-106 |
| | Main Drive Assembly | 3-107 |
| | Motor and Brake Assembly | 3-108 |
| | Motor Control Valve Assembly | 3-108 |
| 3.19 | Swing Drive Brake (SN 0300066417 through 0300182743, B300000100 through B300001091) | 3-111 |
| | Disassembly | 3-111 |
| | Inspection | 3-111 |
| | Assembly | 3-111 |
| 3.20 | Swing Motor (SN 0300066417 through 0300134351) | 3-113 |
| | Disassembly and inspection | 3-113 |
| | Assembly | |
| | One Piece Stator Construction | |
| 3.21 | Swing Motor (SN 0300134352 through 0300182743, B300000100 through B300001091) | 3-129 |
| | Disassembly | |
| | Assembly | |
| | One Piece Stator Construction | |
| 3.22 | Swing Hub Removal | 3-145 |

3121139 iii

| SECTION NO. | TITLE | PAGE NO. |
|-------------|---|----------|
| 3.23 | Swing Bearing | |
| | Turntable Bearing Mounting Bolt Condition Check | |
| | Wear Tolerance | |
| | Swing Bearing Removal | |
| | Swing Bearing Installation | 3-152 |
| | Swing Bearing Torque Values | 3-152 |
| 3.24 | Procedure For Setting Gear Backlash | 3-153 |
| | Swing Drive Lubrication | 3-154 |
| 3.25 | Rotary Coupling (Prior to SN 0300083331) | |
| 3.26 | Rotary Coupling (SN 0300083331 through 0300182743, B300000100 through B300001091) | 3-159 |
| 3.27 | Generator | 3-164 |
| | Maintenance Schedule | 3-164 |
| | Overload Protection | 3-164 |
| | Inspecting Brushes, Replacing Brushes, and Cleaning Slip Rings | 3-164 |
| | Troubleshooting | |
| 3.28 | Ford EFI Engine | |
| 3.23 | Performing Diagnostics | |
| | EFI Diagnostics | |
| | ECM and Sensors | |
| | Fuel System | |
| 3.29 | • | |
| | Deutz EMR 2 | |
| 3.30 | GM Engine General Maintenance | |
| | Maintenance of the Drive Belt. | |
| | Engine Electrical System Maintenance | |
| | Checking/Filling Engine Oil Level | |
| | Changing The Engine Oil | |
| | Coolant Fill Procedure - Dual Fuel Engine | |
| 3.31 | GM Engine Dual Fuel System | 3-194 |
| | Fuel Filter | 3-195 |
| | Electric Lock Off | |
| | EPR Assembly | 3-195 |
| | Low Pressure Regulator (LPR) | 3-196 |
| | Air Fuel Mixer | 3-196 |
| | Electronic Throttle Control (ETC) | 3-197 |
| | Engine Control Module | 3-197 |
| | Heated Exhaust Gas Oxygen Sensor | |
| | Gasoline Multi Point Fuel Injection System (MPFI) | |
| | Gasoline Fuel Pump | |
| | Gasoline Pressure And Temperature Sensor Manifold | |
| | Fuel Filter | |
| | Fuel Injector Rail | |
| | Fuel Injector | |
| 3.32 | GM Engine Fuel System Repair | |
| 3.32 | Propane Fuel System Pressure Relief | |
| | Propane Fuel System Leak Test | |
| | Propane Fuel Filter Replacement | |
| | Electronic Pressure Regulator (EPR) Assembly Replacement | |
| | Temperature Manifold Absolute Pressure (TMAP) Sensor | |
| | Electronic Throttle Control Replacement | |
| | | |
| | Mixer Replacement | |
| | Coolant Hose Replacement | |
| | Vapor Hose Replacement | |
| | Engine Control Module Replacement | |
| | Heated Exhaust Gas Oxygen Sensor Replacement | |
| 3.33 | GM Engine LPG Fuel System Diagnosis | |
| | Fuel System Description | |
| | Diagnostic Aids | 3-206 |

iv 3121139

| SECTION NO. | TITLE PAGE | NO. |
|-------------|--|-----|
| SECTION 4 | - BOOM & PLATFORM | |
| 4.1 | Main Boom Assembly4-1 | |
| | Removal | |
| | Boom Disassembly | |
| | Inspection | |
| | · | |
| | Assembly | |
| | Installation | |
| | Telescope Cylinder/Boom Cable Removal | |
| | Telescope Cylinder/Boom Cable Installation | |
| | Lift Cylinder Removal | |
| | Lift Cylinder Installation | |
| 4.2 | Platform | |
| | Platform Valve Removal 4-18 | |
| | Platform Valve Installation | |
| | Support Removal4-19 | ! |
| | Support Installation | |
| 4.3 | Rotator and Slave Cylinder 4-21 | |
| | Removal | |
| 4.4 | Main Boom Powertrack4-22 | |
| | Removal | |
| 4.5 | Powertrack Maintenance | |
| | One Piece Bracket Maintenance | |
| | Two Piece Bracket Maintenance | |
| | Snap Rings and Screws | |
| 4.6 | Boom Cleanliness Guidelines | |
| 4.7 | Wire Rope | |
| , | Inspection | |
| | Three Month Inspection | |
| | 12 Year or 7000 Hour Replacement | |
| | Replacement Criteria | |
| 4.8 | Boom Rope Torquing Procedures | |
| 4.0 | Torque Procedures | |
| 4.0 | | |
| 4.9 | Elevation & Capacity Switches - 800S | |
| 4.10 | Elevation, Dual Capacity, & Transport Switch - 860SJ | |
| 4.11 | Electronic Platform Leveling | |
| | Description | |
| | Normal Operation | |
| | Platform Leveling Fault4-41 | |
| | CAN Errors | |
| | Replacing the Level Sensors | |
| | Additional Platform and Jib Valves | |
| | Platform Leveling Calibration Procedure | |
| 4.12 | Helac Rotary actuator | |
| | Theory of Operation4-45 | |
| | Tools Required for Assembly/Disassembly | |
| | Disassembly | |
| | Inspection | |
| | Assembly | |
| | Installing Counterbalance Valve | |
| | Testing the Actuator | |
| | Installation and Bleeding | |
| | Troubleshooting | |
| 4.13 | Load Sensing device | |
| 5 | Collibrating the Load Concer | |

| SECTION N | 0. | TITLE PAG | GE NO. |
|-----------|----|---|------------|
| SECTION | 5 | - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS | |
| 5.1 | | Lubricating O-Rings in the Hydraulic System5 | i-1 |
| | | Cup and Brush 5 | -1 |
| | | Dip Method 5 | |
| | | Spray Method | -2 |
| | | Brush-on Method5 | -2 |
| 5.2 | | Cylinder Repair5 | 5-3 |
| | | Axle Lockout Cylinder 5 | -3 |
| | | Cleaning and Inspection | -5 |
| | | Assembly 5 | -6 |
| | | Jib Lift Cylinder (860SJ Only) | -9 |
| | | Main Boom Lift Cylinder 5 | -15 |
| | | Platform Level Cylinder | -21 |
| | | Steer Cylinder (Prior to SN 0300142665) | |
| | | Steer Cylinder (SN 0300014266 through 0300182743, SN B300000100 through B300001091) 5 | -32 |
| | | Telescope Cylinder 5 | -37 |
| 5.3 | | Pressure Setting Procedure5 | -44 |
| | | Set Up of the Function Pump5 | -44 |
| | | Adjustments Made at the Main Valve Block5 | -45 |
| | | Adjustments Made at the Platform Valve Assembly | -46 |
| 5.4 | | Start Up Procedures5 | 5-51 |
| | | Start Up After Overhaul or Replacement of Components | -51 |
| SECTION | 6 | - JLG CONTROL SYSTEM | |
| 6.1 | | JLG Control System Analyzer Kit Instructions | 5-1 |
| | | Introduction | -1 |
| | | To Connect the JLG Control System Analyzer | -2 |
| | | Using the Analyzer 6 | -2 |
| | | Changing the Access Level of the Hand Held Analyzer | -3 |
| | | Adjusting Configuration Using the Hand Held Analyzer | -4 |
| | | Machine Setup | -4 |
| | | Level Vehicle Description | |
| 6.2 | | Machine Personality Settings and Function Speeds | |
| 6.3 | | Machine Orientation When Doing Speed Tests | -35 |
| | | Test Notes | |
| 6.4 | | CANBUS Communications | -36 |
| | | Analyzer Diagnostics Menu Structure 6 | 5-52 |
| SECTION | 7 | - BASIC ELECTRICAL INFORMATION & SCHEMATICS | |
| 7.1 | | General | '-1 |
| 7.2 | | Multimeter Basics | '-1 |
| | | Grounding 7 | '-1 |
| | | Backprobing | '-1 |
| | | Min/Max | '-1 |
| | | Polarity 7 | '-1 |
| | | Scale | '-1 |
| | | Voltage Measurement | '-1 |
| | | Resistance Measurement | '-2 |
| | | Continuity Measurement | '-2 |
| | | Current Measurement | |
| 7.3 | | Checking Switches | |
| | | Basic Check | |
| | | Limit Switches | |
| | | Automatic Switches | |
| | | Switch Wiring - Low Side, High Side | '-4 |

vi 3121139

| SECTION NO. | TITLE | PAGE NO. |
|-------------|---|----------|
| 7.4 | Applying Silicone Dielectric Compound to Electrical Connections | 7-4 |
| | Installation of Dielectric Grease | 7-5 |
| | Deutsch HD, DT, DTM, DRC Series | 7-5 |
| | AWP Seal | |
| | AMP Mate-N-Lok | 7-6 |
| | DIN Connectors | 7-6 |
| | Exclusions | 7-6 |
| 7.5 | AMP Connector | 7-8 |
| | Assembly | 7-8 |
| | Disassembly | |
| | Wedge Lock | |
| | Service - Voltage Reading | |
| 7.6 | Deutsch Connectors | |
| | DT/DTP Series Assembly | 7-12 |
| | DT/DTP Series Disassembly | |
| | HD30/HDP20 Series Assembly | 7-13 |
| | HD30/HDP20 Series Disassembly | |
| 7.7 | Electrical Schematics | |

3121139 vii

| IGURE N | O. TITLE | PAGE NO. |
|-----------------------------|---|----------|
| 1-1. | Operator Maintenance and Lubrication Diagram | 1-7 |
| 1-2. | Deutz Engine Dipstick | 1-10 |
| 1-3. | Filter Lock Assembly | 1-13 |
| 1-4. | Serial Number Locations | 1-14 |
| 1-5. | Torque Chart (SAE Fasteners)- Sheet 1 of 5 | 1-15 |
| 1-6. | Torque Chart (SAE Fasteners)- Sheet 2 of 5 | 1-16 |
| 1-7. | Torque Chart (SAE Fasteners)- Sheet 3 of 5 | 1-17 |
| 1-8. | Torque Chart (METRIC Fasteners) - Sheet 4 of 5 | 1-18 |
| 1-9. | Torque Chart (METRIC Fasteners) - Sheet 5 of 5 | 1-19 |
| 2-1. | Engine Operating Temperature Specifications - Deutz | 2-10 |
| 2-2. | Engine Operating Temperature Specifications - Ford | 2-11 |
| 2-3. | Engine Operating Temperature Specifications - Caterpillar | 2-12 |
| 2-4. | Engine Operating Temperature Specifications - GM | 2-13 |
| 3-1. | Axle and Steering Installation without Tow Package - Sheet 1 of 2 | 3-4 |
| 3-2. | Axle and Steering Installation without Tow Package - Sheet 2 of 2 | |
| 3-3. | Axle and Steering Installation with Tow Package- Sheet 1 of 2 | |
| 3-4. | Axle and Steering Installation with Tow Package - Sheet 2 of 2 | 3-7 |
| 3-5. | Drive Hub Installation - 2WD (Prior to SN 0300083331) | 3-9 |
| 3-6. | Drive Hub Installation - 2WD & 4WD (SN 0300083331 through 0300182743, | |
| | B300000100 through B300001091) | |
| 3-7. | Drive Hub Installation - 4WD (Prior to SN 0300083331) | 3-12 |
| 3-8. | Drive Hub - 2WD (All Machines), 4WD (SN 0300083331 through SN 0300182743, | |
| | B300000100 through B300001091) | |
| 3-9. | Drive Brake, 2WD - Mico (Prior to SN 0300083331) | |
| 3-10. | Drive Brake (SN 0300083331 to SN 0300182743, B300000100 through B300001091) | |
| 3-11. | Drive Motor Cutaway | |
| 3-12. | Bearing Tension | |
| 3-13. | Flow Control Pilot Valves | |
| 3-14. | Drive Motor Adjustment | |
| 3-15. | Drive Motor Cross Section | |
| 3-16. | Removing the Shaft Seal | |
| 3-17. | Loop Flushing Spool | |
| 3-18. | Loop Flushing Spool | |
| 3-19. | Plugs, Fittings, and Speed Sensor | |
| 3-20. | End Cap | |
| 3-21. | Valve Plate & Rear Shaft Bearing | |
| 3-22. | Cylinder Kit | |
| 3-23. | Shaft Seal | |
| 3-24. | Shaft & Front Bearing | |
| 3-25. | Swashplate & Servo Piston | |
| 3-26. | Cylinder Kit Disassembly | |
| 3-27. 3-28. | Servo Piston | |
| 3-26. 3-29. | Swashplate and Journal Bearing | |
| 3-29. 3-30. | Shaft and Front Bearing | |
| 3-30. 3-31. | Cylinder Kit Installation | |
| 3-31. 3-32. | Servo Spring and Minimum Angle Stop | |
| 3-32. 3-33. | Valve Plate and Rear Bearing | |
| 3-33. 3-34. | End Cap | |
| 3-3 4 . 3-35. | Shaft Seal | |
| 3-35. 3-36. | Plugs and Fittings Installation | |
| 3-30. 3-37. | Loop Flushing Spool | |
| 3-37. 3-38. | Main Disassembly - Sheet 1 of 2 | |
| 3-30. 3-39. | Main Disassembly- Sheet 1 of 2 | |
| 3-39. 3-40. | Input Carrier Disassembly. | |
| 3- 4 0. 3-41. | Output Carrier Assembly. | |
| 3-42. | Housing-Spindle Disassembly. | |

viii 3121139

| FIGURE N | IO. TITLE | PAGE NO |
|----------|---|----------------|
| 3-43. | Spindle Brake Disassembly | 3-58 |
| 3-44. | Input Carrier Sub-Assembly | 3-60 |
| 3-45. | Output Carrier Sub-Assembly | 3-62 |
| 3-46. | Spindle Brake Sub-Assembly | 3-64 |
| 3-47. | Housing-Spindle Assembly | |
| 3-48. | Main Assembly - Sheet 1 | |
| 3-49. | Main Assembly - Sheet 2 | |
| 3-50. | Assembly Drawing - Without Integral Input Brake - Sheet 1 of 2 | 3-69 |
| 3-51. | Assembly Drawing - Without Integral Input Brake - Sheet 2 of 2 | |
| 3-52. | Assembly Drawing - With Integral Input Brake - Sheet 1 of 2 | |
| 3-53. | Assembly Drawing - With Integral Input Brake - Sheet 2 of 2 | |
| 3-54. | Assembly Tools - Bearing Cone Pressing - "B" Bearing | |
| 3-55. | Assembly Tools - Bearing Cone Pressing - "A" Bearing | |
| 3-56. | Assembly Tools - Bearing Cup Pressing - "A" & "B" Bearings | |
| 3-57. | Assembly Tools - Seal Pressing | |
| 3-58. | Assembly Tools - Spacer - Brake Disc Installation | |
| 3-59. | Assembly Tools - Brake Retaining Ring Installation | |
| 3-60. | Swing Drive and Turntable Bearing | |
| 3-61. | Swing Drive (Prior to SN 0300066417) | |
| 3-62. | Swing Drive Brake - Mico (Prior to SN 0300066417) | |
| 3-63. | Swing Motor (Prior to SN 0300066417) | |
| 3-64. | Motor Control Valve | |
| 3-65. | Motor and Brake | |
| 3-66. | Main Drive Assembly | |
| 3-67. | Hub-Shaft | |
| 3-68. | Carrier | 3-105 |
| 3-69. | Swing Drive Assembly | 3-109 |
| 3-70. | Swing Motor and Brake Assembly | 3-110 |
| 3-71. | Drive Brake (SN 0300066417 through 0300134351) | |
| 3-72. | Swing Drive Motor (SN 0300066417 through 0300134351) | |
| 3-73. | Swing Drive Motor (SN 0300134352 through 0300182743, B300000100 through B300001091) | 3-130 |
| 3-74. | Swing Bearing Torque Sequence | 3-146 |
| 3-75. | Swing Bearing Tolerance Boom Placement. (Sheet 1 of 2) | 3-147 |
| 3-76. | Swing Bearing Tolerance Boom Placement.(Sheet 2 of 2) | 3-148 |
| 3-77. | Swing Bolt Feeler Gauge Check | 3-149 |
| 3-78. | Swing Bearing Tolerance Measuring Point | 3-149 |
| 3-79. | Swing Bearing Removal - 800S | 3-150 |
| 3-80. | Swing Bearing Removal - 860SJ | 3-151 |
| 3-81. | Rotary Coupling Seal Installation (Prior to SN 0300083331) | 3-155 |
| 3-82. | Rotary Coupling Cutaway (Prior to SN 0300083331) | 3-156 |
| 3-83. | Rotary Coupling Port Location (7 Port) (Prior to SN 0300083331) | 3-157 |
| 3-84. | Rotary Coupling Installation (Prior to SN 0300083331) | 3-158 |
| 3-85. | Rotary Coupling Seal Installation (SN 0300083331 through 0300182743, | |
| | B300000100 through B300001091) | 3-159 |
| 3-86. | Rotary Coupling Cutaway (SN 0300083331 through 0300182743, | |
| | B300000100 through B300001091) | 3-160 |
| 3-87. | Rotary Coupling Port Location (7 Port) (SN 0300083331 through 0300182743, | |
| | B300000100 through B300001091) | 3-161 |
| 3-88. | Rotary Coupling Installation (SN 0300083331 through 0300182743, | |
| | B300000100 through B300001091) | |
| 3-89. | Inspecting Generator Brushes, Replacing Brushes, and Cleaning Slip Rings | |
| 3-90. | EFI Component Location | |
| 3-91. | Typical Fuel System | |
| 3-92. | EMR 2 Engine Side Equipment | |
| 3-93. | Deutz EMR 2 Troubleshooting Flow Chart | |
| 3-94. | Deutz EMR 2 Vehicle Side Connection Diagram | |
| 3-95. | Deutz EMR 2 Engine Side Connection Diagram - Sheet 1 of 2 | 3-183 |

3121139 ix

| IGURE N | O. TITLE | PAGE NO. |
|----------------|---|----------|
| 3-96. | Deutz EMR 2 Engine Side Connection Diagram - Sheet 2 of 2 | 3-184 |
| 3-97. | EMR 2 Engine Plug Pin Identification | 3-185 |
| 3-98. | EMR 2 Vehicle Plug Pin Identification | 3-186 |
| 3-99. | EMR2 Fault Codes - Sheet 1 of 5 | 3-187 |
| 3-100. | EMR2 Fault Codes - Sheet 2 of 5 | 3-188 |
| 3-101. | EMR2 Fault Codes - Sheet 3 of 5 | 3-189 |
| 3-102. | EMR2 Fault Codes - Sheet 4 of 5 | 3-190 |
| 3-103. | EMR2 Fault Codes - Sheet 5 of 5 | |
| 3-104. | Engine Oil Dip Stick | |
| 3-105. | Electric Fuel Lock Off | |
| 3-106. | EPR Assembly | |
| 3-107. | Low Pressure Regulators | |
| 3-108. | Air Fuel Mixer | |
| 3-109. | ETC throttle control device | |
| 3-110. | LPG Engine Control Unit (ECM) | |
| 3-111. | ECM Assembly | |
| 3-112. | Heated Exhaust Gas Oxygen Sensor (HEGO) | |
| 3-113. | Gasoline Fuel Pressure and Temperature Manifold Assembly | |
| 3-114. | Filter Lock Assembly | |
| 3-115. | EPR Assembly | |
| 3-116. | Pressure Regulator Section | |
| 3-117. | (TMAP) Sensor & Electronic Throttle Control (ETC) | |
| 3-117. | Mixer Assembly | |
| 3-119. | EPR Assembly | |
| 4-1. | Boom Assembly Cutaway - Sheet 1 of 2 | |
| 4-2. | Boom Assembly Cutaway - Sheet 2 of 2 | |
| 4-3. | Boom Components - Sheet 1 of 2 | |
| 4-4. | Boom Components - Sheet 2 of 2 | |
| 4-5. | Disassembly of Sheave Assembly | |
| 4-6. | Disassembly Wire Rope Routing Procedure | |
| 4-0. 4-7. | Dimension of Sheaves When New | |
| 4-7. 4-8. | Proximity Switch Adjustment | |
| 4-8. 4-9. | Routing Installation of Retract Wire Ropes | |
| 4-9. 4-10. | Location of Components Platform Support | |
| 4-10. 4-11. | | |
| | Platform Support Torque Values | |
| 4-12. | Reassembly of Components-Rotator and Leveling Cylinder | |
| 4-13. | Main Boom Powertrack Components | |
| 4-14. | Powertrack Installation Main Boom - (Sheet 1 of 2) | |
| 4-15. | Powertrack Installation Main Boom - (Sheet 2 of 2) | |
| 4-16. | Clamping Wire Ropes | |
| 4-17. | Elevation, Dual Capacity and Transport Switch Information - 800S | |
| 4-18. | Elevation, Dual Capacity and Transport Switch Installation - 800S | |
| 4-19. | Elevation, Dual Capacity, and Transport Switch Information - 860SJ | |
| 4-20. | Elevation, Dual Capacity, and Transport Switch Installation - 860SJ | |
| 4-21. | Level Switches - 800S | |
| 4-22. | Level Switches - 860SJ | |
| 4-23. | Rotary Actuator (Exploded View) | |
| 4-24. | Rotary Actuator (Cutaway View) | |
| 4-25. | Rotator Counterbalance Valve | |
| 4-26. | Load Sensing Device | |
| 5-1. | Cylinder Barrel Support | |
| 5-2. | Capscrew Removal | |
| 5-3. | Cylinder Rod Support | |
| 5-4. | Axle Lockout Cylinder | |
| 5-5. | Tapered Bushing Removal | |
| 5-6. | Composite Bearing Installation | |
| 5-7. | Rod Seal Installation | 5-6 |

x 3121139

| FIGURE N | IO. TITLE | PAGE NO |
|--------------------|--|---------|
| 5-8. | Cylinder Head Seal Installation | 5-6 |
| 5-9. | Wiper Seal Installation | 5-7 |
| 5-10. | Installation of Head Seal Kit | |
| 5-11. | Tapered Bushing Installation | 5-7 |
| 5-12. | Seating the Tapered Bushing | |
| 5-13. | Piston Seal Kit Installation | |
| 5-14. | Rod Assembly Installation | |
| 5-15. | Cylinder Barrel Support | |
| 5-16. | Capscrew Removal | |
| 5-17. | Cylinder Rod Support | |
| 5-18. | Jib Lift Cylinder (860SJ Only) | |
| 5-19. | Tapered Bushing Removal | |
| 5-20. | Composite Bearing Installation | |
| 5-21. | Rod Seal Installation. | |
| 5-22. | Cylinder Head Seal Installation | |
| 5-23. | Wiper Seal Installation. | |
| 5-24. | Installation of Head Seal Kit | |
| 5-25. | Tapered Bushing Installation | |
| 5-26. | Seating the Tapered Bearing | |
| 5-27. | Hydrolock Piston Seal Installation. | |
| 5-28. | Piston Seal Kit Installation | |
| 5-29. | Rod Assembly Installation | |
| 5-30. | Cylinder Barrel Support. | |
| 5-31. | Capscrew Removal | |
| 5-32. | Cylinder Rod Support | |
| 5-32. 5-33. | Main Boom Lift Cylinder | |
| 5-34. | Tapered Bushing Removal. | |
| 5-3 5 . | Composite Bearing Installation | |
| 5-36. | Rod Seal Installation. | |
| 5-30. 5-37. | Cylinder Head Seal Installation | |
| 5-37. 5-38. | Wiper Seal Installation. | |
| 5-30. 5-39. | Installation of Head Seal Kit. | |
| 5-39. 5-40. | Tapered Bushing Installation | |
| 5-41. | Seating the Tapered Bearing | |
| 5-42. | Hydrolock Piston Seal Installation. | |
| 5-43. | Piston Seal Kit Installation | |
| 5-44. | Rod Assembly Installation | |
| 5-45. | Cylinder Barrel Support. | |
| 5-46. | Capscrew Removal | |
| 5-47. | Cylinder Rod Support | |
| 5-48. | Platform Level Cylinder | |
| 5-49. | Tapered Bushing Removal | |
| 5-50. | Composite Bearing Installation | |
| 5-50. 5-51. | Rod Seal Installation. | |
| 5-52. | Cylinder Head Seal Installation | |
| 5-52. 5-53. | Wiper Seal Installation. | |
| 5-55. 5-54. | Installation of Head Seal Kit. | |
| 5-5 5 . | Tapered Bushing Installation | |
| 5-55. 5-56. | Seating the Tapered Bearing | |
| 5-50. 5-57. | Hydrolock Piston Seal Installation. | |
| 5-57. 5-58. | Piston Seal Kit Installation | |
| 5-58. 5-59. | | |
| 5-59. 5-60. | Rod Assembly Installation | |
| 5-60. 5-61. | Cylinder Barrel SupportSpanner Nut Support | |
| 5-61. 5-62. | Cylinder Rod Support | |
| 5-62. 5-63. | Steer Cylinder (Prior to SN 0300142665). | |
| 5-64. | Composite Bearing Installation | |

3121139 xi

| FIGURE N | O. TITLE | PAGE NO. |
|-------------------------------|---|----------|
| 5-65. | Rod Seal Installation | 5-30 |
| 5-66. | Cylinder Head Seal Installation | 5-30 |
| 5-67. | Wiper Seal Installation | 5-31 |
| 5-68. | Installation of Head Seal Kit | |
| 5-69. | Piston Seal Kit Installation. | 5-31 |
| 5-70. | Cylinder Barrel Support | 5-32 |
| 5-71. | Spanner Nut Removal | |
| 5-72. | Cylinder Rod Support | |
| 5-73. | Steer Cylinder (SN 0300014266 through 0300182743, SN B300000100 through B300001091) | |
| 5-74. | Composite Bearing Installation | |
| 5-75. | Rod Seal Installation | |
| 5-76. | Cylinder Head Seal Installation | 5-35 |
| 5-77. | Wiper Seal Installation | 5-36 |
| 5-78. | Installation of Head Seal Kit | 5-36 |
| 5-79. | Piston Seal Kit Installation (Prior to SN 0300142664) | 5-36 |
| 5-80. | Cylinder Barrel Support | 5-37 |
| 5-81. | Capscrew Removal | 5-37 |
| 5-82. | Cylinder Rod Support | 5-37 |
| 5-83. | Telescopic Cylinder | 5-38 |
| 5-84. | Tapered Bushing Removal | 5-39 |
| 5-85. | Composite Bearing Installation | 5-40 |
| 5-86. | Rod Seal Installation | 5-40 |
| 5-87. | Cylinder Head Seal Installation | 5-40 |
| 5-88. | Wiper Seal Installation | 5-41 |
| 5-89. | Installation of Head Seal Kit | |
| 5-90. | Tapered Bushing Installation | |
| 5-91. | Seating the Tapered Bearing | |
| 5-92. | Piston Seal Kit Installation | |
| 5-93. | Rod Assembly Installation | |
| 5-94. | Control Valve Installation | |
| 5-95. | Main Valve Identification | |
| 5-96. | Platform Valve Identification | |
| 5-97. | Main Valve Cartridge Torque Values | |
| 5-98. | Platform Valve Cartridge Torque Values | |
| 5-99. | Hydraulic Schematic - Sheet 1of 8 | |
| 5-100. | Hydraulic Schematic - Sheet 2 of 8 | |
| 5-101. | Hydraulic Schematic - Sheet 3 of 8 | |
| 5-102. | Hydraulic Schematic - Sheet 4 of 8 | |
| 5-103. 5-104. | Hydraulic Schematic - Sheet 5 of 8 | |
| 5-10 4 . 5-105. | Hydraulic Schematic - Sheet 6 of 8 | |
| 5-105. 5-106. | Hydraulic Schematic - Sheet 7 of 8 | |
| 5-100. 6-1. | Hand Held Analyzer | |
| 6-1. 6-2. | ADE Block Diagram | |
| 6-3. | Analyzer Flow Chart, Prior to Version 5.X Software - Sheet 1 of 4. | |
| 6-4. | Analyzer Flow Chart, Prior to Version 5.X Software - Sheet 2 of 4 | |
| 6-5. | Analyzer Flow Chart, Prior to Version 5.X Software - Sheet 3 of 4 | 6-39 |
| 6-6. | Analyzer Flow Chart, Prior to Version 5.X Software - Sheet 4 of 4. | |
| 6-7. | Analyzer Flow Chart, Version 5.X Software - Sheet 1 of 4 | |
| 6-8. | Analyzer Flow Chart, Version 5.X Software - Sheet 2 of 4 | |
| 6-9. | Analyzer Flow Chart, Version 5.X Software - Sheet 3 of 4 | |
| 6-10. | Analyzer Flow Chart, Version 5.X Software - Sheet 4 of 4 | |
| 6-11. | Fault Code Light and module Location | |
| 6-12. | Analyzer Connecting Points | |
| 6-13. | Ground Control Module - Sheet 1 of 3 | |
| 6-14. | Ground Control Module - Sheet 2 of 3 | |
| 6-15. | Ground Control Module - Sheet 3 of 3 | 6-49 |

xii 3121139

| FIGURE NO | O. TITLE | PAGE NO. |
|--------------------|---|----------|
| 6-16. | Platform Control Module - Sheet 1 of 2 | 6-50 |
| 6-17. | Platform Control Module - Sheet 2 of 2 | 6-51 |
| 7-1. | Voltage Measurement (DC) | |
| 7-2. | Resistance Measurement | 7-2 |
| 7-3. | Continuity Measurement | 7-2 |
| 7-4. | Current Measurement (DC) | 7-3 |
| 7-5. | Application to Female Contacts | |
| 7-6. | Use of Seal Plugs | |
| 7-7. | Connector Assembly Figure 1 | 7-8 |
| 7-8. | AMP Connector | |
| 7-9. | Connector Assembly Figure 2 | |
| 7-10. | Connector Assembly Figure 3 | |
| 7-11. | Connector Assembly Figure 4 | |
| 7-12. | Connector Disassembly | |
| 7-13. | Connector Installation. | |
| 7-14. 7-15. | DT/DTP Contact Installation DT/DTP Contact Removal. | |
| 7-15. 7-16. | HD/HDP Contact Installation | |
| 7-16. 7-17. | HD/HDP Locking Contacts Into Position. | |
| 7-17. 7-18. | HD/HDP Contact Removal | |
| 7-19. | HD/HDP Unlocking Contacts | |
| 7-20. | Electrical Components Installation (WITHOUT UGM) (Prior to SN 0300085332) - Sheet 1 of 2 | |
| 7-21. | Electrical Components Installation (WITHOUT UGM) (Prior to SN 0300085332) - Sheet 2 of 2 | |
| 7-22. | Electrical Components Installation (WITHOUT UGM) | |
| | (SN 0300085332 through 0300140000) - Sheet 1 of 2 | 7-16 |
| 7-23. | Electrical Components Installation (WITHOUT UGM) | |
| | (SN 0300085332 through 0300140000) - Sheet 2 of 2 | |
| 7-24. | Electrical Components Installation (WITH UGM) (Prior to SN 0300140000) - Sheet 2 of 2 | 7-19 |
| 7-25. | Electrical Components Installation (WITH UGM) (SN 0300140000 through 0300182743 | |
| | and SN B300000100 through B300001091) - Sheet 1 of 2 | 7-20 |
| 7-26. | Electrical Components Installation (WITH UGM) (SN 0300140000 through 0300182743 | |
| | and SN B300000100 through B300001091) - Sheet 2 of 2 | |
| 7-27. | Electrical Schematics Caterpillar, Deutz EMR2 and GM (Prior to SN 0300139080) - Sheet 1 of 6 | |
| 7-28. 7-29. | Electrical Schematics Caterpillar, Deutz EMR2 and GM (Prior to SN 0300139080) - Sheet 2 of 6 | |
| 7-29. 7-30. | Electrical Schematics Caterpillar, Deutz EMR2 and GM (Prior to SN 0300139080) - Sheet 3 of 6 Electrical Schematics Caterpillar, Deutz EMR2 and GM (Prior to SN 0300139080) - Sheet 4 of 6 | |
| 7-30. 7-31. | Electrical Schematics Caterpillar, Deutz EMR2 and GM (Prior to SN 0300139080) - Sheet 4 of 6 Electrical Schematics Caterpillar, Deutz EMR2 and GM (Prior to SN 0300139080) - Sheet 5 of 6 | |
| 7-31. 7-32. | Electrical Schematics Caterpillar, Deutz EMR2 and GM (Frior to SN 0300139080) - Sheet 6 of 6 | |
| 7-33. | Electrical Schematics Caterpillar, Deutz EMR2 and GM (NO 0300139080 through 0300161729 | / 2/ |
| , 55. | and SN B30000100 through B300000639)- Sheet 1 of 10 | 7-28 |
| 7-34. | Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 | |
| | and SN B300000100 through B300000639) - Sheet 2 of 10 | 7-29 |
| 7-35. | Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 | |
| | and SN B300000100 through B300000639) - Sheet 3 of 10 | 7-30 |
| 7-36. | Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 | |
| | and SN B300000100 through B300000639) - Sheet 4 of 10 | 7-31 |
| 7-37. | Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 | |
| | and SN B300000100 through B300000639) - Sheet 5 of 10 | 7-32 |
| 7-38. | Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 | 7.00 |
| 7.20 | and SN B300000100 through B300000639) - Sheet 6 of 10 | /-33 |
| 7-39. | Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 and SN B300000100 through B300000639) - Sheet 7 of 10 | 7 24 |
| 7-40. | Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 | /-34 |
| / -4 0. | and SN B30000100 through B300000639) - Sheet 8 of 10 | 7-35 |
| 7-41. | Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 | |
| | and SN B300000100 through B300000639) - Sheet 9 of 10 | 7-36 |

3121139 xiii

| FIGURE N | O. TITLE | PAGE NO. |
|----------|--|----------|
| 7-42. | Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 | |
| | and SN B300000100 through B300000639) - Sheet 10 of 10 | 7-37 |
| 7-43. | Electrical Schematic (SN 0300161730 through 0300182743 and | |
| | B300000640 through B300001091) - Sheet 1 of 10 | 7-38 |
| 7-44. | Electrical Schematic (SN 0300161730 through 0300182743 and | |
| | B300000640 through B300001091)- Sheet 2 of 10 | 7-39 |
| 7-45. | Electrical Schematic (SN 0300161730 through 0300182743 and | |
| | B300000640 through B300001091)- Sheet 3 of 10 | 7-40 |
| 7-46. | Electrical Schematic (SN 0300161730 through 0300182743 and | |
| | B300000640 through B300001091)- Sheet 4 of 10 | 7-41 |
| 7-47. | Electrical Schematic (SN 0300161730 through 0300182743 and | |
| | B300000640 through B300001091)- Sheet 5 of 10 | 7-42 |
| 7-48. | Electrical Schematic (SN 0300161730 through 0300182743 and | |
| | B300000640 through B300001091)- Sheet 6 of 10 | 7-43 |
| 7-49. | Electrical Schematic (SN 0300161730 through 0300182743 and | |
| | B300000640 through B300001091)- Sheet 7 of 10 | 7-44 |
| 7-50. | Electrical Schematic (SN 0300161730 through 0300182743 and | |
| | B300000640 through B300001091)- Sheet 8 of 10 | 7-45 |
| 7-51. | Electrical Schematic (SN 0300161730 through 0300182743 and | |
| | B300000640 through B300001091)- Sheet 9 of 10 | 7-46 |
| 7-52. | Electrical Schematic (SN 0300161730 through 0300182743 and | |
| | B300000640 through B300001091)- Sheet 10 of 10 | 7-47 |
| 7-53. | Electrical Schematic GM - Sheet 1 of 2 | |
| 7-54. | Electrical Schematic GM - Sheet 2 of 2 | 7-49 |

xiv 3121139

| TABLE NO | . TITLE | PAGE NO |
|----------|--|---------|
| 1-1 | Operating Specifications - Prior to S/N 0300143294 | 1-1 |
| 1-2 | Operating Specifications - S/N 0300143294 & B300000153 to S/N 0300182742 | 1-1 |
| 1-3 | Specifications and Performance Data | 1-2 |
| 1-4 | Capacities | |
| 1-5 | Ford LRG-425 Specifications | 1-2 |
| 1-6 | Deutz F4M2011 Specifications | 1-2 |
| 1-7 | Deutz D2011L04 Specifications | |
| 1-8 | Caterpillar 3044C/ Caterpillar 3.4. | |
| 1-9 | GM 3.0L | |
| 1-10 | Battery Specifications | |
| 1-11 | Tire Specifications | |
| 1-12 | Torque Requirements | |
| 1-13 | Component Weights | |
| 1-14 | Hydraulic Oil | |
| 1-15 | Mobilfluid 424 Specs | |
| 1-16 | Mobil DTE 10 Excel 32 Specs. | |
| 1-17 | Mobil EAL 224H Specs. | |
| 1-17 | UCon Hydrolube HP-5046 | |
| 1-16 | Exxon Univis HVI 26 Specs | |
| 1-19 | Lubrication Specifications | |
| | | |
| 2-1 | Inspection and Maintenance | |
| 2-2 | Cylinder Drift | |
| 2-3 | Inspection and Preventive Maintenance Schedule | |
| 3-1 | Wheel Torque Chart | |
| 3-2 | Troubleshooting | |
| 3-3 | Excessive Noise and/or Vibration | |
| 3-4 | System Operating Hot. | |
| 3-5 | Won't Shift or Slow to Start | |
| 3-6 | Displacement Identifiers | |
| 3-7 | Slipper Foot Thickness & End Play | |
| 3-8 | Cylinder Block Measurements | |
| 3-9 | Troubleshooting | |
| 3-10 | Coupling Port Information Table (Prior to SN 0300083331) | 3-163 |
| 3-11 | Coupling Port Information Table (SN 0300083331 through 0300182743, | |
| | B300000100 through B300001091) | 3-163 |
| 3-12 | Troubleshooting | |
| 3-13 | ECM Diagnostic Trouble Codes | 3-169 |
| 3-14 | LPF Fuel System Diagnosis | 3-207 |
| 3-15 | Symptom Diagnosis | 3-209 |
| 3-16 | DTC to SPN/FMI Cross Reference Chart | 3-217 |
| 4-1 | Troubleshooting | 4-58 |
| 5-1 | Cartridge Torque Values | 5-49 |
| 5-2 | Coil Torque Values | 5-49 |
| 5-3 | Cartridge Torque Values | 5-50 |
| 5-4 | Coil Torque Values | 5-50 |
| 6-1 | Analyzer Abbreviations | |
| 6-2 | Machine Configuration Programming Information Prior to Software Version P5.3 | 6-8 |
| 6-3 | Machine Configuration Programming Information Software Version P5.3 to P6.1 | |
| 6-4 | Machine Configuration Programming Information Software Version P6.1 to Present | |
| 6-5 | Machine Configuration Programming Information | |
| 6-6 | 800S Machine Configuration Programming Settings | |
| 6-7 | 860SJ Machine Configuration Programming Settings | |
| 6-8 | Machine Personality Settings | |
| 6-9 | Function Speeds (In Seconds) | |
| 6-10 | ADJUSTMENTS - Personality Descriptions | |
| 6-11 | Diagnostic Menu Descriptions | |
| 6-11 | Diagnostic Trouble Code Chart (DTC) | 6-57 |

3121139 xv

TABLE NO. TITLE PAGE NO.

This page left blank intentionally.

3121139 xvi

SECTION 1. SPECIFICATIONS

1.1 OPERATING SPECIFICATIONS

Table 1-1. Operating Specifications - Prior to S/N 0300143294

| Maximum Work Load (Capacity) | |
|---------------------------------------|-------------------------------------|
| Unrestricted: | 500 lbs. (230 kg) |
| Restricted | Refer to Capacity Decals on machine |
| | for restricted platform capacities |
| Maximum Capacity - Dual Rating | |
| 800S | 1000 lbs. (450 kg) |
| 860SJ | 750 lbs. (340 kg) |
| Maximum Travel Grade (Gradeability)* | |
| 2WD | 30% |
| 4WD | 45% |
| Maximum Travel Grade (Side Slope)* | 5° |
| Maximum Vertical Platform Height: | |
| 800S | 80 ft. (24.3 m) |
| 860SJ | 86 ft. (26.2 m) |
| Maximum Horizontal Platform Reach | |
| 800S | 71 ft. (21.6 m) |
| 860SJ | 75 ft. (22.9 m) |
| Turning Radius (outside) | 22 ft. 6 in. (6.8 m) |
| Turning Radius (inside) | 12 ft. (3.6 m) |
| Maximum Drive Speed: | 3.5 mph (1.5 m/s) |
| Max. Hydraulic System Pressure | 4500 psi (310 Bar) |
| Maximum Wind Speed | 28 mph (12.5 m/s) |
| Maximum Manual Force | 400 N |
| Electrical System Voltage | 12 Volts |
| Gross Machine Weight (Platform Empty) | |
| 800S | 34,700 lbs. (15,740 kg) |
| 860SJ | 37,900 lbs. (17,191 kg) |

^{*} With boom in stowed position

Table 1-2. Operating Specifications - S/N 0300143294 & B300000153 to S/N 0300182742

| Maximum Work Load (Capacity) | |
|---------------------------------------|--|
| ANSI | |
| Unrestricted: | 500 lbs. (227 kg) |
| Restricted | Refer to Capacity Decals on machine |
| | for restricted platform capacities |
| Maximum Work Load (Capacity) | |
| CE & Australia | |
| Unrestricted: | 500 lbs. (230 kg) |
| Restricted | Refer to Capacity Decals on machine for restricted platform capacities |
| Maximum Capacity - Dual Rating | Torrestricted platform capacities |
| ANSI | |
| 8005 | 1000 lbs. (454 kg) |
| 860SJ | 750 lbs. (340 kg) |
| Maximum Capacity - Dual Rating | |
| CE & Australia | |
| 800S | 1000 lbs. (450 kg) |
| 860SJ | 750 lbs. (340 kg) |
| Maximum Travel Grade (Gradeability)* | |
| 2WD | 30% |
| 4WD | 45% |
| Maximum Travel Grade (Side Slope)* | 5° |
| Maximum Vertical Platform Height: | |
| 8005 | 80 ft. (24.3 m) |
| 860SJ | 86 ft. (26.2 m) |
| Maximum Horizontal Platform Reach | 74.6 (24.6.) |
| 800S 860SJ | 71 ft. (21.6 m) 75 ft. (22.9 m) |
| | |
| Turning Radius (outside) | 22 ft. 6 in. (6.8 m) |
| Turning Radius (inside) | 12 ft. (3.6 m) |
| Maximum Drive Speed: | 3.5 mph (1.5 m/s) |
| Max. Hydraulic System Pressure | 4500 psi (310 Bar) |
| Maximum Wind Speed | 28 mph (12.5 m/s) |
| Maximum Manual Force | 400 N |
| Electrical System Voltage | 12 Volts |
| Gross Machine Weight (Platform Empty) | |
| 8005 | 34,700 lbs. (15,740 kg) |
| 860SJ | 37,900 lbs. (17,191 kg) |

 $[\]hbox{\rm *With boom in stowed position}\\$

1.2 SPECIFICATIONS AND PERFORMANCE DATA

Table 1-3. Specifications and Performance Data

| Swing | 360° |
|---------------------------------|-----------------------------------|
| Tail Swing | 4′8" (1.42 m) |
| Platforms | 36" x 72" (0.91m x 1.83m) |
| | 36" x 96" (0.91m x 2.44m) |
| Overall Width | 8′2" (2.5 m) |
| Stowed Height | |
| 800S | 9′ 10.6" (3.01 m) |
| 860SJ | 10′ (3.04 m) |
| Stowed Length | |
| 800S | 37′ 3.25" (11.4 m) |
| 860SJ | 40′ (12.2 m) |
| Wheel base | 10' (3.04 m) |
| Ground Clearance | 15.625" (0.4 m) |
| Drive Speed | |
| Stowed 2WD | 3.0 mph (5.5 kph) |
| Stowed 4WD | 3.5 mph (5.6 kph) |
| Elevated | 0.75 mph (1.2 kph) |
| Ground Bearing Pressure - 800S | |
| 15-625 | 72 psi (5.0 kgm/cm ²) |
| 15-625FF | 79 psi (5.5 kgm/cm ²) |
| 41/18LLx22.5 | 68 psi (4.8 kgm/cm ²) |
| Ground Bearing Pressure - 860SJ | |
| 15-625 | 81 psi (5.7 kgm/cm ²) |
| 15-625FF | 92 psi (6.5 kgm/cm ²) |
| 41/18LLx22.5 | 79 psi (5.5 kgm/cm ²) |
| Max. Tire Load - 800S | 17,350 lbs. (7870 kg) |
| Max. Tire Load - 860SJ | 20,200 lbs. (9163 kg) |

1.3 CAPACITIES

Table 1-4. Capacities

| Fuel Tank | Approx. 31 gallons (117 liters) |
|--------------------------------------|-----------------------------------|
| Hydraulic Tank (Optional) | Approx. 52.8 gallons (200 liters) |
| HydraulicTank | Approx. 47.8 gallons (181 liters) |
| Engine Oil Capacity Ford Deutz | 4.5 Quarts (4.25 L) w/Filter |
| Cooling System | 5 Quarts (4.5 L) |
| Crankcase | 11 Quarts (10.5 L) w/Filter |
| Total Capacity | 16 Quarts (15 L) |
| Caterpillar | 10.6 quarts (10 L) |
| GM | 4.5 Quarts (4.25 L) w/Filter |

1.4 COMPONENT DATA

Engine Data

Table 1-5. Ford LRG-425 Specifications

| Туре | Water-cooled |
|------------------|------------------------------|
| Fuel | Gasoline |
| Oil Capacity | 4.5 Quarts (4.25 L) w/Filter |
| Idle RPM | 1000 |
| Low RPM | 1800 |
| High RPM | 2800 |
| Alternator | 95 Amp, Belt Drive |
| Fuel Consumption | |
| Low RPM | 3.45 GPH (13.06 lph) |
| High RPM | 4.60 GPH (17.41 lph) |
| Horsepower | 74@3000 RPM, full load |
| Cooling System | 16 Quarts (15.14 L) |
| Spark Plug | AWSF-52-C |
| Spark Plug Gap | 0.044 in. (1.117 mm) |

Table 1-6. Deutz F4M2011 Specifications

| Туре | Liquid Cooled (Oil) |
|---|---|
| Fuel | Diesel |
| Oil Capacity Cooling System Crankcase Total Capacity | 5 Quarts (4.5 L) 11 Quarts (10.5 L) w/Filter 16 Quarts (15 L) |
| Idle RPM | 1000 |
| Low RPM | 1800 |
| High RPM | 2800 |
| Alternator | 55 Amp, belt drive |
| Fuel Consumption Low RPM High RPM | 1.90 GPH (7.19 lph) 2.50 GPH (9.46 lph) |
| Horsepower | 66@3000 RPM, full load |

1-2 3121139

Table 1-7. Deutz D2011L04 Specifications

| Туре | Liquid Cooled (Oil) |
|------------------|--------------------------------------|
| Fuel | Diesel |
| Oil Capacity | |
| Cooling System | 5 Quarts (4.5 L) |
| Crankcase | 11 Quarts (10.5 L) w/Filter |
| Total Capacity | 16 Quarts (15 L) |
| Idle RPM | 1000 |
| Low RPM | 1800 |
| High RPM | 2600 |
| Alternator | 55 Amp, belt drive |
| Fuel Consumption | |
| Low RPM | 1.90 GPH (7.19 lph) |
| High RPM | 2.50 GPH (9.46 lph) |
| Battery | 1000 Cold Cranking Amps, 210 minutes |
| | Reserve Capacity, 12 VDC |
| Horsepower | 64@2600 RPM, full load |

Table 1-8. Caterpillar 3044C/ Caterpillar 3.4

| Туре | Four Stroke Cycle |
|---------------------------------|------------------------------|
| Cylinders | 4in-line |
| Bore | 3.70 in. (94 mm) |
| Stroke | 4.72 in. (120 mm) |
| Aspiration | turbocharged |
| Compression ratio | 19:1 |
| Displacement | 203 in ³ (3.33 L) |
| Firing Order | 1-3-4-2 |
| Rotation (viewed from flywheel) | Counterclockwise |
| Oil Capacity (w/filter) | 10.6 quarts (10 L) |
| Cooling System (Engine Only) | 5.8 quarts (5.5 L) |
| Idle RPM | 1000 |
| Low RPM | 1800 |
| High RPM - 3044C | 2600 |
| High RPM - 3.4 | 2500 |
| Alternator | 60 Amp, belt drive |

Table 1-9. GM 3.0L

| Fuel | Gasoline or Gasoline/LP Gas |
|-----------------------|-----------------------------|
| No. of Cylinders | 4 |
| ВНР | |
| Gasoline | 83 hp @ 3000 rpm |
| LP | 75 hp @ 3000 rpm |
| Bore | 4.0 in. (101.6 mm) |
| Stroke | 3.6 in. (91.44 mm) |
| Displacement | 181 cu.in. (3.0 L, 2966 cc) |
| Oil Capacity w/filter | 4.5 qts. (4.25 L) |
| Minimum Oil Pressure | |
| At Idle | 6 psi (0.4 Bar) @ 1000 rpm |
| Hot | 18 psi (1.2 Bar) @ 2000 rpm |
| Compression Ratio | 9.2:1 |
| Firing Order | 1-3-4-2 |
| Max. RPM | 2800 |

Battery

Table 1-10. Battery Specifications

| Voltage | 12 Volt |
|--------------------|-----------------------------|
| Туре | 31-950 |
| Cold Cranking Amps | 950 CCA @ 0°F (-18°C) |
| Reserve Capacity | 205 Minutes @ 80° F (27° C) |

1.5 TIRES

Table 1-11. Tire Specifications

| Size | Туре | Ply Rating | Load Range | Weight (Tire & Wheel) |
|--------------|-------------------------------|---------------|---------------|--------------------------|
| 15-625 | Pneumatic 95 psi (6.5 Bar) | 16 | Ξ | 269 lbs. (122 kg) |
| 15-625 | Foam-Filled | 16 | Н | 544 lbs. (247 kg) |
| 18-625 | Pneumatic 85 psi (6.5 Bar) | 16 | Н | 288 lbs. (131 kg) |
| 18-625 | Foam-Filled | 16 | Н | 601 lbs. (273 kg) |
| 41/18LLx22.5 | Foam-Filled | 16 | Н | 724 lbs. (329 kg) |

1.6 TORQUE REQUIREMENTS

Table 1-12. Torque Requirements

| Description | Torque Value (Dry) | Interval Hours |
|--------------------------------------|--|----------------|
| Wheel Lugs | 300 ft. lbs. (407 Nm) | 150 |
| Swing Bearing Bolts | 190 ft. lbs. (258 Nm) | 50/600* |
| Starter Solenoid Contacts Coil | 95 in. lbs. (9.5 Nm) 40 in. lbs. (4 Nm) | As required |

^{*}Check swing bearing bolts for security after first 50 hours of operation and every 600 hours thereafter. (See Swing Bearing in Section 3.)

NOTE: When maintenance becomes necessary or a fastener has loosened, refer to the Torque Chart to determine proper torque value.

1-4 3121139

1.7 MAJOR COMPONENT WEIGHTS

Table 1-13. Component Weights

| Component | Pounds | Kilograms |
|----------------------------|--------|-----------|
| Turntable (bare) | 3700 | 1678 |
| Counterweight (800S) | 7000 | 3175 |
| Counterweight (860SJ) | 8750 | 3969 |
| Upright | 1050 | 476 |
| Tower | 685 | 311 |
| Fly Boom (SJ) | 472 | 214 |
| Fly Boom (S) | 490 | 222 |
| Mid Boom (SJ) | 750 | 340 |
| Mid Boom (S) | 740 | 336 |
| Base Boom (SJ) | 1400 | 635 |
| Base Boom (S) | 1410 | 640 |
| Boom Assembly | 3337 | 1514 |
| Telescope Cylinder (800S) | 590 | 268 |
| Telescope Cylinder (860SJ) | 570 | 259 |
| Slave Cylinder | 73 | 33 |
| Drive Hub (2WD) | 218 | 99 |
| Tire & Wheel (pneu) | 269 | 122 |
| Tire & Wheel (FF) | 544 | 247 |

1.8 LUBRICATION

Hydraulic Oil

Table 1-14. Hydraulic Oil

| Hydraulic System Operating Temperature Range | S.A.E. Viscosity Grade |
|--|---------------------------|
| +0°to+180°F (-18°to+83°C) | 10W |
| +0°to+210°F (-18°to+99°C) | 10W-20,10W30 |
| +50° to +210° F (+10° to +99° C) | 20W-20 |

NOTE: Hydraulic oils must have anti-wear qualities at least to API Service Classification GL-3, and sufficient chemical stability for mobile hydraulic system service. JLG Industries recommends Mobilfluid 424 hydraulic oil, which has an SAE viscosity index of 152.

NOTE: When temperatures remain consistently below 20 degrees F. (-7 degrees C.), JLG Industries recommends the use of Mobil DTE10.

NOTE: Aside from JLG recommendations, it is not advisable to mix oils of different brands or types, as they may not contain the same required additives or be of comparable viscosities. If use of hydraulic oil other than Mobilfluid 424 is desired, contact JLG Industries for proper recommendations.

Table 1-15. Mobilfluid 424 Specs

| SAEGrade | 10W30 | |
|-------------------------|---------------|--|
| ISO Grade | 55 | |
| Gravity, API | 29.0 | |
| Density, Lb/Gal. 60°F | 7.35 | |
| Pour Point, Max | -46°F(-43°C) | |
| Flash Point, Min. | 442°F (228°C) | |
| Viscosity | | |
| Brookfield, cP at -18°C | 2700 | |
| at 40°C | 55 cSt | |
| at 100°C | 9.3 cSt | |
| Viscosity Index | 152 | |

Table 1-16. Mobil DTE 10 Excel 32 Specs

| ISO Viscosity Grade | #32 |
|---------------------|-------------------------|
| Gravity API | |
| Pour Point, Max | -65.2°F (-54°C) |
| Flash Point, Min. | 482°F (250°C) |
| Vis | cosity |
| at 40° C | 32.7 cSt |
| at 100°C | 6.6 cSt |
| at 100° F | 32.7 cSt |
| at 212° F | 6.6 cSt |
| cp at -30° F | |
| Viscosity Index | 164 |
| Density@15°C | 0.85 Kg/l |
| Density@60°F | 0.03 lb/in ³ |

Table 1-17. Mobil EAL 224H Specs

| Туре | Synthetic Biodegradable | |
|---|---|--|
| ISO Viscosity Grade | 32/46 | |
| Specific Gravity | .922 | |
| Pour Point, Max | -25°F (-32°C) | |
| Flash Point, Min. | 428°F (220°C) | |
| Operating Temp. | 0 to 180°F (-17 to 162°C) | |
| Weight | 7.64 lb. per gal. (0.9 kg per liter) | |
| Viscosity | | |
| at 40°C | 37 cSt | |
| at 100°C | 8.4cSt | |
| Viscosity Index | 213 | |
| NOTE: Must be stored above 32°F (14°C) | | |

Table 1-18. UCon Hydrolube HP-5046

| Туре | Synthetic Biodegradable | |
|-------------------|-------------------------|--|
| Specific Gravity | 1.082 | |
| Pour Point, Max | -58°F(-50°C) | |
| рН | 9.1 | |
| Viscosity | | |
| at 0°C (32°F) | 340 cSt (1600SUS) | |
| at 40° C (104° F) | 46 cSt (215SUS) | |
| at 65°C (150°F) | 22 cSt (106SUS) | |
| Viscosity Index | 170 | |

Table 1-19. Exxon Univis HVI 26 Specs

| Specific Gravity | 32.1 | |
|---|---------------|--|
| Pour Point Point | -76°F (-60°C) | |
| Flash Point | 217°F (103°C) | |
| Viscosity | | |
| at 40°C | 25.8 cSt | |
| at 100°C | 9.3 cSt | |
| Viscosity Index | 376 | |
| NOTE: Mobil/Exxon recommends that this oil be checked on a | | |

NOTE: Mobil/Exxon recommends that this oil be checked on a yearly basis for viscosity.

1-6 3121139




Figure 1-1. Operator Maintenance and Lubrication Diagram

1.9 OPERATOR MAINTENANCE

NOTE: The following numbers correspond to those in Figure 1-1., Operator Maintenance and Lubrication Diagram.

Table 1-20. Lubrication Specifications

| KEY | SPECIFICATIONS |
|------|---|
| MPG | Multipurpose Grease having a minimum dripping point of 350° F (177° C). Excellent water resistance and adhesive qualities, and being of extreme pressure type. (Timken OK 40 pounds minimum.) |
| EPGL | Extreme Pressure Gear Lube (oil) meeting API service classification GL-5 or MIL-Spec MIL-L-2105 |
| НО | Hydraulic Oil. API service classification GL-3, e.g. Mobilfluid 424. |
| EO | Engine (crankcase) Oil. Gas - API SF, SH, SG class, MIL-L-2104. Diesel - API CC/CD class, MIL-L-2104B/MIL-L-2104C. |

NOTICE

LUBRICATION INTERVALS ARE BASED ON MACHINE OPERATION UNDER NOR-MAL CONDITIONS. FOR MACHINES USED IN MULTI-SHIFT OPERATIONS AND/ OR EXPOSED TO HOSTILE ENVIRONMENTS OR CONDITIONS, LUBRICATION FREQUENCIES MUST BE INCREASED ACCORDINGLY.

NOTE: It is recommended as a good practice to replace all filters at the same time.

1. Swing Bearing - Internal Ball Bearing




Lube Point(s) - 1 Grease Fittings Capacity - A/R Lube - MPG

Interval - Every 3 months or 150 hrs of operation

Comments - Remote Access

2. Wheel Bearings



Lube Point(s) - Repack
Capacity - A/R
Lube - MPG
Interval - Every 2 years or 1200 hours of operation

3. Wheel Drive Hub



Lube Point(s) - Level/Fill Plug Capacity - 17 oz. (0.5 L) - 1/2 Full

Lube - EPGL

Interval - Check level every 3 months or 150 hrs of operation; change every 2 years or 1200 hours of operation Comments - Place Fill port at 12 o'clock position and Check port at 3 o'clock position. Pour lubricant into fill port until it just starts to flow out of check port.

1-8 3121139

4. Hydraulic Return Filter



Interval - Change after first 50 hrs. and every 6 months or 300 hrs. thereafter or as indicated by Condition Indicator.

5. Hydraulic Charge Filter




Interval - Change after first 50 hrs. and every 6 months or 300 hrs. thereafter or as indicated by Condition Indicator.

6. Hydraulic Tank




Lube Point(s) - Fill Cap Capacity - 116 liters Tank 124 liters System Lube - HO Interval - Check Level daily; Change every 2 years or 1200 hours of operation.

7. Platform Filter




Interval - Change as necessary

8. Suction Strainers



Lube Point(s) - 2 Interval - Every 2 years or 1200 hours of operation, remove and clean at time of hydraulic oil change.

9. Oil Change w/Filter - Ford



Lube Point(s) - Fill Cap/Spin-on Element
Capacity - 4.5 Quarts
Lube - EO
Interval - 3 Months or 150 hours of operation
Comments - Check level daily/Change in accordance with engine manual.

10. Oil Change w/Filter - Deutz



Lube Point(s) - Fill Cap/Spin-on Element Capacity - 11 Quarts(10.5 L) Crankcase; Lube - EO Interval - Every Year or 1200 hours of operation Comments - Check level daily/Change in accordance with engine manual. Refer to Figure 1-2., Deutz Engine Dipstick.




Figure 1-2. Deutz Engine Dipstick

11. Oil Change w/Filter - Caterpillar

with engine manual.

Lube Point(s) - Fill Cap/Spin-on Element
Capacity - 10.6 Quarts
Lube - EO
Interval - 3 Months or 150 hours of operation
Comments - Check level daily/Change in accordance


1-10 3121139

12. Oil Change w/Filter - GM



Lube Point(s) - Fill Cap/Spin-on Element Capacity - 4.5 qt. (4.25 L) w/filter Lube - EO Interval - 3 Months or 150 hours of operation Comments - Check level daily/Change in accordance with engine manual.

13. Fuel Filter - Ford



Lube Point(s) - Replaceable Element Interval - Every Year or 1200 hours of operation

14. Fuel Filter - Deutz



Lube Point(s) - Replaceable Element Interval - Every Year or 600 hours of operation

15. Fuel Filter - Caterpillar

Lube Point(s) - Replaceable Element Interval - Every Year or 600 hours of operation

16. Fuel Filter (Gasoline) - GM


Lube Point(s) - Replaceable Element Interval - Every 6 months or 300 hours of operation

17. Air Filter



Lube Point(s) - Replaceable Element Interval - Every 6 months or 300 hours of operation or as indicated by the condition indicator

18. Electronic Pressure Regulator (LP only)



Interval - 3 Months or 150 hours of operation Comments - Drain oil build up. Refer to Draining Oil Build Up From The Propane Regulator

19. Fuel Filter (Propane) - GM Engine



Interval - 3 Months or 150 hours of operation Comments - Replace filter. Refer to Propane Fuel Filter Replacement

Draining Oil Build Up From The Propane Regulator (Prior to S/N 0300134626)


During the course of normal operation oils may build inside the primary and secondary chambers of the propane pressure regulator. These oils may be a result of poor fuel quality, contamination of the fuel supply chain, or regional variation in the make up of the fuel. If the build up of the oil is significant this can effect the operation of the fuel control system. Refer to Section 1.9, Operator Maintenance for maintenance intervals. More frequent draining may be required if the fuel supply has been contaminated.

NOTICE

FOR BEST RESULTS WARM THE ENGINE TO OPERATING TEMPERATURE BEFORE DRAINING. THIS WILL ALLOW THE OILS TO BE LIQUID AND FLOW FREELY FROM THE REGULATOR.

- Move the equipment to a well ventilated area. Ensure there are no external ignition sources.
- 2. Start the engine and bring to operating temperature.

- **3.** With the engine running, close the manual tank valve and run the engine out of fuel.
- **4.** Push in the Emergency Switch once the engine stops.
- Disconnect the electrical connection to the LPG fuel temperature sensor in the auxiliary fuel port of the EPR.



Remove the retainer clip for the LPG fuel temperature sensor and remove the sensor from the regulator body.




NOTE: Have a small container ready to collect oil that will drain freely from the regulator at this point.

- Once all of the oil has been drained, reinstall the LPG fuel temperature sensor and reconnect the electrical connector.
- 8. Open the fuel tank manual valve.
- 9. Start the engine and verify all connections are secure.
- **10.** Dispose of any drained oil in a safe and proper fashion.

1-12 3121139

Propane Fuel Filter Replacement



- 1. Electric Lock Off Solenoid
- 2. Mounting Plate
- 3. Housing Seal
- 4. Filter Magnet
- 5. Filter Housing
- 6. Seal
- 7. Electrical Connector
- 8. Fuel Outlet
- 9. 0-ring
- 10. Filter
- 11. FuelInlet
- 12. Retaining Bolt
- 13. Ring

Figure 1-3. Filter Lock Assembly

REMOVAL

- Relieve the propane fuel system pressure. Refer to Propane Fuel System Pressure Relief.
- 2. Disconnect the negative battery cable.
- **3.** Slowly loosen the Filter housing retaining bolt and remove it.
- 4. Pull the filter housing from the Electric lock off assembly.
- **5.** Locate Filter magnet and remove it.
- 6. Remove the filter from the housing.
- 7. Remove and discard the housing seal.
- 8. Remove and discard the retaining bolt seal.
- Remove and discard mounting plate to lock off o-ring seal.

INSTALLATION

NOTICE

BE SURE TO REINSTALL THE FILTER MAGNET INTO THE HOUSING BEFORE INSTALLING NEW SEAL

- 1. Install the mounting plate to lock off o-ring seal.
- **2.** Install the retaining bolt seal.
- 3. Install the housing seal.
- **4.** Drop the magnet into the bottom of the filter housing.
- 5. Install the filter into the housing.
- 6. Install the retaining bolt into the filter housing.
- 7. Install the filter up to the bottom of the electric lock off.
- 8. Tighten the filter retaining bolt to 106 in lbs (12 Nm).
- **9.** Open manual shut-off valve. Start the vehicle and leak check the propane fuel system at each serviced fitting. Refer to Propane Fuel System Leak Test.

Propane Fuel System Pressure Relief

▲ CAUTION

THE PROPANE FUEL SYSTEM OPERATES AT PRESSURES UP TO 312 PSI (21.5 BAR). TO MINIMIZE THE RISK OF FIRE AND PERSONAL INJURY, RELIEVE THE PROPANE FUEL SYSTEM PRESSURE (WHERE APPLICABLE) BEFORE SERVICING THE PROPANE FUEL SYSTEM COMPONENTS.

To relieve propane fuel system pressure:

- Close the manual shut-off valve on the propane fuel tank.
- 2. Start and run the vehicle until the engine stalls.
- 3. Turn the ignition switch OFF.

A CAUTION

RESIDUAL VAPOR PRESSURE WILL BE PRESENT IN THE FUEL SYSTEM. ENSURE THE WORK AREA IS WELL VENTILATED BEFORE DISCONNECTING ANY FUEL LINE.

1.10 SERIAL NUMBER LOCATION

A serial number plate is affixed to the left rear side of the frame. If the serial number plate is damaged or missing, the machine serial number is stamped on the left side of the frame.




Figure 1-4. Serial Number Locations

1-14 3121139

NO. 5000059 REV. K

NOTES:

| Supplies Texasis Tex | | | | | | | | | Values | for Zinc | Values for Zinc Yellow Chromate Fasteners (Ref 4150707) | v Chron | nate Fa | steners | (Ref 4 | 150707 | (| | | |
|--|-----|----------|--------|---------|------------|-------------|-------------|---------|---------------|---|---|--------------------------------|---|------------|-----------------------------|--------------------------|---------------------------------------|--|--|--|
| Tangele Tan | | | | | | 1S | 4E GRA | DE 5 BC | OLTS & | GRADE | 2 NUTS | (6 | | SAE GI | RADE 8 | нех н | гов (ан | rs & gr, | ADE 8 N | IUTS* |
| NATION SQ IN LB INALB [NMI] INALB INALB [NMI] I | | | | | Clamp Load | Torc (Dr | (/s. ent | Tor | q ue cated | Torq (Loctite® 271 [™] OR Vi | | Torq (Loctite® 26; TITE™ | lue 2 TM or Vibra- ¹ 131) | Clamp Load | Tore (Dry or Loc K= C | tue tite® 263) .20 | Torq (Loctite® 242 OR Vibra-TI1 | Torque (Loctite® 242™ or 271™ (Lo OR Vibra-TITE™111 or HA) | Torque (Loctite® 262 TM or Vibra- TITE TM 131) K=0.15 | ue 2 TM or Vibra- 131) .15 |
| 0.1120 0.00060+1 330 6 0.7 9 7 9 7 9 7 9 7 9 1.12 1.14 9 1.12 1.14 9 1.14 <td></td> <td></td> <td>드</td> <td>Sq In</td> <td>R I</td> <td>IN-LB</td> <td>[N.m]</td> <td>IN-LB</td> <td>[N.m]</td> <td>IN-LB</td> <td>[N.m]</td> <td>IN-LB</td> <td>[N.m]</td> <td>EB LB</td> <td>IN-LB</td> <td>[N.m]</td> <td>IN-LB</td> <td>[N.m]</td> <td>Z</td> <td>[N.m]</td> | | | 드 | Sq In | R I | IN-LB | [N.m] | IN-LB | [N.m] | IN-LB | [N.m] | IN-LB | [N.m] | EB LB | IN-LB | [N.m] | IN-LB | [N.m] | Z | [N.m] |
| 0.1380 0.000661 420 9 1.0 7 0.8 9 1.0 7 0.8 0.1380 0.000661 420 1.6 1 | | _ | | 0.00604 | 380 | 8 | 6.0 | 9 | 0.7 | | | | | | | | | | | |
| 0.1380 0.010409 580 16 12 14 9 9 9 9 9 9 9 9 9 9 1 | | H | | 0.00661 | 420 | 6 | 1.0 | 7 | 0.8 | | | | | | | | | | | |
| 0.1860 0.01015 610 31 2.5 1.5 9 9 4.5 9 4.5 9 4.5 9 4.5 9 4.5 9 4.5 9 4.5 9 1.5 4.5 9 1.5 4.5 9 1.5 4.5 9 1.5 4.5 9 1.5 4.5 9 1.5 4.5 1.5 4.5 1.5 4.5 1.5 4.5 4.5 1.5 4.5 4.5 1.5 4.5 4.5 1.5 4.5 | | | _ | 60600.0 | 580 | 16 | 1.8 | 12 | 1.4 | | | | | | | | | | | |
| 0.1640 0.101470 900 31 3.4 2.2 2.5 9 9 9 3.4 2.2 2.5 9 10.1640 0.101470 940 31 3.5 3.5 3.5 3.5 4 10.5 10.6 | | <u> </u> | H | 0.01015 | 610 | 18 | 2.0 | 13 | 1.5 | | | | | | | | | | | |
| 0.1640 0.01474 940 31 3.5 2.6 940 13.5 2.6 3.6 4.6 4.7 4.6 | | H | H | 0.01400 | 006 | 30 | 3.4 | 22 | 2.5 | | | | | | | | | | | |
| 0.1900 0.01750 1120 43 48 32 3.5 4 60 | | | | 0.01474 | 940 | 31 | 3.5 | 23 | 2.6 | | | | | 1320 | 43 | 5 | | | | |
| 0.02500 0.00364 2.55 36 4 105 1.2 1800 1.8 9 1.8 9 1.8 9 1.8 <td></td> <td>H</td> <td>H</td> <td>0.01750</td> <td>1120</td> <td>43</td> <td>4.8</td> <td>32</td> <td>3.5</td> <td></td> <td></td> <td></td> <td></td> <td>1580</td> <td>09</td> <td>7</td> <td></td> <td></td> <td></td> <td></td> | | H | H | 0.01750 | 1120 | 43 | 4.8 | 32 | 3.5 | | | | | 1580 | 09 | 7 | | | | |
| 0.25000 0.03148 2.020 96 1.08 75 9 1.05 1.2 2.860 1.43 0.5500 0.03140 2.20 1.35 6 10 1.35 1.6 1.6 1.4 1.4 0.03126 0.0524 2.340 1.7 2.3 1.3 1.6 1.6 2.2 4.700 2.6 0.3126 0.0524 3.340 1.7 2.3 1.6 1.6 2.2 4.700 2.6 0.3176 0.0775 4.940 3.0 4.7 2.5 3.4 8 2.6 1.6 2.6 1.6 1.6 1.6 2.6 1.6 | | H | H | 0.02000 | 1285 | 49 | 5.5 | 36 | 4 | | | | | 1800 | 89 | 8 | | | | |
| 0.2500 0.0564 2320 120 13.5 86 10 135 16 17.18 [Mm] FT-LB [Mm] </td <td></td> <td></td> <td></td> <td>0.0318</td> <td>2020</td> <td>96</td> <td>10.8</td> <td>75</td> <td>6</td> <td>105</td> <td>12</td> <td></td> <td></td> <td>2860</td> <td>143</td> <td>16</td> <td>129</td> <td>15</td> <td></td> <td></td> | | | | 0.0318 | 2020 | 96 | 10.8 | 75 | 6 | 105 | 12 | | | 2860 | 143 | 16 | 129 | 15 | | |
| In Sq In LB FT-LB [N.m] | 1 | Н | | 0.0364 | 2320 | 120 | 13.5 | 98 | 10 | 135 | 15 | | | 3280 | 164 | 19 | 148 | 17 | | |
| 03125 0.0524 3340 17 23 13 18 19 26 16 22 4720 25 0.3125 0.0580 0.0580 3700 19 26 14 19 21 29 17 23 520 25 0.3155 0.0787 4940 30 41 25 34 40 54 88 1700 40 0.4375 0.1087 5600 35 47 25 34 40 56 68 37 40 50 88 10 70 40 50 60 70 <t< td=""><td></td><td></td><td>드</td><td>Sq In</td><td>LB</td><td>FT-LB</td><td>[N.m]</td><td>FT-LB</td><td>[N.m]</td><td>FT-LB</td><td>[N.M]</td><td>FT-LB</td><td>[N.m]</td><td>ГВ</td><td>FT-LB</td><td>[N.m]</td><td>FT-LB</td><td>[N.m]</td><td>FT-LB</td><td>[N.m]</td></t<> | | | 드 | Sq In | LB | FT-LB | [N.m] | FT-LB | [N.m] | FT-LB | [N.M] | FT-LB | [N.m] | ГВ | FT-LB | [N.m] | FT-LB | [N.m] | FT-LB | [N.m] |
| 0.3125 0.0580 3700 19 26 14 19 21 29 17 28 520 25 0.3750 0.0775 4940 30 41 25 34 40 54 32 43 7900 45 0.3750 0.0878 5600 55 47 56 75 46 68 32 43 7900 45 0.4375 0.1063 6800 55 75 40 54 66 88 100 47 56 16 68 92 12760 105 0.5000 0.1439 9050 75 102 55 75 88 100 188 1400 170 105 165 88 100 188 1400 170 170 170 170 170 170 170 170 170 170 170 170 170 170 170 170 170 170 170 | | H | H | 0.0524 | 3340 | 17 | 23 | 13 | 18 | 19 | 56 | 16 | 22 | 4720 | 25 | 35 | 20 | 25 | 20 | 25 |
| 0.37560 0.00776 54940 30 41 23 31 35 48 28 38 7000 45 0.43750 0.00876 5600 35 47 25 34 40 56 75 45 61 950 70 0.4375 0.1087 5600 55 75 47 55 61 950 70 950 0.5000 0.1187 7550 55 75 86 16 86 1700 96 90 170 96 90 170 96 90 170 96 90 170 170 96 90 170 170 90 170 <t< td=""><td></td><td>_</td><td></td><td>0.0580</td><td>3700</td><td>19</td><td>56</td><td>14</td><td>19</td><td>21</td><td>59</td><td>17</td><td>23</td><td>5220</td><td>25</td><td>35</td><td>25</td><td>32</td><td>20</td><td>25</td></t<> | | _ | | 0.0580 | 3700 | 19 | 56 | 14 | 19 | 21 | 59 | 17 | 23 | 5220 | 25 | 35 | 25 | 32 | 20 | 25 |
| 0.3756 0.0878 5600 35 47 25 34 40 54 32 43 7900 50 0.4375 0.1063 6800 35 47 45 47 45 45 45 45 46 88 100 | | _ | | 0.0775 | 4940 | 30 | 41 | 23 | 31 | 35 | 48 | 28 | 38 | 2000 | 45 | 09 | 40 | 22 | 35 | 20 |
| 0.4375 0.1063 6800 56 68 47 55 76 40 55 76 40 55 76 40 55 76 40 66 88 76 68 86 10700 108 0.5000 0.1189 9050 75 102 56 75 85 116 68 92 1750 105 0.5000 0.1189 9050 75 102 56 75 85 116 68 92 1750 105 0.5000 0.1480 10700 110 149 80 108 109 1400 120 1400 176 140 109 1400 1400 170 1400 1400 1400 170 1400 <td></td> <td></td> <td></td> <td>0.0878</td> <td>2600</td> <td>35</td> <td>47</td> <td>25</td> <td>34</td> <td>40</td> <td>54</td> <td>32</td> <td>43</td> <td>2000</td> <td>20</td> <td>20</td> <td>45</td> <td>09</td> <td>35</td> <td>20</td> | | | | 0.0878 | 2600 | 35 | 47 | 25 | 34 | 40 | 54 | 32 | 43 | 2000 | 20 | 20 | 45 | 09 | 35 | 20 |
| 0.6250 0.1187 7550 55 75 60 82 50 60 80 60 80 10700 80 0.5000 0.1189 9050 75 105 10 105 10 <td< td=""><td></td><td>H</td><td>H</td><td>0.1063</td><td>0089</td><td>20</td><td>89</td><td>35</td><td>47</td><td>22</td><td>75</td><td>45</td><td>61</td><td>9550</td><td>70</td><td>92</td><td>65</td><td>06</td><td>20</td><td>70</td></td<> | | H | H | 0.1063 | 0089 | 20 | 89 | 35 | 47 | 22 | 75 | 45 | 61 | 9550 | 70 | 92 | 65 | 06 | 20 | 70 |
| 0.55000 0.1419 90500 75 102 65 75 165 1 | | | | 0.1187 | 7550 | 55 | 75 | 40 | 54 | 09 | 82 | 20 | 89 | 10700 | 80 | 110 | 70 | 92 | 09 | 80 |
| 0.55000 0.1589 107700 90 122 65 88 100 136 80 108 14400 120 0.5625 0.1820 11600 110 149 80 168 100 108 149 150 0.5625 0.2000 12960 122 135 164 109 148 162 170 0.6520 0.2260 14400 170 230 122 139 149 162 176 149 162 176 149 162 176 149 162 176 | | | - | 0.1419 | 9050 | 75 | 102 | 55 | 75 | 82 | 116 | 89 | 95 | 12750 | 105 | 145 | 92 | 130 | 80 | 110 |
| 0.5625 0.1820 1160 149 80 122 165 187 170 185 187 1 | | \dashv | - | 0.1599 | 10700 | 06 | 122 | 65 | 88 | 100 | 136 | 80 | 108 | 14400 | 120 | 165 | 110 | 150 | 06 | 120 |
| 0.6525 0.20200 12290 120 163 90 122 184 169 148 185 184 169 148 18250 170 0.6250 0.2260 14300 150 203 110 149 165 256 153 130 240 0.6250 0.2360 16300 170 220 130 176 2300 240 0.7500 0.3340 21300 285 285 386 267 23000 240 0.7500 0.3340 2900 430 287 220 288 386 262 330 470 280 386 523 41600 605 0.8750 0.4820 2900 437 220 288 380 423 3800 475 520 70 449 586 552 4160 605 605 100 605 410 605 810 110 605 810 110 605 </td <td></td> <td>+</td> <td>+</td> <td>0.1820</td> <td>11600</td> <td>110</td> <td>149</td> <td>80</td> <td>108</td> <td>120</td> <td>163</td> <td>98</td> <td>133</td> <td>16400</td> <td>155</td> <td>210</td> <td>140</td> <td>190</td> <td>115</td> <td>155</td> | | + | + | 0.1820 | 11600 | 110 | 149 | 80 | 108 | 120 | 163 | 98 | 133 | 16400 | 155 | 210 | 140 | 190 | 115 | 155 |
| 0.6250 0.2260 14400 150 203 110 149 165 224 153 183 20350 210 0.6250 0.2260 16300 170 230 176 176 190 258 183 183 2070 210 0.7500 0.3730 23600 240 352 360 375 23000 470 0.7500 0.3730 23800 240 475 646 386 323 31600 470 0.8750 0.6800 32400 470 637 320 475 646 386 523 41600 665 0.8750 0.6800 32400 470 637 320 475 520 707 425 576 4580 650 1.0000 0.6800 38600 470 886 480 651 675 916 576 4580 676 987 187 770 485 677 140 | - 1 | _ | | 0.2030 | 12950 | 120 | 163 | 06 | 122 | 135 | 184 | 109 | 148 | 18250 | 170 | 230 | 155 | 210 | 130 | 175 |
| 0.75600 0.32590 170 230 176 190 228 132 200 230 363 200 230 368 235 200 370 23000 240 226 370 23000 240 226 360 365 360 360 370 370 360 360 370 370 360 360 370 370 360 360 370 360 360 370 360 360 360 360 360 360 360 360 360 360 470 475 486 575 310 370 470 475 476 | - 1 | + | + | 0.2260 | 14400 | 150 | 203 | 110 | 149 | 165 | 224 | 135 | 183 | 20350 | 210 | 285 | 190 | 260 | 160 | 220 |
| 0.7500 0.3340 280 363 200 288 289 289 367 370 477 220 288 289 289 363 3500 475 480 288 289 363 3500 470 480 687 380 475 480 687 380 475 480 686 583 380 475 480 686 686 480 686 687 386 583 3800 607 607 488 480 661 675 918 579 785 5150 860 1.0000 0.6630 38600 470 475 520 707 425 579 785 51500 860 1.0000 0.6630 4200 640 889 480 667 949 1736 719 779 785 51500 860 1.1250 0.8660 439 530 719 735 1175 1758 802 | - 1 | + | + | 0.2560 | 16300 | 0/1 | 230 | 130 | 1/6 | 190 | 258 | 153 | 207 | 23000 | 240 | 325 | 215 | 280 | 180 | 245 |
| 0.8750 0.4850 2.900 4.00 563 3.20 4.45 4.75 646 3.86 5.23 4.1600 6.65 0.8750 0.4850 0.4850 6.40 6.83 3.20 4.47 4.75 5.76 4.85 4.60 6.70 1.0000 0.6660 38600 6.40 868 480 6.71 4.75 5.77 7.85 5.70 8.78 4.80 6.75 9.18 5.77 7.85 5.1500 860 8.70 9.95 | 1 | + | $^{+}$ | 0.3340 | 23800 | 300 | 333 | 220 | 906 | 330 | 300 | 240 | 363 | 30100 | 3/3 | 570 | 380 | 460 | 315 | 300 |
| 0.8750 0.5090 32400 470 637 350 475 520 707 425 576 45800 670 1.0000 0.6080 32860 640 888 480 651 675 918 576 4580 670 860 1.0000 0.6680 42200 700 949 530 719 735 918 577 774 878 870 986 59700 986 1.1250 0.8560 47500 880 1193 660 815 875 174 968 88700 1996 1.250 0.8560 47500 880 1139 840 1142 714 968 88700 1996 1.250 0.860 1183 840 1175 1588 8700 1816 8750 1816 8700 1816 8870 1816 8700 1816 8700 1816 8870 1816 8700 1816 8700 181 | 1 | ł | + | 0.27.00 | 29400 | 430 | 583 | 320 | 434 | 475 | 646 | 386 | 523 | 41600 | 605 | 825 | 545 | 740 | 455 | 620 |
| 1,0000 | 1 | ╁ | H | 0.5090 | 32400 | 470 | 637 | 350 | 475 | 520 | 707 | 425 | 576 | 45800 | 670 | 910 | 009 | 815 | 200 | 680 |
| 1,0000 0,6630 42200 700 949 530 719 735 1000 633 858 59700 995 1,1250 0,1630 860 813 840 1142 714 868 86700 1290 1455 1,1250 0,8660 47500 1240 1183 840 1175 1,588 1099 1,388 87200 1,145 1,1550 1,15 | | | L | 0909.0 | 38600 | 640 | 898 | 480 | 651 | 675 | 918 | 579 | 785 | 51500 | 860 | 1170 | 770 | 1045 | 645 | 875 |
| 1.1250 0.76830 42300 800 1085 660 813 840 1142 714 968 88700 1290 1290 1250 0.8660 47500 880 1183 660 895 925 1183 840 1145 1250 0.8660 93800 1120 1518 840 1175 1368 810 1175 1368 810 1175 1368 810 1175 1368 810 1175 1368 810 1175 1368 810 1175 1368 810 1175 1368 810 1175 1368 810 1175 1368 810 1175 1368 810 1175 1368 810 1175 1368 810 1175 1369 810 810 810 810 810 810 810 810 810 810 | 1 | | | 0.6630 | 42200 | 700 | 949 | 530 | 719 | 735 | 1000 | 633 | 858 | 29700 | 982 | 1355 | 895 | 1215 | 745 | 1015 |
| 1,1250 0,8860 47500 880 1193 660 885 925 1258 802 1087 77000 1445 1,2550 0,0860 1380 1120 1518 840 1175 1598 1009 1368 87000 1815 1,2550 10,0960 1240 1681 920 1247 1300 1768 1118 1516 96600 2015 1,2550 11,1550 64100 1460 1979 1100 1491 1525 2074 1322 1792 104000 2285 1,3750 11,4550 73000 1680 2278 1280 1768 1750 2280 1566 2042 11810 2705 1,5500 14,050 73000 1940 2203 1460 1979 2224 2300 3128 1974 2676 142200 3355 1,5500 1580 8770 2200 2983 1640 2224 2300 3128 1974 2676 142200 3355 | | H | Н | 0.7630 | 42300 | 800 | 1085 | 009 | 813 | 840 | 1142 | 714 | 896 | 68700 | 1290 | 1755 | 1160 | 1580 | 965 | 1310 |
| 1.2500 0.9880 53800 1120 16518 840 1139 1175 1598 1009 1385 87200 1815 1.2500 1.0730 59600 1240 1681 920 1247 1176 1118 1616 96600 2016 1.3750 1.1550 64100 1460 1979 1100 1491 1552 2074 1782 1740 2385 1.5700 1.3150 73000 1680 2278 1760 1760 1760 280 1760 280 1760 1770 1770 1770 1780 1780 1780 1780 2705 2705 2705 2705 2706 2706 2706 2706 2707 1780 2706 2706 2706 2707 | - 1 | | | 0.8560 | 47500 | 880 | 1193 | 099 | 895 | 925 | 1258 | 802 | 1087 | 77000 | 1445 | 1965 | 1300 | 1770 | 1085 | 1475 |
| 1,2500 1,0730 59660 1,240 1,247 1,2500 1,078 1,1550 1,078 1,000 1,240 1,000 1,247 1,000 | - 1 | 7 | | 0.9690 | 53800 | 1120 | 1518 | 840 | 1139 | 1175 | 1598 | 1009 | 1368 | 8/200 | 1815 | 2470 | 1635 | 2225 | 1365 | 1855 |
| 1.3750 1.1550 64100 1460 1979 1100 1491 1525 2074 1322 1792 104000 2385 1.3750 1.3150 73000 1680 2276 1260 1708 1750 2380 156 204 1156 205 1.5000 1.4050 78000 1940 2630 1640 1979 205 2754 1755 2379 126500 3165 1.5001 1.580 8770 2200 2224 2224 2300 3128 1974 2676 142200 3555 | | 4 | + | 1.0730 | 29600 | 1240 | 1681 | 920 | 1247 | 1300 | 1768 | 1118 | 1516 | 00996 | 2015 | 2740 | 1810 | 2460 | 1510 | 2055 |
| 1.3750 1.4350 78000 1680 2278 1280 1708 1750 2380 1506 2042 118150 2705 1.5000 1.4050 78000 1940 2283 1460 1979 2025 274 1755 2379 126500 3165 1.5000 1.580 8770 2200 2383 1640 2224 2300 3128 1974 2676 142200 3555 | - 1 | + | + | 1.1550 | 64100 | 1460 | 1979 | 1100 | 1491 | 1525 | 2074 | 1322 | 1792 | 104000 | 2385 | 3245 | 2145 | 2915 | 1785 | 2430 |
| 1.5000 1.4050 87700 2200 2983 1640 2224 2300 3128 1974 2676 142200 31555 | - 1 | + | - | 1.3150 | 73000 | 1680 | 2278 | 1260 | 1708 | 1750 | 2380 | 1506 | 2042 | 118100 | 2705 | 3680 | 2435 | 3310 | 2030 | 2760 |
| 1.5000 1.5800 87700 2200 2983 1640 2224 2300 3128 1974 2676 142200 3555 | - 1 | 9 | - | 1.4050 | 78000 | 1940 | 2630 | 1460 | 1979 | 2025 | 2754 | 1755 | 2379 | 126500 | 3165 | 4305 | 2845 | 3870 | 2370 | 3225 |
| | | 12 1 | _ | 1.5800 | 87700 | 2200 | 2983 | 1640 | 2224 | 2300 | 3128 | 1974 | 2676 | 142200 | 3555 | 4835 | 3200 | 4350 | 2665 | 3625 |

Figure 1-5. Torque Chart (SAE Fasteners)- Sheet 1 of 5

Medium - High Strength (Red) Medium Strength (Blue) Description High Strength (Red) REFERENCE JLG THREAD LOCKING COMPOUND THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
 ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
 * ASSEMBLY USES HARDENED WASHER Vibra-TITETM121 Vibra-TITETM140 Vibra-TITE™ 131 ND Industries P/N Loctite® P/N 242TM 271TM 262TM JLG P/N 0100019 0100071 0100011

| | | | | | | | Vali | nes for | Magni (| Values for Magni Coating Fasteners (Ref 4150701 | Faster | ners (R | ef 4150 | 701) | | | |
|-------|-----|----------|------------------------|------------|------------------|---------------------------|--|---|---------|---|---------------|-------------------|--|---|---|---|--|
| | | | | SAI | 111 | DE 5 B | OLTS & | GRADE 5 BOLTS & GRADE 2 NUTS | 2 NUT | (A) | SAE | RADE 8 | 3 (HEX F | ID) BOL | TS & GF | SAE GRADE 8 (HEX HD) BOLTS & GRADE 8 NUTS* | *STON |
| Size | TPI | Bolt Dia | Tensile Stress Area | Clamp Load | Tor (D K=C | Torque (Dry) K=0.17 | Tor (Loctite€ 271™ OR \ 111 c | Torque (Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140) K=0.16 | | Tor que (Loctite® 262 TM or Vibra- TITE TM 131) K=0.15 | Clamp Load | Tor (Dry or Lo | Torque (Dry or Loctite® 263) K= 0.17 | Torque (Loctite® 242 TM or 271 TM OR Vibra-TITE TM 111 or 140) K=.16 | Torque e® 242 TM or 3 Vibra-TITE TM 1 or 140) K=.16 | Torque (Loctite® 262 TM or Vibra- TITE TM 131) K=0.15 | Torque © 262 TM or Vibra- TE TM 131) K=0.15 |
| | | П | Sq In | EB. | IN-LB | [N.m] | IN-LB | [N.m] | IN-LB | [N.m] | EB. | IN-LB | [N.m] | IN-LB | [N.m] | IN-LB | [N.m] |
| 4 | 40 | 0.1120 | 0.00604 | 380 | 7 | 0.8 | | | | | | | | | | | |
| | 48 | 0.1120 | 0.00661 | 420 | 8 | 6.0 | | | | | | | | | | | |
| 9 | 32 | 0.1380 | 0.00909 | 580 | 14 | 1.5 | | | | | | | | | | | |
| α | 32 | 0.1380 | 0.01015 | 019 | 25 | o: 0 | | | | | | | | | | | |
| , | 38 | 0.1640 | 0.01474 | 940 | 56 | 2.9 | | | | | 1320 | 37 | 4 | | | | |
| 10 | 24 | 0.1900 | 0.01750 | 1120 | 36 | 4.1 | | | | | 1580 | 51 | 9 | | | | |
| | 32 | 0.1900 | 0.02000 | 1285 | 42 | 4.7 | | | | | 1800 | 58 | 7 | | | | |
| 1/4 | 20 | 0.2500 | 0.0318 | 2020 | 98 | 9.7 | 80 | 6 | Ī | | 2860 | 122 | 14 | 114 | 13 | | |
| | 28 | 0.2500 | 0.0364 | 2320 | 66 | 11.1 | 92 | 11 | | | 3280 | 139 | 16 | 131 | 15 | | |
| | | ln | Sq In | LB | FT-LB | [N.m] | FT-LB | [N.m] | FT-LB | [N.m] | LB | FT-LB | [N.m] | FT-LB | [N.m] | FT-LB | [N.m] |
| 5/16 | 18 | 0.3125 | 0.0524 | 3340 | 15 | 20 | 14 | 19 | 15 | 20 | 4720 | 20 | 25 | 20 | 25 | 20 | 25 |
| | 24 | 0.3125 | 0.0580 | 3700 | 15 | 20 | 15 | 21 | 15 | 20 | 5220 | 25 | 35 | 20 | 25 | 20 | 25 |
| 3/8 | 16 | 0.3750 | 0.0775 | 4940 | 25 | 35 | 25 | 34 | 25 | 34 | 7000 | 35 | 50 | 35 | 50 | 35 | 50 |
| | 24 | 0.3750 | 0.0878 | 2600 | 30 | 40 | 28 | 38 | 25 | 34 | 7900 | 40 | 55 | 40 | 55 | 35 | 50 |
| 2//16 | 14 | 0.4375 | 0.1063 | 0089 | 40 | 55 | 40 | 54 | 35 | 48 | 9550 | 09 | 80 | 55 | 75 | 50 | 70 |
| | 50 | 0.4375 | 0.1187 | 7550 | 45 | 09 | 44 | 09 | 40 | 54 | 10700 | 65 | 90 | 09 | 80 | 60 | 80 |
| 1/2 | 13 | 0.5000 | 0.1419 | 9050 | 65 | 06 | 09 | 82 | 55 | 75 | 12750 | 06 | 120 | 85 | 115 | 80 | 110 |
| | 50 | 0.5000 | 0.1599 | 10700 | 75 | 100 | 71 | 97 | 65 | 88 | 14400 | 100 | 135 | 95 | 130 | 06 | 120 |
| 9/16 | 15 | 0.5625 | 0.1820 | 11600 | 90 | 120 | 87 | 118 | 80 | 109 | 16400 | 130 | 175 | 125 | 170 | 115 | 155 |
| 5/8 | 2 = | 0.3023 | 0.2030 | 14400 | 130 | 175 | 120 | 163 | 115 | 156 | 20350 | 180 | 245 | 170 | 230 | 150 | 220 |
| S | 18 | 0.6250 | 0.2560 | 16300 | 145 | 195 | 136 | 185 | 125 | 170 | 23000 | 205 | 280 | 190 | 260 | 180 | 245 |
| 3/4 | 10 | 0.7500 | 0.3340 | 21300 | 225 | 305 | 213 | 290 | 200 | 272 | 30100 | 320 | 435 | 300 | 410 | 280 | 380 |
| | 16 | 0.7500 | 0.3730 | 23800 | 255 | 345 | 238 | 324 | 225 | 306 | 33600 | 355 | 485 | 335 | 455 | 315 | 430 |
| 2/8 | 6 | 0.8750 | 0.4620 | 29400 | 365 | 495 | 343 | 466 | 320 | 435 | 41600 | 515 | 700 | 485 | 099 | 455 | 620 |
| , | 14 | 0.8750 | 0.5090 | 32400 | 400 | 545 | 378 | 514 | 355 | 483 | 45800 | 570 | 775 | 535 | 730 | 500 | 680 |
| - | φ | 1.0000 | 0.6060 | 38600 | 545 | 740 | 575 | 700 | 480 | 653 | 51500 | 730 | 995 | 685 | 930 | 645 | 8/5 |
| 0/++ | 7 2 | 1.0000 | 0.5630 | 42200 | 900 | 010 | 202 | CQ/ | 230 | 12/ | 00/66 | 1005 | 1400 | 1030 | 1400 | 745 | 1010 |
| 0/1 | 12 | 1.1250 | 0.8560 | 42300 | 755 | 1025 | 713 | 696 | 029 | 911 | 27000 | 1225 | 1665 | 1155 | 1570 | 1085 | 1475 |
| 1 1/4 | 7 | 1.2500 | 0.9690 | 53800 | 955 | 1300 | 897 | 1219 | 840 | 1142 | 87200 | 1545 | 2100 | 1455 | 1980 | 1365 | 1855 |
| | 12 | 1.2500 | 1.0730 | 29600 | 1055 | 1435 | 666 | 1351 | 930 | 1265 | 00996 | 1710 | 2325 | 1610 | 2190 | 1510 | 2055 |
| 1 3/8 | 9 | 1.3750 | 1.1550 | 64100 | 1250 | 1700 | 1175 | 1598 | 1100 | 1496 | 104000 | 2025 | 2755 | 1905 | 2590 | 1785 | 2430 |
| | 12 | 1.3750 | 1.3150 | 73000 | 1420 | 1930 | 1338 | 1820 | 1255 | 1707 | 118100 | 2300 | 3130 | 2165 | 2945 | 2030 | 2760 |
| 1 1/2 | 9 | 1.5000 | 1.4050 | 78000 | 1660 | 2260 | 1560 | 2122 | 1465 | 1992 | 126500 | 2690 | 3660 | 2530 | 3440 | 2370 | 3225 |
| | 12 | 1.5000 | 1.5800 | 87700 | 1865 | 2535 | 1754 | 2385 | 1645 | 2237 | 142200 | 3020 | 4105 | 2845 | 3870 | 2665 | 3625 |

Figure 1-6. Torque Chart (SAE Fasteners)- Sheet 2 of 5

NO. 5000059 REV. K

1. THESE TOROUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = $\pm 10\%$ 3. *ASSEMBLY USES HARDENED WASHER NOTES:

1-16 3121139

| | | | | | | | | 0) | SOCKE | T HEA | SOCKET HEAD CAP SCREWS | REWS | | | | | |
|--|--|--------------------------|-----------|----------------------|---------------|----------------|--|--------|-----------------------------------|---|--------------------------|------------|----------------------------|--|--|---|---|
| Magni Coating (Ref 4150701)* | Magni Coa | Magni Coa | Magni Coa | Magni Coa | ni Coa | - - | ng (Ref ² | 115070 | 1)* | | Zinc | /ellow C | hromate | Fasten | ers (Ref | Zinc Yellow Chromate Fasteners (Ref 4150707)* | *(2 |
| TPI Bolt Dia Stress Area See Note 4 (Dry) K = .17 | Tensile Clamp Load Stress Area See Note 4 | Clamp Load See Note 4 | | Torque (Dry) K = .17 | uve (= .17 | | Torque (Loctite® 242 TM or 271 TM OR Vibra-TITE TM 111 or 140 OR Precoat 85®) | | (Loctite® TITE TM 1 | Torque 262 TM or Vibra- 31) K=0.15 | Clamp Load See Note 4 | D Ω × | Torque (Dry) K = .20 | Tor (Loctite® 24 OR Vibra-T 140 OR Pr | Torque (Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140 OR Precoat 85®) K=0.18 | (Loctite® TITE TM 1 | Torque 262 TM or Vibra- 31) K=0.15 |
| In Sq in LB IN·LB [N·m] | Sq In LB IN-LB | R IN-LB | IN-LB | | [N.m] | | IN-LB | [N.m] | IN-LB | [N.m] | 87 | IN-LB | [N.m] | IN-LB | [N.m] | IN-LB | [N.m] |
| 40 0.1120 0.00604 | L | 0.00604 | | | | | | | | | | | | | | | |
| 0.1120 | | 0.00661 | | | | | | | | | | | | | | | |
| 32 0.1380 0.00909 | 1 | 000000 | | | | _ | | | | | | | | | | | |
| 0.1380 | + | 0.01013 | | | | | | | | | | | | | | | |
| 0.1640 | - | 0.01474 | | | | | | | | | | | | | | | |
| 0.1900 | | 0.01750 | | | | - | | | | | | | | | | | |
| 0.1900 0.02000 | 0.02000 | | | | | - | | | | | | | | | | | |
| 0.2500 0.0318 2860 122 | 0.0318 2860 122 | 2860 122 | 122 | | 14 | - | 114 | 13 | | | 2860 | 143 | 16 | 129 | 15 | | |
| 0.2500 0.0364 3280 | 0.0364 3280 139 | 3280 139 | 139 | | 16 | | 131 | 15 | | | 3280 | 164 | 19 | 148 | 17 | | |
| Sq In | Sq In LB FT-LB | LB FT-LB | FT-LB | | [N.m] | | FT-LB | [N.M] | FT-LB | [N.m] | ПВ | FT-LB | [N.m] | FT-LB | [N.m] | FT-LB | [N.m] |
| 0.0524 4720 20 | 0.0524 4720 20 | 4720 20 | 50 | | 25 | | 20 | 25 | 20 | 52 | 4720 | 25 | 32 | 20 | 25 | 20 | 25 |
| 0.3125 0.0580 5220 25 | 0.0580 5220 25 | 5220 25 | 25 | | 35 | | 20 | 25 | 20 | 52 | 5220 | 25 | 32 | 25 | 35 | 20 | 25 |
| 0.3750 0.0775 7000 35 | 0.0775 7000 35 | 7000 35 | 35 | | 20 | - | 35 | 50 | 35 | 20 | 2000 | 45 | 09 | 40 | 22 | 35 | 20 |
| 0.0878 7900 40 | 0.0878 7900 40 | 7900 40 | 40 | | 22 | _ | 40 | 55 | 35 | 20 | 0062 | 20 | 20 | 45 | 09 | 35 | 50 |
| 0.4375 0.1063 9550 | 0.1063 9550 60 | 9550 60 | 09 | | 80 | _ | 55 | 75 | 50 | 20 | 0226 | 70 | 92 | 65 | 06 | 50 | 70 |
| 0.1187 10700 65 | 0.1187 10700 65 | 10700 65 | 65 | | 90 | - | 09 | 80 | 09 | 80 | 10700 | 80 | 110 | 20 | 92 | 09 | 80 |
| 0.5000 0.1419 12750 90 | 0.1419 12750 90 | 12750 90 | 06 | - | 120 | - | 82 | 115 | 80 | 110 | 12750 | 105 | 145 | 32 | 130 | 80 | 110 |
| 00 5 | 0.1599 14400 100 | 16400 100 | 00 5 | 1 | 133 | + | 25 | 130 | 30 | 120 | 16400 | 120 | 100 | 140 | 000 | 30 | 120 |
| 0.5625 0.2030 18250 145 | 0.2030 18250 145 | 18250 145 | 145 | | 195 | + | 135 | 185 | 130 | 175 | 18250 | 170 | 230 | 155 | 210 | 130 | 175 |
| 0.6250 0.2260 20350 180 | 0.2260 20350 180 | 20350 180 | 180 | | 245 | П | 170 | 230 | 160 | 220 | 20350 | 210 | 285 | 190 | 260 | 160 | 220 |
| 0.6250 0.2560 23000 205 | 0.2560 23000 205 | 23000 205 | 205 | | 280 | T | 190 | 260 | 180 | 245 | 23000 | 240 | 325 | 215 | 290 | 180 | 245 |
| 10 0.7500 0.3340 33100 320 435 16 0.7500 0.3730 33600 355 485 | 0.3340 30100 320 0.3730 33600 355 | 33600 355 | 355 | | 435 | T | 335 | 455 | 315 | 380 430 | 30100 | 375 420 | 510 570 | 340 380 | 460 515 | 280 315 | 380 |
| 0.4620 41600 515 | 0.4620 41600 515 | 41600 515 | 515 | | 200 | T | 485 | 099 | 455 | 620 | 41600 | 605 | 825 | 545 | 740 | 455 | 620 |
| 0.5090 45800 570 | 0.5090 45800 570 | 45800 570 | 220 | | 275 | П | 535 | 730 | 200 | 089 | 45800 | 029 | 910 | 009 | 815 | 200 | 680 |
| 1.0000 0.6060 51500 730 | 0.6060 51500 730 | 51500 730 | 730 | | 662 | Н | 685 | 930 | 645 | 978 | 21500 | 860 | 1170 | 2// | 1055 | 645 | 875 |
| 59700 845 | 0.6630 59700 845 | 59700 845 | 845 | | 1150 | Г | 795 | 1080 | 745 | 1015 | 00269 | 366 | 1355 | 968 | 1215 | 745 | 1015 |
| 0.7630 68700 1095 | 0.7630 68700 1095 | 68700 1095 | 1095 | | 1490 | П | 1030 | 1400 | 965 | 1310 | 00289 | 1290 | 1755 | 1160 | 1580 | 396 | 1310 |
| 0.8560 77000 | 0.8560 77000 1225 | 77000 1225 | 1225 | | 1665 | П | 1155 | 1570 | 1085 | 1475 | 00022 | 1445 | 1965 | 1300 | 1770 | 1085 | 1475 |
| 1.2500 0.9690 87200 1545 | 0.9690 87200 1545 | 87200 1545 | 1545 | | 2100 | | 1455 | 1980 | 1365 | 1855 | 87200 | 1815 | 2470 | 1635 | 2225 | 1365 | 1855 |
| 1.0730 96600 1710 | 1.0730 96600 1710 | 96600 1710 | 1710 | | 2325 | | 1610 | 2190 | 1510 | 2022 | 00996 | 2015 | 2740 | 1810 | 2460 | 1510 | 2055 |
| 1.3750 1.1550 104000 2025 | 1.1550 104000 2025 | 104000 2025 | 2025 | | 2755 | | 1905 | 2590 | 1785 | 2430 | 104000 | 2385 | 3245 | 2145 | 2915 | 1785 | 2430 |
| 1.3750 1.3150 118100 2300 | 1.3150 118100 2300 | 118100 2300 | 2300 | | 3130 | | 2165 | 2945 | 2030 | 2760 | 118100 | 2705 | 3680 | 2435 | 3310 | 2030 | 2760 |
| 1.5000 1.4050 126500 2690 | 1.4050 126500 2690 | 126500 2690 | 2690 | | 3660 | П | 2530 | 3440 | 2370 | 3225 | 126500 | 3165 | 4305 | 2845 | 3870 | 2370 | 3225 |
| 12 1.5000 1.5800 142200 3020 4105 | 1.5800 142200 3020 | 142200 3020 | 3020 | | 4105 | -1 | 2845 | 3870 | 2665 | 3625 | 142200 | 3555 | 4835 | 3200 | 4350 | 2665 | 3625 |
| | | | | | | | | | | | | | | | | | |

Figure 1-7. Torque Chart (SAE Fasteners)- Sheet 3 of 5

NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS

2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%

3. ASSEMBLY USES HARDENED WASHER OR FASTENER IS PLACED AGAINST PLATED STEEL OR RAW ALUMINUM

4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

1-17 3121139

| CLASS 10.9 METRIC (HEXXEOCKETI HEAD) BOLTS CLASS 10.9 METRIC (HEXXEOCKETI HEAD) BOLTS CLASS 10.9 METRIC NUTS CLASS 10.0 METRIC NUTS CLAS | | | | | Va | lues for . | Zinc Yello | w Chrom | ate Fas | Values for Zinc Yellow Chromate Fasteners (Ref 4150707) | if 4150707) | |
|--|------|-------|---------------------------|---------------|---|-----------------------|---|---------|---------------|---|---|--|
| Tensile Clamp Torque T | | | | CLASS | 8 8.8 METRIC CLAS | S (HEX/SC S 8 METR | OCKET HEAL IC NUTS |) BOLTS | CLASS . | ASS 10.9 MET CLASS 1 12.9 SOCKET | TRIC (HEX HEAE 0 METRIC NUT HEAD CAP SCR | S S REWS M3 - M5* |
| Sq mm KN [N.m] [N.m] [N.m] [N.m] [N.m] [N.m] 0.5 503 2.19 1.3 1.0 1.2 1.4 3.13 [N.m] 0.6 6.78 2.95 2.1 1.6 1.9 2.3 4.22 1.0 0.7 8.78 3.82 3.1 2.3 2.8 8.4 5.47 1.0 0.7 8.78 3.82 3.1 2.3 4.22 8.8 8.8 8.8 8.8 8.8 8.8 8.8 8.8 8.8 8.8 8.8 8.8 8.8 9.4 1.2 8.8 8.8 9.4 1.2 8.8 9.4 1.2 8.8 9.4 1.2 8.8 9.4 1.2 8.8 9.4 1.2 8.8 9.4 1.2 8.8 9.4 1.2 8.8 9.4 1.2 8.8 9.4 1.2 9.4 1.2 9.4 1.2 9.4 1.2 9.4 1.2 | Size | РІТСН | Tensile Stress Area | Clamp Load | Torque (Dry or Loctite® 263 TM) | Torque (Lub) | Torque (Loctite® 262 TM OR Vibra- TITE TM 131) | | Clamp Load | Torque (Dry or Loctite® 263 TM) K = 0.20 | Torque (Lub OR Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140) K= 0.18 | To rque (Loctite® 262 TM OR Vibra-TITE TM 131) K=0.15 |
| 0.5 5.03 2.19 1.3 1.0 1.2 1.4 3.13 0.6 6.78 2.96 2.1 1.6 1.9 2.3 4.22 0.7 8.78 3.82 3.1 2.3 2.8 3.4 5.47 0.8 14.20 6.18 6.2 4.6 5.6 6.8 8.85 1 2.010 8.74 1.1 7.9 9.4 12.5 12.5 1.25 3.60 12.6 1.8 5.6 8.85 3.7 1.25 3.60 12.6 1.9 2.3 2.8 3.7 1.2 1.75 3.60 12.9 3.8 4.5 5.6 3.6 3.7 3.7 3.7 3.8 4.5 5.6 3.6 3.7 3.7 3.7 3.7 3.7 3.7 3.7 3.7 3.7 3.7 3.7 3.7 3.7 | | | Sq mm | X | [N.m] | [N.m] | [N.m] | [N.m] | K | [N.m] | [N.m] | [w:N] |
| 0.6 6.78 2.95 2.1 1.6 1.9 2.3 4.2 7.2 4.2 7.2 4.2 7.2 4.2 7.2 4.2 7.2 4.2 7.3 4.2 7.2 4.2 7.3 4.2 7.3 4.2 7.3 </td <td>3</td> <td>0.5</td> <td>5.03</td> <td>2.19</td> <td>1.3</td> <td>1.0</td> <td>1.2</td> <td>1.4</td> <td>3.13</td> <td></td> <td></td> <td></td> | 3 | 0.5 | 5.03 | 2.19 | 1.3 | 1.0 | 1.2 | 1.4 | 3.13 | | | |
| 0.7 8.78 3.82 3.1 2.3 2.8 3.4 5.47 7.8 6.8 7.9 7.9 9.4 5.6 6.8 8.85 7.8 7.9 7.9 9.4 1.2 6.8 8.85 7.8 7.8 7.9 9.4 1.2 6.8 8.85 7.8 7 | 3.5 | 9.0 | 8.78 | 2.95 | 2.1 | 1.6 | 1.9 | 2.3 | 4.22 | | | |
| 0.8 14.20 6.18 6.2 4.6 5.6 6.8 8.85 8.85 1 20.10 8.74 11 7.9 9.4 12 12.5 1 20.10 8.74 11 7.9 9.4 12 12.5 1.25 36.60 15.9 26 19 23 28 22.8 37 1.5 58.00 25.2 50 38 45 55 38.1 70 1.75 84.30 38.7 88 66 79 97 52.5 125 2 1.5 58.0 140 105 126 36.5 36.5 36.5 36.5 2 1.5 58.0 140 105 126 37.8 430 430 2.5 1.6 1.6 1.9 1.6 1.9 4.8 4.8 4.8 4.8 4.8 4.8 4.8 4.8 4.8 4.8 4.8 4.8 | 4 | 0.7 | 8.78 | 3.82 | 3.1 | 2.3 | 2.8 | 3.4 | 5.47 | | | |
| 1 20.10 8.74 11 7.9 9.4 12 12.5 1.25 36.60 12.6 18 13 16 19 18.0 25 1.25 36.60 15.9 26 19 23 28 22.8 37 1.5 58.00 25.2 50 38 45 55 36.1 70 1.75 84.30 36.7 88 66 79 97 52.5 125 2 1.15 50.0 140 105 126 36.1 70 2 1.15 68.3 2.19 164 197 24.1 37.8 315 2.5 1.92 83.5 1.64 19.4 11.5 4.0 4.0 2.5 1.92 1.08.0 32.0 22.1 11.5 6.1 4.0 2.5 2.45 1.06.5 426 52.3 18.1 22.5 610 2.5 2.45< | 5 | 0.8 | 14.20 | 6.18 | 6.2 | 4.6 | 5.6 | 6.8 | 8.85 | | | |
| 1 28.90 12.6 18 13 16 19 18.0 25 1.25 36.60 15.9 26 19 23 28 22.8 37 1.5 58.00 25.2 50 38 45 55 36.1 70 1.75 84.30 36.7 88 66 79 97 52.5 125 2 115 50.0 140 105 164 174 71.6 200 2.5 115 68.3 219 164 197 241 31.5 200 2.5 145 164 164 197 1136 610 31.5 2.5 145 22.6 271 241 47.6 610 430 2.5 245 106.5 426 523 683 181 22.0 1065 3.5 561 108.5 1080 810 970 1130 286.0 1545 | 9 | 1 | 20.10 | 8.74 | 11 | 7.9 | 9.4 | 12 | 12.5 | | | |
| 1.25 36.60 15.9 26 19 23 28 28 37 37 1.5 58.00 25.2 50 38 45 55 36.1 70 70 1.75 84.30 36.7 88 66 79 97 52.5 125 70 2 115 50.0 140 105 126 154 716 200 125 <t< td=""><td>7</td><td>1</td><td>28.90</td><td>12.6</td><td>18</td><td>13</td><td>16</td><td>19</td><td>18.0</td><td>25</td><td>23</td><td>19</td></t<> | 7 | 1 | 28.90 | 12.6 | 18 | 13 | 16 | 19 | 18.0 | 25 | 23 | 19 |
| 1.5 58.00 25.2 50 38 45 55 36.1 70 70 1.75 84.30 36.7 88 66 79 97 52.5 125 126 2 115 50.0 140 105 126 154 716 200 126 2.5 157 68.3 219 164 197 241 37.6 315 200 2.5 157 68.3 301 226 271 331 119.5 430 516 430 2.5 245 106.5 426 320 469 15.2 430 516 400 523 1460 110 523 181 226.0 1065 1066 1060 </td <td>8</td> <td>1.25</td> <td>36.60</td> <td>15.9</td> <td>26</td> <td>19</td> <td>23</td> <td>28</td> <td>22.8</td> <td>37</td> <td>33</td> <td>27</td> | 8 | 1.25 | 36.60 | 15.9 | 26 | 19 | 23 | 28 | 22.8 | 37 | 33 | 27 |
| 1.75 84.30 36.7 88 66 79 97 52.5 125 2 115 50.0 140 105 126 154 71.6 200 2 157 68.3 219 164 197 241 97.8 315 2.5 152 182 301 266 271 331 119.5 430 2.5 182 302 320 383 469 15.5 400 2.5 245 106.5 320 383 469 16.5 400 2.5 303 132.0 581 469 16.3 110.6 106.5 3 459 193.5 168 810 970 1130 222.0 1065 3.5 561 244.0 1460 1100 1320 1530 349.5 2095 3.5 644 302.0 1990 1490 1790 2090 432.5 2855 | 10 | 1.5 | 58.00 | 25.2 | 50 | 38 | 45 | 55 | 36.1 | 70 | 99 | 99 |
| 2 115 50.0 140 105 126 154 71.6 200 2 157 68.3 219 164 197 241 97.8 315 2.5 192 83.5 301 226 271 331 119.5 430 2.5 245 106.5 426 320 383 469 152.5 610 2.5 245 132.0 581 436 663 811 22.0 1065 3 459 199.5 1080 810 970 1130 286.0 1545 3.5 561 244.0 1460 1100 370 1320 1530 399.5 2095 4 817 356.5 2560 1920 1790 2090 432.5 2855 4 1120 487.0 1960 3070 3680 4290 698.0 5865 | 12 | 1.75 | 84.30 | 36.7 | 88 | 99 | 79 | 97 | 52.5 | 125 | 115 | 95 |
| 2 157 68.3 219 164 197 241 97.8 315 2.5 192 83.5 301 226 271 331 119.5 430 2.5 245 106.5 426 220 383 469 152.5 610 2.5 303 132.0 581 436 189.0 189.0 189.0 3 453 153.5 737 553 663 811 222.0 1065 3.5 561 2440 1460 1100 1320 1530 349.5 2095 3.5 644 302.0 1990 1490 1790 2090 432.5 2855 4 817 355.5 2560 1920 2300 2890 698.0 5865 | 14 | 2 | 115 | 50.0 | 140 | 105 | 126 | 154 | 71.6 | 200 | 180 | 150 |
| 2.5 192 83.5 301 226 271 331 119.5 430 2.5 245 106.5 426 320 383 469 152.5 610 2.5 303 132.0 581 436 523 639 189.0 630 3 459 153.5 737 553 663 811 222.0 1065 3 459 199.5 1080 810 970 1130 286.0 1545 3.5 561 244.0 1460 1100 1320 1530 349.5 2095 4 817 365.5 2560 1920 2300 2690 509.0 3665 4 1120 487.0 4090 3070 3680 4290 698.0 5865 | 16 | 2 | 157 | 68.3 | 219 | 164 | 197 | 241 | 97.8 | 315 | 280 | 235 |
| 2.5 245 106.5 426 320 383 469 152.5 610 2.5 303 132.0 581 436 523 639 189.0 630 3 353 153.5 737 553 663 811 222.0 1065 3 459 199.5 1080 810 970 1130 286.0 1545 3.5 561 244.0 1460 1100 1320 1530 349.5 2095 4 817 355.5 2560 1920 2300 2690 509.0 3665 4.5 1120 487.0 4090 3070 3680 4290 698.0 5865 | 18 | 2.5 | 192 | 83.5 | 301 | 226 | 271 | 331 | 119.5 | 430 | 385 | 325 |
| 2.5 303 132.0 581 436 523 639 189.0 830 3 353 153.5 737 553 663 811 222.0 1065 3 459 199.5 1080 810 970 1130 286.0 1545 3.5 561 244.0 1460 1100 1320 1530 349.5 2095 4 817 355.5 2560 1920 2300 2690 509.0 3665 4.5 1120 487.0 4090 3070 3680 4290 698.0 5865 | 20 | 2.5 | 245 | 106.5 | 426 | 320 | 383 | 469 | 152.5 | 610 | 550 | 460 |
| 3 353 153.5 737 553 663 811 222.0 1065 3 459 199.5 1080 810 970 1130 286.0 1545 3.5 561 244.0 1460 1100 1320 1530 349.5 2095 3.5 694 302.0 1990 1490 1790 2090 432.5 2855 4 817 355.5 2560 1920 2300 2690 509.0 3665 4.5 1120 487.0 4090 3070 3680 4290 698.0 5865 | 22 | 2.5 | 303 | 132.0 | 581 | 436 | 523 | 639 | 189.0 | 830 | 750 | 625 |
| 3 459 199.5 1080 810 970 1130 286.0 1545 3.5 561 244.0 1460 1100 1320 1530 349.5 2095 3.5 694 302.0 1990 1490 1790 2090 432.5 2855 4 817 355.5 2560 1920 2300 2690 509.0 3665 4.5 1120 487.0 4090 3070 3680 4290 698.0 5865 | 24 | 3 | 353 | 153.5 | 737 | 553 | 663 | 811 | 222.0 | 1065 | 960 | 800 |
| 3.5 561 244.0 1460 1100 1320 1530 349.5 2095 3.5 694 302.0 1990 1490 1790 2090 432.5 2855 4 817 355.5 2560 1920 2300 2690 509.0 3665 4.5 1120 487.0 4090 3070 3680 4290 698.0 5865 | 27 | 3 | 459 | 199.5 | 1080 | 810 | 970 | 1130 | 286.0 | 1545 | 1390 | 1160 |
| 3.5 694 302.0 1990 1490 1790 2090 432.5 2855 4 817 355.5 2560 1920 2300 2690 509.0 3665 4.5 1120 487.0 4090 3070 3680 4290 698.0 5865 | 30 | 3.5 | 561 | 244.0 | 1460 | 1100 | 1320 | 1530 | 349.5 | 2095 | 1885 | 1575 |
| 4 817 356.5 2560 1920 2300 2690 509.0 3665 4.5 1120 487.0 4090 3070 3680 4290 698.0 5865 | 33 | 3.5 | 694 | 302.0 | 1990 | 1490 | 1790 | 2090 | 432.5 | 2855 | 2570 | 2140 |
| 4.5 1120 487.0 4090 3070 3680 4290 698.0 5865 | 36 | 4 | 817 | 355.5 | 2560 | 1920 | 2300 | 2690 | 509.0 | 3665 | 3300 | 2750 |
| | 42 | 4.5 | 1120 | 487.0 | 4090 | 3070 | 3680 | 4290 | 698.0 | 5865 | 5275 | 4395 |

NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE WALUES ARE STATIO TORQUE MASURED PER STANDARD ALIDIT METHODS TOLERANCE = ±10%
2. ALL TORQUE VALUES ARE STATIO TORQUE MASHER OR FASTENER IS PLACED ACAMINST PLATED STEEL OR RAW ALUMINUM
**3. ASSEMBLY USES HARDEN GARANER OR PLAGED ACAMINST PLATED ACAMI

Figure 1-8. Torque Chart (METRIC Fasteners) - Sheet 4 of 5

1-18 3121139

| | | | | Š | alues for Ma | Values for Magni Coated Fasteners (Ref 4150701) | asteners | (Ref 415) | 0701) | |
|------|-------|---------------------------|---------------|---|---|---|------------|---|---|---|
| | | | CLASS | CLASS 8.8 METRIC (HEX/SOCKET HEAD) BOLTS CLASS 8 METRIC NUTS | ETRIC (HEX/SOCKET HI CLASS 8 METRIC NUTS | HEAD) BOLTS | CLAS | S 10.9 METH CLASS 10 S 12.9 SOCK M6 AN | CLASS 10.9 METRIC (HEX HEAD) BOLTS CLASS 10 METRIC NUTS CLASS 12.9 SOCKET HEAD CAP SCREWS M6 AND ABOVE* | D) BOLTS TS SCREWS |
| Size | РІТСН | Tensile Stress Area | Clamp Load | Torque (Dry or Loctite® 263™) K=0.17 | Torque (Loctite® 262 TM OR Vibra-TITE TM 131) K=0.16 | Torque (Lottite® 242 TM or 271 TM OR Vibra- TITE TM 111 or 140) | Clamp Load | Torque (Dry or Loctite® 263™) K = 0.17 | Torque (Lub OR Loctite® 242 TM or 271 TM OR Vibra-TITE TM 111 or 140) | Torque (Loctite® 262 TM OR Vibra-TITE TM 131) K=0.15 |
| | | Sq mm | NY | [m:N] | [N.m] | [N.m] | NY | [m·N] | [N.m] | [N.m] |
| 3 | 0.5 | 5.03 | 2.19 | 1.1 | 1.1 | 1.0 | 3.13 | | | |
| 3.5 | 0.6 | 6.78 | 2.95 | 1.8 | 1.7 | 1.5 | 4.22 | | | |
| 4 | 0.7 | 8.78 | 3.82 | 2.6 | 2.4 | 2.3 | 5.47 | | | |
| 5 | 0.8 | 14.20 | 6.18 | 5.3 | 4.9 | 4.6 | 8.85 | | | |
| 6 | 1 | 20.10 | 8.74 | 6 | 8.4 | 7.9 | 12.5 | 13 | 12 | 11 |
| 7 | 1 | 28.90 | 12.6 | 15 | 14 | 13 | 18.0 | 21 | 20 | 19 |
| 8 | 1.25 | 36.60 | 15.9 | 22 | 20 | 19 | 22.8 | 31 | 29 | 27 |
| 10 | 1.5 | 58.00 | 25.2 | 43 | 40 | 38 | 36.1 | 61 | 58 | 55 |
| 12 | 1.75 | 84.30 | 36.7 | 75 | 70 | 99 | 52.5 | 105 | 100 | 95 |
| 14 | 2 | 115 | 50.0 | 119 | 110 | 105 | 71.6 | 170 | 160 | 150 |
| 16 | 2 | 157 | 68.3 | 186 | 175 | 165 | 97.8 | 265 | 250 | 235 |
| 18 | 2.5 | 192 | 83.5 | 256 | 240 | 225 | 119.5 | 365 | 345 | 325 |
| 20 | 2.5 | 245 | 106.5 | 362 | 340 | 320 | 152.5 | 520 | 490 | 460 |
| 22 | 2.5 | 303 | 132.0 | 494 | 465 | 435 | 189.0 | 705 | 665 | 625 |
| 24 | 3 | 353 | 153.5 | 627 | 590 | 555 | 222.0 | 905 | 850 | 800 |
| 27 | 3 | 459 | 199.5 | 916 | 860 | 810 | 286.0 | 1315 | 1235 | 1160 |
| 30 | 3.5 | 561 | 244.0 | 1245 | 1170 | 1100 | 349.5 | 1780 | 1680 | 1575 |
| 33 | 3.5 | 694 | 302.0 | 1694 | 1595 | 1495 | 432.5 | 2425 | 2285 | 2140 |
| 36 | 4 | 817 | 355.5 | 2176 | 2050 | 1920 | 509.0 | 3115 | 2930 | 2750 |
| 42 | 4.5 | 1120 | 487.0 | 3477 | 3275 | 3070 | 698.0 | 4985 | 4690 | 4395 |
| | | | | | | | | | | |

Figure 1-9. Torque Chart (METRIC Fasteners) - Sheet 5 of 5

1-19 3121139

ES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
43. ASSEMBLY USES HARDENED WASHER OR FASTENER IS PLACED AGAINST PLATED STEEL OR RAW ALUMINUM
4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIF

| NOTES: | |
|--------|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

1-20 3121139

SECTION 2. GENERAL

2.1 MACHINE PREPARATION, INSPECTION, AND MAINTENANCE

General

This section provides the necessary information needed by those personnel that are responsible to place the machine in operation readiness and maintain its safe operating condition. For maximum service life and safe operation, ensure that all the necessary inspections and maintenance have been completed before placing the machine into service.

Preparation, Inspection, and Maintenance

It is important to establish and conform to a comprehensive inspection and preventive maintenance program. The following table outlines the periodic machine inspections and maintenance recommended by JLG Industries, Inc. Consult your national, regional, or local regulations for further requirements for aerial work platforms. The frequency of inspections and maintenance must be increased as environment, severity and frequency of usage requires.

Pre-Start Inspection

It is the User's or Operator's primary responsibility to perform a Pre-Start Inspection of the machine prior to use daily or at each change of operator. Reference the Operator's and Safety Manual for completion procedures for the Pre-Start Inspection. The Operator and Safety Manual must be read in its entirety and understood prior to performing the Pre-Start Inspection.

Pre-Delivery Inspection and Frequent Inspection

The Pre-Delivery Inspection and Frequent Inspection shall be performed by a qualified JLG equipment mechanic. JLG Industries, Inc. recognizes a qualified JLG equipment mechanic as a person who, by possession of a recognized degree, certificate, extensive knowledge, training, or experience, has successfully demonstrated the ability and proficiency to service, repair, and maintain the subject JLG product model.

The Pre-Delivery Inspection and Frequent Inspection procedures are performed in the same manner, but at different times. The Pre-Delivery Inspection shall be performed prior to each sale, lease, or rental delivery. The Frequent Inspection shall be accomplished for each machine in service for 3 months or 150 hours (whichever comes first); out of service for a period of more than 3 months; or when purchased used. The frequency of this inspection must be increased as environment, severity and frequency of usage requires.

Reference the JLG Pre-Delivery and Frequent Inspection Form and the Inspection and Preventative Maintenance Schedule for items requiring inspection during the performance of these inspections. Reference the appropriate areas of this manual for servicing and maintenance procedures.

Annual Machine Inspection

The Annual Machine Inspection must be performed on an annual basis, no later than thirteen (13) months from the date of the prior Annual Machine Inspection. JLG Industries recommends this task be performed by a Factory Trained Service Technician. JLG Industries, Inc. recognizes a Factory-Trained Service Technician as a person who has successfully completed the JLG Service Training School for the subject JLG product model. Reference the machine Service and Maintenance Manual and appropriate JLG inspection form for performance of this inspection.

Reference the JLG Annual Machine Inspection Form and the Inspection and Preventative Maintenance Schedule for items requiring inspection during the performance of this inspection. Reference the appropriate areas of this manual for servicing and maintenance procedures.

For the purpose of receiving safety-related bulletins, it is important that JLG Industries, Inc. has updated ownership information for each machine. When performing each Annual Machine Inspection, notify JLG Industries, Inc. of the current machine ownership.

Preventative Maintenance

In conjunction with the specified inspections, maintenance shall be performed by a qualified JLG equipment mechanic. JLG Industries, Inc. recognizes a qualified JLG equipment mechanic as a person who, by possession of a recognized degree, certificate, extensive knowledge, training, or experience, has successfully demonstrated the ability and proficiency to service, repair, and maintain the subject JLG product model.

Reference the Preventative Maintenance Schedule and the appropriate areas of this manual for servicing and maintenance procedures. The frequency of service and maintenance must be increased as environment, severity and frequency of usage requires.

3121139 2-1

| Table 2-1. Ins | pection and Maintenan | ce |
|----------------|-----------------------|----|
| | | |

| Туре | Frequency | Primary Responsibility | Service Qualification | Reference |
|--------------------------------|---|---------------------------|--|--|
| Pre-Start Inspection | Prior to use each day; or At each Operator change. | User or Operator | User or Operator | Operation and Safety Manual |
| Pre-Delivery Inspection | Prior to each sale, lease, or rental delivery. | Owner, Dealer, or User | Qualified JLG Mechanic | Service and Maintenance Manual and applicable JLG inspection form. |
| Frequent Inspection | In service for 3 months or 150 hours, whichever comes first; or Out of service for a period of more than 3 months; or purchased used. | Owner, Dealer, or User | Qualified JLG Mechanic | Service and Maintenance Manual and applicable JLG inspection form. |
| Annual Machine Inspec- tion | Annually, no later than 13 months from the date of the prior inspection. | Owner, Dealer, or User | Factory Trained Service Technician (Recommended) | Service and Maintenance Manual and applicable JLG inspection form. |
| Preventative Maintenance | At intervals as specified in the Service and Mainte- nance Manual. | Owner, Dealer, or User | Qualified JLG Mechanic | Service and Maintenance Manual |

2.2 SERVICE AND GUIDELINES

General

The following information is provided to assist you in the use and application of servicing and maintenance procedures contained in this book.

Safety and Workmanship

Your safety, and that of others, is the first consideration when engaging in the maintenance of equipment. Always be conscious of weight. Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. When raising a portion of the equipment, ensure that adequate support is provided.

Cleanliness

1. The most important single item in preserving the long service life of a machine is to keep dirt and foreign materials out of the vital components. Precautions have been taken to safeguard against this. Shields, covers, seals, and filters are provided to keep air, fuel, and oil supplies clean; however, these items must be maintained on a scheduled basis in order to function properly.

- 2. At any time when air, fuel, or oil lines are disconnected, clear adjacent areas as well as the openings and fittings themselves. As soon as a line or component is disconnected, cap or cover all openings to prevent entry of foreign matter.
- 3. Clean and inspect all parts during servicing or maintenance, and assure that all passages and openings are unobstructed. Cover all parts to keep them clean. Be sure all parts are clean before they are installed. New parts should remain in their containers until they are ready to be used.

Components Removal and Installation

- Use adjustable lifting devices, whenever possible, if mechanical assistance is required. All slings (chains, cables, etc.) should be parallel to each other and as near perpendicular as possible to top of part being lifted.
- 2. Should it be necessary to remove a component on an angle, keep in mind that the capacity of an eyebolt or similar bracket lessens, as the angle between the supporting structure and the component becomes less than 90 degrees.
- If a part resists removal, check to see whether all nuts, bolts, cables, brackets, wiring, etc., have been removed and that no adjacent parts are interfering.

2-2 3121139

Component Disassembly and Reassembly

When disassembling or reassembling a component, complete the procedural steps in sequence. Do not partially disassemble or assemble one part, then start on another. Always recheck your work to assure that nothing has been overlooked. Do not make any adjustments, other than those recommended, without obtaining proper approval.

Pressure-Fit Parts

When assembling pressure-fit parts, use a molybdenum disulfide base compound or equivalent to lubricate the mating surface.

Bearings

- When a bearing is removed, cover it to keep out dirt and abrasives. Clean bearings in nonflammable cleaning solvent and allow to drip dry. Compressed air can be used but do not spin the bearing.
- Discard bearings if the races and balls (or rollers) are pitted, scored, or burned.
- If bearing is found to be serviceable, apply a light coat of oil and wrap it in clean (waxed) paper. Do not unwrap reusable or new bearings until they are ready to install.
- **4.** Lubricate new or used serviceable bearings before installation. When pressing a bearing into a retainer or bore, apply pressure to the outer race. If the bearing is to be installed on a shaft, apply pressure to the inner race.

Gaskets

Check that holes in gaskets align with openings in the mating parts. If it becomes necessary to hand-fabricate a gasket, use gasket material or stock of equivalent material and thickness. Be sure to cut holes in the right location, as blank gaskets can cause serious system damage.

Bolt Usage and Torque Application

NOTICE

SELF LOCKING FASTENERS, SUCH AS NYLON INSERT AND THREAD DEFORMING LOCKNUTS, ARE NOT INTENDED TO BE REINSTALLED AFTER REMOVAL.

- Always use new replacement hardware when installing locking fasteners. Use bolts of proper length. A bolt which is too long will bottom before the head is tight against its related part. If a bolt is too short, there will not be enough thread area to engage and hold the part properly. When replacing bolts, use only those having the same specifications of the original, or one which is equivalent.
- 2. Unless specific torque requirements are given within the text, standard torque values should be used on heat-treated bolts, studs, and steel nuts, in accordance with recommended shop practices. (See Torque Chart Section 1.)

Hydraulic Lines and Electrical Wiring

Clearly mark or tag hydraulic lines and electrical wiring, as well as their receptacles, when disconnecting or removing them from the unit. This will assure that they are correctly reinstalled.

Hydraulic System

- Keep the system clean. If evidence of metal or rubber particles are found in the hydraulic system, drain and flush the entire system.
- Disassemble and reassemble parts on clean work surface. Clean all metal parts with non-flammable cleaning solvent. Lubricate components, as required, to aid assembly.

3121139 2-3

Lubrication

Service applicable components with the amount, type, and grade of lubricant recommended in this manual, at the specified intervals. When recommended lubricants are not available, consult your local supplier for an equivalent that meets or exceeds the specifications listed.

Battery

Clean battery using a non-metallic brush and a solution of baking soda and water. Rinse with clean water. After cleaning, thoroughly dry battery and coat terminals with an anti corrosion compound.

Lubrication and Servicing

Components and assemblies requiring lubrication and servicing are shown in the Lubrication Chart in Section 1.

2.3 LUBRICATION AND INFORMATION

Hydraulic System

- 1. The primary enemy of a hydraulic system is contamination. Contaminants enter the system by various means, e.g., using inadequate hydraulic oil, allowing moisture, grease, filings, sealing components, sand, etc., to enter when performing maintenance, or by permitting the pump to cavitate due to insufficient system warm-up or leaks in the pump supply (suction) lines.
- 2. The design and manufacturing tolerances of the component working parts are very close, therefore, even the smallest amount of dirt or foreign matter entering a system can cause wear or damage to the components and generally results in faulty operation. Every precaution must be taken to keep hydraulic oil clean, including reserve oil in storage. Hydraulic system filters should be checked, cleaned, and/or replaced as necessary, at the specified intervals required in the Lubrication Chart in Section 1. Always examine filters for evidence of metal particles.
- Cloudy oils indicate a high moisture content which permits organic growth, resulting in oxidation or corrosion. If this condition occurs, the system must be drained, flushed, and refilled with clean oil.
- 4. It is not advisable to mix oils of different brands or types, as they may not contain the same required additives or be of comparable viscosities. Good grade mineral oils, with viscosities suited to the ambient temperatures in which the machine is operating, are recommended for use.

NOTE: Metal particles may appear in the oil or filters of new machines due to the wear-in of meshing components.

Hydraulic Oil

Refer to Section 1 for recommendations for viscosity ranges.

Changing Hydraulic Oil

- Filter elements must be changed after the first 50 hours of operation and every 300 hours (unless specified otherwise) thereafter. If it is necessary to change the oil, use only those oils meeting or exceeding the specifications appearing in this manual. If unable to obtain the same type of oil supplied with the machine, consult local supplier for assistance in selecting the proper equivalent. Avoid mixing petroleum and synthetic base oils.
- 2. Use every precaution to keep the hydraulic oil clean. If the oil must be poured from the original container into another, be sure to clean all possible contaminants from the service container. Always clean the mesh element of the filter and replace the cartridge any time the system oil is changed.
- 3. While the unit is shut down, a good preventive maintenance measure is to make a thorough inspection of all hydraulic components, lines, fittings, etc., as well as a functional check of each system, before placing the machine back in service.

Lubrication Specifications

Specified lubricants, as recommended by the component manufacturers, are always the best choice, however, multi-purpose greases usually have the qualities which meet a variety of single purpose grease requirements. Should any question arise, regarding the use of greases in maintenance stock, consult your local supplier for evaluation. Refer to Section 1 for an explanation of the lubricant key designations appearing in the Lubrication Chart.

2-4 3121139

2.4 CYLINDER DRIFT

Theory

When a hydraulic cylinder is supporting a load, cylinder drift may occur as a result of any of the circumstances below:

- Normal leakage of load holding valves or malfunction of load holding valves. See Cylinder Leakage Test and Table 2-2, Cylinder Drift below for evaluation.
- · Damaged or worn piston seal.
- Normal thermal expansion and contraction of the hydraulic oil within cylinders (See Cylinder Thermal Drift below).

The first two circumstances may result in cylinder movement due to oil leakage out of the cylinder externally or by leaking back to tank or due to oil leaking internally from one cylinder chamber to the other.

Thermal expansion or contraction of oil in hydraulic cylinders is a normal occurrence and does not result in oil leaking out of the cylinder or leaking internally from one cylinder chamber to the other. Thermal expansion or contraction is the tendency for materials to change size in response to a change in temperature.

Cylinder Leakage Test

Cylinder oil must be at stabilized ambient temperature before beginning this test.

Measure drift at cylinder rod with a calibrated dial indicator.

In an area free of obstructions, cylinder must have load applied and appropriately positioned to detect drift.

Cylinder leakage is acceptable if it passes this test.

Table 2-2. Cylinder Drift

| Cylinder Bo | re Diameter | Max. Accep in 10 N | table Drift linutes |
|-------------|-------------|-----------------------|------------------------|
| inches | mm | inches | mm |
| 3 | 76.2 | 0.026 | 0.66 |
| 3.5 | 89 | 0.019 | 0.48 |
| 4 | 101.6 | 0.015 | 0.38 |
| 5 | 127 | 0.009 | 0.22 |
| 6 | 152.4 | 0.006 | 0.15 |
| 7 | 177.8 | 0.005 | 0.13 |
| 8 | 203.2 | 0.004 | 0.10 |
| 9 | 228.6 | 0.003 | 0.08 |

NOTE: This information is based on 6 drops per minute cylinder leakage.

Cylinder Thermal Drift

The oil in all hydraulic cylinders will expand or contract due to thermal effects over time and may result in changes to the boom and/or platform position while the machine is stationary. These effects occur as the cylinder oil changes temperature, usually from a higher oil temperature as it cools and approaches the ambient air temperature. Results of these effects are related to several factors including cylinder length and change in temperature over the time the cylinder remains stationary.

3121139 2-5

2.5 PINS AND COMPOSITE BEARING REPAIR GUIDELINES

Filament wound bearings.

- Pinned joints should be disassembled and inspected if the following occurs:
 - a. Excessive sloppiness in joints.
 - **b.** Noise originating from the joint during operation.
- 2. Filament wound bearings should be replaced if any of the following is observed:
 - **a.** Frayed or separated fibers on the liner surface.
 - b. Cracked or damaged liner backing.
 - c. Bearings that have moved or spun in their housing.
 - d. Debris embedded in liner surface.
- 3. Pins should be replaced if any of the following is observed (pin should be properly cleaned prior to inspection):
 - **a.** Detectable wear in the bearing area.
 - b. Flaking, pealing, scoring, or scratches on the pin surface.
 - **c.** Rusting of the pin in the bearing area.
- Re-assembly of pinned joints using filament wound bearings.
 - a. Housing should be blown out to remove all dirt and debris. Bearings and bearing housings must be free of all contamination.
 - **b.** Bearing / pins should be cleaned with a solvent to remove all grease and oil. Filament wound bearing are a dry joint and should not be lubricated.
 - c. Pins should be inspected to ensure it is free of burrs, nicks, and scratches which would damage the bearing during installation and operation.

2.6 WELDING ON JLG EQUIPMENT

NOTE: This instruction applies to repairs, or modifications to the machine and to welding performed from the machine on an external structure, or component,

Do the Following When Welding on JLG Equipment

- · Disconnect the battery.
- Disconnect the moment pin connection (where fitted).
- · Ground only to structure being welded.

Do NOT Do the Following When Welding on JLG Equipment

- Ground on frame and weld on any other area than the chassis.
- Ground on turntable and weld on any other area than the turntable.
- Ground on the platform/support and weld on any other area than the platform/support.
- Ground on a specific boom section and weld on any other area than that specific boom section.
- Allow pins, wear pads, wire ropes, bearings, gearing, seals, valves, electrical wiring, or hoses to be between the grounding position and the welded area.

NOTICE

FAILURE TO COMPLY WITH THE ABOVE REQUIREMENTS MAY RESULT IN COMPONENT DAMAGE (I.E. ELECTRONIC MODULES, SWING BEARING, COLLECTOR RING, BOOM WIRE ROPES ETC.)

2-6 3121139

Table 2-3. Inspection and Preventive Maintenance Schedule

| | | INTERVAL | |
|---|---|---|------------------|
| AREA | Pre-Delivery ¹ or Frequent ² Inspection | Annual ³ (Yearly) Inspection | Every 2 Years |
| Boom Assembly | | | |
| Boom Weldments | 1,2,4 | 1,2,4 | |
| Hose/Cable Carrier Installations | 1,2,9,12 | 1,2,9,12 | |
| Pivot Pins and Pin Retainers | 1,2 | 1,2 | |
| Sheaves, Sheave Pins | 1,2 | 1,2 | |
| Bearings | 1,2 | 1,2 | |
| Wear Pads | 1,2 | 1,2 | |
| Covers or Shields | 1,2 | 1,2 | |
| Extend/Retract Chain or Cable Systems | 1,2,3 | 1,2,3 | |
| Boom Assembly | 1,2,3,4,5 | 1,2,3,4,5,7,9,14 | |
| Platform Assembly | | | |
| Platform | | 1,2 | |
| Railing | 1 | 1,2 | |
| Gate | 1,5 | 1,5 | |
| Floor | 1 | 1,2 | |
| Rotator | 5,9,15 | 5,9,15 | |
| Lanyard Anchorage Point | 1,2,10 | 1,2,10 | |
| Turntable Assembly | | | |
| Swing Bearing | 1,2,14 | 1,2,3,13,14 | |
| Oil Coupling | 9 | 9 | |
| Swing Drive System | 11 | 11 | |
| Turntable Lock | 1,2,5 | 1,2,5 | |
| Hood, Hood Props, Hood Latches | 5 | 1,2,5 | |
| Chassis Assembly | | | |
| Tires | 16,17,18 | 16,17,18 | |
| Wheel Nuts/Bolts | 15 | 15 | |
| Wheel Bearings | | | 14,24 |
| Oscillating Axle/Lockout Cylinder Systems | 5,8 | 5,8 | |
| Extendable Axle Systems | 5,8 | 5,8 | |
| SteerComponents | 1,2 | 1,2 | |
| Spindle Thrust Bearing/Washers | 1,2 | 1,2 | |
| Drive Hubs | 11 | 11 | |
| | 1 | | |

3121139 2-7

Table 2-3. Inspection and Preventive Maintenance Schedule

| | | INTERVAL | |
|--|---|---|------------------|
| AREA | Pre-Delivery ¹ or Frequent ² Inspection | Annual ³ (Yearly) Inspection | Every 2 Years |
| Functions/Controls | | | |
| Platform Controls | 5,6 | 6 | |
| Ground Controls | 5,6 | 6 | |
| Function Control Locks, Guards, or Detents | 1,5 | 5 | |
| Footswitch | 5 | 5 | |
| Emergency Stop Switches (Ground & Platform) | 5 | 5 | |
| Function Limit or Cutout Switch Systems | 5 | 5 | |
| Drive Brakes | 5 | 5 | |
| Swing Brakes | 5 | 5 | |
| Auxiliary Power | 5 | 5 | |
| Power System | | | |
| Engine Idle, Throttle, and RPM | 3 | 3 | |
| Engine Fluids (Oil, Coolant, Fuel) | 9,11 | 11 | |
| Air/Fuel Filter | 1,7 | 7 | |
| Exhaust System | 1,9 | 9 | |
| Batteries | 1,9 | 19 | |
| Battery Fluid | 11 | 11 | |
| Battery Charger | 5 | 5 | |
| Fuel Reservoir, Cap, and Breather | 1,2,5 | 1,5 | |
| Hydraulic/Electric System | | | |
| Hydraulic Pumps | 1,2,9 | 1,2,9 | |
| Hydraulic Cylinders | 1,2,7,9 | 1,2,9 | |
| Cylinder Attachment Pins and Pin Retainers | 1,2,9 | 1,2 | |
| Hydraulic Hoses, Lines, and Fittings | 1,2,9,12 | 1,2,9,12 | |
| Hydraulic Reservoir, Cap, and Breather | 1,2,5,9 | 1,5 | 24 |
| Hydraulic Filter | 1,7,9 | 7 | |
| HydraulicFluid | 7,11 | 7,11 | |
| Electrical Connections | 1,20 | 20 | |
| Instruments, Gauges, Switches, Lights, Horn | 1 | 5,23 | |
| General | | | |
| Operation and Safety Manuals in Storage Box | 21 | 21 | |
| ANSI and AEM Manuals/Handbooks Installed (ANSI Markets Only) | | 21 | |
| Capacity Decals Installed, Secure, Legible | 21 | 21 | |
| All Decals/Placards Installed, Secure, Legible | 21 | 21 | |

2-8 3121139

Table 2-3. Inspection and Preventive Maintenance Schedule

| | | INTERVAL | |
|---|---|---|------------------|
| AREA | Pre-Delivery ¹ or Frequent ² Inspection | Annual ³ (Yearly) Inspection | Every 2 Years |
| Annual Machine Inspection Due | | 21 | |
| No Unauthorized Modifications or Additions | 21 | 21 | |
| All Relevant Safety Publications Incorporated | 21 | 21 | |
| General Structural Condition and Welds | 2,4 | 2,4 | |
| All Fasteners, Pins, Shields, and Covers | 1,2 | 1,2 | |
| Grease and Lubricate to Specifications | 22 | 22 | |
| Function Test of All Systems | 21 | 21,22 | |
| Paint and Appearance | 7 | 7 | |
| Stamp Inspection Date on Frame | | 22 | |
| Notify JLG of Machine Ownership | | 22 | |

Footnotes:

Performance Codes:

- 1 Check for proper and secure installation
- 2 Visual inspection for damage, cracks, distortion or excessive wear
- 3 Check for proper adjustment
- 4 Check for cracked or broken welds
- 5 Operates Properly
- 6 Returns to neutral or "off" position when released
- 7 Clean and free of debris
- 8 Interlocks function properly
- $9-Check \, for \, signs \, of \, leakage \,$
- 10 Decals installed and legible
- 11 Check for proper fluid level
- 12 Check for chafing and proper routing
- 13 Check for proper tolerances
- 14-Properly lubricated
- 15 Torqued to proper specification
- 16 No gouges, excessive wear, or cords showing
- 17 Properly inflated and seated around rim
- 18-Proper and authorized components
- $19-Fully\,charged$
- 20 No loose connections, corrosion, or abrasions
- 21-Verify
- 22-Perform
- 23 Sealed Properly
- 24 Drain, Clean, Refill

3121139 2-9

¹Prior to each sale, lease, or delivery

 $^{^2}$ In service for 3 months or 150 Hours; or Out of service for 3 months or more; or Purchased used

 $^{^3}$ Annually, no later than 13 months from the date of the prior inspection





Figure 2-1. Engine Operating Temperature Specifications - Deutz


2-10 3121139




4150548 E

Figure 2-2. Engine Operating Temperature Specifications - Ford

3121139 2-11







4150548 E

Figure 2-3. Engine Operating Temperature Specifications - Caterpillar

2-12 3121139





4150548 E

Figure 2-4. Engine Operating Temperature Specifications - GM

3121139 2-13

| NOTES: | |
|--------|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | - |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

2-14 3121139

SECTION 3. CHASSIS & TURNTABLE

3.1 TIRES & WHEELS

Tire Inflation

The air pressure for pneumatic tires must be equal to the air pressure that is stenciled on the side of the JLG product or rim decal for safe and proper operational characteristics.

Tire Damage

For pneumatic tires, JLG Industries, Inc. recommends that when any cut, rip, or tear is discovered that exposes sidewall or tread area cords in the tire, measures must be taken to remove the JLG product from service immediately. Arrangements must be made for replacement of the tire or tire assembly.

For polyurethane foam filled tires, JLG Industries, Inc. recommends that when any of the following are discovered, measures must be taken to remove the JLG product from service immediately and arrangements must be made for replacement of the tire or tire assembly.

- A smooth, even cut through the cord plies which exceeds
 3 in. (7.5 cm) in total length.
- Any tears or rips (ragged edges) in the cord plies which exceeds 1 in. (2.5 cm) in any direction.
- Any punctures which exceed 1 in. in diameter.
- Any damage to the bead area cords of the tire.

If a tire is damaged but is within the above noted criteria, the tire must be inspected on a daily basis to ensure the damage has not propagated beyond the allowable criteria.

Tire Replacement

JLG recommends a replacement tire be the same size, ply and brand as originally installed on the machine. Please refer to the JLG Parts Manual for the part number of the approved tires for a particular machine model. If not using a JLG approved replacement tire, we recommend that replacement tires have the following characteristics:

- Equal or greater ply/load rating and size of original.
- Tire tread contact width equal or greater than original.
- Wheel diameter, width, and offset dimensions equal to the original.
- Approved for the application by the tire manufacturer (including inflation pressure and maximum tire load).

Unless specifically approved by JLG Industries Inc. do not replace a foam filled or ballast filled tire assembly with a pneumatic tire. When selecting and installing a replacement tire, ensure that all tires are inflated to the pressure recommended by JLG. Due to size variations between tire brands, both tires on the same axle should be the same.

Wheel Replacement

The rims installed on each product model have been designed for stability requirements which consist of track width, tire pressure, and load capacity. Size changes such as rim width, center piece location, larger or smaller diameter, etc., without written factory recommendations, may result in an unsafe condition regarding stability.

Wheel Installation

It is extremely important to apply and maintain proper wheel mounting torque.


M WARNING

WHEEL NUTS MUST BE INSTALLED AND MAINTAINED AT THE PROPER TORQUE TO PREVENT LOOSE WHEELS, BROKEN STUDS, AND POSSIBLE DANGEROUS SEPARATION OF WHEEL FROM THE AXLE. BE SURE TO USE ONLY THE NUTS MATCHED TO THE CONE ANGLE OF THE WHEEL.

Tighten the lug nuts to the proper torque to prevent wheels from coming loose. Use a torque wrench to tighten the fasteners. If you do not have a torque wrench, tighten the fasteners with a lug wrench, then immediately have a service garage or dealer tighten the lug nuts to the proper torque. Over-tightening will result in breaking the studs or permanently deforming the mounting stud holes in the wheels. The proper procedure for attaching wheels is as follows:

 Tighten all nuts by hand to prevent cross threading. DO NOT use a lubricant on threads or nuts.

2. Tighten nuts in the following sequence:



The tightening of the nuts should be done in stages. Following the recommended sequence, tighten nuts per wheel torque chart.

Table 3-1. Wheel Torque Chart

| | TORQUE SEQUENCE | |
|------------------------|--------------------------|--------------------------|
| 1st Stage | 2nd Stage | 3rd Stage |
| 70 ft. lbs. (95 Nm) | 170 ft. lbs. (225 Nm) | 300 ft. lbs. (405 Nm) |

4. Wheel nuts should be torqued after first 50 hours of operation and after each wheel removal. Check torque every 3 months or 150 hours of operation.

3.2 LOCKOUT CYLINDER BLEEDING


NOTICE

ENSURE PLATFORM IS FULLY LOWERED AND BOOM IS CENTERED OVER REAR AXLE PRIOR TO BEGINNING BLEEDING PROCEDURE.

NOTICE

ENSURE MACHINE IS ON A LEVEL SURFACE AND REAR WHEELS ARE BLOCKED, BRAKE WIRE IS DISCONNECTED.

- 1. Make sure machine is on a level surface.
- Center boom over rear axle to make sure the cam valve in the rotary coupling is depressed.
- 3. Place chocks under the tires to ensure the machine does not move. Disable the machine brakes by disconnecting the brake solenoid on the dual select valve.



- **4.** Use suitable containers to catch any excess hydraulic fluid. Place the containers under each lockout cylinder.
- **5.** Open one bleeder screws at a time.
- Start the engine, position drive control lever on the main hydraulic pump forward or reverse.
- 7. Close bleeder screws when all air is dissipated (bled).
- Reconnect the brake solenoid and remove the wheel chocks.
- 9. Perform oscillating axle lockout test.
- 10. If necessary, repeat steps 1 through 7.

3-2 3121139

This page left blank intentionally.




Figure 3-1. Axle and Steering Installation without Tow Package - Sheet 1 of 2 $\,$

3-4 3121139

| 1. | Axle Weldment | 9. | Pivot Pin | 17. | Tanged Washer | 25. | Washer |
|----|---------------------------|-----|-------------|-----|---------------|-----|------------|
| 2. | Lockout Cylinder Assembly | 10. | Washer | 18. | Bearing Nut | 26. | WearShim |
| 3. | Tie Rod | 11. | Bushing | 19. | Dust Cap | 27. | Stud |
| 4. | Spindle Weldment | 12. | Washer | 20. | Cup Bearing | 28. | Lugnut |
| 5. | Steer Cylinder Assembly | 13. | Bolt | 21. | Cone Bearing | 29. | Shim |
| 6. | Hub Assembly | 14. | Keeper Pin | 22. | Lip Seal | 30. | Stop Plate |
| 7. | Housing | 15. | Tie Rod Pin | 23. | King Pin | | |
| 8. | Spindle | 16. | Attach Pin | 24. | Bearing | | |

Figure 3-2. Axle and Steering Installation without Tow Package - Sheet 2 of 2




Figure 3-3. Axle and Steering Installation with Tow Package- Sheet 1 of 2

3-6 3121139

| 1. 2. 3. | Bolt Bolt Bolt | 17. | Axle Weldment Tie Rod Bolt | 32. | Hitch Pin Connecting link Keeper Shaft | 47. | Bearing Nut Bolt Hub Assembly |
|----------------|---------------------------|-----|----------------------------------|------------|--|-----|-------------------------------------|
| 3. 4. | Garmax Bushing | | Bolt | 33. 34. | | | Lugnut |
| 5. | Lockout Cylinder Assembly | | Garmax Bearing | | Spindle Weldment (RH) | | Flatwasher |
| 6. | Pin | 21. | Bearing | 36. | Special Washer | 51. | Spindle |
| 7. | Main Pivot Pin | 22. | Garmax Bearing | 37. | Thrustwasher | 52. | Housing |
| 8. | Pin | 23. | Garmax Bearing | 38. | Thrustwasher | 53. | Inner Bearing Cup |
| 9. | Axle Wear Shim | 24. | Steer Cylinder Assembly | 39. | Thrustwasher | 54. | Inner Bearing Cone |
| 10. | Keeper Shaft | 25. | Steer Spindle Attach Pin (RH) | 40. | Special Washer | 55. | Outer Bearing Cup |
| 11. | Keeper Shaft | 26. | Steer Spindle Attach Pin (LH) | 41. | Pivot Bar | 56. | Outer Bearing Cone |
| 12. | Axle Wear Shim | 27. | Tie Rod Pin | 42. | Bolt | 57. | Lip Seal |
| 13. | Axle Wear Shim | 28. | Kingpin | 43. | Screw | 58. | Stud |
| 14. | Flatwasher | 29. | Attach Pin | 44. | Stop pad Stop pad | 59. | Dust Cap |
| 15. | Special Washer | 30. | Pin | 45. | Shim | 60. | Special Washer |
| | | | | | | 61. | Tanged Washer |

Figure 3-4. Axle and Steering Installation with Tow Package - Sheet 2 of 2

3.3 OSCILLATING AXLE LOCKOUT TEST

NOTICE

LOCKOUT SYSTEM TEST MUST BE PERFORMED QUARTERLY, ANY TIME A SYSTEM COMPONENT IS REPLACED, OR WHEN IMPROPER SYSTEM OPERATION IS SUSPECTED.

NOTE: Ensure boom is fully retracted, lowered, and centered between drive wheels prior to beginning lockout cylinder test.


- 1. Place a 6 in. (15.2 cm) high block with ascension ramp in front of left front wheel.
- From platform control station, activate machine hydraulic system.
- Place FUNCTION SPEED CONTROL and DRIVE SPEED/ TORQUE SELECT control switches to their respective LOW positions.
- 4. Place DRIVE control lever to FORWARD position and carefully drive machine up ascension ramp until left front wheel is on top of block.
- Carefully activate SWING control lever and position boom over right side of machine.
- With boom over right side of machine, place DRIVE control lever to REVERSE and drive machine off of block and ramp.
- **7.** Have an assistant check to see that left front wheel remains locked in position off of ground.
- 8. Carefully activate SWING control lever and return boom to stowed position (centered between drive wheels). When boom reaches center, stowed position, lockout cylinders should release and allow wheel to rest on ground, it may be necessary activate DRIVE to release cylinders.
- **9.** Place the 6 in. (15.2 cm) high block with ascension ramp in front of right front wheel.
- **10.** Place DRIVE control lever to FORWARD and carefully drive machine up ascension ramp until right front wheel is on top of block.
- Carefully activate SWING control lever and position boom over left side of machine.
- With boom over left side of machine, place DRIVE control lever to REVERSE and drive machine off of block and ramp.
- Have an assistant check to see that right front wheel remains locked in position off of ground.
- 14. Carefully activate SWING control lever and return boom to stowed position (centered between drive wheels). When boom reaches center, stowed position, lockout cylinders should release and allow wheel to rest on ground, it may be necessary activate DRIVE to release cylinders.

15. If lockout cylinders do not function properly, have qualified personnel correct the malfunction prior to any further operation.

3.4 FREE WHEELING OPTION


To Disengage Drive Motors and Brakes (Free Wheel) for Emergency Towing

- 1. Chock wheels securely if not on flat level surface.
- 2. Disconnect both drive hubs by reversing the disconnect caps in the center of the hubs.
- **3.** If equipped, move steer/tow selector valve to float (tow) position by pulling control knob out.



To Engage Drive Motors and Brakes (Normal Operation)

- If equipped, move steer/tow valve to steer position by pushing valve knob in.
- Connect both drive hubs by inverting disconnect cap in center of hub.
- **3.** Remove chocks from wheels as required.



3-8 3121139

3.5 WHEEL DRIVE ASSEMBLY, 2WD (PRIOR TO SN 0300083331)

Removal

NOTE: The drive motor and/or drive brake can be removed through the axle flange as part of the wheel drive assembly or they can be removed separately through the bottom of the frame while leaving the drive hub bolted to the axle.

1. Use a jack to lift the frame enough so the tire and wheel assembly is off of the ground. Place blocking strong enough to support the weight of the machine under the frame and remove the jack.

NOTE: The pneumatic tire & wheel assembly weighs approximately 269 lbs. (122 kg). The foam-filled tire & wheel assembly weighs approximately 544 lbs. (247.25 kg).

2. Remove the tire and wheel assembly.

3. Through the access holes in the axle, tag and disconnect the hydraulic lines running to the drive motor and drive brake. Cap or plug all openings to ensure no dirt enters the hydraulic system.

NOTE: The drive hub, drive brake, and drive motor assembly weighs approximately 275 lbs. (125 kg).

- **4.** Use a supporting device capable of handling the weight of the drive hub, drive brake, and drive motor and unbolt the drive hub from the frame. Remove the entire assembly from the machine.
- **5.** Remove the nuts and washers that secure the drive motor to the drive hub and drive brake and remove the drive motor. Remove and discard the o-ring between the drive motor and drive brake.
- **6.** Remove the drive brake from the drive hub. Remove and discard the o-ring between the drive brake and drive hub.
- 7. If necessary, remove the studs from the drive hub.





Figure 3-5. Drive Hub Installation - 2WD (Prior to SN 0300083331)

Installation

- If re-installing the existing studs or installing new ones, coat the threads of the studs with JLG Threadlocker P/N 0100011 before screwing them into the drive hub.
- 2. Install a new o-ring between the drive brake and drive hub and slide the drive brake over the studs with the brake port positioned as shown.



- **3.** Install a new o-ring between the drive brake and drive motor and slide the drive motor over the studs. Install the washers and nuts to secure the assembly together and torque the nuts to 75 ft. lbs. (102 Nm).
- **4.** Place the drive hub flange against the mounting flange on the axle and fasten it in place with the bolts and washers. Torque the bolts to 220 ft. lbs. (298 Nm).
- 5. Install the tire and wheel assembly.

3-10 3121139

3.6 WHEEL DRIVE ASSEMBLY, 2WD & 4WD (SN 0300083331 THROUGH 0300182743, B300000100 THROUGH B300001091)

Removal

NOTE: The drive motor can be removed through the axle flange as part of the wheel drive assembly or they can be removed separately through the bottom of the frame while leaving the drive hub bolted to the axle.

1. Use a jack to lift the frame enough so the tire and wheel assembly is off of the ground. Place blocking strong enough to support the weight of the machine under the frame and remove the jack.

NOTE: The pneumatic tire & wheel assembly weighs approximately 269 lbs. (122 kg). The foam-filled tire & wheel assembly weighs approximately 544 lbs. (247.25 kg).

- 2. Remove the tire and wheel assembly.
- 3. Through the access holes in the axle, tag and disconnect the hydraulic lines running to the drive motor. Cap or plug all openings to ensure no dirt enters the hydraulic system.

NOTE: The drive hub and drive motor assembly weighs approximately 270 lbs. (122 kg).

- **4.** Use a supporting device capable of handling the weight of the drive hub and drive motor and unbolt the drive hub from the frame. Remove the entire assembly from the machine.
- Remove the bolts and washers that secure the drive motor to the drive hub and remove the drive motor. Remove and discard the o-ring between the drive motor and drive hub.

Installation

- 1. Install a new o-ring between the drive motor and drive hub. Install the bolts and washers to secure them together and torque to 110 ft. lbs. (149 Nm).
- 2. Place the drive hub flange against the mounting flange on the axle and fasten it in place with the bolts and washers. Torque the bolts to 220 ft. lbs. (298 Nm).
- 3. Install the tire and wheel assembly.




Figure 3-6. Drive Hub Installation - 2WD & 4WD (SN 0300083331 through 0300182743, B300000100 through B300001091)

3.7 WHEEL DRIVE ASSEMBLY, 4WD (PRIOR TO SN 0300083331)

Removal

NOTE: The drive motor can be removed through the axle flange as part of the wheel drive assembly or they can be removed separately through the bottom of the frame while leaving the drive hub bolted to the axle.

 Use a jack to lift the frame enough so the tire and wheel assembly is off of the ground. Place blocking strong enough to support the weight of the machine under the frame and remove the jack.

NOTE: The pneumatic tire & wheel assembly weighs approximately 269 lbs. (122 kg). The foam-filled tire & wheel assembly weighs approximately 544 lbs. (247.25 kg).

- 2. Remove the tire and wheel assembly.
- **3.** Through the access holes in the axle, tag and disconnect the hydraulic lines running to the drive motor. Cap or plug all openings to ensure no dirt enters the hydraulic system.

NOTE: The drive hub and drive motor assembly weighs approximately 270 lbs. (122 kg).

- **4.** Use a supporting device capable of handling the weight of the drive hub and drive motor and unbolt the drive hub from the frame. Remove the entire assembly from the machine.
- Remove the bolts and washers that secure the drive motor to the drive hub and remove the drive motor. Remove and discard the o-ring between the drive motor and drive hub.

Installation

- Install a new o-ring between the drive motor and drive hub. Install the bolts and washers to secure them together and torque to 110 ft. lbs. (149 Nm).
- 2. Place the drive hub flange against the mounting flange on the axle and fasten it in place with the bolts and washers. Torque the bolts to 220 ft. lbs. (298 Nm).
- 3. Install the tire and wheel assembly.




Figure 3-7. Drive Hub Installation - 4WD (Prior to SN 0300083331)

3-12 3121139

3.8 DRIVE HUB - 2WD (ALL MACHINES), 4WD (SN 0300083331 TO SN 0300182743, B300000100 THROUGH B300001091)

Disassembly

- Position hub over suitable container and remove drain plugs (10) from unit. Allow oil to completely drain, then replace drain plugs.
- 2. Remove eight bolts (41) and four shoulder bolts (42) securing cover assembly to hub (7). Remove cover assembly (23) and discard o-ring seal (22).
- Lift carrier assembly and top thrust washer and thrust bearing(39, 40) from hub. Thrust washer may stick inside cover.
- **4.** Pry ring gear (21) loose from hub and remove it. Remove o-ring seal (22) from hub counterbore and discard it.
- Remove input gear (37) and thrust spacer (36) from input shaft assembly and remove input shaft assembly from hub.
- **6.** Lift internal gear (12) and thrust washer and thrust bearing (39, 40) from hub. Thrust washer may stick to bottom of carrier.
- Remove retaining ring (9) from spindle (1) and discard; lift hub from spindle.

A CAUTION

EYE PROTECTION SHOULD BE WORN DURING RETAINING RING REMOVAL.

- 8. Remove inside bearing cone (6) and bearing shim (8).
- **9.** If necessary, pry seal (2) out of hub using screwdriver or pry bar. With seal removed, outside bearing cone (4) can be removed.
- **10.** If necessary, remove inner and outer bearing cones (3, 5) using a suitable slide hammer puller.

NOTICE

WHEN REBUILDING DRIVE HUB, REMOVE AND REPLACE ALL O-RINGS AND RETAINING RINGS.

Cleaning and Inspection

- Thoroughly clean all parts in an approved cleaning solvent.
- Inspect bearing cups and cones for damage, pitting, corrosion, or excessive wear. If necessary, replace bearings as a complete set ensuring that they remain covered until use.
- Inspect bearing mounting surfaces on spindle, hub, input shaft and carrier. Replace components as necessary.
- **4.** Inspect all geared components for chipped or broken teeth and for excessive or uneven wear patterns.
- 5. Inspect carrier for damage, especially in anti-roll pin and planet shaft hole areas.
- **6.** Inspect all planet shafts for scoring or other damage.
- **7.** Inspect all threaded components for damage including stretching, thread deformation, or twisting.
- **8.** Inspect seal mounting area in hub for burrs or sharp edges. Dress applicable surfaces or replace components as necessary.
- **9.** Inspect cover for cracks or other damage, and o-ring sealing area for burrs or sharp edges. Dress applicable surfaces or replace cover as necessary.

Repair

- 1. Cover Assembly:
 - **a.** Remove two bolts (25) securing disconnect cap (26) to cover (23) and remove cap.
 - **b.** Remove two bolts (25) securing cover cap (24) to cover and remove cap.
 - **c.** Remove disconnect rod (27) from cap and remove o-rings (28, 29) from cover cap. Discard o-rings.
 - **d.** If necessary, remove pipe plug (30) from cover.
 - **e.** Clean and inspect parts in accordance with Cleaning and Inspection procedures. Replace parts as necessary.
 - **f.** If removed, screw pipe plug into cover.
 - **g.** Slip o-ring (29) over cover cap and against face.
 - **h.** Place o-ring (28) into cover cap internal groove. Disconnect rod may be used to push o-ring into groove.
 - i. Place cover cap into cover with large hole located over pipe plug. Secure cover cap to cover with two bolts. Torque bolts to 70-80 in. lbs. (7.9-9.0 Nm).
 - j. Place disconnect cap over cover cap with nipple facing out and secure with two bolts. Torque bolts to 70-80 in. lbs. (7.9-9.0 Nm).


k. Turn cover over and push disconnect rod into cover cap. Rod will be held in place by friction from o-ring.

2. Carrier Assembly:

- **a.** Drive anti-roll pin (19) into planet shaft (17) using a suitable punch.
- b. Using a suitable press, press planet shaft from carrier (13). After planet shaft is removed, drive anti-roll pin from shaft.
- **c.** Remove cluster gear (18) and thrust washers (14) from carriers.
- Remove sixteen needle rollers (15) from cluster gear bore.
- **e.** Remove spacer (16) from cluster gear bore and remove second set of sixteen needle rollers (15).
- **f.** Repeat steps (a) through (e) for remaining two cluster gears.
- g. Clean and inspect all parts in accordance with Cleaning and Inspection procedures. Replace parts as necessary.
- Apply a coat of grease or petroleum jelly to cluster gear bore.



i. Place sixteen needle rollers into cluster gear bore.



j. Place spacer into opposite side of cluster gear and against needle rollers.



- k. Place second set of sixteen needle rollers into cluster gear.
- I. Apply grease or petroleum jelly to tang side of two thrust washers. Place thrust washers against bosses in carrier with washer tang fitting into slot in carrier outside diameter.



m. While keeping thrust washers in place, slide cluster gear into carrier with larger gear on side with small pin hole.



n. Line up cluster gear and thrust washers with hole in carrier and slide planet shaft through. Ensure cham-

3-14 3121139

fered side of hole in planet shaft is lined up with pin hole in carrier.



- **o.** Drive anti-roll pin flush into carrier hole, locking planet shaft into place.
- 3. Input Shaft Assembly:

A CAUTION

EYE PROTECTION SHOULD BE WORN DURING RETAINING RING REMOVAL AND INSTALLATION.

- **a.** Carefully remove retaining ring (33) from counterbore in the spindle (1) and discard retaining ring.
- **b.** Remove two spacers (31) and spring (32) from input shaft.
- c. Clean and inspect all parts in accordance with Cleaning and Inspection procedures. Replace parts as necessary.
- **d.** Place washer (31), spring (32), and washer (31), in that order, onto input shaft.



e. Install retaining ring into input shaft groove to secure spacers and spring to shaft.




Assembly

 Using a suitable press, press new bearing cups (3, 5), with large inside diameters facing out, into hub (7) counterbore.



2. Place bearing cone (4) into bearing cup (3) in small end of hub.



3. Press new seal (2) into hub counterbore with flat metal side facing in. Use a flat object to ensure that seal is pressed evenly and is flush with hub face.



4. Lower hub onto spindle (1) with large open end up.



5. Place bearing cone (6) over end of spindle and into bearing cup.



6. Place bearing shim (8) over end of spindle and against bearing cone.



▲ CAUTION

EYE PROTECTION SHOULD BE WORN DURING RETAINING RING INSTALLATION.


7. Install new retaining ring (9) completely into spindle groove and against bearing shim. Ensure retaining ring is entirely in groove.



8. Place internal gear (12) onto end of spindle.




Install thrust washers and thrust bearing (39, 40) on the portion of the spindle which extends into the internal gear.



3-16 3121139

10. Install retaining ring (34) into input shaft retaining ring groove.



11. Place input shaft assembly (35) into spindle bore with unsplined end facing out.




12. Place thrust spacer (36) over input shaft (35) with counterbore side facing spindle.




13. Locate the four counter reamed holes in the face of the hub, mark them for later identification.



14. Place o-ring (22) into hub counterbore. Use petroleum or grease to hold o-ring in place. Slight stretching of o-ring may be necessary to insure proper seating.



15. Place carrier assembly on a flat surface with large gears up and positioned as shown. Find punch marked tooth on each large gear and locate at 12 o'clock (straight up) from each planet pin. Marked tooth will be located just under carrier on upper two gears.



16. With shoulder side of ring gear (21) facing down, place ring gear over (into mesh with) large gears. Ensure punch marks remain in correct location during ring gear installation.



17. While holding ring gear, input gear, and cluster gears in mesh, place small side of cluster gears into mesh with

internal gear. On ring gear, locate hole marked 'X' over one of counterbore holes in hub.



NOTE: If gears do not mesh easily or carrier assembly does not rotate freely, then remove carrier and ring gear and check cluster gear timing.

18. Install input gear (37) into carrier, meshing with large diameter cluster gears (18). Counterbore in bore of input gear must be to outside of carrier assembly.



19. After inserting at least one shoulder bolt in the proper location, rotate the carrier. Check freedom of rotation and timing.



20. Install thrust washers and thrust bearing (39, 40) into carrier counterbore.



21. Place o-ring (22) into cover assembly counterbore. Use petroleum jelly or grease to hold o-ring in place.



22. Place cover assembly over ring gear with oil level check plug in cover located approximately 90 degrees from oil fill plug in hub.

3-18 3*121139*


23. Locate four shoulder bolts (42), 90 degrees apart into counterbore holes in hub marked in step (13). Torque shoulder bolts to 47 ft. lbs. (64 Nm).



24. Install bolts (41) in remaining holes. Torque bolts to 47 ft. lbs. (64 Nm).



25. Place coupling (1) into spindle and onto input shaft.



26. Fill hub one-half full of EPGL 90 lubricant before operation.




Figure 3-8. Drive Hub - 2WD (All Machines), 4WD (SN 0300083331 through SN 0300182743, B300000100 through B300001091)

3-20 3121139

3.9 DRIVE BRAKE, 2WD - MICO (PRIOR TO SN 0300083331)

Disassembly

1. Remove pressure plate (3) from cover plate (16) by removing capscrews (1) and washers (2).

▲ CAUTION

PRESSURE PLATE IS UNDER SPRING TENSION OF APPROXIMATELY 2000 LBS (907 KGF). THE TWO CAPSCREWS MUST BE LOOSENED EVENLY TO RELIEVE THIS FORCE. IF A HYDRAULIC PRESS IS AVAILABLE, 3000 LBS (1361 KGF) MINIMUM, THE PRESSURE PLATE CAN BE HELD IN POSITION WHILE REMOVING THE CAPSCREWS. COVER PLATE (16) MUST BE SUPPORTED AS SHOWN IN FIGURE 3-9.

- 2. Remove case seal (4) from cover plate (16).
- **3.** Remove piston (7) from pressure plate (3).
- **4.** Remove o-ring (5), backup ring (6), o-ring (8) and backup ring (9) from piston (7).
- **5.** Remove stator disc (11), rotor disc (12) and return plate (13) from cover (16).
- Remove dowel pins (15) and springs (14) from cover plate (16). Record this information for assembly purposes.
- **NOTE:** Not all models use the same number of springs or spring pattern. Record this information for assembly purposes.
 - **7.** Remove retaining ring (19) from cover plate (16).
 - **8.** Remove shaft (10) by pressing or using a soft mallet on male end of shaft (10).
- **NOTE:** Cover plate (16) must be supported as shown in Figure 3-9.
 - **9.** Remove retaining ring (20) from cover plate (16) and press out oil seal (17) and bearing (18) if required.
- **NOTE:** Cover plate (16) must be supported as indicated in Figure 3-9.

Assembly

NOTICE

LUBRICATE ALL RUBBER COMPONENTS FROM REPAIR KIT WITH CLEAN TYPE FLUID USED IN THE SYSTEM.

- 1. Use an alkaline wash to clean parts before assembly.
- **2.** Press oil seal (17) into cover plate (16) until it is flush with bearing shoulder. Note direction of seal.
- **3.** Press bearing (18) into position until it bottoms out on borestep.


NOTE: Cover plate (16) must be supported as indicated in Figure 3-9.

- **4.** Install retaining ring (20) in cover plate (16).
- **5.** Press shaft (10) into bearing (18) until it bottoms on shoulder.

NOTE: Bearing (18) inner race and cover plate (16) must be supported as indicated in Figure 3-9. during this operation.

- **6.** Install retaining ring (19) on shaft (10).
- 7. Insert dowel pins (15) and springs (14) in cover plate (16).

NOTE: Be sure to use the same number of springs and spring pattern as recorded during disassembly.



NOTE: Start with the red springs and space them as evenly as possible throughout the spring retainer, then take the first blue spring and put it in any one of the remaining empty holes, second blue spring should be placed as directly across from the first blue spring as possible.

- **8.** Position return plate (13) on springs (14).
- **NOTE:** Discs (11 & 12) and return plate (13) must remain dry during installation. No oil residue must be allowed to contaminate disc surfaces.
 - 9. Install rotor disc (12) and stator disc (13).
 - **10.** Install o-ring (5), backup ring (6), o-ring (8) and backup ring (9) on piston (7). Note order of o-rings and backup rings. Insert piston (7) into pressure plate (3).
- **NOTE:** Be careful not to shear o-rings or backup rings. Be careful not to scratch or mar piston.
 - 11. Install new case seal (4) in cover plate (16).

- **12.** Position pressure plate (3) on cover plate (16) aligning dowel pins (15) with holes in pressure plate.
- **13.** Install capscrews (1) and washers (2) and tighten evenly to draw pressure plate (3) to cover plate (16). Torque capscrews 48-50 ft. lbs. (65.1-67.8 Nm).
- **NOTE:** A hydraulic press will simplify installation of pressure plate on cover. Clamp pressure plate in position while tightening the capscrews. Cover plate (16) must be supported as indicated in Figure 3-9.

▲ CAUTION

IF HYDROSTATIC BENCH TESTING IS PERFORMED ON THE BRAKE ASSEMBLY, RELEASE PRESSURE MUST NOT EXCEED 500 PSI (134.5 BAR).

3-22 3121139




Figure 3-9. Drive Brake, 2WD - Mico (Prior to SN 0300083331)

14. Springs

15. Dowel Pin

19. Retaining Ring

20. Retaining Ring

9. Backup Ring

10. Shaft

4.

Case Seal

5. 0-ring

Bleeding

- 1. Install brake in system and connect pressure lines.
- **2.** Bleed pressure release section of brake by pressurizing side inlet port and allowing air to escape from top port.
- Pressure should not exceed 6.9 bar (100 psi) during bleeding.
- **3.** Apply sufficient pressure to release brake and check for proper operation in system.

Table 3-2. Troubleshooting

| PROBLEM | CAUSE | EXPLANATION | ACTION | | |
|-------------------------|---|---|---|--|--|
| Brake slips | Excessive pressure in hydraulic system | If there is back pressure in the actuation line of the brake, holding torque will be reduced. Check filters, hose size, restrictions in hydraulic components. | | | |
| | Oil in brake if designed for dry use | Wet linings generate 67% of the dry torque rating. If the brake has oil in it, check the type of oil hydraulic or gearbox. 1. Gearbox oil 2. Hydraulic oil WOTE: Internal componeed to be cleaned and required. | | | |
| | Disc plates worn | The thickness of the disc stack sets the torque level. A thin stack reduces torque. | Check disc thickness. | | |
| | Springs broken or have taken a permanent set Broken or set springs can rare occurrence. | | Check release pressure. (See spring replacement). | | |
| Brake drags or runs hot | Low actuation pressure | The brake should be pressurized to minimum of 1.38 bar (20 psi) over the full release pressure under normal operating conditions. Lower pressures will cause the brake to drag thus generating heat. | Place pressure gauge in bleed port & check pressure with system on. | | |
| | Bearing failure | If the bearing should fail, a large amount of drag can be generated. | Replace bearing. | | |
| Brake will not release | Stuck or clogged valve | Brakes are designed to come on when system pressure drops below stated release pressure. If pressure cannot get to brake, the brake will not release. | Place pressure gauge in bleed port - check for adequate pressure. Replace in operative line or component. | | |
| | Bad o-rings | If release piston will not hold pressure, brake will not release. | Replace o-rings. | | |
| | Discs frozen | These brakes are designed for only limited dynamic braking. A severe emergency stop or prolonged reduced release pressure operation may result in this type of damage. | Replace disc stack. | | |

3-24 3121139

3.10 DRIVE BRAKE (SN 0300083331 TO SN 0300182743, B300000100 THROUGH B300001091)

Disassembly

1. Supporting brake:, remove the six socket head capscrews and washers (13 & 14) in equal increments to ensure the spring pressure within the brake is reduced gradually and evenly.

If a press is available, the cylinder housing (8) can be restrained while removing the six capscrews and washers (13 & 14).

The brake assembly can now be fully dismantled and the parts examined.

- Remove cylinder housing (8) and piston (9) subassembly and dismantle if required, removing o-ring seals (15 & 17) and backing rings (16 & 18) as necessary.
- 3. Remove gasket (7) from housing (2).
- **4.** Remove friction plates (3 & 6) and pressure plate (4).
- 5. Remove two dowel pins (19).
- **6.** Remove springs (22 & 23).
- **7.** Should it be necessary to replace ball bearing (10) or shaft seal (12), reverse remainder of brake subassembly, supporting on face C of housing (2).
- **8.** Remove internal retaining ring (11).
- **9.** Using arbor press or similar to break Loctite seal, remove brake shaft (1) from housing (2) and lay aside.
- **10.** Reverse housing (2) and press out ball bearing (10). Shaft seal (12) can also be removed if necessary.

Inspection

- **1.** Inspect friction plates (3 & 6) and friction surface on pressure plate (4) for wear or damage.
- 2. Examine friction plates (3) and brake shaft (1) for wear or damage to the splines.
- **3.** Examine input and output splines of brake shaft (1) for wear or damage.
- Examine compression springs (22 & 23) for damage or fatigue.
- **5.** Check ball bearing (10) for axial float or wear.
- **6.** Examine o-ring seals (15 & 17) and backing rings (16 & 18) for damage.

Assembly


- 1. Lightly lubricate rotary shaft seal (12) and assemble to housing (2) taking care not to damage seal lip.
- 2. Apply ring of Loctite 641 or equivalent adhesive to full circumference of housing (2) bearing recess adjacent to shoulder.

Apply complete coverage of Loctite 641 to outside diameter of bearing (10) and assemble fully In housing (2), retaining with internal retaining ring (11). Remove excess adhesive with a clean cloth.

Press shaft (1) through bearing (10), ensuring bearing inner ring Is adequately supported.

- **3.** Assemble correct quantity of springs (22 & 23) in orientation required.
- **4.** Lubricate o-ring seals (15 & 17) with Molykote 55M (or equivalent) silicon grease and assemble together with backing rings (16 & 18) to piston (9). To ensure correct brake operation. It is important that the backing rings are assembled opposite to the pressurized side of piston
- Correctly orientate piston (9) aligning spaces with the two dowel pin holes and, assemble into cylinder housing (8) taking care not to damage seals and carefully lay aside.
- **6.** Locate 2-off pins (19) in housing (2) followed by pressure plate (4) and friction plates i.e. an inner (3) followed by an outer (6) in correct sequence.
- **7.** Position gasket (7) in correct orientation.
- **8.** Align two holes in cylinder with dowel pins (19) and assemble piston & cylinder sub-assembly to remainder of brake securing with 6 capscrews and washers (13 & 14). Torque to 55 ft.lbs. (75 Nm).

NOTE: The use of a suitable press (hydraulic or arbor) pressing down on cylinder end face B will ease assembly of the capscrews (13).



- 1. Shaft 2. Housing
- 3. Friction Plate 4. Pressure Plate
- 5. Gasket
- - 7. Gasket

 - 8. Cylinder
- 9. Piston
 - 10. Ball Bearing
- 11. Retaining Ring

 - 12. Shaft Seal
 - 13. Capscrew 14. Lockwasher
 - 15. 0-ring
- 16. Backup Ring
- 17. 0-ring
- 18. Backup Ring 19. Dowel Pin
- 20. Plug
- 21. Plug
- 22. Spring (Natural)
- 23. Spring (Blue)


Figure 3-10. Drive Brake (SN 0300083331 to SN 0300182743, B300000100 through B300001091)

3-26 3121139


3.11 DRIVE MOTOR - 2WD (PRIOR TO SN 0300083331)

Spare Parts Kits

Sealing kit, existing spare parts: shaft sealing ring, 6 different o-rings and a circlip (sealing mat.: perbunan)




Same sealing kit like shown above only seal material changed to Viton




Drive shaft




Bearing set/miscellaneous parts




Rotary group complete 9 pistons, cylinder sub-assembly, valve plate (cw or ccw corresponding to the order) retaining plate and retaining ball.




Swashplate



Parts of the control device: control piston, piston rod, plug, spring stopper max flow, hex. nut, and hex. head nut



Spare parts kit DFR pilot valve






Figure 3-11. Drive Motor Cutaway

Replacing the Drive Shaft Seal

1. Remove snap ring.




2. Change the shaft seal and check its sliding surface (drive shaft) and housing. Grease the sealing ring.



3-28 3121139


3. Be careful while you seal the drive shaft, use an adhesive tape.



4. Assemble the sealing ring, fitting tool holds the correct position of the sealing ring in the pump housing.



5. Assemble the snap ring.



6. Assemble the snap ring in the correct position.




NOTE: This description shows how to change the drive shaft sealing ring but isn't the way of serial assembly. the sealing ring is assembled together with the taper roller bearing from inside the pump housing normally to get a secure condition. If you decide to repair the pump in the shown way be very careful while handling so that the drive shaft will not be damaged during disassembly of the shaft sealing ring.

Disassembly

1. Disassemble the pilot valve.



2. Mark the position of the port plate and remove the socket screw of the port plate.



3. Remove the port plate together with the valve plate (hold the valve plate so that the plate can't fall down).



4. Remove the o-ring.




5. Disassemble the taper roller bearing (near by port plate).




6. Remove the adjustment shim.



7. Unscrew the cap nut and remove it.




8. Loosen the fixing nut of the stopper max flow and disassemble it.



3-30 *3121139*


9. Turn in the stopper max flow to get swivel angle zero.



10. Disassemble the rotary group in horizontal position.



11. Disassemble the stopper - max flow.




12. Remove the threaded pin (stopper - max flow).




13. Disassemble the plug.




14. Disassemble the control plate while moving the swash-plate.




15. The swashplate must be lifted a little bit to disassemble the piston rod.




16. Disassemble the swashplate.



17. Remove the spring.



18. Remove both bearing shells.



19. Remove the drive shaft.



20. Disassemble the snap ring.



21. Disassemble the sealing ring.



22. The external front bearing ring is pulled out of the pump housing.




3-32 3121139


23. Remove the o-ring. Lifting of the valve plate isn't shown.



24. A usual commercial bearing puller is used to disassemble the external bearing ring of the taper roller bearing inside the port plate. Take care of the surface of the port plate.




25. The spring has additional pretension while you disassemble the three pressure pins inside the cylinder.




Assembly

- **1.** Assemble the variable displacement pump in reverse order.
- **2.** Measurement of the taper roller bearing pretension (see adjustment figure).



NOTE: There is a correct connection of the piston rod and swashplate.



3. Pumps clockwise driven must have a position of the valve plate 4° out of center in the same direction decentered like drive direction.

NOTE: Spare parts exist as clockwise and counter-clockwise valve plates.




4. Pumps anti-clockwise driven must have a position of the valve plate 4° decentered in counter-clockwise position.




5. Assembly of the port plate and pump housing:

NOTE: The correct position of the drilling that connects high pressure to the control valve. Check control valve drilling position at the pump housing and fit together.



Taper roller bearing initial tension





Cast iron pump housing must have initial tension of the bearings: 0......0,05 mm, grind Pos. 12 if necessary.


Figure 3-12. Bearing Tension


3-34 *3121139*

all valves shown here do have open position of the orifice (see picture below "pos. of orifice").










Adapter without orifice of the DFR-pilot valve , if you use a metric pilot pipe connection \boldsymbol{X} .

NOTE: Differential volume if you are rotating the threaded pin - each rotation is appr. $3,1 \text{ cm}^3$.

Figure 3-13. Flow Control Pilot Valves

Testing and Setup

DR: When pressure line is closed adjust the pressure of the controller (if it's DFR design then open the adjustable orifice and increase force of the spring - FR -).



FR: If swivel angle is in the mid position adjust differential pressure 14 bar adjustable orifice is partly closed).



Mechanical flow limiter: While screwing in the threaded pin you will be able to reduce the flow from Vg max to 50% of Vg max.



Drive Motor Adjustment Procedure

- 1. Remove the cap nut from adjustment screw.
- Loosen jam nut on the adjustment screw and make adjustment.
- **3.** Measure from top of jam nut to the end of adjustment screw. Refer to Figure 3-14., Drive Motor Adjustment.
- 4. Tighten jam nut, install cap nut.

NOTE: The o-ring must be seated in groove in cap nut.




Figure 3-14. Drive Motor Adjustment

3-36 3121139

3.12 DRIVE MOTOR

Description

The drive motors are low to medium power, two-position axial piston motors incorporating an integral servo piston. They are designed for operation in both open and closed circuit applications. The standard control is a direct acting single line hydraulic control. The integral servo piston controls motor displacement.

The motors are spring biased to maximum displacement and hydraulically shifted to minimum displacement. Minimum and maximum displacement can be set with fixed internal stops. The large diameter servo piston allows smooth acceleration and deceleration with relatively large circuit orificing.





Figure 3-15. Drive Motor Cross Section

Shaft Seal Replacement

REMOVAL

 Remove the snap ring (1) retaining the shaft seal and support washer.



- Snap Ring
- 2. Support Washer
- 3. Shaft Seal

Figure 3-16. Removing the Shaft Seal

- 2. Remove the support washer (2).
- 3. Carefully pry out the shaft seal (3).

NOTE: To avoid damaging the shaft during removal, install a large sheet metal screw into the chuck of a slide hammer. Drive the screw into the seal surface and use the slide hammer to pull the seal.

4. Discard the seal.

INSPECT THE COMPONENTS

Inspect the new seal, the motor housing seal bore, and the sealing area on the shaft for rust, wear, and contamination. Polish the shaft and clean the housing if necessary.


INSTALLATION

- Cover the shaft splines with an installation sleeve to protect the shaft seal during installation.
- **2.** Install a new shaft seal with the cupped side facing the motor. Press seal into housing until it bottoms out. Press evenly to avoid binding and damaging the seal.
- 3. Install seal support washer.
- 4. Install snap ring.
- 5. Remove the installation sleeve.

Loop Flushing Valve

REMOVAL

1. Using a 11/16 in. internal hex wrench remove plug (1) and (2).



- 1. Plug 2. Plug
- 0-ring 6.
- 7. Spring
 - 13. Orifice Poppet Spring

11. Washer

12. Shift Spool

- Plug 4. 0-ring
- Spring
- 5. 0-ring
- 10. Washer

Figure 3-17. Loop Flushing Spool

- Using a 1/4 in. hex wrench remove plug (3).
- Remove o-rings (4, 5, and 6). 3.
- Using pliers, remove centering springs (7, 8, and 9).
- Remove spring retaining washers (10 and 11). 5.
- Remove shift spool (12).
- **7.** Remove orifice poppet (13).

INSPECT THE COMPONENTS

Inspect new o-rings and the sealing area for rust, wear, or contamination. Also check springs and poppet for wear.

INSTALLATION

- 1. Install orifice poppet (13).
- Install shift spool (12).
- Install spring retaining washers onto springs (10 and 11). 3.
- Carefully install centering springs (7, 8, and 9).
- Install new o-rings (6, 4, and 5). 5.
- Using a 1/4 in. hex wrench torque plug (3) to 20 ft. lbs. (27 Nm).
- 7. Using a 11/16 in. internal hex, torque plugs (2 and 1) to 27 ft. lbs. (37 Nm).

3-38 3121139

Troubleshooting

Table 3-3. Excessive Noise and/or Vibration

| Item | Description | Action |
|---|---|--|
| Check oil level in reservoir and oil supply to the motor. | Insufficient hydraulic fluid could lead to cavitation that would cause system noise. | Fill the reservoir to the proper level and ensure that oil supply to the motor is adequate and the lines are unobstructed. |
| Check for air in the system. | Air trapped within the system lines, or the motor itself, could result in cavitation that would cause system noise. | Ensure that all of the system lines and components are purged of air. |
| Inspect the output shaft couplings. | A loose or incorrect shaft coupling will produce vibrations that could result in system noise. | Ensure that the correct coupling is used and that it fits properly onto the shaft. |
| Inspect the output shaft alignment. | Misaligned shafts create excessive frictional vibration that could result in system noise. | Ensure that the shafts are properly aligned. |
| Hydraulic oil viscosity above limits. | Viscosity above acceptable limits will result in cavitation that would lead to system noise. | Replace hydraulic oil with appropriate fluid for operating conditions. |

Table 3-4. System Operating Hot

| ltem | Description | Action |
|--|---|---|
| Check oil level in reservoir and oil supply to the pump. | Insufficient amount of hydraulic fluid will not meet the cooling demands of the system. | Fill the reservoir to the proper level. |
| Inspect the heat exchanger (if so equipped). | If the heat exchanger fails, or becomes obstructed, it may not meet the cooling demands of the system. | Ensure that heat exchanger is receiving adequate air flow and that the heat exchanger is in good operating condition. Repair or replace as necessary. |
| Check the system relief valves. | If a system relief valve becomes unseated for an extended period of time or fails for any other reason, the system could become overheated. | Repair or replace any malfunctioning relief valves as applicable and verify that the loads on the machine are not excessive. |

Table 3-5. Won't Shift or Slow to Start

| ltem | Description | Action |
|--|--|--|
| Check the signal line to the servo control port. | Obstructed or restricted flow through the servo control signal lines could result in slow shift or no shift conditions within the motor. | Ensure that the signal lines are not obstructed or restricted and that signal pressure is adequate to shift the motor. |
| Check that the correct supply and drain orifices are properly installed, and are not obstructed. | | Ensure that the proper control orifices are installed in the motor and verify that they are not obstructed. Clean or replace as necessary. |


Disassembly

NOTE: Removal of the end cap voids warranty.

During assembly, coat all moving parts with a film of clean hydraulic oil. This assures that these parts will be lubricated during start-up.

Replace all o-Rings and gaskets.

It is recommended that all o-rings be replaced. Lightly lubricate all o-rings with clean petroleum jelly prior to assembly.



1. Plug Plug

2.

3. Plug 0-ring

6. 0-ring

7.


- Spring
- 12. Shift Spool

13. Orifice Poppet

- 10. Washer
- 11. Washer Spring
- 4. 0-ring Spring

Figure 3-18. Loop Flushing Spool

- 1. Using a 11/16 in wrench remove plug (1) and (2).
- Using a 5/8 in hex wrench remove plug (3).
- Remove o-rings (4, 5, and 6).
- Using pliers, remove centering springs (7, 8, and 9).
- Remove spring retaining washers (10 and 11).
- Remove shift spool (12).
- Remove orifice poppet (13).




- 14. Lock Nut
- 15. O-ring Plug
- 16. Control Line Plug 17. Control Line Plug
- 18. Cavity Plug
- 19. Drain Plug
- 20. Drain Plug
- 21. Work Port Plug

Figure 3-19. Plugs, Fittings, and Speed Sensor

- 8. Remove all fittings from the unit. Discard any o-rings on the fittings.
- 9. Using an 11/16 in. hex wrench, loosen the speed sensor lock nut (14) if equipped. Then remove the speed sensor using a Vi in. hex wrench. Units without speed sensor have an o-ring plug (15) installed in that location. Remove it with a Va inch internal hex wrench.
- **10.** Using a 1/4 in. internal hex wrench, remove control line plugs (16, 17). Discard o-rings. Using a 3 mm hex wrench, remove cavity plug (18, if equipped with twoline control) from X2 cavity.
- 11. Using a 5/16 in. internal hex wrench, remove drain plugs (19, 20). Discard o-rings.
- 12. Using a 9/16 in. internal hex wrench, remove work port plugs (21, if equipped with axial ports). Discard o-rings.

3-40 3121139




- 22. Screw
- 23. End Cap
- 24. 0-ring

Figure 3-20. End Cap

- **13.** Using an 8 mm internal hex wrench, remove the end cap screws (22).
- **14.** Remove the end cap (23). Remove o-ring (24) from the housing or end cap.

When the end cap screws are removed, pressure from the servo spring will cause the end cap to bind on the shaft. Press down on the portion of the end cap covering the servo piston and hold the end cap level while removing.



- 25. Valve Plate
- 26. End Cap
- 27. 0-ring
- 28. 0-ring
- 29. Angle Stop
- 30. Servo Spring

Figure 3-21. Valve Plate & Rear Shaft Bearing



TAKE CARE NOT TO SCRATCH THE SURFACE OF THE VALVE PLATE.


15. Remove the valve plate (25) and timing pin (26) from the end cap.

Each displacement has a unique valve plate. For identification, the last two digits of the valve plate part number are stamped on its surface.

- 16. Remove and discard the o-rings (27, 28).
- **17.** Remove the rear shaft bearing (29) from the end cap with a bearing puller.

The bearing may be difficult to remove with a puller. Try this as an alternative: Pack the bearing cavity with heavy grease. After the shaft is removed, insert it into the bearing cavity and tap lightly with a soft mallet on the splined end. The grease will force the bearing out. Use caution not to drive the bearing past the rear shaft journal as the bearing may become trapped on the shaft and damaged.

18. Remove minimum angle stop (29) and servo spring (30) from the housing.



31. Cylinder Kit Assembly


Figure 3-22. Cylinder Kit

19. Turn the housing on its side and remove the cylinder kit assembly (31). Set the assembly aside, being careful not to scratch the running surface.

NOTE: Grooves on the surface of the cylinder kit identify its displacement:

Table 3-6. Displacement Identifiers

| # of Grooves | Frame L | Frame K |
|--------------|---------|---------|
| 1 | 25 | 38 |
| 2 | 30 | 45 |
| 3 | 35 | |




- 32. Snap Ring
- 33. Support Washer
- 34. Shaft Seal

Figure 3-23. Shaft Seal

20. Turn the housing over and remove the snap ring (32) retaining the shaft seal and support washer. Remove the support washer (33) and carefully pry out the shaft seal

(34). Discard the seal.

To avoid damaging the shaft during seal removal, install a large sheet metal screw into the chuck of a slide hammer. Drive the screw into the seal surface and use the slide hammer to pull the seal.




- 35. Inner Snap Ring
- 36. Snap Ring
- 37. Bearing
- 38. Shaft

Figure 3-24. Shaft & Front Bearing

- **21.** Remove the inner snap ring (35) and the shaft / bearing assembly.
- **22.** Remove the snap-ring (36) retaining the shaft front bearing. Pull the bearing (37) off of the shaft (38).


3-42 3121139



- 39. Swashplate
- 40. Servo Piston
- 41. Piston Seal
- 42. 0-ring
- 43. Journal Bearings

Figure 3-25. Swashplate & Servo Piston

- **23.** Turn housing over and remove the swashplate (39) by lifting on the end opposite the servo lever.
- **24.** Remove the servo piston (40). Remove the piston seal (41) and o-ring (42) from the servo piston. Discard the seal and o-ring.
- **25.** Remove the journal bearings (43) from the housing. If the bearings are to be reused, note the location and orientation of each bearing for reassembly.



- 44. Piston
- 45. Slipper Retainer
- 46. Cylinder Block
- 47. Ball Guide
- 48. Holddown Pins
- 49. Retaining Ring
- 50. Block Spring Washer
- 51. Spiral Retaining Ring
- 52. Block Spring
- 53. Inner Block Spring Washer

Figure 3-26. Cylinder Kit Disassembly

26. Remove pistons (44) and slipper retainer (45) from the cylinder block (46).

The pistons are not selectively fitted, however units with high hourly usage may develop wear patterns. Number the pistons and bores for reassembly if they are to be reused.

27. Remove the ball guide (47), hold-down pins (48), and retaining ring (49) from the cylinder block.

NOTE: Most repairs do not require block spring removal. Perform this procedure only if you suspect problems with the block spring.

▲ CAUTION

RISK OF PERSONAL INJURY: COMPRESSING THE BLOCK SPRING REQUIRES FORCE OF ABOUT 80 TO 90 LBF (350 TO 400 N). USE A PRESS SUFFICIENT TO MAINTAIN THIS FORCE WITH REASONABLE EFFORT. ENSURE THE SPRING IS SECURE BEFORE ATTEMPTING TO REMOVE THE SPIRAL RETAINING RING. RELEASE THE PRESSURE SLOWLY AFTER THE RETAINING RING IS REMOVED.


28. Turn the block over. Using a press, apply pressure on the block spring washer (50) to compress the block spring. Compress the spring enough to safely remove the spiral retaining ring (51). While maintaining pressure, unwind the spiral retaining ring (51). Carefully release the pressure and remove the outer block spring washer (50), block spring (52), and inner block spring washer (53) from the cylinder block.

Inspection

After disassembly, wash all parts (including the end-cap and housing) thoroughly with clean solvent and allow to air dry. Blow out oil passages in the housing and end cap with compressed air. Conduct inspection in a clean area and keep all parts free from contamination. Clean and dry parts again after any rework or resurfacing.

PISTON

Inspect the pistons for damage and discoloration. Discolored pistons may indicate excessive heat; do not reuse.



SLIPPERS

Inspect the running surface of the slippers. Replace any piston assemblies with scored or excessively rounded slipper edges. Measure the slipper foot thickness. Replace any piston assemblies with excessively worn slippers. Check the slipper axial end-play. Replace any piston assemblies with excessive end-play.

Minimum slipper foot thickness and maximum axial end-play are given in the table below.

Table 3-7. Slipper Foot Thickness & End Play


| Measurement | L Frame | K Frame | | |
|-------------------------|-------------|----------------------------|--|--|
| Slipper Foot Thickness | mm (in.) | 2.71 4.07 (0.11) (0.16) | | |
| Piston/Slipper End Play | | 0.15 (0.006) | | |

CYLINDER BLOCK

Measure the cylinder block height. Replace blocks worn beyond the minimum height specification. Inspect the running surface of the cylinder block. Replace or resurface worn or scratched blocks. Blocks may be resurfaced to the specifications shown in the drawing, provided resurfacing will not reduce the block height below the minimum specification. Table 3-8, Cylinder Block Measurements.

Table 3-8. Cylinder Block Measurements


| Measurement | L25 | L30 | L35 | K38 | K45 |
|-----------------------------------|----------------------|----------------------|----------------------|----------------------|----------------------|
| Minimum Cylinder Block Height (A) | 50.8 (2.00) | 50.8 (2.00) | 50.8 (2.00) | 54.4 (2.14) | 54.4 (2.14) |
| Cylinder Block Surface Flatness | 0.002 (0.0000079) | 0.002 (0.0000079) | 0.002 (0.0000079) | 0.002 (0.0000079) | 0.002 (0.0000079) |



3-44 3121139


BALL GUIDE AND SLIPPER RETAINER

Inspect the ball guide and slipper retainer for damage, discoloration, or excessive wear. A discolored ball guide or slipper retainer indicates excessive heat. Do not reuse.



VALVE PLATE


The condition of the valve plate is critical to the efficiency of the motor. Inspect the valve plate surfaces carefully for excessive wear, grooves, or scratches. Replace or resurface grooved or scratched valve plates. Measure the valve plate thickness and replace if worn beyond the minimum specification. Valve plates may be resurfaced to the specifications shown in the drawing, provided resurfacing will not reduce the thickness below the minimum specification.



SWASHPLATE AND JOURNAL BEARINGS

Inspect the running face, servo ball-joint, and swashplate journal surfaces for damage or excessive wear. Some material transfer may appear on these surfaces and is acceptable providing the surface condition meets specifications shown. Measure the swashplate thickness from the journals to the running face. Replace swashplate if damaged or worn beyond mini-


mum specification. Replace swashplate if the difference in thickness from one side to the other exceeds specification.



Inspect the journal bearings for damage or excessive wear. Replace journal bearings if scratched, warped, or excessively worn. The polymer wear layer must be smooth and intact.

SHAFT BEARINGS

Inspect bearings for excessive wear or contamination. Rotate the bearings while feeling for uneven movement. Bearings should spin smoothly and freely. Replace bearings that appear worn or do not rotate smoothly.




SHAFT

Inspect the motor shaft. Look for damage or excessive wear on the output and block splines. Inspect the bearing surfaces and sealing surface. Replace shafts with damaged or excessively worn splines, bearing surfaces, or sealing surfaces.


SERVO PISTON AND MINIMUM ANGLE STOP

Inspect the minimum angle stop, servo piston head, and servo piston ball-socket for damage or excessive wear. Replace if necessary.



LOOP FLUSHING SPOOL


Inspect the loop flushing spool. Check for cracks or damage. Replace if necessary.



Assembly

1. Install new o-ring (1) and piston seal (2) to the servo piston (3). Install the piston seal over the o-ring.

Installing the piston seal stretches it, making it difficult to install the servo piston in its bore. Allow 30 minutes for the seal to relax after installation. To speed up seal relaxation, compress the seal by installing the piston head into the servo cavity in the end-cap and let it stand for at least five minutes.



- 1. O-ring
- 2. Piston Seal
- . Servo Piston

Figure 3-27. Servo Piston


2. After piston seal has relaxed, lubricate and install servo piston into the housing bore. Align the piston with the ball socket facing the inside of the housing.

3-46 3121139

▲ CAUTION

RISK OF PERSONAL INJURY: COMPRESSING THE BLOCK SPRING REQUIRES ABOUT 80 TO 90 LBF (350 TO 400 N) OF FORCE. USE A PRESS SUFFICIENT TO MAINTAIN THIS FORCE WITH REASONABLE EFFORT. ENSURE THE SPRING IS SECURE BEFORE ATTEMPTING TO INSTALL THE SPIRAL RETAINING RING. RELEASE THE PRESSURE SLOWLY AFTER THE RETAINING RING IS INSTALLED.

3. Install the inner block spring washer (4), block spring (5), and outer washer (6) into the cylinder block. Using a press, compress the block spring enough to expose the retaining ring groove. Wind the spiral retaining ring (7) into the groove in the cylinder block.




- 4. Block Spring Washer
- 9. Holddown Pins
- 5. Block Spring
- 10. Ball Guide
- 6. Outer Washer
- 11. Piston
- 7. Spiral Retaining Ring
- 12. Slipper Retainer
- 8. Retaining Ring

Figure 3-28. Cylinder Kit Assembly

- **4.** Turn the block over and install the retaining ring (8), hold-down pins (9), and ball guide (10) to the cylinder block.
- 5. Install the pistons (11) to the slipper retainer (12). Install the piston/retainer assembly into the cylinder block. Ensure the concave surface of the retainer seats on the ball guide. If you're reusing the pistons, install them to the original block bores. Lubricate the pistons, slippers, retainer, and ball guide before assembly. Set the cylinder kit aside on a clean surface until needed.

6. Install the journal bearings (13) into the housing seats. Use assembly grease to keep the bearings seated during assembly. Ensure the locating nubs drop into the cavities in the seats. If you're reusing the bearings, install them in the original location and orientation. Lubricate the journal bearings.




- 13. Journal Bearings
- 14. Swashplate

Figure 3-29. Swashplate and Journal Bearing

7. Install the swashplate (14) into the housing. Tilt the swashplate and guide the servo lever ball into its socket in the servo piston rod. Ensure the swashplate seats into the journal bearings and moves freely. Lubricate the running surface of the swashplate.

8. Press front shaft bearing (15) onto shaft (16). Press bearing onto shaft with lettering facing out. Lubricate bearing rollers. Install snap-ring (17) onto shaft.




- 15. Front Shaft Bearing
- 16. Shaft
- 17. Snap Ring
- 18. Snap Ring

Figure 3-30. Shaft and Front Bearing

9. While holding the swashplate in place, turn the housing on its side. Install the install shaft/bearing assembly into housing from the flange end. Install the snap-ring (18).


10. Verify swashplate and bearings are properly seated. Install the cylinder kit (19) onto the shaft. Install with the slippers facing the swashplate. Rock the shaft to align the block splines and slide the cylinder kit into place. Orient the motor with the shaft pointing downward and verify the cylinder kit, swashplate, journal bearings, and servo piston are all secure and properly installed.



19. Cylinder Kit

Figure 3-31. Cylinder Kit Installation

11. Lubricate and install the servo spring (20), and minimum angle stop (21) into the housing bore.




- 20. Servo Spring
- 21. Minimum Angle Stop

Figure 3-32. Servo Spring and Minimum Angle
Ston

3-48 3121139

12. Press the rear shaft bearing (22) into the end cap. Install the bearing with letters facing out. Press until bearing surface is 0.08 ± 0.01 in $(2 \pm 0.25 \text{ mm})$ above end cap surface.




- 22. Rear Shaft Bearing
- 23. Timing Pin
- 24. Valve Plate

Figure 3-33. Valve Plate and Rear Bearing

- 13. Install timing pin (23) into its bore in the end cap. Install the pin with its groove facing toward or away from the shaft. Press the pin until the end protrudes 0.12 ± 0.01 in $(3 \pm 0.25 \text{ mm})$ above end cap surface.
- 14. Install the valve plate (24) onto the end cap. Install the valve plate with the yellow surface toward the cylinder block. Align the slot in the valve plate with the timing pin. Apply a liberal coat of assembly grease to the end cap side of the valve plate to keep it in place during installation.

15. Install the end cap (25) onto the housing with the end cap screws (26). Check to ensure the end cap will properly seat onto the housing without interference. Improper assembly of the internal components may prevent the end cap from seating properly. Ensure the o-rings seat properly when installing the end cap.




- 25. End Cap
- 26. Screw

Figure 3-34. End Cap

- **16.** Using an 8 mm internal hex wrench, tighten the end cap screws. Tighten the screws in opposite corners slowly and evenly to compress the servo spring and properly seat the end cap. Torque end cap screws 35-45 ft. lbs. (47-61 Nm).
- **17.** Before installing the shaft seal, ensure the shaft turns smoothly with less than 120 in. lbs. (13.5 Nm) of force. If the shaft does not turn smoothly within the specified maximum force, disassemble and check the unit.

18. Cover shaft splines with an installation sleeve. Install a new shaft seal (27) with the cup side facing the motor. Press seal into housing until it bottoms out. Press evenly to avoid binding and damaging the seal. Install seal support washer (28) and snap ring (29).



- 27. Shaft Seal
- 28. Seal Support Washer
- 29. Snap Ring

Figure 3-35. Shaft Seal

19. Install remaining plugs and fittings to the housing. Refer to the drawing below for wrench sizes and installation torques.





Figure 3-36. Plugs and Fittings Installation

3-50 *3121139*

20. Install orifice poppet (30).



| 30. | Orifice Poppet | 34. | Spring | 37. | 0-ring | 40. | Plug |
|-----|----------------|-----|--------|-----|--------|-----|------|
| 31. | Shift Spool | 35. | Spring | 38. | 0-ring | 41. | Plug |
| 32. | Spring | 36. | Spring | 39. | 0-ring | 42. | Plug |
| 33. | Spring | | | | | | |

Figure 3-37. Loop Flushing Spool

- 21. Install shift spool (31).
- **22.** Install spring retaining washers onto springs (32 and 33).
- **23.** Carefully install centering springs (34, 35, and 36).
- **24.** Install new o-rings (37, 38, and 39).
- **25.** Using a 5/8 in wrench torque plug (40) to 20 ft. lbs. (27 Nm).
- **26.** Using a 11/16 in wrench, torque plugs (41 and 42) to 27 ft.lbs. (37 Nm).

Initial Start-up Procedures

Follow this procedure when starting-up a new motor or when installing a motor that has been removed.

NOTICE

INSPECT MOTOR FOR DAMAGE BEFORE INSTALLATION. MAKE CERTAIN ALL SYSTEM COMPONENTS (RESERVOIR, HOSES, VALVES, FITTINGS, HEAT EXCHANGER, ETC.) ARE CLEAN BEFORE FILLING WITH FLUID.

- Fill the reservoir with recommended hydraulic fluid. Always filter fluid through a 10 micron filter when pouring into the reservoir. Never reuse hydraulic fluid.
- 2. Fill the inlet line leading from the pump to the reservoir. Check the inlet line for properly tightened fittings and be certain it is free of restrictions and air leaks.
- **3.** Fill the pump and motor housing with clean hydraulic fluid. Pour filtered oil directly into the upper most case drain port.
- **4.** To ensure the pump and motor stay filled with oil, install case drain lines into the upper most case drain ports.
- **5.** Install a 0 to 500 psi (0 to 35 bar) gauge in the charge pressure gauge port of the pump to monitor system pressure during start up.
- **6.** While watching the pressure gauge, run the engine at the lowest possible speed until system pressure builds to normal levels (minimum 160 psi [11 bar]). Once system pressure is established, increase to full operating speed. If system pressure is not maintained, shut down the prime mover, determine cause, and take corrective action.
- **7.** Operate the hydraulic system for at least fifteen minutes under light load conditions.
- **8.** Check and adjust control settings as necessary after installation.
- **9.** Shut down the prime mover and remove the pressure gauge. Replace plug at the charge pressure gauge port.
- Check the fluid level in the reservoir; add clean filtered fluid if necessary. The motor is now ready for operation.

3.13 DRIVE HUB (4WD MACHINES W/ INTEGRAL BRAKE) (PRIOR TO SN 0300083331)

Roll, Leak and Brake Testing

Drive Hub units should always be roll and leak tested before disassembly and after assembly to make sure that the unit's gears, bearings and seals are working properly. The following information briefly outlines what to look for when performing these tests.

NOTE: The brake must be released before performing the roll test. This can be accomplished by either pressurizing the brake using the Brake Leak Test procedure below or by tightening the bolts into the piston through the end plate (See Brake Disassembly Procedure).

NOTE: Bolts must be removed while performing brake release test.

THE ROLL TEST

The purpose of the roll test is to determine if the unit's gears are rotating freely and properly. You should be able to rotate the gears in your unit by applying <u>constant</u> force to the roll checker. If you feel <u>more</u> drag in the gears only at certain points, then the gears are not rolling freely and should be examined for improper installation or defects. Some gear packages roll with more difficulty than others. Do not be concerned if the gears in your unit seem to roll hard as long as they roll with <u>consistency</u>.

THE LEAK TEST (MAIN UNIT)

The purpose of a leak test is to make sure the unit is air tight. You can tell if your unit has a leak if the pressure gauge reading on your leak checking fitting starts to fall after the unit has been pressurized and allowed to equalize. Leaks will most likely occur at the pipe plugs, the main seal or wherever orings or gaskets are located. The exact location of a leak can usually be detected by brushing a soap and water solution around the main seal and where the orings or gaskets meet on the exterior of the unit, then checking for air bubbles. If a leak is detected in a seal, oring or gasket, the part must be replaced, and the unit rechecked. Leak test at 10 psi for 20 minutes.

THE BRAKE TEST

Input Brake - 1,850 in-lb (208 Nm) Static, 225 psi (15.5 bar) Full Release, 3000 psi (207 bar) maximum o-ring check.

If brake does not release at these pressure values, brake has to be inspected, repaired or replaced.


NOTE: Failure to perform this test may result in damaged or ineffective brake parts.

Tightening and Torquing Bolts

If an air impact wrench is used to tighten bolts, extreme care should be taken to ensure that the bolts are not tightened beyond their specified torque.

The following steps describe how to tighten and torque bolts or socket head capscrews in a bolt circle.

- 1. Tighten (but do not torque) bolt "A" until snug.
- 2. Go to the opposite side of the bolt circle and tighten bolt "B" until equally snug.
- Crisscross around the bolt circle and tighten remaining bolts.
- Now use a torque wrench to apply the specified torque to bolt "A".
- Using the same sequence, crisscross around the bolt circle and apply an equal torque to the remaining bolts.




3-52 3121139

Main Disassembly

NOTE: Refer to Figure 3-38., Main Disassembly - Sheet 1 of 2 and Figure 3-39., Main Disassembly- Sheet 2 of 2.


- 1. Perform Roll Check, Leak Check and Brake Check if applicable prior to disassembling the unit.
- **2.** Drain oil from unit. Note the condition and volume of the oil.
- 3. Remove Input Coupling (9) from Spindle (1A) end of unit
- 4. Remove Cover Bolts (14) and remove Cover (6).
- **5.** Remove O-ring (19) and Thrust Spacer (10) from the Cover (6).

- **6.** Remove Input Sun Gear (17) from Input Carrier Sub-Assembly (3A).
- **7.** Remove Input Carrier Sub-Assembly (3A) from Housing (1E).
- Remove Output Sun Gear (8) from Output Carrier Sub-Assembly (4A).
- **9.** Remove Input Shaft (7) from Output Carrier Sub-Assembly (4A).
- **10.** Remove Output Carrier Sub-Assembly (4A) from Housing (1E).



- 6. Cover
- 9. Input Coupling
- 10. Thrust Spacer
- 14. Cover Bolts
- 19. 0-ring

Figure 3-38. Main Disassembly - Sheet 1 of 2



- 7. Input Shaft
- 8. Output Sun Gear
- 17. Input Sun Gear


Figure 3-39. Main Disassembly- Sheet 2 of 2

3-54 3121139

Input Carrier Disassembly

NOTE: Refer to Figure 3-40., Input Carrier Disassembly.

- 1. Place the Carrier (3A) on a press with the spline end up and drive the Planet Shaft (3E) out of the Carrier (3A).
- **2.** Slide the Planet Gear (3F) and the two Thrust Washers (3B) out of the Carrier (3A).
- **3.** Remove the 14 needle Bearings (3C) from the bore of the Planet Gear (3F).
- **4.** Repeat steps 1 through 3 for each of the two remaining planet gears.



- 3A. Carrier
- 3B. Thrust Washers
- 3C. Needle Bearings
- 3E. Planet Shaft
- 3F. Planet Gear

Figure 3-40. Input Carrier Disassembly

Output Carrier Disassembly


NOTE: Refer to Figure 3-41., Output Carrier Assembly.

1. Using a small diameter punch, Drive the Roll Pin (4G) which holds the Planet Shaft (4E) in the Carrier (4A) down into the Planet Shaft (4E) until it bottoms.

NOTE: Make sure that the Roll Pin has bottomed. Otherwise, damage to the carrier could occur when the Planet Shaft is removed.

2. Remove the Planet Shaft (4E) from the Carrier (4A). Use a small punch to remove the Roll Pin (4G) from the Planet Shaft (4E).

- **3.** Slide the Planet Gear (4F) and the two Thrust Washers (4B) out of the Carrier (4A).
- **4.** Remove the 15 needle Bearings (4C) from the bore of the Planet Gear (4F).
- **5.** Repeat steps 1 through 4 for each of the two remaining planet gears.
- **6.** Remove the Thrust Washer (4H) from the Carrier (4A).
- **7.** Using retaining ring pliers, remove the Retaining Ring (4K) from the Carrier (4A) and pull the Thrust Washer (4J) and Spring (4I) out of the Carrier (4A).



- 4A. Carrier
- 4B. Thrust Washers
- 4C. Needle Bearings
- 4E. Planet Shaft
- 4F. Planet Gear
- 4G. Roll Pin
- 4H. Thrust Washer
- 41. Spring
- 4J. Thrust Washer
- 4K. Retaining Ring

Figure 3-41. Output Carrier Assembly

3-56 3121139

Housing-Spindle Disassembly

NOTE: Refer to Figure 3-42., Housing-Spindle Disassembly.


1. Place unit on bench with Spindle (1A) end down.

A CAUTION

EYE PROTECTION MUST BE WORN WHILE PERFORMING THE NEXT STEP IN THIS PROCEDURE.

- **2.** Using retaining ring pliers, remove Retaining Ring (1G) from the groove in Spindle (1A).
- **3.** Remove Bearing Spacer (1F) from top of Bearing Cone (1D).
- **4.** While supporting the unit on Housing (1E) flange, press Spindle (1A) out of Housing (1E). The Seal (1B) and "B" position Bearing Cone (1D) should come out of Housing (1E) with Spindle (1A).

- **5.** Remove "A" position Bearing Cone (1D) from Bearing Cup (1D) in Housing (1E).
- **6.** Lift Housing (1E) off of Spindle (1A).
- 7. If necessary, press Studs (1N) out of Housing (1E). Locate Housing (1E) on Seal (1B) end.
- **8.** Remove "B" position Bearing Cone (1D) from Spindle (1A).
- 9. Remove Seal (1B) from the Spindle (1A).
- Using a soft steel rod, knock both Bearing Cups (1C) out of Housing (1E).



- 1B. Seal
- 1C. Bearing Cups
- 1D. Bearing Cone
- 1E. Housing
- 1F. Bearing Spacer
- 1G. Retaining Ring
- 1H. Wheel Stud

Figure 3-42. Housing-Spindle Disassembly

Spindle-Brake Disassembly

NOTE: Refer to Figure 3-43., Spindle Brake Disassembly.

NOTE: This procedure applies only to units with integral input


brake (2).

NOTE: For this procedure, use the Brake Assembly Drawing, which will show the proper balloon numbers for the individual brake components. In the following instructions, if the number has a "-" between two numbers, it refers to the Brake Assembly Drawing only and NOT the Drive Hub Assembly Drawing.

NOTE: The Pressure Plug (12) requires a special tool for installation. It is not recommended to remove this plug unless it is leaking. The plug is called a Koenig Expander. The installation tool is not supplied by Fairfield manufacturing, but can be supplied by the manufacturer of the Koenig Expander, Sherex Industries, or one of their distributors.

▲ CAUTION

EYE PROTECTION MUST BE WORN WHILE PERFORMING STEPS 1-3 IN THIS PROCEDURE.



- 1-A. Spindle
- 12. Pressure Plug
- 2-1. Internal Circlip
- 2-2. 0-ring
- 2-3. Backup Ring
- 2-4. 0-ring
- 2-5. Backup Ring
- 2-7. End Plate
- 2-8. Piston
- 2-9. Stator
- 2-10. Spacer
- 2-11. Capscrew
- 2-12. Rotor
- 2-13. Compression Spring

2-6. Internal Circlip

Figure 3-43. Spindle Brake Disassembly

3-58 3121139

- 1. Compress the Compression Springs (2-13) by installing a minimum of three M4 x 16mm Socket Head Capscrews (2-11) equally spaced through End Plate (2-7) and into Piston (2-8) and tightening incrementally until spring force has been taken off of the Retaining Ring (2-6).
- 2. Using a small pry bar or screwdriver, pry one end of the Retaining Ring (2-6) out of the groove in Spindle (1A), then, using pliers, pull Retaining Ring (2-6) the rest of the way out of the groove.
- **3.** Back Socket Head Capscrews (2-11) incrementally out of Piston (2-8) until spring force is relieved from the End Plate (2-7).
- Remove Socket Head Capscrews (2-11) and End Plate (2-7) from brake cavity in Spindle.
- **5.** Remove Compression Springs (2-13) from Piston (2-8).

A CAUTION

EYE PROTECTION MUST BE WORN WHILE PERFORMING THE NEXT STEP IN THIS PROCEDURE.

- 6. Using an air hose, slowly and carefully pressurize the brake port in the Spindle (1A) until the Piston (2-8) comes out of piston bore of Spindle (1A), Then pull the Piston (2-8) the rest of the way out of the Spindle (1A) by hand.
- **7.** Remove Backup Rings (2-3) & (2-5) and O-rings (2-2) & (2-4) from Piston (2-8).
- **8.** Remove Rotors (2-12) and Stators (2-9) from Spindle (1A).

A CAUTION

EYE PROTECTION MUST BE WORN WHILE PERFORMING THE NEXT STEP IN THIS PROCEDURE.

- **9.** Invert Spindle (1A) and, using retaining ring pliers, remove Retaining Ring (2-1).
- 10. Remove Spacer (2-10) from Spindle.

Input Carrier Sub-Assembly

NOTE: Refer to Figure 3-44., Input Carrier Sub-Assembly.

- 1. Apply a liberal coat of grease to the bore of one Input Planet Gear (3F).
- Line the inside of the Planet Gear (3F) with 14 Needle Rollers (3C).
- **NOTE:** The last roller installed must be installed end wise. That is, the end of the last roller must be placed in between the ends of the two rollers that form the space, and then slid, parallel to the other rollers, into place.
 - **3.** Set Carrier (3A) in an upright position.

- **4.** Insert a Planet Shaft (3E) into the planet shaft hole in the end of the Carrier (3A) opposite the splined end.
- 5. Place one Thrust Washer (3B) onto the end of Planet Shaft (3E). Make sure the flat faces towards the inside of the carrier and make sure the button fits in the pocket inside the Carrier (3A).
- **6.** Place one more Thrust Washer (3B) into the Carrier (3A). Align the Thrust Washer (3B) in the same manner described in Step 5.


NOTE: Some grease may need to be applied to the Thrust Washers (3B) to hold them in place while installing the planet gear. Instead of using grease, the washers could be inserted from the ID of the carrier for the buttons to fit into pockets of the carrier.

- **7.** Following the thrust washers, place Planet Gear (3F) with needle rollers, into the Carrier (3A) between the Thrust Washers (3B).
- **8.** Push the Planet Shaft (3E) through the Planet Gear (3F) and the other Thrust Washer (3B) until it touches the other side of the Carrier (3A).

A CAUTION

SAFETY GLASSES MUST BE WORN DURING THE NEXT STEP.

- **9.** Press the Planet Shaft (3E) until it is pressed to the appropriate depth.
- **NOTE:** If planet shaft locating tooling is not available, press lightly on Planet Shaft (3E) and make sure not to press Planet Shaft (3E) through the small shoulder in Carrier (3A). This shoulder is intended to keep the planet pin from working loose in that direction during proper operation of the unit. It is **NOT** intended to keep the planet pin from being pressed through the carrier.
 - **10.** On the side of the Carrier (3A) where the Planet Shaft (3E) was inserted, stake the Carrier (3A) in 3 places using a punch and a hammer around the Planet Shaft (3E) to assure the shaft stays in place during operation of the unit.
 - Repeat Steps 1 through 10 for the installation of the two remaining Planet Gears (3F).



- 3A. Carrier
- 3B. Thrust Washers
- 3C. Needle Bearings
- 3E. Planet Shaft
- 3F. Planet Gear

Figure 3-44. Input Carrier Sub-Assembly

3-60 3121139

Output Carrier Sub-Assembly

NOTE: Refer to Figure 3-45., Output Carrier Sub-Assembly.

- Place Spring (4I) into the deep counterbore of the Output Carrier (4A).
- 2. Place Washer (4J) on top of Spring (4I).

A CAUTION

SAFETY GLASSES MUST BE WORN DURING THE NEXT STEP.


- **3.** With Retaining Ring (4K) installed on snap ring pliers, place on top of Washer (4J) and compress Spring (4l) until Retaining Ring (4K) is seated completely in groove.
- **4.** Apply a liberal coat of grease to the bore of one Output Planet Gear (4F).
- Line the inside of the Planet Gear (4F) with 15 Needle Rollers (4C).
- **NOTE:** The last roller installed must be installed end wise. That is, the end of the last roller must be placed in between the ends of the two rollers that form the space, and then slid, parallel to the other rollers, into place.
 - **6.** Place Thrust Washer (4H) into the shallow counterbore of the Output Carrier (4A).
 - 7. Set Carrier (4A) in an upright position.

- **8.** Insert a Planet Shaft (4E) into one of the planet shaft holes on the Carrier (4A). The end of the planet shaft that does **NOT** have the roll pin hole should be inserted in the carrier **FIRST**.
- **9.** Place one Thrust Washer (4B) onto the end of Planet Shaft (4E). Make sure the flat faces towards the inside of the carrier and make sure the button fits in the pocket inside the Carrier (4A).
- **10.** Following the thrust washer, place Planet Gear (4F) with needle rollers, onto Planet Shaft (4E).
- **11.** Following the planet gear, place one more Thrust Washer (4B) onto Planet Shaft (4E). Align the Thrust Washer (4B) in the same manner described in Step 6.
- **12.** Now insert Planet Shaft (4E) through the opposite planet shaft hole on Carrier (4A). Use an alignment punch or similar tool to align the roll pin holes on Carrier (4A) and Planet Shaft (4E).

A CAUTION

SAFETY GLASSES MUST BE WORN DURING THE NEXT STEP.

- **13.** Drive Roll Pin (4G) down into the aligned roll pin holes. Pin should be flush with OD of carrier.
- **14.** Repeat Steps 4,5, & 8-13 for the installation of the two remaining Planet Gears (4F).



- 4A. Output Carrier
- 4B. Thrust Washer
- 4C. Needle Rollers
- 4E. Planet Shaft
- 4F. Planet Gear
- 4G. Roll Pin
- 4H. Thrust Washer
- 41. Spring
- 4J. Washer
- 4K. Retaining Ring

Figure 3-45. Output Carrier Sub-Assembly

3-62 3121139

Spindle Brake Sub-Assembly

NOTE: Refer to Figure 3-46., Spindle Brake Sub-Assembly.

NOTE: This procedure applies only to units with integral input brake (2).

NOTE: For this procedure, use the Brake Assembly Drawing (Figure 3-46.), which will show the proper balloon numbers for the individual brake components. In the following instructions, if the number has a "-" between two numbers, it refers to the Brake Assembly Drawing only and NOT the Drive Hub Assembly Drawing.

NOTE: The Pressure Plug (12) requires a special tool for installation. It is not recommended to remove this plug unless it is leaking. The plug is called a Koenig Expander. The installation tool is not supplied by Fairfield manufacturing, but can be supplied by the manufacturer of the Koenig Expander, Sherex Industries, or one of their distributors.

- Install Pressure Plug (12) into Spindle (1A) using following procedure:
- · Clean hole in spindle using appropriate Loctite spray.
- Dip collar of plug in Loctite 290 or 680 (keep unplugged portion of hole free of Loctite).
- Using appropriate tool, install plug flush with surface of spindle.

▲ CAUTION

SAFETY GLASSES MUST BE WORN DURING THE NEXT STEP.

- 2. Place Spindle (1A) such that the splined end is facing down. Using appropriate tool (See back of manual), install Retaining Ring (2-1) into the spindle groove within the splines.
- **3.** Place Washer (2-10) on top of Retaining Ring (2-1).
- 4. Place Stator (2-9) on top of Washer (2-10).
- **5.** Place Rotor (2-12) on top of Stator (2-9).
- **6.** Repeat steps 3 & 4 until there are a total of 8 Stators (2-9) and 7 Rotors (2-12) installed.
- **7.** Place Piston (2-8) such that the smaller O.D. end is facing upward.
- **8.** Grease the large Backup Ring (2-3) and install in the large-diameter groove at the bottom of the Piston (2-8).
- **9.** Grease the large O-Ring (2-2) and install in the large-diameter groove at the bottom of the Piston (2-8), on top of the large Backup Ring (2-3).
- **10.** Grease the small O-Ring (2-5) and install in the small-diameter groove near the top of the Piston (2-8). Make sure the o-ring is seated on the bottom of the groove.

11. Grease the small Backup Ring (2-4) and install in the small-diameter groove near the top of the Piston (2-8), on top of the small O-Ring (2-5).

NOTE: If piston comes pre-assembled with shipping bolts (2-11), skip to Step 15.

- **12.** Insert Piston (2-8) into Spindle (1A) until it contacts the Stator (2-9).
- **13.** Insert the appropriate number of Springs (2-13) into Piston (2-8) counterbore. Use the brake spring chart below and a bill of materials for your particular model number to determine the number of springs.


| BRAKE CODE | BRAKE P/N | NUMBER OF SPRINGS |
|---------------|-----------|----------------------|
| Α | 902337 | 12 |
| В | 902341 | 10 |
| C | 902342 | 8 |
| D | 902343 | 6 |
| E | 902345 | 9 |

14. Place Pressure Plate (2-7) on top of Springs (2-13).

A CAUTION

SAFETY GLASSES MUST BE WORN DURING THE NEXT TWO STEPS.

- **15.** Using snap ring pliers, install Retaining Ring (2-6) into groove in Spindle (1A) and on top of Pressure Plate (2-7). Make sure that Retaining Ring (2-6) is seated properly in the groove.
- **16.** Remove Shipping Bolts (2-11) in brake pressure plate to release springs in brake. Before removing bolts, use the Coupling (9) (See Assembly Drawing at back of manual) to center and align the Brake Rotors (2-12) with the Spindle (1A).



1-A. Spindle 2-7. End Plate
12. Pressure Plug 2-8. Piston
2-1. Internal Circlip 2-9. Stator
2-2. O-ring 2-10. Spacer
2-3. Backup Ring 2-11. Capscrew
2-4. O-ring 2-12. Rotor
2-5. Backup Ring 2-13. Compression Spring

2-6. Internal Circlip

Figure 3-46. Spindle Brake Sub-Assembly

3-64 3121139

Housing-Spindle Sub-Assembly

NOTE: Refer to Figure 3-47., Housing-Spindle Assembly.

NOTE: Spray a light film of oil on all component parts during

assembly.

A CAUTION

SAFETY GLASSES MUST BE WORN DURING THE ENTIRE HOUSING-SPINDLE SUBASSEMBLY.

- **1.** Press Bearing Cup (1C), position A, into Housing (1E) using appropriate pressing tool (See back of manual).
- **2.** Turn Housing (1E) over and place into pressing base. Press nine Studs (1H) into Housing (1E).

NOTE: Use enough pressure to press in studs. Don t use excessively high pressure to press in studs or Housing may crack. Make sure head of stud contacts face of flange on Housing.

NOTE: Spray a generous amount of oil on bearings during installation.

- **3.** Press Bearing Cup (1C), position "B", into Housing (1E) using "B" Bearing Cone pressing tool (see back of manual).
- **4.** Place Bearing Cone (1D), into Bearing Cup (1C), position "B".
- **5.** Grease Seal (1B) lip and press seal into Housing (1E) using seal pressing tool (see back of manual) until seal is flush with end of Housing.
- **6.** Turn Housing (1E) over and lower onto Spindle (1A).
- 7. Install Bearing Cone (1D) into Bearing Cup (1C), position "A". and lightly press on Bearing Cup using the "A" Bearing Cone pressing tool (see back of manual) while rotating Housing (1E) in both directions to seat bearings.
- **8.** Place Bearing Spacer (1F) on top of Bearing Cone (1D).
- **9.** Using retaining ring pliers, install Retaining Ring (1G) into Spindle (1A) groove. Make sure ring is completely seated in groove.

NOTE: Extra bearing pre-load caused by pressing "A" Bearing Cone (1D) must be removed. This should be done by placing a flat piece of steel or a pressing tool on the end of the spindle, and then lightly striking the tool with a piece of barstock. This should be adequate to remove any additional bearing pre-load.

DW2B Integral Brake Check


- **1.** Using appropriate fittings, connect hydraulic line from hand pump to brake port.
- 2. Check to see that brake is set by trying to rotate Input Shaft (7). This can be accomplished by installing an appropriate tool (any tool that can locate on the splines of the Input Coupling (9), such as a mating splined shaft) into Input Coupling (9).
- **3.** Bleed brake. Increase hydraulic pressure gradually while trying to rotate the input until brake just starts to release. Note this pressure. Make sure the pressure falls into the appropriate range below.

| | BRAKE CODE | BRAKE P/N | JUST RELEASE PRESSURE RANGE (psi) |
|---|---------------|-----------|--------------------------------------|
| Ī | Α | 902337 | 185-230 |
| Ī | В | 902341 | 155-192 |
| Ī | C | 902342 | 125-155 |
| Ī | D | 902343 | 93-115 |
| ſ | E | 902345 | 132-172 |

4. Increase pressure to 3,000 psi and hold for 30 seconds to check for leaks. Repair leaks if necessary.

NOTE: Make sure that brake re-engages when pressure is released.

NOTE: When done, make sure Input Coupling (9) is centered in Spindle (1A) to make installation of motor possible without release of brake.



1B. Seal

1F. Bearing Spacer

1C. Bearing Cups

1G. Retaining Ring

1D. Bearing Cone

1H. Wheel Stud

1E. Housing

Figure 3-47. Housing-Spindle Assembly

3-66 3121139


Main Assembly

NOTE: Refer to Figure 3-48., Main Assembly - Sheet 1 and Figure 3-49., Main Assembly - Sheet 2.

NOTE: All components should receive a generous amount of lubricant oil as they are being assembled.


- Place Housing-Spindle Sub-Assembly on the bench with Spindle (1A) side down.
- **2.** Place Output Carrier Sub-Assembly into Housing (1E) and onto Spindle (1A).
- **3.** Insert the larger diameter splined end of Input Shaft (7) through bore of Output Carrier Sub Assembly (4A) until shoulder of Input Shaft (7) contacts Thrust Washer (4J) (See assembly drawing at back of manual).

- **4.** With the modified spline end facing up, place the Output Sun Gear (8) into mesh with the planet gears from the Output Carrier Sub-Assembly (4A).
- **5.** Place Input Carrier Sub-Assembly (3A) onto Output Sun Gear (8) splines.
- **6.** Grease O-Ring (19) and insert into groove in Cover Sub-Assembly (6).
- **7.** Install Cover Sub-Assembly (6) onto Housing (1E) and install twelve Bolts (14) into Cover (6). Torque bolts to 70-80 in. lbs. (8-9 Nm).
- **8.** Attach ID Tag (15) onto unit. If Cover has knobs as part of the cover, peen the top of each knob to form a head to hold on the Tag. If the cover has no such knobs, use drive screws.
- **9.** Check disconnect, roll and leak check unit, leak check brake, check brake release pressure.



- 7. Input Shaft
- 8. Output Sun Gear
- 17. Input Sun Gear

Figure 3-48. Main Assembly - Sheet 1



- 6. Cover
- 9. Input Coupling
- 10. Thrust Spacer
- 14. Cover Bolts
- 19. 0-ring

Figure 3-49. Main Assembly - Sheet 2

3-68 3121139

Figure 3-50. Assembly Drawing - Without Integral Input Brake - Sheet 1 of 2

| 1A. Spindle | 1B. Lip Seal | 4C. Needle Bearing | 7. Input Shaft |
|----------------------------|--------------------|--------------------------|-----------------------|
| 1G. Retaining Ring - Ext | 3A. Carrier | 41. Spring | 9. Coupling |
| 12. Pressure Plug | 3F. Planet Gear | 4K. Retaining Ring - Int | 6. CoverSubassembly |
| 16. O-ring Pipe Plug | 3E. Planet Shaft | 4G. Roll Pin | 10. Thrust Spacer |
| 1F. Thrust Washer | 3C. Needle Bearing | 4B. Thrust Washer | 15. Id Plate |
| 1E. Housing/Ring Gear | 3B. Thrust Washer | 4H. Thrust Washer | 14. 12 Pt Flange Bolt |
| 1N. Stud | 4A. Carrier | 4J. Thrust Washer | 19. 0-ring |
| 1C. Tapered Bearing - Cup | 4F. Planet Gear | 17. Sun Gear | |
| 1D. Tapered Bearing - Cone | 4E. Planet Shaft | 8. Sun Gear | |

Figure 3-51. Assembly Drawing - Without Integral Input Brake - Sheet 2 of 2

3-70 3121139




Figure 3-52. Assembly Drawing - With Integral Input Brake - Sheet 1 of 2

| 1A. Spindle | 1D. Tapered Bearing - Cone | 4E. Planet Shaft | 8. Sun Gear |
|---------------------------|----------------------------|------------------------|-----------------------|
| 2. Input Brake | 1B. Lip Seal | 4C. Needle Bearing | 7. Input Shaft |
| 1G. Retaining Ring - Ext | 3A. Carrier | 41. Spring | 9. Coupling |
| 12. Pressure Plug | 3F. Planet Gear | 4K. Retaining Ring-Int | 6. CoverSubassembly |
| 16. O-ring Pipe Plug | 3E. Planet Shaft | 4G. Roll Pin | 10. Thrust Spacer |
| 1F. Thrust Washer | 3C. Needle Bearing | 4B. Thrust Washer | 15. Id Plate |
| 1E. Housing/Ring Gear | 3B. Thrust Washer | 4H. Thrust Washer | 14. 12 Pt Flange Bolt |
| 1N. Stud | 4A. Carrier | 4J. Thrust Washer | 19. 0-ring |
| 1C. Tapered Bearing - Cup | 4F. Planet Gear | 17. Sun Gear | |

Figure 3-53. Assembly Drawing - With Integral Input Brake - Sheet 2 of 2

3-72 3121139




Figure 3-54. Assembly Tools - Bearing Cone Pressing - "B" Bearing




Figure 3-55. Assembly Tools - Bearing Cone Pressing - "A" Bearing

3-74 3121139




Figure 3-56. Assembly Tools - Bearing Cup Pressing - "A" & "B" Bearings




Figure 3-57. Assembly Tools - Seal Pressing

3-76 3121139




Figure 3-58. Assembly Tools - Spacer - Brake Disc Installation




Figure 3-59. Assembly Tools - Brake Retaining Ring Installation

3-78 3121139

3.14 RE-ALIGNING DRIVE HUB INPUT COUPLING

The following procedure applies to drive hubs with integral brakes.


Equipment Required

- 1. Hydraulic power supply (hand pump) capable of producing 200 psi (13.8 bar).
- **2.** Hydraulic fittings to adapt hydraulic supply to brake release port on hub.

Procedure

1. Using appropriate fittings, connect a line from the hydraulic power supply to the brake port.

- **2.** Pressurize the brake release port 155 to 200 psi (10.6 to 13.8 bar) to release the brake.
- **3.** Verify that the brake is released by rotating the input coupling or hub spindle.
- **4.** Once the brake is released, the input coupling will be free to re-align with the drive motor.
- **5.** Install the drive motor on the hub, then release the hydraulic pressure at the brake release port. The coupling will remain in position.
- **6.** Disconnect the hydraulic power supply and reconnect the line going into the brake release port.



- Swing Motor
- Swing Brake
- Swing Drive 3.
- Swing Bearing
- $Remote\,Lube\,Fitting$
- $Backlash\,Adjuster$ 6.
- 7. Bearing Bolt

Figure 3-60. Swing Drive and Turntable Bearing

3-80 3121139

3.15 SWING DRIVE (PRIOR TO SN 0300066417)

Disassembly

- 1. Loosen all 12 cover bolts (12) & (13) and drain the oil from the unit.
- 2. Remove the 12 cover bolts (12) & (13) and lift off the cover (6). Remove and discard the o-ring (5) from the counterbore of the cover (6).
- **3.** Remove the input gear (8) and thrust washer (10).
- **4.** Lift out the carrier assembly (3) and top thrust washer (11). The thrust washer (11) may stick to the inside of the carrier (3).
- **5.** Remove the input thrust spacer (9).
- **6.** Lift out the internal gear (2) and thrust washer (11). The thrust washer (11) may stick to the under side of the carrier (3).
- 7. Remove the retaining ring (1I) from the output shaft (1A) and discard.

▲ CAUTION

EYE PROTECTION SHOULD BE WORN DURING RETAINING RING (11) REMOVAL.


- **8.** Remove bearing shim (1H) from the output shaft (1A).
- **9.** The output shaft (1A) may now be pressed out of the hub (1G).
- **10.** The bearing cups (1C) & (1E) will remain in hub (1G) as will bearing cone (1F). Bearing cone (1D) will remain on the same output shaft (1A). The seal (1B) will be automatically removed during this procedure.
- **NOTE:** If bearing replacement is necessary, the bearing cups can be removed with a slide hammer puller driven out with a punch.
 - 11. To remove the cluster gears (3F) from the carrier (3A), drive the anti-roll pin (3G) into the planet shaft (3E) may now be tapped out of the carrier. After planet shaft (3E) has been removed the roll pin (3G) can be driven out.
 - **12.** The cluster gear (3F) can now be removed from the carrier (3A). The thrust washers (3B) will be removed with the cluster gear (3F).
 - **13.** The needle rollers (3C) and spacer (3D) are now removed from the cluster gear (3F).

NOTICE


WHEN REBUILDING OR REPAIRING THE UNIT, THE RETAINING RING (11), ORINGS (5) AND SEAL (1B) SHOULD ALWAYS BE REPLACED.

Main Assembly Procedure

1. With the hub shaft sub-assembly resting on the shaft (1A) install internal gear (2). The spline of the internal gear (2) bore will mesh the spline of the output shaft (1A).



2. Thrust washer (11) is installed on the face of the output shaft (1A). Sufficient grease or petroleum jelly should be used to hold thrust washer in place.




3. Place o-ring (5) into hub counterbore. Use petroleum jelly to hold o-ring in place. Also at this time locate and mark the 4 counter beamed holes in the face of the hub (1G). This is for identification later in the assembly.

A CAUTION


BEWARE OF SHARP EDGES OF THE COUNTERBORE WHILE SEATING THIS O-RING.




4. Thrust spacer (9) is installed into the bore of the output shaft (1A). This should be a slip fit and thrust spaces should rotate in this location.



5. Place carrier assembly (3) on a flat surface with the large gears (3F) up and positioned as shown. Find the punch marked tooth on each large gear (3F) and locate at 12 0'clock (straight-up) from each planet pin. Marked tooth will be located just under the carrier (3A) on upper two gears (3F).



6. With shoulder side of ring gear (4) facing down, place ring gear over (into mesh with) large gears. Be sure that punch marks remain in correct location during ring gear installation. The side of the ring gear with an X stamped on it should be up.




7. While holding ring gear (4) and cluster gears (3F) in mesh, place small side of cluster gears (3F) into mesh with the internal gear (2) and input gear (13). On the ring gear locate the hole marked "x" over one of the marked counterbore holes (step 3) in hub (1G).




NOTE: If gears do not mesh easily or carrier assembly does not rotate freely, then remove the carrier and ring gear and check the cluster gear timing.

3-82 3121139

8. Input gear (8) is installed, meshing with teeth of the large diameter cluster gear (3F). The counterbore on the input gear (8) locates on the shoulder of the thrust spacer (9). This is to be a slip fit and operate freely.



9. Thrust washer (10) is installed onto the input gear (8) and should locate on the gear teeth shoulder.



10. Thrust washer (11) is installed into the counterbore of the carrier (3).



11. Place o-ring (5) into cover (6) counterbore. Use petroleum jelly to hold o-ring in place.


▲ CAUTION

BEWARE OF SHARP EDGES OF THE COUNTERBORE WHILE SEATING THIS ORING.




12. The cover (6) is now installed on this assembly. Taking care to correctly align pipe plug hole (20) with those in the hub (1J), usually 90° to one another.


Locate the 4 counterbore holes in hub (1G) (marked in step 3) and install 4 shoulder bolts (13). A slight tap with a hammer may be necessary to align shoulder bolt with hub (1G) counterbore.




13. Install regular grade 8 bolts (12) into remaining holes.



14. Pipe plugs (20) are to be installed into cover (6) using a lubricant of some sort.




15. Torque shoulder bolts (13) to 23-27 ft. lbs. (31-37 Nm) and regular grade 8 bolts (12) to 23-27 ft. lbs. (31-37 Nm).




This completes the assembly. The unit must be filled one-half full of EP 90 lubricant before operation if the unit is mounted horizontally, and completely filled if mounted vertically. In vertical mounting application case oil circulation is recommended.

Hub Shaft Sub-Assembly

1. Press bearing cone (1D) onto shaft (1A).



2. Press bearing cup (1C) into hub (1G) taking care to insure cup start square with the bore of the hub.




3. Invert hub (1G) and press bearing cup (1E) into inter counterbore of hub (1G).



3-84 3121139


4. Returning the hub (1G) to locate on the large diameter end, the output shaft (1A) is carefully installed into the hub (1G).




5. The shaft seal (1B) is installed over the output shaft (1A) and into the counterbore of the hub (1G). Care should be taken to insure the seal (1B) is being correctly installed (smooth face up and located just flush with the counterbore face).




6. The bearing cone (1F) is an interference fit and has to be pressed or tapped on.



7. Pipe plugs (1J & 1K) should be checked and/ or installed at this time in the assembly.



8. Bearing spacer (1H) is installed around the output shaft (1A) and locates on bearing cone (1F).



9. Retaining ring (1I) installed into groove provided in the output shaft (1A). This retaining ring (1I) should never be reused in a repair or rebuild.




EYE PROTECTION SHOULD BE WORN DURING THIS PROCEDURE.




10. A soft metal punch should be used to ensure that this retaining ring (1I) is completely seated in the groove of the output shaft (1A).

▲ CAUTION

EYE PROTECTION SHOULD BE WORN DURING THIS PROCEDURE.



11. Upon completion of step 10, rap the internal end of the output shaft (1A) twice with a piece of soft metal rod. This will release the preload which was on the bearings.




This completes the hub shaft sub-assembly —items (1A) through (1J). If this assembly is not going to be used right away, it should be oiled and covered to help prevent rusting,

Carrier Sub-Assembly

 Apply a coat of grease or petroleum jelly to cluster gear bore.



2. Place sixteen needle rollers into cluster gear bore.



3. Place spacer washer into opposite side of cluster gear and against needle rollers.



3-86 3121139

4. Place second set of sixteen needle rollers into cluster gear.




5. Apply grease or petroleum jelly to the tang side of two thrust washers. Place thrust washers against bosses in carrier with washer tang fitting into slot in carrier outside diameter.


NOTE: Some old style carriers will not have slots and tangs should be located inside boss relief.



6. While keeping thrust washers in place, slide cluster gear into carrier with the larger gear on the side with the small pin hole.




7. Line up cluster gear and thrust washer with hole in carrier and slide planet shaft through. Line up chamfered side of hole in planet shaft with pin hole in carrier.



8. Drive anti-roll pin flush into carrier hole, thereby locking planet shaft into place.

Repeat these steps for remaining two cluster gears to complete carrier assembly.






Figure 3-61. Swing Drive (Prior to SN 0300066417)

3-88 3121139

3.16 SWING DRIVE BRAKE - MICO (PRIOR TO SN 0300066417)

Disassembly

1. Remove pressure plate (3) from cover plate (16) by removing capscrews (1) and washers (2).

A CAUTION

PRESSURE PLATE IS UNDER SPRING TENSION OF APPROXIMATELY 2000 LBS (907 KGF). THE TWO CAPSCREWS MUST BE LOOSENED EVENLY TO RELIEVE THIS FORCE. IF A HYDRAULIC PRESS IS AVAILABLE, 3000 LBS (1361 KGF) MINIMUM, THE PRESSURE PLATE CAN BE HELD IN POSITION WHILE REMOVING THE CAPSCREWS. COVER PLATE (16) MUST BE SUPPORTED AS SHOWN IN FIGURE 3-9.

- 2. Remove case seal (4) from cover plate (16).
- 3. Remove piston (7) from pressure plate (3).
- **4.** Remove o-ring (5), backup ring (6), o-ring (8) and backup ring (9) from piston (7).
- **5.** Remove stator disc (11), rotor disc (12) and return plate (13) from cover (16).
- Remove dowel pins (15) and springs (14) from cover plate (16). Record this information for assembly purposes.
- **NOTE:** Not all models use the same number of springs or spring pattern. Record this information for assembly purposes.
 - **7.** Remove retaining ring (19) from cover plate (16).
 - **8.** Remove shaft (10) by pressing or using a soft mallet on male end of shaft (10).
- **NOTE:** Cover plate (16) must be supported as shown in Figure 3-62.
 - **9.** Remove retaining ring (20) from cover plate (16) and press out oil seal (17) and bearing (18) if required.

NOTE: Cover plate (16) must be supported as indicated in Figure 3-62.

Assembly

NOTICE

LUBRICATE ALL RUBBER COMPONENTS FROM REPAIR KIT WITH CLEAN TYPE FLUID USED IN THE SYSTEM.

- 1. Use an alkaline wash to clean parts before assembly.
- 2. Press oil seal (17) into cover plate (16) until it is flush with bearing shoulder. Note direction of seal.
- **3.** Press bearing (18) into position until it bottoms out on borestep.


NOTE: Cover plate (16) must be supported as indicated in Figure 3-62.

- **4.** Install retaining ring (20) in cover plate (16).
- **5.** Press shaft (10) into bearing (18) until it bottoms on shoulder.

NOTE: Bearing (18) inner race and cover plate (16) must be supported as indicated in Figure 3-62. during this operation.

- 6. Install retaining ring (19) on shaft (10).
- Insert dowel pins (15) and springs (14) in cover plate (16).

NOTE: Be sure to use the same number of springs and spring pattern as recorded during disassembly.



- **NOTE:** Start with the red springs and space them as evenly as possible throughout the spring retainer, then take the first blue spring and put it in any one of the remaining empty holes, second blue spring should be placed as directly across from the first blue spring as possible.
 - **8.** Position return plate (13) on springs (14).
- **NOTE:** Discs (11 & 12) and return plate (13) must remain dry during installation. No oil residue must be allowed to contaminate disc surfaces.
 - 9. Install rotor disc (12) and stator disc (13).
 - **10.** Install o-ring (5), backup ring (6), o-ring (8) and backup ring (9) on piston (7). Note order of o-rings and backup rings. Insert piston (7) into pressure plate (3).
- **NOTE:** Be careful not to shear o-rings or backup rings. Be careful not to scratch or mar piston.


- 11. Install new case seal (4) in cover plate (16).
- **12.** Position pressure plate (3) on cover plate (16) aligning dowel pins (15) with holes in pressure plate.
- **13.** Install capscrews (1) and washers (2) and tighten evenly to draw pressure plate (3) to cover plate (16). Torque capscrews 48-50 ft. lbs. (65.1-67.8 Nm).

NOTE: A hydraulic press will simplify installation of pressure plate on cover. Clamp pressure plate in position while tighten¦ing the capscrews. Cover plate (16) must be supported as indicated in Figure 3-9.

▲ CAUTION

IF HYDROSTATIC BENCH TESTING IS PERFORMED ON THE BRAKE ASSEMBLY, RELEASE PRESSURE MUST NOT EXCEED 500 PSI (134.5 BAR).

3-90 3121139



- Capscrew
 Washer
- 3. Pressure Plate4. Case Seal
- 5. 0-ring
- 6. Backup Ring
- 7. Piston
- 8. O-ring
- 9. Backup Ring10. Shaft
- 11. Stator Disc
- n 12. Rotor Disc
 - 13. Return Plate14. Springs
 - 15. Dowel Pin
- 16. Cover Plate
- 17. Oil Seal
- 18. Bearing
- 19. Retaining Ring
- 20. Retaining Ring

Figure 3-62. Swing Drive Brake - Mico (Prior to SN 0300066417)

Bleeding

- 1. Install brake in system and connect pressure lines.
- **2.** Bleed pressure release section of brake by pressurizing side inlet port and allowing air to escape from top port.
- Pressure should not exceed 6.9 bar (100 psi) during bleeding.
- **3.** Apply sufficient pressure to release brake and check for proper operation in system.

Table 3-9. Troubleshooting

| PROBLEM | CAUSE | EXPLANATION | ACTION |
|-------------------------|--|--|--|
| Brakeslips | Excessive pressure in hydraulic system | If there is back pressure in the actuation line of the brake, holding torque will be reduced. | Check filters, hose size, restrictions in other hydraulic components. |
| | Oil in brake if designed for dry use | Wet linings generate 67% of the dry torque rating. If the brake has oil in it, check the type of oil hydraulic or gearbox. 1. Gearbox oil 2. Hydraulic oil | Replace oil seal in brake. Check motor seal Check piston seals NOTE: Internal components will need to be inspected, cleaned and replaced as required. |
| | Disc plates worn | The thickness of the disc stack sets the torque level. A thin stack reduces torque. | Check disc thickness. |
| | Springs broken or have taken a permanent set | Broken or set springs can cause reduced torque - a rare occurrence. | Check release pressure. (See spring replacement). |
| Brake drags or runs hot | Low actuation pressure | The brake should be pressurized to minimum of 1.38 bar (20 psi) over the full release pressure under normal operating conditions. Lower pressures will cause the brake to drag thus generating heat. | Place pressure gauge in bleed port & check pressure with system on. |
| | Bearing failure | If the bearing should fail, a large amount of drag can be generated. | Replace bearing. |
| Brake will not release | Stuck or clogged valve | Brakes are designed to come on when system pressure drops below stated release pressure. If pressure cannot get to brake, the brake will not release. | Place pressure gauge in bleed port - check for adequate pressure. Replace inoperative line or component. |
| | Bad o-rings | If release piston will not hold pressure, brake will not release. | Replace o-rings. |
| | Discs frozen | These brakes are designed for only limited dynamic braking. A severe emergency stop or prolonged reduced release pressure operation may result in this type of damage. | Replace disc stack. |


3-92 3121139

3.17 SWING MOTOR (PRIOR TO SN 0300066417)


Disassembly

Cleanliness is extremely important when repairing these motors. Work in a clean area. Before disconnecting lines, clean port area of motor. Remove key when used. Check shaft and key slot. Remove burrs, nicks and sharp edges. Before disassembly, drain oil from motor. Then plug ports and thoroughly clean exterior of motor.


Although not all drawings show motor in a vise, we recommend that you keep the motor in a vise during disassembly. Follow the clamping procedures explained throughout the manual.




1. Place motor in vice and clamp across edge of flange with output shaft down. When clamping, use protective device on vice such as special soft jaws, pieces of hard rubber or board.



- 2. remove capscrews and seal washers.
- 3. Remove end cap.
- **4.** Remove seal from end cap.




- 5. Remove gerotor.
- **5.** Remove seal from gerotor.
- 7. Remove drive spacer if applicable.



- 8. Remove drive.
- 9. Remove spacer plate.
- 10. Remove seal from housing.
- Remove output shaft from housing.

12. Remove needle thrust bearing from shaft or housing.




- **13.** Reposition motor in vise. Clamp across ports as shown above. Do not clamp side of housing. Excessive clamping pressure on side of housing causes distortion.
- **14.** Remove capscrews from mounting flange. These screws are assembled with Loctite to hold them in place.

The screws will require 300-400 in. lbs. (35-45 Nm) of torque to break loose and 100 in. lbs. (11 Nm) torque to remove. Do not use impact wrench on screws that have been secured with Loctite. This could result in rounded heads or broken sockets.

NOTE: If torque higher than given above is required to break screws loose, apply heat according to following instructions.


NOTE: When heated, Loctite partially melts. This reduces the torque required to remove screw. Use small flame propane torch to heat small area of housing where screw enters (see figure below). Be careful not to overheat housing and damage motor. Gradually apply torque to screw with socket wrench as heat is applied for 8 to 10 seconds. As soon as screw breaks loose, remove heat from housing. Continue turning screw until it is completely removed.



15. Carefully remove flange from housing.

NOTICE

SOME MOTORS MAY HAVE A QUAD SEAL AND BACKUP RING IN PLACE OF THE PRESSURE SEAL. THE QUAD SEAL AND BACKUP RING ARE NO LONGER AVAILABLE AND ARE REPLACED BY THE PRESSURE SEAL. THEY ARE INTERCHANGEABLE, BUT SOME PRECAUTIONS MUST BE TAKEN TO INSURE PROPER INSTALLATION. FOLLOW THE REASSEMBLY INSTRUCTIONS.





16. Exclusion seal, backup ring, pressure seal and seal will come off with flange. Use seal removal tool as shown to remove exclusion and pressure seals.

NOTICE


BE CAREFUL NOT TO SCRATCH SEAL CAVITY O.D. THIS COULD CREATE A LEAK PATH.

3-94 3121139





Work from outer side for both (either) Seals.



17. A metal plug, with seal, plugs a machining hole in the housing. It is not necessary to remove plug and replace seal unless leakage occurs around plug. To remove plug, insert 5 mm (.187 in.) hex key through port opening and push it out. The 009 plug is not interchangeable with 007 and 008 plugs.

Inspection and Cleaning

Check all mating surfaces. Replace any parts with scratches or burrs that could cause leakage or damage. Clean all metal parts in clean solvent. Blow dry with air. Do not wipe parts with cloth or paper towel because lint or other matter could get into the hydraulic system and cause damage.

Check around key slot and chamfered area of shaft for burrs, nicks or sharp edges that could damage seals during reassembly. Remove nicks or burrs with hard smooth stone (such as an Arkansas stone). Do not file or grind motor parts.

NOTE: Lubricate all seals with petroleum jelly. Use new seals when reassembling motor.

NOTICE

DO NOT STRETCH SEALS BEFORE INSTALLING THEM.

Cleanliness is extremely important in the successful application of Loctite. Before Loctite can be applied, the parts should be cleaned as follow:


NOTE: Fully cured Loctite resists most solvents, oils, gasoline and kerosene and is not affected by cleaning operations. It is not necessary to remove cured Loctite that is securely bonded in tapped holes; however, any loose particles of cured Loctite should be removed.

- a. Wash the housing with solvent to remove oil, grease and debris. Pay particular attention to four tapped holes on flanged end.
- **b.** Blow dry with compressed air. Clean and dry tapped holes.
- **c.** Wire brush screw threads to remove cured Loctite and other debris. Discard any screws that have damaged threads or rounded heads.
- **d.** Wash screws with non-petroleum base solvent. Blow dry with compressed air.

Assembly

SHAFT END

 If you remove plug and seal, lubricate seal and install on plug. Some plugs have two o-ring grooves but require only one o-ring. Install o-ring in groove closest to end of plug. Push plug into housing. Be careful not to damage seal.






Lubricate output shaft with hydraulic oil, then install shaft in housing.

NOTICE

DO NOT PERMIT OIL TO GET INTO THE FOUR TAPPED HOLES.

3. Install needle thrust bearing, then bearing race on shaft. Pull shaft partially out of housing. Push all three parts in housing together. The bearing race must rotate freely when in position.



No. 600470 (007 Motors) No. 600523 (008, 009 Motors)

- Install exclusion seal in flange. Carefully press exclusion seal into place.
- **5.** Visually check seal seat in mounting flange for scratches or other marks that might damage the pressure seal. Check for cracks in flange that could cause leakage.
- 6. Lubricate I.D. of seal tube and O.D. of shaft pressure seal with light film of petroleum jelly. Align small I.D. end of seal tube with seal seat in mounting flange. Install backup ring and pressure seal in tube with lip seal face up. Insert seal driver in tube and firmly push seal seat with a rotating action.

NOTICE

AFTER INSTALLING SEAL IN FLANGE, EXAMINE SEAL CONDITION. IF DAMAGED OR IMPROPERLY INSTALLED, YOU MUST REPLACE IT BEFORE CONTINUING WITH REASSEMBLY.


- 7. Install 49 mm (1.937 in.) I.D. seal in flange.
- **8.** It is recommended to apply a light coat of Loctite Primer NF in tapped holes of housing. Allow primer to dry for at least 1 minute. Do not force dry with air jet; the primer will blow away.

Use of primer is optional. With primer, curing time is approximately 15 minutes. Without primer curing time is approximately 6 hours.

3-96 3121139


Place tip of applicator at top of threaded portion.

Apply 3 or 4 drops in each hole.




9. Apply 3 or 4 drops of Loctite sealant at top of threads for each of the four holes in housing. Do not allow parts with Loctite applied to come on contact with metal parts other than those for assembly. Wipe off excess Loctite from housing face, using a non petroleum base solvent.

Do not apply Loctite to threads more than 15 minutes before installing screws. If housing stands for more than 15 minutes, repeat application. No additional cleaning or removal of previously applied Loctite is necessary.



10. Before installing flange and seal assembly over shaft, place protective sleeve or bullet over shaft. Then lubricate space between exclusion seal and pressure seal, as well as lips of both seals.

Install flange. Rotate flange slowly while pushing down over shaft. Be careful not to invert or damage seals.



11. After removing bullet, clamp motor in vise as shown above. Make sure shaft cannot fall out. Install dry screws and alternately torque them immediately to 250 in. lbs. (28 Nm). If you use primer, allow to cure 10 to 15 minutes. Without primer, allow 6 hours curing time before subjecting to high torque reversals. On all other applications, you can run motor immediately.

If you use new screws, make sure they are correct length: 22 mm (0.875 in.) under head length. See parts book for correct part number.

GEROTOR END

1. Reposition motor with gerotor end up, then clamp across ports. Do not clamp on side of housing.

NOTICE

TO AID INSTALLATION OF SEALS, APPLY LIGHT COAT OF CLEAN PETROLEUM JELLY TO SEALS. DO NOT STRETCH SEALS BEFORE INSTALLING THEM IN GROOVE.

- **2.** Pour approximately 35 cc of clean hydraulic oil in output shaft cavity.
- **3.** Install 73 mm (2.875 in.) I.D. seal in housing seal groove. Avoid twisting seal.


Timing Procedure

a. Install drive. Use felt tip marker to mark or drive tooth. Align this tooth with timing dot on shaft.


NOTE: If drive is not symmetrical, install larger splined end into shaft.

- **b.** Install spacer plate.
- **c.** Install 73 mm (2.875 in) I.D. seal in gerotor seal groove. Carefully place gerotor on spacer plate, seal side toward spacer plate.


Standard rotation align any star point with tooth marked on drive (see figure below).



Reverse rotation align any star valley with marked tooth (see figure below).




- **1.** Rotate gerotor to line up with bolt holes. Be careful not to disengage star from drive or disturb gerotor seal.
- 2. Install drive spacer if applicable.
- **3.** Install 73 mm (2.875 in.) seal in end cap. Carefully place end cap on gerotor.



4. Install capscrews and seal washers (if applicable) in end cap. Pre-tighten screws to 40 in. lbs. (7.4 Nm). Make sure seal washers are properly seated. Then torque screws to 235-250 in. lbs. (27-28 Nm) in sequence, as shown above.

3-98 3121139



- 1. Capscrew
- **Exclusion Seal** 2.
- Mounting Flange 3.
- Backup Ring (-008, -009 Motors)
- 5. Pressure Seal
- 6. Seal
- 7. Bearing Race
- 8. Needle Bearing Thrust
- 9. Output Shaft
- 10. Seal Washer (When Applicable)
- 11. Capscrew
- 12. Plug/0-ring S/A
- 13. End Cap
- 14. Seal

- 15. Drive Spacer (When Applicable)
- 16. Geroter
- 17. Seal
- 18. Spacer Plate
- 19. Drive
- 20. Seal
- 21. Housing
- 22. Plug
- 23. Seal
- 24. Plug/O-ring S/A (End Ported Motors)
- 25. 0-ring
- 26. 0-ring
- $27. \quad Optional-Base\,Block\,Mounting\,Kit$
- 28. Capscrew

Figure 3-63. Swing Motor (Prior to SN 0300066417)

3121139 3-99

3.18 SWING DRIVE (SN 0300066417 THROUGH 0300182743, B300000100 THROUGH B300001091)

Roll, Leak And Brake Testing

Drive Hub units should always be roll and leak tested before disassembly and after assembly to make sure that the unit's gears, bearings and seals are working properly. The following information briefly outlines what to look for when performing these tests.

NOTE: The brake must be released before performing the roll test. This can be accomplished by either pressure testing using the Brake Leak Test procedure below or by tightening the 12 bolts into the piston through the end plate (See Brake Disassembly Procedure).

NOTE: Bolts must be removed while performing brake release test.

Roll Test

The purpose of the roll test is to determine if the unit's gears are rotating freely and properly. You should be able to rotate the gears in your unit by applying constant force to the roll checker. If you feel more drag in the gears only at certain points, then the gears are not rolling freely and should be examined for improper installation or defects. Some gear packages roll with more difficulty than others. Do not be concerned if the gears in your unit seem to roll hard as long as they roll with consistency. Release the pressure at the Brake Housing (6) and remove the test fixtures.

Leak Test (Main Unit)

The purpose of a leak test is to make sure the unit is air tight. You can tell if your unit has a leak if the pressure gauge reading on your air checker starts to fall after the unit has been pressurized and allowed to equalize. Leaks will most likely occur at the pipe plugs, the main seal or wherever o-rings or gaskets are located. The exact location of a leak can usually be detected by brushing a soap and water solution around the main seal and where the o-rings or gaskets meet on the exterior of the unit, then checking for air bubbles. If a leak is detected in a seal, o-ring or gasket, the part must be replaced, and the unit rechecked. Leak test at 10 psi (0.7 bar) for 20 minutes.

Brake Test


The brake test must be performed with the Motor removed and the Brake Test Plate (T-214404) installed. Install the Hex Bolts through Brake Test Plate and torque to 80-100 ft. lbs. (108-135 Nm). Install Roll Checking Tool (T-212731) and apply 210 psi (14 bar) to the o-ring port in the side of the Brake Housing. The roll checking fixture should roll freely. Increase the pressure to 3000 psi (207 bar) and perform the Roll Test.

NOTE: Failure to perform this lest may result in damaged or ineffective brake parts.

Tightening and Torquing Bolts

If an air impact wrench is used to tighten bolts, extreme care should be taken to ensure that the bolts are not tightened beyond their specified torque.

The following steps describe how to tighten and torque bolts or socket head capscrews in a bolt circle.




- 1. Tighten (but do not torque) bolt "A" until snug.
- **2.** Go to the opposite side of the bolt circle and tighten bolt "B" until equally snug.
- 3. Crisscross around the bolt circle and tighten remaining
- Now use a torque wrench to apply the specified torque to bolt "A".
- 5. Using the same sequence, crisscross around the bolt circle and apply an equal torque to the remaining bolts.

3-100 3121139

Motor Control Valve Disassembly

NOTE: Refer to Figure 3-64., Motor Control Valve.

- 1. Place unit on bench with the motor end up.
- Remove O-ring Plug (1P) and drain the oil from the gearbox.
- **3.** Remove Hydraulic Tubing Assembly (35) by loosening fittings on both ends of tube with a wrench.
- **4.** Using a wrench, loosen jam nuts on Elbow Fittings (30) and remove fittings from Brake (6) and Motor Control Valve (32).
- **5.** Remove O-ring Plugs (23) from Motor Control Valve (32).
- **6.** Remove Motor Control Valve (32) from Motor (31) by removing the four Bolts (21) and washers (22).



- 1P. O-ring Plug
- 6. Hydraulic Brake
- 21. Hex Bolt
- 22. Lockwasher
- 23. Plug

- 30. Elbow Fitting
- 31. Hydraulic Motor
- 32. Motor Control Valve
- 35. Hydraulic Tubing

Figure 3-64. Motor Control Valve

Motor and Brake Disassembly

NOTE: Refer to Figure 3-65., Motor and Brake.


- 1. With unit resting on bench with Motor (31) end up, loosen Hex Bolts (29) and remove Lift Lugs (28) from the Motor (31).
- **2.** Pull Motor (31) straight up and remove Motor (31) from Brake Housing (6).
- **3.** Remove O-ring (26) from between Motor (31) and Brake Housing (6).

- **4.** Remove the Springs (8L) from the piston.
- 5. Apply less than 50 psi (3.45 bar) air to the "brake port" to remove Brake Piston (8A).

A CAUTION

THE PISTON MAY MOVE QUICKLY. EYE PROTECTION SHOULD BE WORN DURING THIS PROCEDURE.

6. Remove Rotors (8J) and Stators (8K) from Brake Housing (6).



6. Brake Housing
8A. Brake Piston
8L. Spring
8J. Rotors
81. Motor
82. Lift Lug
83. Motor
84. Lift Lug
85. Motor
86. O-ring
87. Lift Lug
88. Lift Lug
89. Hex Bolt
81. Motor

8K. Stator

Figure 3-65. Motor and Brake


3-102 *3121139*

Main Drive Disassembly

NOTE: Refer to Figure 3-66., Main Drive Assembly.

- 1. Remove Sun Gear (8) with Retaining Ring (44) inside.
- **2.** With the unit resting on the Output Shaft (Pinion) (1A), remove the Bolts (12) from the Brake Housing (6).
- 3. Remove the Brake Housing (6) from the main assembly.
- **4.** Remove O-ring (5A) from between Brake Housing (6) and Ring Gear (4).

- **5.** Remove Thrust Washer (11) from between Brake Housing (6) and Carrier Subassembly.
- 6. Remove Ring Gear (4) from Housing (1G).
- **7.** Remove O-ring (5) from between Ring Gear (4) and Housing (1G).
- 8. Remove Carrier Sub-Assembly.
- **9.** Remove Thrust Washer (11) from between Carrier Sub-Assembly and Internal Gear (2).
- 10. Remove Internal Gear (2).



- 1A. Output Shaft (Pinion)
- 1G. Housing
- 2. Internal Gear
- 3F. Carrier subassembly
- 4. Ring Gear
- 5. 0-ring
- 5A. O-ring
- 6. Brake Housing
- 8. Sun Gear
- 11. Thrust Washer
- 12. Bolt
- 13. Dowel Pin
- 20. Pipe Plug
- 44. Ring

Figure 3-66. Main Drive Assembly

Hub-Shaft Disassembly

NOTE: Refer to Figure 3-67., Hub-Shaft.

1. Using retaining ring pliers remove Retaining Ring (11) from groove in Output Shaft (1A) and discard.

A CAUTION


EYE PROTECTION SHOULD BE WORN DURING THIS PROCEDURE.

- 2. Remove Thrust Washer (1H).
- **3.** While supporting the Housing (1G) on the Output Shaft (1A) end, press the Output Shaft (1A) out of the Housing (1G).

NOTE: The Lip Seal (1B) will be pressed out of the Housing (1G) by the Bearing Cone (1D) during this step.

- 4. Remove the Bearing Cone (1E) from the Housing (1G).
- **5.** Use a bearing puller to remove the Bearing Cone (1D) from the Shaft (1A).
- **6.** Bearing Cups (1C & 1F) will remain in Housing (1G)

NOTE: If bearing replacement is necessary, the Bearing Cups (1C & 1F) can be removed with a slide hammer puller or driven out with punch.



- 1A. Output Shaft
- 1B. Lip Seal
- 1C. Bearing Cup
- 1D. Bearing Cone
- 1E. Bearing Cone
- 1F. Bearing Cup
- 1G. Housing
- 1H. Thrust Washer
- 11. Retaining Ring

Figure 3-67. Hub-Shaft

3-104 *3121139*


Carrier Disassembly

NOTE: Refer to Figure 3-68., Carrier.

1. Using a 3/16" punch drive the Roll Pin (3G) which holds the Planet Shaft (3E) in the Carrier (3A) down into the Planet Shaft (3E) until it bottoms.

NOTE: Make sure that the Roll Pin has bottomed. Otherwise, damage to the carrier could occur when the Planet Shaft is removed.

- 2. Remove the Planet Shaft (3E) from the Carrier (3A). Use a small punch to remove the Roll Pin (3D) from the Planet Shaft (3E).
- **3.** Slide the Planet Gear (3F), the two Thrust Washers (3B) out of the Carrier (3A).
- **4.** Remove both rows of Needle Bearings (3C) and the Spacer (3D) from the bore of the Planet Gear (3F).
- **5.** Repeat Steps 1 through 4 for the remaining two Cluster Gears (3F).



- 3A. Carrier
- 3B. Thrust Washers
- 3C. Needle Bearing
- 3D. Spacer

- 3E. Planet Shaft
- 3F. Cluster Gear
- 3G. Roll Pin

Figure 3-68. Carrier

Hub-Shaft Assembly

NOTE: Refer to Figure 3-67., Hub-Shaft.

- Press Bearing Cup (1C) into Housing (1G) taking care to ensure cup starts square with the bore of Hub (1G).
- 2. Place Bearing Cone (1D) in Bearing Cup (1C) in Housing (1G).
- 3. Press or tap Seal (1B) Into the counterbore of Housing (1G) to the point where it becomes flush with the Housing (1G) face. Care should be taken to insure Seal (1B) is being correctly installed (smooth face up). Apply grease to the rubber portion of the seal bore.
- **4.** Invert Hub (1G) and press Bearing Cup (1E) into counterbore of Housing (1G).
- Carefully lower Housing (1G) onto the Output Shaft (1A) until Bearing Cone (1D) contacts the Output Shaft (1A).
- 6. Press on the small end of the Bearing Cone (1D), being careful not to contact the bearing cage, until the Bearing Cone (1D) seats on the shoulder of the Output Shaft (1A).
- **7.** Start the Bearing Cone (1F) onto the Output Shaft (1A).
- Press or tap the Bearing Cone (1F) onto the Output Shaft (1A) until it is just seated in the Bearing Cup (1E). while rotating the Housing (G).
- 9. Install Bearing Spacer (1H) onto Output Shaft (1A) and against Bearing Cone (1F).
- 10. Install Retaining Ring (1I) into the groove in the Output Shaft (1A). This Retaining Ring (1I) should never be reused in a repair or rebuild.

▲ WARNING

EYE PROTECTION SHOULD BE WORN DURING THIS PROCEDURE.

11. Tap the Retaining Ring (1I) with a soft metal punch to ensure that the Retaining Ring (1I) is completely seated in the groove of the Output Shaft (1A).

A WARNING

EYE PROTECTION SHOULD BE WORN DURING THIS PROCEDURE.

12. Install O-ring Plug (1P) and torque to 23-24 ft. lbs. (31-32 Nm).

Carrier Assembly

NOTE: Refer to Figure 3-68. Carrier.

- 1. Apply a liberal Coat of grease to the bore of Cluster Gear (3F). This will enable the Needle Rollers (3C) to be held in place during assembly.
- 2. Install the first row of Needle Rollers (3C) into the bore of Cluster Gear (3F).
- **3.** Insert Spacer (3D) into bore of Cluster Gear (3F) on top of the Needle Rollers (3C).
- **4.** Place second row of Needle Rollers (3C) into bore of Cluster Gear (3F) against Spacer (3D).
- **5.** Place Carrier (3A) so that one of the roll pin holes is straight up.
- **6.** Start Planet Shaft (3E) through the hole in Carrier (3A). Using ample grease to hold it in position, slide one Thrust Washer (3B) over the Planet Shaft (3E) with the tang resting in the cast slot of the Carrier (3A).
- 7. With large end of Cluster Gear (3F) facing the roll pin hole in the Carrier, place the Cluster Gear into position in carrier (3A) and push Planet Shaft (3E) through the Cluster Gear (3F) without going all the way through.
- **8.** Slide the second Thrust Washer (3B) between the Cluster Gear (3F) and the Carrier (3A) with the tang of the washer located in the cast slot of the Carrier (3A). Finish sliding the Planet Shaft (3E) through the Thrust Washer (3B) and into the Carrier (3A).
- 9. Position the non-chamfered side on the Planet Shaft (3E) roll pin hole so that it is in line with the hole in the Carrier (3A) using a 1/8" (3 mm) diameter punch.
- 10. After using a 3/16" (5 mm) punch to align the two roll pin holes. Drive the Roll Pin (3G) through Carrier (3A) and into the Planet Shaft (3E) until the Roll Pin (3G) is flush with the bottom of the cast slot in the Carrier (3A) outside diameter at the thrust washer (3B) tang. Use a 1/4" (6 mm) pin punch to make sure the Roll Pin (3G) is flush in the slot.
- **11.** Repeat Steps 1 through 10 for the remaining two Cluster Gears(3F).

3-106 3121139

Main Drive Assembly

NOTE: Refer to Figure 3-66., Main Drive Assembly.

- 1. With the Hub Shaft Sub-Assembly resting on the Shaft (1A) install Internal Gear (2). The spline of the Internal Gear (2) bore will mesh with the spline of the Output Shaft (1A). This will be a tight fit.
- **2.** Inspect the location of the Internal Gear (2) on the Output Shaft (1A). The portion of the Output Shaft (1A) should protrude through the Internal Gear (2) bore.
- Install 4 Dowel Pins (13) into counterbore holes in Hub (IG).
- Install Thrust Washer (11) in counterbore of Carrier Sub-Assembly (Small Cluster-Gear end) Use grease to hold in place.
- **5.** Place O-ring (5) into Hub counter-bore. Use grease to hold o-ring in place.

▲ WARNING

BEWARE OF SHARP EDGES OF THE COUNTERBORE WHILE SEATING THIS ORING.

- 6. Place Carrier Sub-Assembly on bench with the large end of Cluster Gears (3F) facing up with one at the 12 o'clock position. Find the punch marked tooth on each gear at the large end and locate at 12 o'clock (straight up) from each planet pin. Marked tooth will be located just under the Carrier on upper two gears. Check the timing through the slots in the carrier (See Carrier Sub-Assembly).
- 7. With large shoulder side of Ring Gear (4) facing down, place Ring Gear (4) over (into mesh with) cluster gears (3F). Be sure that cluster gear timing marks (punch marks) remain in correct location during Ring Gear (4) installation. The side of the Ring Gear (4) with an "X" or punch mark stamped on it should be up.
- **8.** While holding Ring Gear (4) and Cluster Gears (3F) in mesh, place small end of Cluster Gears (3F) into mesh with the Internal Gear (2). On the Ring Gear (4) locate the hole marked "X", or punch marked, over one of the marked counter-bored holes (Step 5) in Hub (1G). Check timing through the slots in the carrier. Rotate carrier in assembly to check for freedom of rotation.

NOTE: If gears do not mesh easily or Carrier Assembly does not rotate freely, then remove the Carrier and Ring Gear and check the Cluster Gear timing.

- **9.** Install Thrust Washer (11) into the counterbore on the face of the carrier. Use grease to hold in place.
- **10.** Place O-ring (5A) into counterbore of Brake Housing (6). Use grease to hold o-ring in place.

A CAUTION

BEWARE OF SHARP EDGES OF THE COUNTER-BORE WHILE SEATING THIS ORING.

- **11.** Install the Brake Housing (6), taking care to correctly align Pipe Plug hole (20) with those in the Hub (I G).
- **12.** Install Bolts (12) through the Brake Housing (6) into the Hub (1G) and torque to 23-27 ft. lbs. (31-37 Nm).
- **13.** With gearbox standing on the pinion end fill gearbox with 43 oz. of ISO VG150/VG220 gear Oil.
- **14.** Install Retaining Ring (44) into the groove in the Sun Gear (8).
- **15.** Install the Sun Gear (8) into mesh with the Planet Gears (3F).
- **16.** Install Pipe Plug (20) into Cover (6) torque to 23-24 ft. lbs. (31-32 Nm).

Motor and Brake Assembly

NOTE: Refer to Figure 3-65., Motor and Brake.

- 1. Alternate Stators (8K) (O.D. lobes) with Rotors (8J) (I.D. splines) into bore of Brake Housing (6). starting with a Stator (8K) and ending with a Stator (8K).
- 2. Grease the o-rings (8F) & (8D) and backup rings (8H) & (8E). and place them in their respective grooves in the Brake Housing (6) and Piston (8A). Make sure the backup rings are correctly positioned.
- **3.** Apply grease sparingly to the Piston O.D. (8A) and the bore of the Brake Housing (6). Insert Piston (8A) into Brake Housing (6) be sure not to damage the o-rings.
- Install Springs (8L) into the spring pockets of the Piston (8A).
- Test the brake and perform the roll test. Remove the Brake Test Plate.
- **6.** Install the O-ring (26) onto the pilot of the Motor (31), use grease to keep the o-ring in place.
- 7. Place Motor (31) into Brake pilot, and line up holes.
- **8.** Assemble Lift Lugs (28) onto Hex Bolts (29). Assemble Hex Bolts (29) with Lift Lugs (28) through the Motor (31) and Brake (6) against Motor flange. Torque to 80-100 ft. lbs. (108-136 Nm).

Motor Control Valve Assembly


NOTE: Refer to Figure 3-64., Motor Control Valve.

 Lay assembly down with motor ports facing up. Remove the two plastic plugs in the motor ports, being careful not to lose the o-ring in each port. Assemble the Motor control Valve (32) onto the Motor (31) with Bolt (21) and Lock Washers (22). Torque Bolts (21) to 23-27 ft. lbs. (31-37 Nm).

NOTE: Be sure to align the holes in the control valve with the motor ports.


- **2.** Install Elbow Fittings (30) into Brake (6). Do not tighten jam nuts.
- **3.** Install Elbow Fittings (30) into Motor Control Valve (32). Do not tighten jam nuts.
- **4.** Assemble Tube (35) into Elbow Fittings (30) and torque to 13-15 ft. lbs (18-20 Nm). Tighten the jam nuts on the Elbow Fittings (30) and torque to 13-15 ft. lbs. (18-20 Nm).
- Install one O-ring Plug (23) into Motor Control Valve (32) and torque to 30-31 ft. lbs. (41-42 Nm).
- 6. Pressure test brake, tube and control valve connections by applying 3000 psi (207 bar) pressure to the open port in the Motor Control Valve (32) and holding for 1 minute. Check for leaks at the control-valve-motor interface and the tube connections. Release pressure and install the remaining O-ring Plug (23) into Motor Control Valve (32) and torque to 30-31 ft. lbs. (41-42 Nm).

3-108 3121139



- 1A. Output Shaft
- 1B. Lip Seal
- 1C. Bearing
- 1D. Bearing
- 1G. Housing
- 1H. Thrust Washer
- 11. Retaining Ring
- 1J. Pipe Plug
- 2. Internal Gear
- 3. Carrier Assembly
- 4. Ring Gear
- 5. 0-Ring
- 5A. O-Ring
- 6. Brake Housing
- 8. Sun Gear
- 11. Thrust washer
- 12. Bolt
- 13. Dowel Pin
- 20. Pipe Plug
- 44. Internal Retaining Ring

Figure 3-69. Swing Drive Assembly



- 6. Brake Housing
 8A. Piston
 8D. 0-Ring
 8E. Backup Ring
 8F. 0-Ring
 8H. Backup Ring
 8J. Rotor Disc
 8K. Stator Disc
- 8L. Spring21. Thrust Washer22. Lock washer23. Pipe Plug26. 0-Ring
- 23. Pipe Plug26. 0-Ring28. Lifting lug29. Bolt30. Elbow
- 35. Tube
 101. Bolt
 102. End Cover
 103. Commutator Seal
 104. Ring Seal
- 103. Commutator Seal104. Ring Seal105. Commutator and Ring Assy106. Ring107. Manifold
- 108. Rotor Set109. Wear Plate110. Drive Link112. Coupling Shaft113. Inner Bearing
- 113. Inner Bearing114. Thrust Washer115. Thrust Bearing116. Inner Seal
- 117. Backup Washer
- 118. Housing
- 119. Outer Bearing
- 120. Seal
- 125. Backup Washer

Figure 3-70. Swing Motor and Brake Assembly

3-110 *3121139*

3.19 SWING DRIVE BRAKE (SN 0300066417 THROUGH 0300182743, B300000100 THROUGH B300001091)

Disassembly

 Supporting brake: remove the six socket head capscrews and washers (13 & 14) in equal increments to ensure the spring pressure within the brake is reduced gradually and evenly.

If a press is available, the cylinder housing (8) can be restrained while removing the six capscrews and washers (13 & 14).

The brake assembly can now be fully dismantled and the parts examined.

- 2. Remove cylinder housing (8) and piston (9) subassembly and dismantle if required, removing o-ring seals (15 & 17) and backing rings (16 & 18) as necessary.
- 3. Remove gasket (7) from housing (2).
- 4. Remove friction plates (3 & 6) and pressure plate (4).
- 5. Remove two dowel pins (19).
- **6.** Remove springs (22 & 23).
- **7.** Should it be necessary to replace ball bearing (10) or shaft seal (12), reverse remainder of brake subassembly, supporting on face C of housing (2).
- **8.** Remove internal retaining ring (11).
- **9.** Using arbor press or similar to break Loctite seal, remove brake shaft (1) from housing (2) and lay aside.
- **10.** Reverse housing (2) and press out ball bearing (10). Shaft seal (12) can also be removed if necessary.

Inspection

- 1. Inspect friction plates (3 & 6) and friction surface on pressure plate (4) for wear or damage.
- **2.** Examine friction plates (3) and brake shaft (1) for wear or damage to the splines.
- **3.** Examine input and output splines of brake shaft (1) for wear or damage.
- **4.** Examine compression springs (22 & 23) for damage or fatigue.
- **5.** Check ball bearing (10) for axial float or wear.
- **6.** Examine o-ring seals (15 & 17) and backing rings (16 & 18) for damage.

Assembly


- 1. Lightly lubricate rotary shaft seal (12) and assemble to housing (2) taking care not to damage seal lip.
- Apply ring of Loctite 641 or equivalent adhesive to full circumference of housing (2) bearing recess adjacent to shoulder.

Apply complete coverage of Loctite 641 to outside diameter of bearing (10) and assemble fully In housing (2), retaining with internal retaining ring (11). Remove excess adhesive with a clean cloth.

Press shaft (1) through bearing (10), ensuring bearing inner ring Is adequately supported.

- **3.** Assemble correct quantity of springs (22 & 23) in orientation required.
- 4. Lubricate o-ring seals (15 & 17) with Molykote 55M (or equivalent) silicon grease and assemble together with backing rings (16 & 18) to piston (9). To ensure correct brake operation. It is important that the backing rings are assembled opposite to the pressurized side of piston.
- **5.** Correctly orientate piston (9) aligning spaces with the two dowel pin holes and, assemble into cylinder housing (8) taking care not to damage seals and carefully lay aside.
- **6.** Locate 2-off pins (19) in housing (2) followed by pressure plate (4) and friction plates i.e. an inner (3) followed by an outer (6) in correct sequence.
- **7.** Position gasket (7) in correct orientation.
- **8.** Align two holes in cylinder with dowel pins (19) and assemble piston & cylinder sub-assembly to remainder of brake securing with 6 capscrews and washers (13 & 14). Torque to 55 ft.lbs. (75 Nm).

NOTE: The use of a suitable press (hydraulic or arbor) pressing down on cylinder end face B will ease assembly of the capscrews (13).



- 1. Shaft 2. Housing
- 3. Friction Plate
- 4. Pressure Plate
- 5. Gasket
- 6. Outer Plate
- 7. Gasket
- 8. Cylinder 9. Piston
- 10. Ball Bearing
- 11. Retaining Ring
 - 12. Shaft Seal
 - 13. Capscrew
 - 14. Lockwasher
 - 15. 0-ring
- 16. Backup Ring
- 17. 0-ring
- 18. Backup Ring 19. Dowel Pin
- 20. Plug
- 22. Spring (Natural)
- 23. Spring (Blue)


Figure 3-71. Drive Brake (SN 0300066417 through 0300134351)

3-112 3121139

3.20 SWING MOTOR (SN 0300066417 THROUGH 0300134351)

Disassembly and inspection

 Place the Torqlink™ in a soft jawed vice, with coupling shaft (12) pointed down and the vise jaws clamping firmly on the sides of the housing (18) mounting flange or port bosses. Remove manifold port o-rings (18A) if applicable.




▲ CAUTION


IFTHETORQLINK™ IS NOT FIRMLY HELD IN THE VISE, IT COULD BE DISLODGED DURINGTHE SERVICE PROCEDURES, CAUSING INJURY.

Scribe an alignment mark down and across the Torq-link™ components from end cover (2) to housing (18) to facilitate reassembly orientation where required. Loosen two shuttle or relief valve plugs (21) for disassembly later if included in end cover. 3/16 or 3/8 in.
 (4.76 or 9.52 mm) Allen wrench or 1 in. hex socket required.






3. Remove the five, six, or seven special ring head bolts (1) using an appropriate 1/2 or 9/16 in. (12.7 or 14.28 mm) size socket. Inspect bolts for damaged threads, or sealing rings, under the bolt head. Replace damaged bolts.



4. Remove end cover assembly (2) and seal ring (4). Discard seal ring.



NOTE: Refer to the appropriate "alternate cover construction" on the exploded view to determine the end cover construction being serviced.



- 1. Special Bolts
- 2. End Cover
- 3. Seal Ring-Commutator
- 4. Seal Ring
- 5. Commutator Ring
- 6. Commutator Ring
- 7. Manifold
- 8. Rotor Set
- 8A. Rotor


- 8B. Stator or Stator Vane
- 8C. Vane
- 8D. Stator Half
- 9. WearPlate
- 10. Drive Link
- 12. Coupling Shaft
- 13. Bearing/Bushing, Inner
- 14. Thrust Washer
- 15. Thrust Bearing

- 16. Seal
- 17. Backup Washer
- 18. Housing
- 18A. O-Ring
- 19. Bearing/Bushing, Outer
- 20. Dirt & Water Seal
- 21. Plug

Figure 3-72. Swing Drive Motor (SN 0300066417 through 0300134351)

3-114 *3121139*

5. If the end cover (2) is equipped with shuttle valve components, remove the two previously loosened plugs (21).




NOTICE

BE READY TO CATCH THE SHUTTLE VALVE OR RELIEF VALVE COMPONENTS THAT WILL FALL OUT OF THE END COVER VALVE CAVITY WHEN THE PLUGS ARE REMOVED.

NOTE: The insert and if included the orifice plug in the end cover (2) must not be removed as they are serviced as an integral part of the end cover.

6. Thoroughly wash end cover (2) in proper solvent and blow dry. Be sure the end cover valve apertures, including the internal orifice plug, are free of contamination. Inspect end cover for cracks and the bolt head recesses for good bolt head sealing surfaces. Replace end cover as necessary.



NOTE: A polished pattern (not scratches) on the cover from rotation of the commutator (5) is normal. Discoloration would indicate excess fluid temperature, thermal shock, or excess speed and require system investigation for cause and close inspection of end cover, commutator, manifold, and rotor set.

Remove commutator ring (6). Inspect commutator ring for cracks, or burrs.



Remove commutator (5) and seal ring (3) Remove seal ring from commutator, using an air hose to blow air into ring groove until seal ring is lifted out and discard seal ring. Inspect commutator for cracks or burrs, wear, scoring, spalling or brinelling. If any of these conditions exist, replace commutator and commutator ring as a matched set.





9. Remove manifold (7) and inspect for cracks surface scoring, brinelling or spalling. Replace manifold if any of these conditions exist. A polished pattern on the ground surface from commutator or rotor rotation is normal. Remove and discard the seal rings (4) that are on both sides of the manifold.



NOTE: The manifold is constructed of plates bonded together to form an integral component not subject tofurtherdisassemblyforservice. Compare configuration of both sides oft hem an if old to ensure that same surface is reassembled against the rotor set.

10. Remove rotor set (8) and warplane (9), together to retain the rotor set in its assembled form, maintaining the same rotor vane (8C) to stator (8B) contact surfaces. The drive link (10) may come away from the coupling shaft (12) with the rotor set, and wearplate. You may have to shift the rotor set on the warplane to work the drive link out of the rotor (8A) and warplane. Inspect the rotor set in its assembled form for nicks, scoring, or spalling on any surface and for broken or worn splines. If the rotor set component requires replacement, the complete rotor set must be replaced as it is a matched set. Inspect the warplane for cracks, brinelling, or scoring. Discard seal ring (4) that is between the rotor set and wearplate.




NOTE: The rotor set (8) components may become disassembled during service procedures. Marking the surface of the rotor and stator that is facing UP, with etching ink or grease pencil before removal from Torqlink™ will ensure correct reassembly of rotor into stator and rotor set intoTorqlink™.Marking all rotor components and mating spline components for exact repositioning at assembly will ensure maximum wear life and performance of rotor set andTorqlink™.



NOTE: Series TG Torqlinks[™] may have a rotor set with two stator halves (8B) with a seal ring (4) between them and two sets of seven vanes (8C). Discard seal ring only if stator halves become disassembled during the service procedures.

NOTE: A polished pattern on the wear plate from rotor rotation is normal.

11. Place rotor set (8) and wear plate (9) on a flat surface and center rotor (8A) in stator (8B) such that two rotor lobes (180 degrees apart) and a roller vane (8C) centerline are on the same stator centerline. Check the rotor lobe to roller vane clearance with a feeler gage at this common centerline. If there is more than 0.005 in. (0.13 mm) of clearance, replace rotor set.



3-116 3121139

NOTE: If rotor set (8) has two stator halves (8B & 8D) and two sets of seven vanes (8C & 8E) as shown in the alternate construction TG rotor set assembly view, check the rotor lobe to roller vane clearance at both ends of rotor.

12. Remove drive link (10) from coupling shaft (12) if it was not removed with rotor set and wear plate. Inspect drive link for cracks and worn or damaged splines. No perceptible lash (play) should be noted between mating spline parts. Remove and discard seal ring (4) from housing (18).



13. Remove thrust bearing (11) from top of coupling shaft (12). Inspect for wear, brinelling, corrosion and a full complement of retained rollers.




14. Check exposed portion of coupling shaft (12) to be sure you have removed all signs of rust and corrosion which might prevent its withdrawal through the seal and bearing. Crocus cloth or fine emery paper may be used.



15. Remove coupling shaft (12), by pushing on the output end of shaft. Inspect coupling shaft bearing and seal surfaces for spalling, nicks, grooves, severe wear or corrosion and discoloration. Inspect for damaged or worn internal and external splines or keyway. Replace coupling shaft if any of these conditions exist.





NOTE: Minor shaft wear in seal area is permissible. If wear exceeds 0.020 in. (0.51 mm) diametrically, replace coupling shaft.

NOTE: A slight "polish" is permissible in the shaft bearing areas. Anything more would require coupling shaft replacement.

- 16. Remove and discard seal ring (4) from housing (18).
- **17.** Remove thrust bearing (15) and thrust washer (14) Inspect for wear, brinelling, corrosion and a full complement of retained rollers.



18. Remove seal (16) and backup washer (17) from Small Frame, housing (18). Discard both.





19. Remove housing (18) from vise, invert it and remove and discard seal (20). A blind hole bearing or seal puller is required.





20. Inspect housing (18) assembly for cracks, the machined surfaces for nicks, burrs, brinelling or corrosion. Remove burrs that can be removed without changing dimensional characteristics. Inspect tapped holes for thread damage. If the housing is defective in these areas, discard the housing assembly.



3-118 *3121139*


21. If the housing (18) assembly has passed inspection to this point, inspect the housing bearings/bushings (19) and (13) and if they are captured in the housing cavity the two thrust washers (14) and thrust bearing (15). The bearing rollers must be firmly retained in the bearing cages, but must rotate and orbit freely. All rollers and thrust washers must be free of brinelling and corrosion. The bushing (19) or (13) to coupling shaft diameter clearance must not exceed 0.010 in. (0.025 mm). A bearing, bushing, or thrust washer that does not pass inspection must be replaced. If the housing has passed this inspection the disassembly of the Torqlink™ is completed.







NOTE: The depth or location of bearing/bushing (13) in relation to the housing wear plate surface and the depth or location of bearing/bushing (19) in relation to the beginning of bearing/bushing counterbore should be measured and

noted before removing the bearings/ bushings. This will facilitate the correct reassembly of new bearings/bushings.



22. If the bearings, bushing or thrust washers must be replaced use a suitable size bearing puller to remove bearing/bushings (19) and (13) from housing (18) without damaging the housing. Remove thrust washers (14) and thrust bearing (15) if they were previously retained in the housing by bearing (13).





Assembly

Replace all seals and seal rings with new ones each time you reassemble the Torqlink™ unit. Lubricate all seals and seal rings with SAE 10W40 oil or clean grease before assembly.

NOTE: Individual seals and seal rings as well as a complete seal kit are available. The parts should be available through most OEM parts distributors or Parker approved Torqlink™ distributors. (Contact your local dealer for availability).

NOTE: Unless otherwise indicated, do not oil or grease parts before assembly.

Wash all parts in clean petroleum-based solvents before assembly. Blow them dry with compressed air. Remove any paint chips from mating surfaces of the end cover, commutator set, manifold rotor set, wear plate and housing and from port and sealing areas.

WARNING

SINCE THEY ARE FLAMMABLE, BE EXTREMELY CAREFUL WHEN USING ANY SOLVENT. EVEN A SMALL EXPLOSION OR FIRE COULD CAUSE INJURY OR DEATH.

A CAUTION

WEAR EYE PROTECTION AND BE SURE TO COMPLY WITH OSHA OR OTHER MAXIMUM AIR PRESSURE REQUIREMENTS.

1. If the housing (18) bearing components were removed for replacement, thoroughly coat and pack a **new** outer bearing/bushing (19) with clean corrosion resistant grease recommended in the material section. Press the new bearing/bushing into the counterbore at the mounting flange end of the housing, using the appropriate sized bearing mandrel, which will control the bearing/ bushing depth.

Torqlink™ housings require the use of bearing mandrel to press bearing/ bushing (19) into the housing to a required depth of 0.151/0.161 in. (3.84/4.09 mm) from the end of the bearing counterbore.





NOTE: Bearing mandrel must be pressed against the lettered end of bearing shell. Take care that the housing bore is square with the press base and the bearing/bushing is not cocked when pressing a bearing/bushing into the housing.


NOTICE

IF THE BEARING MANDREL SPECIFIED IN THE "TOOLS AND MATERIALS REQUIRED FOR SERVICING" SECTION IS NOT AVAILABLE AND ALTERNATE METHODS ARE USED TO PRESS IN BEARING/BUSHING (13) AND (19) THE BEARING/BUSHING DEPTHS SPECIFIED MUST BE ACHIEVED TO INSURE ADEQUATE BEARING SUPPORT AND CORRECT RELATIONSHIP TO ADJACENT COMPONENTS WHEN ASSEMBLED.


3-120 3121139

NOTICE

BECAUSE THE BEARING/BUSHINGS (13) AND (19) HAVE A PRESS FIT INTO THE HOUSING THEY MUST BE DISCARDED WHEN REMOVED. THEY MUST NOT BE REUSED.



2. The Torqlink™ inner housing bearing/bushing (13) can now be pressed into its counterbore in housing (18) flush to 0.03 in. (.76 mm) below the housing wear plate contact face. Use the opposite end of the bearing mandrel that was used to press in the outer bearing/bushing (19).












3. Press a new dirt and water seal (20) into the housing (18) outer bearing counterbore.

The Torqlink[™] dirt and water seal (20) must be pressed in until its' flange is flush against the housing.





4. Place housing (18) assembly into a soft jawed vise with the coupling shaft bore down, clamping against the mounting flange.



5. On the Torqlinks[™] assemble a new backup washer (17) and new seal (16) with the seal lip facing toward the inside of Torqlink[™], into their respective counterbores in housing (18) if they were not assembled in procedure 2.





NOTICE

ORIGINAL DESIGN LARGE FRAME, TF & TG TORQLINKS™ THAT DO NOT HAVE BACKUP WASHER (25) WHEN DISASSEMBLED MUST BE ASSEMBLED WITH A NEW BACKUP WASHER (17), NEW BACKUP WASHER (25), AND NEW SEAL (16).

6. Assemble thrust washer (14) then thrust bearing (15) that was removed from the Torqlink™.



NOTE: Torqlinks[™] require one thrust washer (14) with thrust bearing (15).The coupling shaft will be seated directly against the thrust washer.

3-122 *3121139*

7. Apply masking tape around splines or keyway on shaft (12) to prevent damage to seal.



8. Be sure that a generous amount of clean corrosion resistant grease has been applied to the lower (outer) housing bearing/bushing (19). Install the coupling shaft (12) into housing (18), seating it against the thrust bearing (15) in the housings.




NOTICE

THE OUTER BEARING (19) IS NOT LUBRICATED BY THE SYSTEM'S HYDRAULIC FLUID. BE SURE IT IS THOROUGHLY PACKED WITH THE RECOMMENDED GREASE, PARKER GEAR GREASE SPECIFICATION #045236, E/M LUBRICANT #K-70M.

NOTE: Mobil Mobilith SHC * 460

NOTE: A 102Tube (P/N 406010) is included in each seal kit.

NOTE: The coupling shaft (12) will be flush or just below the housing wear plate surface on Torqlinks™ when properly seated. The coupling shaft must rotate smoothly on the thrust bearing package.





9. Apply a small amount of clean grease to a new seal ring (4) and insert it into the housing (18) seal ring groove.



NOTE: One or two alignment studs screwed finger tight into housing (18) bolt holes, approximately 180 degrees apart, will facilitate the assembly and alignment of components as required in the following procedures. The studs can be made by cutting off the heads of either 3/8-24 UNF 2A or 5/16-24 UNF 2A bolts as required that are over 0.5 in. (12.7 mm) longer than the bolts (1) used in the Torqlink™.

10. Install drive link (10) the long splined end down into the coupling shaft (12) and engage the drive link splines into mesh with the coupling shaft splines.




NOTE: Use any alignment marks put on the coupling shaft and drive link before disassembly to assemble the drive link splines in their original position in the mating coupling shaft splines.


11. Assemble wear plate (9) over the drive link (10) and alignment studs onto the housing (18).



12. Apply a small amount of clean grease to a new seal ring (4) and assemble it into the seal ring groove on the wear plate side of the rotor set stator (8B).



13. Install the assembled rotor set (8) onto wear plate (9) with rotor (8A) counterbore and seal ring side down and the splines into mesh with the drive link splines.




NOTE: It may be necessary to turn one alignment stud out of the housing (18) temporarily to assemble rotor set (8) or manifold (7) over the drive link.

NOTE: If necessary, go to the appropriate, "Rotor Set Component Assembly Procedure."

NOTE: The rotor set rotor counterbore side must be down against wear plate for drive link clearance and to maintain the original rotor-drive link spline contact. A rotor set without a counterbore and that was not etched before disassembly can be reinstalled using the drive link spline pattern on the rotor splines if apparent, to determine which side was down. The rotor set seal ring groove faces toward the wear plate (9).


14. Apply clean grease to a new seal ring (4) and assemble it in the seal ring groove in the rotor set contact side of manifold (7).



3-124 3121139

NOTE: The manifold (7) is made up of several plates bonded together permanently to form an integral component. The manifold surface that must contact the rotor set has it's series of irregular shaped cavities on the largest circumference or circle around the inside diameter. The polished impression left on the manifold by the rotor set is another indication of which surface must contact the rotor set.


15. Assemble the manifold (7) over the alignment studs and drive link (10) and onto the rotor set. Be sure the correct manifold surface is against the rotor set.




16. Apply grease to a new seal ring (4) and insert it in the seal ring groove exposed on the manifold.




17. Assemble the commutator ring (6) over alignment studs onto the manifold.




18. Assemble a new seal ring (3) flat side up, into commutator (5) and assemble commutator over the end of drive link (10) onto manifold (7) with seal ring side up.







19. If shuttle valve components items #21, were removed from the end cover (2) turn a plug (21), loosely into one end of the valve cavity in the end cover. A 3/16 in. Allen wrench is required.

20. Assemble a new seal ring (4) into end cover (2) and assemble end cover over the alignment studs and onto the commutator set. If the end cover has only 5 bolt holes be sure the cover holes are aligned with the 5 threaded holes in housing (18). The correct 5 bolt end cover bolt hole relationship to housing port bosses.









NOTE: If the end cover has a valve (24) or has five bolt holes, use the line you previously scribed on the cover to radially align the end cover into its original position.

21. Assemble the 5 or 7 special bolts (1) and screw in finger tight. Remove and replace the two alignment studs with bolts after the other bolts are in place. Alternately and progressively tighten the bolts to pull the end cover and other components into place with a final torque of 45-55 ft. lbs. (61-75 Nm) for the seven 3/8-24 threaded bolts.








3-126 *3121139*

NOTE: The special bolts required for use with the relief or shuttle valve (24) end cover assembly (2) are longer than the bolts required with standard and cover assembly. Refer to the individual service parts lists or parts list charts for correct service part number if replacement is required.

22. Torque the two shuttle valve plug assemblies (21) in end cover assembly to 9-12 ft. lbs. (12-16 Nm) if cover is so equipped.

Torque the two relief valve plug assemblies (21) in end cover assembly to 45-55 ft. lbs. (61-75 Nm) if cover is so equipped.



One Piece Stator Construction

A disassembled rotor (8A) stator (8B) and vanes (8C) that cannot be readily assembled by hand can be assembled by the following procedures.

1. Place stator (8B) onto wear plate (9) with seal ring (4) side down, after following Torqlink™ assembly procedures 1 through 13. Be sure the seal ring is in place.




- 2. If assembly alignment studs are not being utilized, align stator bolt holes with wear plate and housing bolt holes and turn two bolts (1) finger tight into bolt holes approximately 180 degrees apart to retain stator and wear plate stationary.
- **3.** Assemble the rotor (8A), counterbore down if applicable, into stator (8B), and onto wear plate (9) with rotor splines into mesh with drive link (10) splines.



NOTE: If the manifold side of the rotor was etched during Torqlink disassembly, this side should be up. If the rotor is not etched and does not have a counterbore, use the drive link spline contact pattern apparent on the rotor splines to determine the rotor side that must be against the wear plate.


4. Assemble six vanes (8C), or as many vanes that will readily assemble into the stator vane pockets.



NOTICE

EXCESSIVE FORCE USED TO PUSH THE ROTOR VANES INTO PLACE COULD SHEAR OFF THE COATING APPLIED TO THE STATOR VANE POCKETS.

5. Grasp the output end of coupling shaft (12) with locking pliers or other appropriate turning device and rotate coupling shaft, drive link and rotor to seat the rotor and the assembled vanes (8C) into stator (8B), creating the necessary clearance to assemble the seventh or full complement of seven vanes. Assemble the seven vanes using minimum force.




6. Remove the two assembled bolts (1) if used to retain stator and wear plate.

3-128 3121139

3.21 SWING MOTOR (SN 0300134352 THROUGH 0300182743, B300000100 THROUGH B300001091)

Disassembly


7. Place the Torqmotor™ in a soft jawed vice, with coupling shaft (12) pointed down and the vise jaws clamping firmly on the sides of the housing (18) mounting flange or port bosses. Remove manifold port o-rings (18A) if applicable.




A WARNING

IF THE TORQMOTOR™ IS NOT FIRMLY HELD IN THE VISE, IT COULD BE DIS-LODGED DURINGTHE SERVICE PROCEDURES, CAUSING INJURY.

8. Scribe an alignment mark down and across the Torqmotor™ components from end cover (2) to housing (18) to facilitate reassembly orientation where required. Loosen two shuttle or relief valve plugs (21) for disassembly later if included in end cover. 3/16 or 3/8 in. Allen wrench or 1 in. hex socket required.






9. Remove the five, six, or seven special ring head bolts (1) using an appropriate 1/2 or 9/16 in. size socket. Inspect bolts for damaged threads, or sealing rings, under the bolt head. Replace damaged bolts.



10. Remove end cover assembly (2) and seal ring (4). Discard seal ring.



NOTE: Refer to the appropriate "alternate cover construction" on the exploded view to determine the end cover construction being serviced.




- 1. Special Bolts
- 2. End Cover
- 3. Seal Ring-Commutator
- 4. Seal Ring
- 5. Commutator Ring
- 6. Commutator Ring
- 7. Manifold
- 8. Rotor Set
- 8A. Rotor
- 8B. Stator or Stator Vane
- 8D. Stator Half
- 9. Wear Plate
- 10. Drive Link
- 11. Not Used

- 12. Coupling Shaft
- 13. Bearing/Bushing, Inner
- 14. Thrust Washer
- 15. Thrust Bearing
- 16. Seal
- 17. Backup Washer
- 18. Housing

- 18A. 0-Ring
- 19. Bearing/Bushing, Outer
- 20. Dirt & Water Seal
- 21. Plug

Figure 3-73. Swing Drive Motor (SN 0300134352 through 0300182743, B300000100 through B300001091)

3-130 3121139 5. If the end cover (2) is equipped with shuttle valve components, remove the two previously loosened plugs (21).




NOTICE

BE READY TO CATCH THE SHUTTLE VALVE OR RELIEF VALVE COMPONENTS THAT WILL FALL OUT OF THE END COVER VALVE CAVITY WHEN THE PLUGS ARE REMOVED.

NOTE: O- ring is not included in seal kit but serviced separately, if required.

NOTE: The insert and if included the orifice plug in the end cover (2) must not be removed as they are serviced as an integral part of the end cover.

6. Thoroughly wash end cover (2) in proper solvent and blow dry. Be sure the end cover valve apertures, including the internal orifice plug, are free of contamination. Inspect end cover for cracks and the bolt head recesses for good bolt head sealing surfaces. Replace end cover as necessary.



NOTE: A polished pattern (not scratches) on the cover from rotation of the commutator (5) is normal. Discoloration would indicate excess fluid temperature, thermal shock, or excess speed and require system investigation for cause and close

inspection of end cover, commutator, manifold, and rotor set

7. Remove commutator ring (6). Inspect commutator ring for cracks, or burrs.



8. Remove commutator (5) and seal ring (3) Remove seal ring from commutator, using an air hose to blow air into ring groove until seal ring is lifted out and discard seal ring. Inspect commutator for cracks or burrs, wear, scoring, spalling or brinelling. If any of these conditions exist, replace commutator and commutator ring as a matched set.






9. Remove manifold (7) and inspect for cracks surface scoring, brinelling or spalling. Replace manifold if any of these conditions exist. A polished pattern on the ground surface from commutator or rotor rotation is normal. Remove and discard the seal rings (4) that are on both sides of the manifold.



NOTE: The manifold is constructed of plates bonded together to form an integral component not subject to further disassembly for service. Compare configuration of both sides oft hem an if old to ensure that same surface is reassembled against the rotor set.

10. Remove rotor set (8) and wear plate (9), together to retain the rotor set in its assembled form, maintaining the same rotor vane (8C) to stator (8B) contact surfaces. The drive link (10) may come away from the coupling shaft (12) with the rotor set, and wear plate. You may have to shift the rotor set on the wear plate to work the drive link out of the rotor (8A) and wear plate. Inspect the rotor set in its assembled form for nicks, scoring, or spalling on any surface and for broken or worn splines. If the rotor set component requires replacement, the complete rotor set must be replaced as it is a matched set. Inspect the warplane for cracks, brinelling, or scoring. Discard seal ring (4) that is between the rotor set and wear plate.




NOTE: The rotor set (8) components may become disassembled during service procedures. Marking the surface of the rotor and stator that is facing UP, with etching ink or grease pencil before removal from Torqmotor™ will ensure correct reassembly of rotor into stator and rotor set intoTorqmotor™.Marking all rotor components and mating spline components for exact repositioning at assembly will ensure maximum wear life and performance of rotor set and Torqmotor™.



NOTE: Series TG and TH may have a rotor set with two stator halves (8B & 8D) with a seal ring (4) between them and two sets of seven vanes (8C & 8E). Discard seal ring only if stator halves become disassembled during the service procedures.

NOTE: A polished pattern on the wear plate from rotor rotation is normal.

11. Place rotor set (8) and wear plate (9) on a flat surface and center rotor (8A) in stator (8B) such that two rotor lobes (180 degrees apart) and a roller vane (8C) centerline are on the same stator centerline. Check the rotor lobe to roller vane clearance with a feeler gage at this common centerline. If there is more than 0.005 in. (0.13 mm) of clearance, replace rotor set.



3-132 *3121139*

NOTE: If rotor set (8) has two stator halves (8B & 8D) and two sets of seven vanes (8C & 8E) as shown in the alternate construction TG rotor set assembly view, check the rotor lobe to roller vane clearance at both ends of rotor.


12. Remove drive link (10) from coupling shaft (12) if it was not removed with rotor set and wear plate. Inspect drive link for cracks and worn or damaged splines. No perceptible lash (play) should be noted between mating spline parts. Remove and discard seal ring (4) from housing (18).



13. Remove thrust bearing (11) from top of coupling shaft (12). Inspect for wear, brinelling, corrosion and a full complement of retained rollers.




14. Check exposed portion of coupling shaft (12) to be sure you have removed all signs of rust and corrosion which might prevent its withdrawal through the seal and bearing. Crocus cloth or fine emery paper may be used. Remove any key (12A), nut (12B), washer (12C), bolt (12D), lock washer (12E), or retaining ring (12F).



15. Remove coupling shaft (12), by pushing on the output end of shaft. Inspect coupling shaft bearing and seal surfaces for spalling, nicks, grooves, severe wear or corrosion and discoloration. Inspect for damaged or worn internal and external splines or keyway. Replace coupling shaft if any of these conditions exist.





NOTE: Minor shaft wear in seal area is permissible. If wear exceeds 0.020 in. (0.51 mm) diametrically, replace coupling shaft.

NOTE: A slight "polish" is permissible in the shaft bearing areas. Anything more would require coupling shaft replacement.

16. Remove and discard seal ring (4) from housing (18).

17. Remove thrust bearing (15) and thrust washer (14) Inspect for wear, brinelling, corrosion and a full complement of retained rollers.



18. Remove seal (16) and backup ring (17) from Small Frame, housing (18) and backup washer (25). Discard both.



19. Remove seal (16), backup ring (17) and backup washer (25) from large frame, housing by working them around unseated thrust washers (14) and thrust bearing (15) and out of the housing. Discard seal and washers.




20. Remove housing (18) from vise, invert it and remove and discard seal. A blind hole bearing or seal puller is required.




3-134 *3121139*

21. Inspect housing (18) assembly for cracks, the machined surfaces for nicks, burrs, brinelling or corrosion. Remove burrs that can be removed without changing dimensional characteristics. Inspect tapped holes for thread damage. If the housing is defective in these areas, discard the housing assembly.



22. If the housing (18) assembly has passed inspection to this point, inspect the housing bearings/bushings (19) and (13) and if they are captured in the housing cavity the two thrust washers (14) and thrust bearing (15). The bearing rollers must be firmly retained in the bearing cages, but must rotate and orbit freely. All rollers and thrust washers must be free of brinelling and corrosion. The bushing (19) or (13) to coupling shaft diameter clearance must not exceed 0.010 in. (0.025 mm). A bearing, bushing, or thrust washer that does not pass inspection must be replaced. If the housing has passed this inspection the disassembly of the Torqmotor™ is completed.





NOTE: The depth or location of bearing/bushing (13) in relation to the housing wear plate surface and the depth or location of bearing/bushing (19) in relation to the beginning of bearing/bushing counterbore should be measured and noted before removing the bearings/ bushings. This will facilitate the correct reassembly of new bearings/bushings.



23. If the bearings, bushing or thrust washers must be replaced use a suitable size bearing puller to remove bearing/bushings (19) and (13) from housing (18) without damaging the housing. Remove thrust washers (14) and thrust bearing (15) if they were previously retained in the housing by bearing (13).





Assembly

Replace all seals and seal rings with new ones each time you reassemble the Torqmotor™ unit. Lubricate all seals and seal rings with SAE 10W40 oil or clean grease before assembly.

NOTE: Individual seals and seal rings as well as a complete seal kit are available. The parts should be available through most OEM parts distributors or Parker approved Torqmotor™ distributors. (Contact your local dealer for availability).

NOTE: Unless otherwise indicated, do not oil or grease parts before assembly.

Wash all parts in clean petroleum-based solvents before assembly. Blow them dry with compressed air. Remove any paint chips from mating surfaces of the end cover, commutator set, manifold rotor set, wear plate and housing and from port and sealing areas.

▲ DANGER


SINCE THEY ARE FLAMMABLE, BE EXTREMELY CAREFUL WHEN USING ANY SOLVENT. EVEN A SMALL EXPLOSION OR FIRE COULD CAUSE INJURY OR DEATH.

A WARNING

WEAR EYE PROTECTION AND BE SURE TO COMPLY WITH OSHA OR OTHER MAXIMUM AIR PRESSURE REQUIREMENTS.

1. If the housing (18) bearing components were removed for replacement, thoroughly coat and pack a new outer bearing/bushing (19) with clean corrosion resistant grease recommended in the material section. Press the new bearing/bushing into the counterbore at the mounting flange end of the housing, using the appropriate sized bearing mandrel, which will control the bearing/ bushing depth.

Torqmotor™ housings require the use of bearing mandrel to press bearing/ bushing (19) into the housing to a required depth of 0.151/0.161 in. (3.84/4.09 mm) from the end of the bearing counterbore.



3-136 3121139




NOTE: Bearing mandrel must be pressed against the lettered end of bearing shell. Take care that the housing bore is square with the press base and the bearing/bushing is not cocked when pressing a bearing/bushing into the housing.

NOTICE


IF THE BEARING MANDREL SPECIFIED IN THE "TOOLS AND MATERIALS REQUIRED FOR SERVICING" SECTION IS NOT AVAILABLE AND ALTERNATE METHODS ARE USED TO PRESS IN BEARING/BUSHING (13) AND (19) THE BEARING/BUSHING DEPTHS SPECIFIED MUST BE ACHIEVED TO INSURE ADEQUATE BEARING SUPPORT AND CORRECT RELATIONSHIP TO ADJACENT COMPONENTS WHEN ASSEMBLED.

NOTICE

BECAUSE THE BEARING/BUSHINGS (13) AND (19) HAVE A PRESS FIT INTO THE HOUSING THEY MUST BE DISCARDED WHEN REMOVED. THEY MUST NOT BE REUSED.



2. The Torqmotor™ inner housing bearing/bushing (13) can now be pressed into its counterbore in housing (18) flush to 0.03 in. (.76 mm) below the housing wear plate contact face. Use the opposite end of the bearing mandrel that was used to press in the outer bearing/ bushing (19).











3. Press a new dirt and water seal (20) into the housing (18) outer bearing counterbore.

The Torqmotor™ dirt and water seal (20) must be pressed in until its flange is flush against the housing.





4. Place housing (18) assembly into a soft jawed vise with the coupling shaft bore down, clamping against the mounting flange.



5. On the Torqmotor™ assemble a new backup washer (17) and new seal (16) with the seal lip facing toward the inside of Torqmotor™, into their respective counterbores in housing (18) if they were not assembled in procedure 2





3-138 *3121139*

NOTICE


ORIGINAL DESIGN LARGE FRAME, TF & TG TORQMOTORS™ THAT DO NOT HAVE BACKUP WASHER (25) WHEN DISASSEMBLED MUST BE ASSEMBLED WITH A NEW BACKUP WASHER (17), NEW BACKUP WASHER (25), AND NEW SEAL (16).

6. Assemble thrust washer (14) then thrust bearing (15) that was removed from the Torqmotor™.



NOTE: Torqmotors[™] require one thrust washer (14) with thrust bearing (15).The coupling shaft will be seated directly against the thrust.

7. Apply masking tape around splines or keyway on shaft (12) to prevent damage to seal.



8. Be sure that a generous amount of clean corrosion resistant grease has been applied to the lower (outer) housing bearing/bushing (19). Install the coupling shaft (12) into housing (18), seating it against the thrust bearing (15) in the housings.




NOTICE

THE OUTER BEARING (19) IS NOT LUBRICATED BY THE SYSTEM'S HYDRAULIC FLUID. BE SURE IT IS THOROUGHLY PACKED WITH THE RECOMMENDED GREASE, PARKER GEAR GREASE SPECIFICATION #045236, E/M LUBRICANT #K-70M.

NOTE: Mobil Mobilith SHC * 460

NOTE: A 102Tube (P/N 406010) is included in each seal kit.

NOTE: The coupling shaft (12) will be flush or just below the housing wear plate surface on Torqmotors[™] when properly seated. The coupling shaft must rotate smoothly on the thrust bearing package.





Apply a small amount of clean grease to a new seal ring
 and insert it into the housing (18) seal ring groove.



NOTE: One or two alignment studs screwed finger tight into housing (18) bolt holes, approximately 180 degrees apart, will facilitate the assembly and alignment of components as required in the following procedures. The studs can be made by cutting off the heads of either 3/8-24 UNF 2A or 5/16-24 UNF 2A bolts as required that are over 0.5 in.

(12.7 mm) longer than the bolts (1) used in the Torqmotor™.

10. Install drive link (10) the long splined end down into the coupling shaft (12) and engage the drive link splines into mesh with the coupling shaft splines.




NOTE: Use any alignment marks put on the coupling shaft and drive link before disassembly to assemble the drive link splines in their original position in the mating coupling shaft splines.

11. Assemble wear plate (9) over the drive link (10) and alignment studs onto the housing (18).



3-140 *3121139*

12. Apply a small amount of clean grease to a new seal ring (4) and assemble it into the seal ring groove on the wear plate side of the rotor set stator (8B).



13. Install the assembled rotor set (8) onto wear plate (9) with rotor (8A) counterbore and seal ring side down and the splines into mesh with the drive link splines.




NOTE: It may be necessary to turn one alignment stud out of the housing (18) temporarily to assemble rotor set (8) or manifold (7) over the drive link.

NOTE: If necessary, go to the appropriate, "Rotor Set Component Assembly Procedure."


NOTE: The rotor set rotor counterbore side must be down against wear plate for drive link clearance and to maintain the original rotor-drive link spline contact. A rotor set without a counterbore and that was not etched before disassembly can be reinstalled using the drive link spline pattern on the rotor splines if apparent, to determine which side was down. The rotor set seal ring groove faces toward the wear plate (9).

14. Apply clean grease to a new seal ring (4) and assemble it in the seal ring groove in the rotor set contact side of manifold (7).



NOTE: The manifold (7) is made up of several plates bonded together permanently to form an integral component. The manifold surface that must contact the rotor set has it's series of irregular shaped cavities on the largest circumference or circle around the inside diameter. The polished impression left on the manifold by the rotor set is another indication of which surface must contact the rotor set.

15. Assemble the manifold (7) over the alignment studs and drive link (10) and onto the rotor set. Be sure the correct manifold surface is against the rotor set.



16. Apply grease to a new seal ring (4) and insert it in the seal ring groove exposed on the manifold.



17. Assemble the commutator ring (6) over alignment studs onto the manifold.




18. Assemble a new seal ring (3) flat side up, into commutator (5) and assemble commutator over the end of drive link (10) onto manifold (7) with seal ring side up.







19. Assemble a new seal ring (4) into end cover (2) and assemble end cover over the alignment studs and onto the commutator set. If the end cover has only 5 bolt holes be sure the cover holes are aligned with the 5 threaded holes in housing (18). The correct 5 bolt end cover bolt hole relationship to housing port bosses.








3-142 3121139












NOTE: The special bolts required for use with the relief or shuttle valve (24) end cover assembly (2) are longer than the bolts required with standard and cover assembly. Refer to the individual service parts lists or parts list charts for correct service part number if replacement is required.

21. Torque the two shuttle valve plug assemblies (21) in end cover assembly to 9-12 ft. lbs. (12-16 Nm) if cover is so equipped.

Torque the two relief valve plug assemblies (21) in end cover assembly to 45-55 ft. lbs. (61-75 Nm) if cover is so equipped.






One Piece Stator Construction

A disassembled rotor (8A) stator (8B) and vanes (8C) that cannot be readily assembled by hand can be assembled by the following procedures.

1. Place stator (8B) onto wear plate (9) with seal ring (4) side down, after following Torqmotor™ assembly procedures 1 through 13. Be sure the seal ring is in place.




- 2. If assembly alignment studs are not being utilized, align stator bolt holes with wear plate and housing bolt holes and turn two bolts (1) finger tight into bolt holes approximately 180 degrees apart to retain stator and wear plate stationary.
- **3.** Assemble the rotor (8A), counterbore down if applicable, into stator (8B), and onto wear plate (9) with rotor splines into mesh with drive link (10) splines.



NOTE: If the manifold side of the rotor was etched during Torqmotor disassembly, this side should be up. If the rotor is not etched and does not have a counterbore, use the drive link spline contact pattern apparent on the rotor splines to determine the rotor side that must be against the wear plate.

3-144 3121139

4. Assemble six vanes (8C), or as many vanes that will readily assemble into the stator vane pockets.



NOTICE

EXCESSIVE FORCE USED TO PUSH THE ROTOR VANES INTO PLACE COULD SHEAR OFF THE COATING APPLIED TO THE STATOR VANE POCKETS.


5. Grasp the output end of coupling shaft (12) with locking pliers or other appropriate turning device and rotate coupling shaft, drive link and rotor to seat the rotor and the assembled vanes (8C) into stator (8B), creating the necessary clearance to assemble the seventh or full complement of seven vanes. Assemble the seven vanes using minimum force.



6. Remove the two assembled bolts (1) if used to retain stator and wear plate.


3.22 SWING HUB REMOVAL

- **1.** Disconnect all wiring harness terminals connected to the swing motor.
- 2. Gently loosen the set screw. Do not remove.
- 3. Remove the shoulder bolt using Allen Wrench.



- **4.** Remove the cap bolts securing swing drive hub to the turntable.
- **5.** Using the suitable lifting device, remove the swing drive hub from mounting plate without damaging the swing gear.
- **6.** Place swing drive hub in the clean area.
- Refer to Swing Drive Section for swing drive maintenance.

3.23 SWING BEARING



NOTE: Swing Bearing Torque Sequence is typical for both inner and outer races.

Figure 3-74. Swing Bearing Torque Sequence

Turntable Bearing Mounting Bolt Condition Check

NOTE: This check is designed to replace the existing bearing bolt torque checks on JLG Lifts in service. This check must be performed after the first 50 hours of machine operation and every 600 hours of machine operation thereafter. If during this check any bolts are found to be missing or loose, replace missing or loose bolts with new bolts and torque to the value specified in the torque chart, after lubricating the bolt threads with JLG Threadlocker P/N 0100019. After replacing and retorquing bolt or bolts recheck all existing bolts for looseness.

- 1. Check the frame to bearing attach bolts as follows:
 - **a.** Elevate the fully extended main boom to horizontal. (See Figure 3-75.)
 - **b.** At the positions indicated on Figure 3-75., try to insert a 0.0015 in. feeler gauge between the bolt and hardened washer at the arrow indicated position.

- **c.** Ensure that the 0.0015" feeler gauge will not penetrate under the bolt head to the bolt shank.
- **d.** Swing the turntable 90 degrees, and check some selected bolts at the new position.
- **e.** Continue rotating the turntable at 90 degrees intervals until a sampling of bolts have been checked in all quadrants.
- **2.** Check the turntable to bearing Attach bolts as follows:
 - Elevate the fully retracted main boom to full elevation.
 - **b.** At the position indicated on Figure 3-77., try to insert the 0.0015" feeler gauge between the bolt head and hardened washer at the arrow indicated position.
 - **c.** Lower the boom to horizontal and fully extend the boom.
 - **d.** At the position indicated on Figure 3-76, try and insert the 0.0015" feeler gauge between the bolt head and hardened washer at the arrow indicated position.

3-146 3121139




Figure 3-75. Swing Bearing Tolerance Boom Placement. (Sheet 1 of 2)




Figure 3-76. Swing Bearing Tolerance Boom Placement. (Sheet 2 of 2)

3-148 3121139




Figure 3-77. Swing Bolt Feeler Gauge Check.

Wear Tolerance

- 1. From the underside of the machine, at rear center, with the main boom fully elevated and fully retracted, and tower boom stowed, as shown in Figure 3-75., Swing Bearing Tolerance Boom Placement. (Sheet 1 of 2), using a magnetic base dial indicator, measure and record the distance between the swing bearing and turntable. See Figure 3-78., Swing Bearing Tolerance Measuring Point.
- 2. At the same point, with the main boom at horizontal and fully extended, and the tower boom fully elevated and fully retracted as shown in Figure 3-76., Swing Bearing Tolerance Boom Placement.(Sheet 2 of 2). Using a magnetic base dial indicator, measure and record the distance between the swing bearing and turntable. See Figure 3-78., Swing Bearing Tolerance Measuring Point.
- **3.** If a difference greater than 0.079 in. (2.00 mm) is determined, the swing bearing should be replaced.
- **4.** If a difference less than 0.079 in. (2.00 mm) is determined, and any of the following conditions exist, the bearing should be removed, disassembled, and inspected for the following:
 - a. Metal particles in the grease.
 - **b.** Increased drive power required.
 - c. Noise.
 - d. Rough rotation.
- If bearing inspection shows no defects, reassemble and return to service.

NOTICE

THE SWING BEARING IS ONE OF THE MOST CRITICAL POINTS ON AN AERIAL LIFT. IT IS HERE THAT THE STRESSES OF LIFTING ARE CONCENTRATED, AT THE CENTER OF ROTATION. BECAUSE OF THIS, PROPER MAINTENANCE OF THE SWING BEARING BOLTS IS A MUST FOR SAFE OPERATION.




Figure 3-78. Swing Bearing Tolerance Measuring Point.

Swing Bearing Removal

1. From Ground Control station, operate the boom adequately to provide access to frame opening to rotary coupling.

A WARNING

NEVER WORK BENEATH THE BOOM WITHOUT FIRST ENGAGING BOOM SAFETY PROP OR PROVIDING ADEQUATE OVERHEAD SLING SUPPORT AND/OR BLOCK-ING

- 2. Attach an adequate support sling to the boom and draw all slack from sling. Prop or block the boom if feasible.
- **3.** From inside turntable, remove mounting hardware which attach rotary coupling retaining yoke brackets to turntable.

NOTICE

HYDRAULIC LINES AND PORTS SHOULD BE CAPPED IMMEDIATELY AFTER DISCONNECTING LINES TO AVOID THE ENTRY OF CONTAMINANTS INTO THE SYSTEM.

- **4.** Tag and disconnect the hydraulic lines from the fittings on the top of the rotary coupling. Use a suitable container to retain any residual hydraulic fluid. Immediately cap lines and ports.
- **5.** Attach suitable overhead lifting equipment to the base of the turntable weldment.
- **6.** Use a suitable tool to scribe a line on the inner race of the swing bearing and on the underside of the turntable. This will aid in aligning the bearing upon installation. Remove the bolts and washers which attach the turntable to the bearing inner race. Discard the bolts.
- 7. Use the lifting equipment to carefully lift the complete turntable assembly from the bearing. Ensure that no damage occurs to the turntable, bearing or framemounted components.




Figure 3-79. Swing Bearing Removal - 800S

3-150 3121139




Figure 3-80. Swing Bearing Removal - 860SJ

- Carefully place the turntable on a suitably supported trestle.
- 9. Use a suitable tool to scribe a line on the outer race of the swing bearing and the frame. This line will aid in aligning the bearing upon installation. Remove the bolts and washers which attach the outer race of the bearing to the frame. Discard the bolts. Use suitable lifting equipment to remove the bearing from the frame, then move the bearing to a clean, suitably supported work

Swing Bearing Installation

1. Using suitable lifting equipment, carefully lower the swing bearing into position on the frame. Ensure the scribed line of the outer race of the bearing aligns with the scribed line on the frame. If a new swing bearing is used, ensure that the spot with minimum gear backlash (marked with yellow paint) is towards the centerline of the swing drive (as close as the bolt pattern will allow).

A CAUTION

JLG INDUSTRIES RECOMMENDS THAT ALL REMOVED BEARING BOLTS BE DISCARDED AND REPLACED WITH NEW BOLTS. SINCE THE SWING BEARING IS THE ONLY STRUCTURAL LINK BETWEEN THE FRAME AND TURNTABLE, IT IS IMPERATIVE THAT SUCH REPLACEMENT HARDWARE MEETS JLG SPECIFICATIONS. USE OF GENUINE JLG HARDWARE IS HIGHLY RECOMMENDED.

Apply a light coating of JLG Threadlocker P/N 0100019 to the new bearing bolts, and loosely install the bolts and washers through the frame and outer race of bearing.

NOTICE

IF COMPRESSED AIR OR ELECTRICALLY OPERATED IMPACT WRENCH IS USED FOR TIGHTENING THE BEARING ATTACHMENT BOLTS, THE TORQUE SETTING ACCURACY OF THE TOOL SHOULD BE CHECKED PRIOR TO USE.

3. Refer to the Torque Sequence diagram as shown in Figure 3-74., Swing Bearing Torque Sequence. Spray a light coat of Safety Solvent 13 on the new bearing bolts. Then apply a light coating of JLG Threadlocker P/N 0100019 to the new bearing bolts, and install the bolts and washers through the frame and outer race of the bearing. Tighten the bolts to a torque of 190 ft. lbs. (258 Nm) w/ Loctite.

- 4. Remove the lifting equipment from the bearing.
- **5.** Using suitable lifting equipment, carefully position the turntable assembly above the machine frame.
- 6. Carefully lower the turntable onto the swing bearing, ensuring that the scribed line of the inner race of the bearing aligns with scribed line on the turntable. If a new swing bearing is used, ensure that the filler plug fitting is at 90 degrees from the fore and aft center line of the turntable.
- 7. Spray a light coat of Safety Solvent 13 on the new bearing bolts. Then apply a light coating of JLG Threadlocker P/N 0100019 to the new bearing bolts, and install the bolts and washers through the turntable and inner race of the bearing.
- **8.** Following the Torque Sequence diagram shown in Figure 3-74., Swing Bearing Torque Sequence, tighten the bolts to a torque of 190 ft. lbs. (258 Nm) w/Loctite.
- 9. Remove the lifting equipment.
- **10.** Install the rotary coupling retaining yoke brackets, apply a light coating of JLG Threadlocker P/N 0100011 to the attaching bolts and secure the yoke to the turntable with the mounting hardware.
- **11.** Connect the hydraulic lines to the rotary coupling as tagged prior to removal.
- **12.** At ground control station, use boom lift control to lower boom to stowed position.
- **13.** Using all applicable safety precautions, activate the hydraulic system and check the swing system for proper and safe operation.

Swing Bearing Torque Values

- 1. Outer Race 190 ft. lbs. (258 Nm) w/Loctite.
- 2. Inner Race 190 ft. lbs. (258 Nm) w/Loctite.
- 3. See Swing Bearing Torquing Sequence.

A WARNING


CHECK THE INNER AND OUTER SWING BEARING BOLTS FOR MISSING OR LOOSENESS AFTER FIRST 50 HOURS OF OPERATION, AND EVERY 600 HOURS THEREAFTER.

3-152 3121139

3.24 PROCEDURE FOR SETTING GEAR BACKLASH


Ensure mounting plate and mounting location of the base plate are clean and painted with a uniform coating of minimum thickness (no runs, drips, etc.).

- **1.** Set backlash to 0.008 to 0.012 in. (0.203 to 0.304 mm) using the following procedure.
- **2.** Place shim between pinion and bearing on the bearing high spot.




3. Apply JLG Threadlocker P/N 0100019 to the shoulder screw (shown below) and torque to 205 ft. lbs. (278 Nm).

NOTE: Torque shoulder bolt against turntable baseplate. Shoulder bolt will not tighten against the swing drive mounting plates.




4. Remove the turntable lock pin.

5. Apply JLG Threadlocker P/N 0100019 to the capscrews (shown below) and pre-torque to 30 ft. lbs. (42 Nm).




6. Tighten the setscrew (shown below) until the pinion is completely snug against the shim and bearing and then back off the setscrew.




7. Apply JLG Threadlocker P/N 0100019 to the setscrew and torque to 50 ft.lbs. (68 Nm).


8. Apply JLG Threadlocker P/N 0100019 to the jam nut (shown below) and tighten.



9. Torque the capscrews shown in step 5 to 340 footpounds (569 Nm).




10. Remove shim and discard.



Swing Drive Lubrication

Fill Swing Drive Gearbox with 43 oz (1.27 L) 90w80gear oil with EP additives. Oil should cover the ring gear. Torque pipe plug to 23-25 ft. lbs. (31-33 Nm).



3-154 *3121139*

3.25 ROTARY COUPLING (PRIOR TO SN 0300083331)

Use the following procedure to install the seal kit.

- 1. If not already removed, remove the axle oscillation valve from the cylinder barrel. The spool of the valve protrudes into the barrel and will damage the spool and seals if left in place.
- **2.** Remove snap ring (7) from end.
- **3.** Remove thrust ring (6) from the same end.
- **4.** Remove center body (1) from housing (3).

- **5.** Cut off old seals (2,4,5).
- **6.** Assemble lip seals (2) in direction shown in Figure 3-81., Rotary Coupling Seal Installation (Prior to SN 0300083331).
- 7. Reassemble o-ring (4).
- **8.** Heat cap seals (5) in hydraulic oil for 5 minutes at 300° F (149° C).
- 9. Assemble cap seals over o-rings.
- Reinsert center body into housing (lube with hydraulic oil).





Figure 3-81. Rotary Coupling Seal Installation (Prior to SN 0300083331)



- 1. Center Body
- 2. Seal
- 3. Housing
- 4. 0-ring
- 5. Seal
- 6. Thrust Ring
- 7. Snap Ring
- 8. Valve Block (Axle Oscillation)

Figure 3-82. Rotary Coupling Cutaway (Prior to SN 0300083331)

3-156 3121139





Figure 3-83. Rotary Coupling Port Location (7 Port) (Prior to SN 0300083331)



- 2. Body Bracket
- **Rotary Coupling** 7. Locknut
- Block Valve Assembly 8. Washer
- 9. Seal
- 10. 0-ring
- 11. Cap Seal 12. Ring
- 13. Retaining Ring 14. Plug
- 15. Capscrew 16. Bearing
- 17. Check Valve
- 18. Plunger Valve
- 19. Spring
- 20. 0-ring
- A. JLG Threadlocker

Figure 3-84. Rotary Coupling Installation (Prior to SN 0300083331)

3121139 3-158

3.26 ROTARY COUPLING (SN 0300083331 THROUGH 0300182743, B300000100 THROUGH B300001091)

Use the following procedure to install the seal kit.

- 1. If not already removed, remove the axle oscillation valve from the cylinder barrel. The spool of the valve protrudes into the barrel and will damage the spool and seals if left in place.
- **2.** Remove snap ring (7) from end.
- 3. Remove thrust ring (6) from the same end.
- 4. Remove center body (1) from housing (3).
- **5.** Cut off old seals (2, 4, 5).

- 6. Remove proximity switch.
- Assemble lip seals (2) in direction shown in Figure 3-81., Rotary Coupling Seal Installation (Prior to SN 0300083331).
- **8.** Reassemble o-ring (4).
- Heat cap seals (5) in hydraulic oil for 5 minutes at 300° F (149° C).
- 10. Assemble cap seals over o-rings.
- Reinsert center body into housing (lube with hydraulic oil).
- 12. Replace thrust ring and snap ring.
- 13. Install proximity switch as shown in Figure 3-88.





Figure 3-85. Rotary Coupling Seal Installation (SN 0300083331 through 0300182743, B300000100 through B300001091)



- 1. Center Body
- 2. Seal
- 3. Housing
- 4. 0-ring
- 5. Seal

- 6. Thrust Ring
- 7. Snap Ring
- 8. Valve Block (Axle Oscillation)
- 9. 0-ring
- 10. Proximity Switch

Figure 3-86. Rotary Coupling Cutaway (SN 0300083331 through 0300182743, B300000100 through B300001091)

3-160 3121139




Figure 3-87. Rotary Coupling Port Location (7 Port) (SN 0300083331 through 0300182743, B300000100 through B300001091)




Figure 3-88. Rotary Coupling Installation (SN 0300083331 through 0300182743, B300000100 through B300001091)

3-162 *3121139*

Table 3-10. Coupling Port Information Table (Prior to SN 0300083331)

| Port No. | Outlets | Port Size | Description | Operating Pressure PSI (Bar) | Proof Pressure PSI (Bar) |
|-------------|---------|-----------|---------------|------------------------------------|--------------------------------|
| 1 | 2 | -6 | Brake | 400(28) | 600 (41) |
| 2 | 2 | -6 | 2 Speed | 4500 (310) | 6750 (465) |
| 3 | 1 | -6 | Steer | 2000 (138) | 3000 (207) |
| 4 | 1 | -6 | Steer | 2000 (138) | 3000 (207) |
| 5 | 3 | 2-16, 1-6 | Drive Reverse | 4500 (310) | 6750 (465) |
| 6 | 1 | -16 | Drive Forward | 4500 (310) | 6750 (465) |
| 7 | 3 | 2-12, 1-6 | Drain | 250 (17) | 375 (26) |
| Р | 1 | 4 | Port | 4500 (310) | 6750 (465) |

Table 3-11. Coupling Port Information Table (SN 0300083331 through 0300182743, B300000100 through B300001091)


| Port No. | Outlets | Port Size | Description | Operating Pressure PSI (Bar) | Proof Pressure PSI (Bar) |
|-------------|---------|-----------|---------------|------------------------------------|--------------------------------|
| 1 | 1 | -8 | Brake | 450 (31) | 675 (46) |
| 2 | 2 | -6 | 2 Speed | 4500 (310) | 6750 (465) |
| 3 | 1 | -6 | Steer | 2500 (172) | 3750 (258) |
| 4 | 1 | -6 | Steer | 2500 (172) | 3750 (258) |
| 5 | 2 | 1-6, 1-16 | Drive Reverse | 4500(310) | 6750(465) |
| 6 | 1 | -16 | Drive Forward | 4500 (310) | 6750 (465) |
| 7 | 3 | 2-8, 1-6 | Drain | 250 (17) | 375 (26) |

3.27 GENERATOR

Maintenance Schedule


EVERY 250 HOURS

Every 250 hours of operation, check the drive belt for proper tension.




EVERY 500 HOURS

Every 500 hours of operation, service the generator brushes and slip rings. Hostile environments may require more frequent service.



Every 500 hours of service, blow out the inside of the generator. If operating in a hostile environment, clean monthly.




Overload Protection

▲ CAUTION

STOP THE ENGINE WHENEVER CHECKING OR INSPECTING THE CIRCUIT BREAKER.

The circuit breaker protects the generator windings from overload. If the circuit breaker opens, generator output stops. If the circuit breaker continues to open, check for faulty equipment connected to the platform receptacles.



Inspecting Brushes, Replacing Brushes, and Cleaning Slip Rings

Refer to Figure 3-89., Inspecting Generator Brushes, Replacing Brushes, and Cleaning Slip Rings.

INSPECTING BRUSH POSITION

Inspect brush alignment with slip rings. View alignment through the air vents in the stator barrel. The brushes must ride completely on the slip rings.

INSPECTING BRUSHES

Remove the end panel. Inspect the wires. Remove the brush holder assembly. Pull the brushes from the holders.

Replace the brushes if damaged, or if the brush is at or near minimum length.

CLEANING SLIP RINGS

Visually inspect the slip rings. Under normal use, the rings turn dark brown.

If the slip rings are corroded or their surface is uneven, remove the belt to turn the shaft by hand for cleaning.

Clean the rings with 220 grit emery paper. Remove as little material as possible. If the rings are deeply pitted and do not clean up, consult generator factory service.

Reinstall the belt, brush holder assembly, and end panel.

3-164 3121139




Figure 3-89. Inspecting Generator Brushes, Replacing Brushes, and Cleaning Slip Rings

Troubleshooting

Table 3-12. Troubleshooting

| No generator output at platform AC receptacles Reset circuit breaker CE1. | Trouble | Remedy |
|--|--|---|
| Be sure all equipments turned off when starting unit. Reset circuit breaker (B1. Check plug PLG3 connection and/or connections at receptades RC3 and RC5. Be sure + 12 volts DC input voltage is being supplied to control box. Check sliprings, wring to brushes, and brush position on sliprings. Install new brushes if necessary. Disconnect leads 12 and 13 from brushes, and check continuity across sliprings (nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections and replace if necessary. Check control board PC2 and connections and replace if necessary. Disconnect leads 12 and 13 from brushes, and brush position on sliprings, Install new brushes if necessary. Disconnect leads 12 and 13 from brushes, and brush position on sliprings, Install new brushes if necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip ings nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Disconnect plug PLG4 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check solution board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if ne | No generator output at platform AC receptacles. | Be sure generator control switch is turned on at platform. |
| Reset circuit breaker CB1. Check plug PLG3 connection and/or connections a treeptacles RC3 and RC5. Be sure + 12 volts DC input voltage is being supplied to control box. Check slip rings, writing to brushes, and brush position on slip rings. Install new brushes if necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings (nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check slip rings, writing to brushes, and brush position on slip rings. Install new brushes if necessary. Check slip rings, writing to brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if notor is open. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if rotor is open. Disconnect plug PLG4 and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary | | Check and secure electrical connections at platform, generator, and control box. |
| Check plug PLG3 connection and/or connections at receptacles RC3 and RC5. Besure + 12 volts DC input voltage is being supplied to control box. Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings (nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check power board PC1 and slow position on slip rings. Install new brushes if necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if necessary. Disconnect stator weld leads 1, 2, and 3 from circuit breaker CB1, and check continuity between leads. Replace generator if necessary. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC2 and connections at platform, generator, and control box. Check power board PC2 and connections at platform, generator, and control box. Check power | | Be sure all equipment is turned off when starting unit. |
| Besure + 12 volts DC input voltage is being supplied to control box. Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings (nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check opwore board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check ontrol board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Werify generator output at platform AC receptacles. Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Check ontrol board PC2 and connections, and replace if necessary. Check ontrol board PC2 and connections, and replace if necessary. Check ontrol board PC2 and connections, and replace if necessary. Check ontrol board PC2 and connections, and replace if necessary. Check ontrol board PC2 and connections, and replace if necessary. Check ontrol board PC2 and connections, and replace if necessary. Check ontrol board PC2 and connections, and replace if necessary. Check ontrol board PC2 and connections, and replace if necessary. Check of the part of the | | Reset circuit breaker CB1. |
| Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings (nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect plug PLG4 and check continuity between exiter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check power board PC1 and 13 from brushes, and brush position on slip rings. Install new brushes if necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect plug PLG4 and check continuity between exiter leads 5 and 6. Replace generator if necessary. Disconnect plug PLG4 and check continuity between exiter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC3 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power | | Check plug PLG3 connection and/or connections at receptacles RC3 and RC5. |
| Disconnect leads 12 and 13 from brushes, and check continuity across slip rings (nominal reading is 26 ohms). Replace generator if rotor is open. | | Be sure + 12 volts DC input voltage is being supplied to control box. |
| Disconnect stator weld leads 1, 2, and 3 from circuit breaker CB1, and check continuity between leads. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check sliprings, wiring to brushes, and brush position on sliprings. Install new brushes if necessary. Check power board PC1 and connections, and replace if necessary. Verify generator output at platform AC receptacles. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check sliprings, wiring to brushes, and brush position on sliprings. Install new brushes if necessary. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Verify generator output at platform AC receptacles. Check piprings, wiring to brushes, and brush position on sliprings. Install new brushes if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC3 and connections at platform, generator, and control box. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check sliprings, wiring to brushes, and brush position on sliprings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and brush position on sliprings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and check continuity across sliprings nominal reading is 26 ohms). Replace generator if rotor is open. | | Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. |
| Disconnectplug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Check slip rings, wiring to brushes, and brush position o | | Disconnect leads 12 and 13 from brushes, and check continuity across slip rings (nominal reading is 26 ohms). Replace generator if rotor is open. |
| Check power board PC1 and connections, and replace if necessary. Low generator output at platform AC recepta- cles. Disconnect leads 12 and 13 from brushes, and brush position onslip rings. Install new brushes if necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Werify generator is running at 3600 rpm (60Hz) or 3000 rpm (50Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC1 and connections, and replace if necessary. Check control board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections at platform, generator, and control box. Check slip rings, w | | Disconnect stator weld leads 1, 2, and 3 from circuit breaker CB1, and check continuity between leads. Replace generator if necessary. |
| Check control board PC2 and connections, and replace if necessary. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC2 and connections at platform, generator, and control box. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Disconnectleads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | | Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. |
| Low generator output at platform AC recepta- cles. Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect plug PL64 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Check power board PC1 and connections, and replace if necessary. Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Check ontrol board PC2 and connections, and replace if necessary. Check ontrol board PC2 and connections, and replace if necessary. Check ontrol board PC2 and connections, and replace if necessary. Check ontrol board PC2 and connections, and replace if necessary. Check ontrol board PC2 and connections, and replace if necessary. Check and secure electrical connections at platform, generator, and control box. Verify generator is running at 3600 rpm (60Hz) or 3000 rpm (50Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | | Check power board PC1 and connections, and replace if necessary. |
| Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect leads 12 and 13 from brushes, and check continuity between leads. Replace generator if necessary. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check power board PC2 and connections at platform, generator, and control box. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | | Check control board PC2 and connections, and replace if necessary. |
| Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes ir necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC1 and connections, and replace if necessary. Check power board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check and secure electrical connections, and replace if necessary. Check and secure electrical connections at platform, generator, and control box. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Checkslip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | Low generator output at platform AC recepta- | Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). |
| Disconnect stator weld leads 1, 2, and 3 from circuit breaker CB1, and check continuity between leads. Replace generator if necessary. Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. High generator output at platform AC receptacles. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check solip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check ontrol board PC2 and connections, and replace if necessary. Check and secure electrical connections, and replace if necessary. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | cles. | Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. |
| Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Werify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check spip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check and secure electrical connections at platform, generator, and control box. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | | Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. |
| Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. High generator output at platform AC receptacles. Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections at platform, generator, and control box. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | | Disconnect stator weld leads 1, 2, and 3 from circuit breaker CB1, and check continuity between leads. Replace generator if necessary. |
| Check control board PC2 and connections, and replace if necessary. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check and secure electrical connections at platform, generator, and control box. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | | Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. |
| High generator output at platform AC recepta- cles. Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Erratic generator output at platform AC recepta- cles. Check and secure electrical connections at platform, generator, and control box. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | | Check power board PC1 and connections, and replace if necessary. |
| Checkslip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check and secure electrical connections at platform, generator, and control box. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | | Check control board PC2 and connections, and replace if necessary. |
| Check power board PC1 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check control board PC2 and connections, and replace if necessary. Check and secure electrical connections at platform, generator, and control box. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | High generator output at platform AC recepta- | Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). |
| Check control board PC2 and connections, and replace if necessary. Erratic generator output at platform AC recepta- cles. Check and secure electrical connections at platform, generator, and control box. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | cles. | Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. |
| Check and secure electrical connections at platform, generator, and control box. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | | Check power board PC1 and connections, and replace if necessary. |
| Cles. Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | | Check control board PC2 and connections, and replace if necessary. |
| Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | Erratic generator output at platform AC recepta- | Check and secure electrical connections at platform, generator, and control box. |
| Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. | cles. | Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). |
| | | Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes necessary. |
| Check power board PC1 and connections, and replace if necessary. | | Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. |
| | | Check power board PC1 and connections, and replace if necessary. |
| Check control board PC2 and connections, and replace if necessary. | | Check control board PC2 and connections, and replace if necessary. |

3-166 3121139

3.28 FORD EFI ENGINE

Performing Diagnostics

- **1.** Verify the complaint and determine if it is a deviation from normal operation.
- Once the complaint has been verified, preliminary checks can be done. Conduct a thorough visual inspection, be alert for unusual sounds or odors, and gather diagnostic trouble code information.
- Perform a system check that will verify the proper operation of the system in question and check for recent information updates.
- If a diagnostic trouble code (DTC) is stored, contact a JLG distributor to make an effective repair.
- If no DTC is stored, select the symptom from the symptom tables and follow the diagnostic path or suggestions to complete the repair.
- 6. After the repair has been made and validated for proper operation, the old part should be momentarily reinstalled to verify that it was indeed the source of the problem.

If no matching symptom is available, analyze the complaint and develop a plan for diagnostics utilizing the wiring diagrams, technical assistance, and repair history.

Intermittent conditions may be resolved by using a check sheet to pinpoint the circuit or electrical system component. Some diagnostic charts contain Diagnostic Aids which give additional information about a system. Be sure to use all of the information that is available to you.

VISUAL/PHYSICAL ENGINE INSPECTION CHECK

Perform a careful visual and physical engine inspection before performing any diagnostic procedure. Perform all necessary repairs before proceeding with additional diagnosis, this can often lead to repairing a problem without performing unnecessary steps. Use the following guidelines when performing a visual/physical inspection check:

- Inspect engine for modifications or aftermarket equipment that can contribute to the symptom; verify that all electrical and mechanical loads or accessory equipment is "OFF" or disconnected before performing diagnosis.
- Inspect engine fluids for correct levels and evidence of leaks.
- Inspect vacuum hoses for damage, leaks, cracks, kinks and improper routing, inspect intake manifold sealing surface for a possible vacuum leak.
- Inspect PCV valve for proper installation and operation.
- Inspect all wires and harnesses for proper connections and routing; bent or broken connector pins; burned, chafed, or pinched wires; and corrosion. Verify that harness grounds are clean and tight.
- Inspect engine control module (ECM), sensors, and actuators for physical damage.
- Inspect ECM grounds for cleanliness, tightness, and proper location.
- Inspect fuel system for adequate fuel level, and fuel quality (concerns such as proper octane, contamination, winter/ summer blend).
- Inspect intake air system and air filter for restrictions.
- · Inspect battery condition and starter current draw.

If no evidence of a problem is found after visual/physical engine check has been performed, proceed to MIL DTC retrieval procedure.

EFI Diagnostics

The EFI diagnostics are designed to assist in locating a faulty circuit or component. When a malfunction is detected by the Engine Control Module (ECM), a diagnostic trouble code (DTC) is set and will be displayed on the JLG Control System Analyzer. Refer to Section 6 - JLG Control System.

CLEARING TROUBLE CODES

To clear the trouble codes from the ECM, the electrical current running to the ECM must be shut off. To do this, disconnect the negative terminal from the battery for a period of approximately 15 minutes.


ECM and Sensors

CRANKSHAFT POSITION (CKP) SENSOR

The crankshaft position (CKP) sensor provides a signal used by the engine control module (ECM) to calculate the ignition sequence. The CKP sensor initiates the reference pulses which the ECM uses to calculate RPM and crankshaft position.

CAMSHAFT POSITION (CMP) SENSOR AND SIGNAL

The camshaft position (CMP) sensor sends a CMP signal to the ECM. The ECM uses this signal as a "sync pulse" to trigger the injectors in the proper sequence. The ECM uses the CMP signal to indicate the position of the #1 piston during its power stroke. The CMP uses a Hall Effect sensor to measure piston position. This allows the ECM to calculate true sequential fuel injection (SFI) mode of operation. If the ECM detects an incorrect CMP signal while the engine is running, DTC 53 will set. If the CMP signal is lost while the engine is running, the fuel injection system will shift to a calculated sequential fuel injection mode based on the last fuel injection pulse, and the engine will continue to nun. As long as the fault is present, the engine can be restarted. It will run in the previously established injection sequence.



3-168 3121139


Table 3-13. ECM Diagnostic Trouble Codes

| Diagnostic Trouble Code | Description |
|-------------------------------|---|
| 11 | All Systems OK |
| 12 | Throttle Position (TP) Sensor Low Voltage |
| 14 | Manifold Absolute Pressure (MAP) Low Voltage |
| 15 | Under Minimum Map Sensor Temperature |
| 21 | Overspeed |
| 22 | Throttle Position (TP) Sensor High Voltage |
| 23 | Over maximum throttle |
| 24 | Manifold Absolute Pressure (MAP) High Voltage |
| 25 | Over Maximum Map Sensor Temperature |
| 26 | Over maximum initial Throttle Position Sensor Voltage |
| 31 | Fuel Pump Low Voltage |
| 32 | Heated Oxygen Sensor (HO2S) Low Voltage |
| 33 | Engine Coolant Temperature (ECT) Sensor High Voltage |
| 35 | Intake Air Temperature (IAT) Sensor High Voltage |
| 41 | Fuel Pump High Voltage |
| 42 | Heated Oxygen Sensor (HO2S) High Voltage |
| 43 | Engine Coolant Temperature (ECT) Sensor Low Voltage |
| 45 | Intake Air Temperature (IAT) Sensor Low Voltage |
| 51 | Low Oil Pressure |
| 52 | Crankshaft Position (CKP) Sensor Extra/Missing Pulses |
| 53 | Camshaft Position Sensor (CMP) Sensor Illegal Pattern |
| 54 | Engine Control Module (ECM) Fault Illegal Operation |
| 55 | Engine Control Module (ECM) Fault Illegal Interruption |
| 56 | Engine Control Module (ECM) Fault COP (Computer Operating Properly) Failure |
| 61 | System Voltage Low |
| 62 | System Voltage High |

ENGINE COOLANT TEMPERATURE (ECT) SENSOR

The engine coolant temperature (ECT) sensor is a g thermistor (a resistor which changes value based on temperature) mounted in the engine coolant stream. Low coolant temperature produces a high resistance of 100,000 ohms at -40°C (-40°F). High temperature causes a low resistance of 70 ohms at 130°C (266°F). The ECM supplies a 5-volt signal to the ECT sensor through resistors in the ECM and measures the voltage. The signal voltage will be high when the engine is cold and low when the engine is hot. By measuring the voltage, the ECM calculates the engine coolant temperature. Engine coolant temperature affects most of the systems that the ECM controls.

After engine start-up, the temperature should rise steadily to about 85°C (185°F). it then stabilizes when the thermostat opens. If the engine has not been run for several hours (overnight), the engine coolant temperature and intake air temperature displays should be close to each other. A fault in the engine coolant sensor circuit will set DTC 33 or DTC 43.



ELECTRICALLY ERASABLE PROGRAMMABLE READ ONLY MEMORY (EEPROM)

The electrically erasable programmable read only memory (EEPROM) is a permanent memory chip that is located within the ECM. The EEPROM contains the pro-gram and the calibration information that the ECM needs to control engine operations.

If the ECM is replaced, the new ECM will need to be programmed. An IBM-compatible computer and software containing the correct program and calibration for the application are required to program the ECM.


HEATED OXYGEN SENSOR

The heated oxygen sensor is mounted in the exhaust stream where it can monitor the oxygen content of the exhaust gas. The oxygen present in the exhaust gas reacts with the sensor to produce a voltage output. This voltage should constantly fluctuate from approximately 100 mV to 900 mV. The heated oxygen sensor voltage can be monitored on an IBM PC-compatible computer with diagnostic software. By monitoring the voltage out-put of the oxygen sensor, the ECM calculates the pulse width command for the injectors to produce the proper combustion chamber mixture.

Low HO2S voltage indicates a lean mixture which will result in a rich command to compensate.

High HO2S voltage indicates a rich mixture which will result in a lean command to compensate.

A constant voltage below 200 mV for 10 consecutive seconds will set OTC 32. A constant voltage above 650 mV for 10 consecutive seconds will set OTC 42.




3-170 3121139

Figure 3-90. EFI Component Location

INTAKE AIR TEMPERATURE (IAT) SENSOR

The intake air temperature (IAT) sensor is a thermistor which changes its resistance based on the temperature of air entering the engine. Low temperature produces a high resistance of 100,000 ohms at -40°C (-40°F). High temperature causes a low resistance of 70 ohms at 130°C (266°F). The ECM supplies a 5volt signal to the sensor through a resistor in the ECM and monitors the signal voltage. The signal voltage will be high when the incoming air is cold and low when the incoming air is hot. By measuring the voltage, the ECM calculates the incoming air temperature. The IAT sensor signal is used to adjust spark timing according to the incoming air density. An IBM PC-compatible computer with diagnostic soft-ware can be used to display the temperature of the air entering the engine. The temperature should read close to the ambient air temperature when the engine is cold, and rise as engine compartment temperature increases. If the engine has not been run for several hours (overnight), the IAT sensor temperature and engine coolant temperature should read close to each other. A failure in the IAT sensor circuit will set DTC 35 or DTC 45.




MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR

The manifold absolute pressure (MAP) sensor responds to changes in intake manifold pressure (vacuum). The MAP sensor signal voltage to the ECM varies from below 2 volts at idle (high vacuum) to above 4 volts with the ignition ON, engine not running or at wide-open throttle (low vacuum).

The MAP sensor is used to determine the following:

- Engine vacuum level for engine control purposes.
- · Barometric pressure (BARO)

If the ECM detects a voltage that is significantly lower than the estimated MAP value for 2 or more consecutive seconds, DTC 14 will be set. A signal voltage significantly higher than the estimated MAP value for 2 or more consecutive seconds will set DTC 24.



ENGINE CONTROL MODULE (ECM)

The ECM controls the following:


- · Fuel metering system
- · Ignition timing
- · On-board diagnostics for engine functions

The ECM constantly observes the information from various sensors. The ECM controls the systems that affect engine performance. The ECM performs the diagnostic function of the system. It can recognize operational problems, alert the operator through the Malfunction Indicator Lamp (MIL), and store diagnostic trouble codes (DTCs). DTCs identify the problem areas to aid the technician in making repairs.

The ECM supplies either 5 or 12 volts to power various sensors or switches. The power is supplied through resistances in the ECM which are so huh in value that a test light will not light when connected to the circuit. In some cases, even an ordinary shop voltmeter will not give an accurate reading because its resistance is too low. Therefore, a digital voltmeter with at least 10 meg ohms input impedance is required to ensure accurate voltage readings. The ECM controls output circuits such as the fuel injectors, electronic governor, etc., by control ling the ground or the power feed circuit through transistors or other solid state devices.

3-172 3121139

The ECM is designed to maintain exhaust emission levels to government mandated standards while providing excellent operation and fuel efficiency. The ECM monitors numerous engine functions via electronic sensors such as the throttle position (TP) sensor and the heated oxygen sensor (HO2S).



ECM INPUTS/OUTPUTS

Inputs—Operating Conditions

- Engine Coolant Temperature
- · Crankshaft Position
- Exhaust Oxygen Content
- · Manifold Absolute Pressure
- Battery Voltage
- Throttle Position
- Fuel Pump Voltage
- Intake Air Temperature
- · Camshaft Position

Outputs - System Controlled

- Fuel Control
- · Idle Air Control
- · Electric Fuel Pump
- · Diagnostics:
 - Malfunction Indicator Lamp
 - Data Link Connector (DLC)

ECM SERVICE PRECAUTIONS

The ECM is designed to withstand normal current draws associated with engine operation. When servicing the ECM, observe the following guidelines:


- Do not overload any circuit.
- Do not probe wires for testing. This can cause a voltage drop that would be critical to the operation of the ECM.
- When testing for opens and shorts, do not ground or apply voltage to any of the ECM's circuits unless instructed to do so.
- When measuring voltages, use only a digital voltmeter with an input impedance of at least 10 megohms.

- Do not jump start with more than 12 volts. This could cause damage to the electronic components.
- Do not employ any non-standard practices such as charging the battery with an arc welder.
- Take proper precautions to avoid static damage to the ECM. Refer to "Electrostatic Discharge Damage" for more information.

THROTTLE POSITION (TP) SENSOR

The throttle position (TP) sensor is a potentiometer connected to the throttle shaft on the throttle body which is built into the electronic governor. The ECM monitors the voltage on the signal line and calculates throttle position. As the throttle valve angle is changed, the TP sensor signal also changes. At a closed throttle position, the output of the TP sensor is low. As the throttle valve opens, the output increases so that at wide open throttle (WOT), the output voltage should be above 4 volts.

The ECM calculates fuel delivery based on throttle valve angle (operator demand). A broken or loose TP sensor may cause intermittent bursts of fuel from an injector and unstable idle because the ECM thinks the throttle is moving. A hard failure in the TP sensor 5-Volt reference or signal circuits for greater than 2 consecutive seconds will set either a DTC 12 or DTC 22. A hard failure with the TP sensor ground circuit for more than two consecutive seconds may set DTC 22. If either DTC 12 or DTC 22 are set, the throttle will be forced to a 6% (idle) position.



USE OF CIRCUIT TESTING TOOLS

Do not use a test light to diagnose the engine electrical systems unless specifically instructed by the diagnostic procedures. A test light can put an excessive load on an ECM circuit and result in component damage. For volt-age measurements, use only a digital voltmeter with an input impedance of at least 10 megohms.

ELECTROSTATIC DISCHARGE DAMAGE

Electronic components used in the ECM are often designed to carry very low voltage. Electronic components are susceptible to damage caused by electrostatic discharge. Less than 100 volts of static electricity can cause damage to some electronic components. By comparison, It takes as much as 4000 volts for a person to feel the spark of a static discharge.

There are several ways for a person to become statically charged. The most common methods of charging are by friction and induction.

An example of charging by friction is a person sliding across a seat.

Charge by induction occurs when a person with well-insulated shoes stands near a highly charged object and momentarily touches ground. Charges of the same polarity are drained off, leaving the person highly charged with the opposite polarity. Static charges can cause damage, therefore it is important to-use care when handling and testing electronic components.

To prevent possible electrostatic discharge damage, follow these guidelines:


- Do not touch the ECM connector pins or soldered components on the ECM board.
- Do not open the replacement part package until the part is ready to be installed.
- Before removing the part from the package, ground the package to a known good ground on the equipment.
- If the part has been handled while sliding across a seat, while sitting down from a standing position, or while walking a distance, touch a known good ground before installing the part.

Fuel System

FUEL INJECTOR

The Electronic Fuel Injection (EFI) fuel injector is a solenoidoperated device controlled by the ECM. The ECM energizes the solenoid, which opens a valve to allow fuel delivery.

The fuel is injected under pressure in a conical spray pattern at the opening of the intake valve. Excess fuel not used by the injectors passes through the fuel pressure regulator before being returned to the fuel tank. A fuel injector which is stuck partly open will cause a loss of fuel pressure after the engine is shut down, causing long crank times.



FUEL METERING SYSTEM COMPONENTS

The fuel metering system is made up of the following parts:

- · The fuel injectors
- · The fuel rail
- · The fuel pressure regulator/filter assembly
- · The electronic governor
- The ECM
- · The crankshaft position (CKP) sensor
- The camshaft position (CMP) sensor
- · The fuel pump
- · The fuel pump relay

BASIC SYSTEM OPERATION

The fuel metering system starts with the fuel in the fuel tank. The fuel is drawn up to the fuel pump through a pre-filter. The electric fuel pump then delivers the fuel to the fuel rail through an inane fuel filter. The pump is designed to provide fuel at a pressure above the pressure needed by the injectors. A fuel pressure regulator in the fuel filter assembly keeps fuel available to the fuel injectors at a constant pressure. A return line delivers unused fuel back to the tank.

3-174 3121139




Figure 3-91. Typical Fuel System

FUEL METERING SYSTEM PURPOSE

The basic function of the air/fuel metering system is to control the air/fuel delivery to the engine. Fuel is delivered to the engine by individual fuel injectors mounted in the intake manifold near each intake valve.

The main control sensor is the heated oxygen sensor (H02S) located in the exhaust system. The H02S tells the ECM how much oxygen is in the exhaust gas. The ECM changes the air/fuel ratio to the engine by control-ling the amount of time that the fuel injector is "ON." The best mixture to minimize exhaust emissions is 14.7 parts of air to 1 part of gasoline by weight, which provides the most efficient combustion. Because of the constant measuring and adjusting of the air/fuel ratio, the fuel injection system is called a "closed loop" system.


The ECM monitors signals from several sensors in order to determine the fuel needs of the engine. Fuel is delivered under one of several conditions called "modes." All modes are controlled by the ECM. Refer to "Open Loop and Closed Loop Operation" for more information.

FUEL PRESSURE REGULATOR

The fuel pressure regulator is a relief valve mounted in the fuel filter. It provides a constant fuel pressure of 441 kPa (64 psi).

If the pressure is too low, poor performance and a DTC 32 will set. If the pressure is too high, excessive odor and/or a DTC 42 will result.

When replacing the fuel filter, be sure to use an identical filter/ regulator assembly. A standard fuel filter does not regulate pressure and could cause engine problems or component damage.




FUEL PUMP ELECTRICAL CIRCUIT

When the key is first turned "ON," the ECM energizes the fuel pump relay for two seconds to build up the fuel pressure quickly. If the engine is not started within two seconds, the ECM shuts the fuel pump off and waits until the engine is cranked. When the engine is cranked and crankshaft position signal has been detected by the SECM, the ECM supplies 12 volts to the fuel pump relay to energize the electric fuel pump.

An inoperative fuel pump will cause a "no-start" condition. A fuel pump which does not provide enough pressure will result in poor performance.


FUEL RAIL

The fuel rail is mounted to the top of the engine and distributes fuel to the individual injectors. Fuel is delivered to the fuel inlet tube of the fuel rail by the fuel lines.



ELECTRONIC GOVERNOR AND THROTTLE BODY

In the 2.5L EFI industrial engine, throttle control is achieved by using an electronic governor which is controlled by the engine control module (ECM).



The electronic governor consists of a throttle body, an electronically-actuated throttle plate, and a built-in throttle position (TP) sensor. There are two pigtails that exit the governor body. The 3-wire pigtail connects the TP sensor to the ECM. Refer to "Throttle Position (TP) Sensor" for more information.

The 2-wire pigtail carries the throttle signal from the ECM to the governor. Desired engine speeds are stored in the configuration program for each specific application, and can be changed with the ECM calibration software. When an engine speed is selected with the toggle switch, the ECM sends the appropriate signal to the governor. This is a pulse-width modulated (PWM) signal which cannot be read with conventional diagnostic tools such as a voltmeter. A 12-volt signal is pulsed on and off at a high rate of speed. The width of the "on" pulse determines the amount of throttle opening. The ECM sends a signal with the appropriate pulse width to the governor based on the operator's choice of switch settings.

The electronic governor also acts as an idle air control (IAC) valve. Changes in engine load are detected by the ECM by comparing manifold absolute pressure (MAP) with throttle position. When the ECM detects a change in engine load, it can adjust idle speed by changing the PWM signal to the governor.

3-176 3121139

OPEN LOOP AND CLOSED LOOP OPERATION

The ECM will operate in the following two modes:

- Open loop
- Closed loop

When the engine is first started, the system is in "open loop" operation. In open loop, the ECM ignores the signal from the heated oxygen sensor (HO2S). it uses a pre-programmed routine to calculate the air/fuel ratio based on inputs from the TP, ECT, and MAP sensors.


The system remains in open loop until the following conditions are met:

- The HO2S has a varying voltage output showing that it is hot enough to operate properly (this depends on temperature).
- The ECT has reached 160°F (71°C).
- · Seven minutes has elapsed since starting the engine.

After these conditions are met, the engine is said to be operating in "closed loop." In closed loop, The ECM continuously adjusts the air/fuel ratio by responding to signals from the HO2S (except at wide-open throttle). When the HO2S reports a lean condition (low sensor signal voltage), the ECM responds by increasing the "on" time of the fuel injectors, thus enriching the mixture. When the HO2S reports a rich condition (high sensor signal Voltages the ECM responds by reducing the "on" time of the fuel injectors, thus leaning out the mixture.


CAMSHAFT POSITION (CMP) SENSOR

The CMP sensor uses a variable reactor sensor to detect camshaft position. The CMP signal is created as piston #1 is a predetermined number of degrees after top dead center on the power stroke.



CRANKSHAFT POSITION (CKP) SENSOR

The crankshaft position (CKP) sensor provides a signal used by the engine control module (ECM) to calculate the ignition sequence. The sensor initiates the reference pulses which the ECM uses to calculate RPM and crank-shaft position.



ELECTRONIC IGNITION


The electronic ignition system controls fuel combustion by providing a spark to ignite the compressed air/fuel w mixture at the correct time. To provide optimum engine performance, fuel economy, and control of exhaust emissions, the ECM controls the spark advance of the ignition system. Electronic ignition has the following advantages over a mechanical distributor system:

- · No moving parts
- · Less maintenance
- · Remote mounting capability
- · No mechanical load on the engine
- More coil cooldown time between firing events
- · Elimination of mechanical timing adjustments
- · Increased available ignition coil saturation time

IGNITION COIL

The electronic ignition system uses a coil pack with one ignition coil for each two cylinders in the engine. Each cylinder is paired with its opposing cylinder in the firing order, so that one cylinder on compression fires simultaneously with the opposing cylinder on exhaust. The spark that occurs in the cylinder on the exhaust stroke is referred to as a "waste spark."


The primary coils in the coil pack are triggered by the "Ignition Coil Feed #1" and "Ignition Coil Feed #2" Signals from the ECM.



ENGINE CONTROL MODULE (ECM)

The ECM is responsible for maintaining proper spark and fuel injection timing for all operating conditions. To provide optimum operation and emissions, the ECM monitors the input signals from the following components in order to calculate spark timing:

- Engine coolant temperature (ECT) sensor
- Intake air temperature (IAT) sensor
- · Throttle position sensor
- · Crankshaft position sensor



3-178 3121139

3.29 DEUTZEMR 2

The EMR2 consists of the sensors, the control unit and the actuator. Engine-side controls as well as the JLG Control System are connected by means of separate cable harnesses to the EMR control unit.

The sensors attached to the engine provide the electronics in the control unit with all the relevant physical parameters In accordance with the information of the current condition of the engine and the preconditions (throttle position etc.), the EMR2 controls an actuator that operates the control rod of the injection pump and thus doses the fuel quantity in accordance with the performance requirements.

The exact position of the regulating rod is reported back and, if necessary, is corrected, by means of the control rod travel sensor, situated together with the rotation magnets in a housing of the actuator.

The EMR2 is equipped with safety devices and measures in the hardware and software in order to ensure emergency running (Limp home) functions.

In order to switch the engine off, the EMR2 is switched in a deenergized fashion over the ignition switch. A strong spring in the actuator presses the control rod in the de-energized condition into the zero position. As a redundancy measure, an additional solenoid serves for switching off and this, independently of the actuator, also moves the control rod in the deenergized condition into the zero position.

After the programming, that is carried out over the ISO9141 interface, the EMR2 possesses a motor-specific data set and this is then fixedly assigned to the engine. Included in this are the various application cases as well as the customer's wishes regarding a particular scope of function.

Each EMR2 module is matched by serial number to the engine. Modules cannot be swapped between engines.




Figure 3-92. EMR 2 Engine Side Equipment

3-180 3121139




Figure 3-93. Deutz EMR 2 Troubleshooting Flow Chart




Figure 3-94. Deutz EMR 2 Vehicle Side Connection Diagram

3-182 3121139




Figure 3-95. Deutz EMR 2 Engine Side Connection Diagram - Sheet 1 of 2





Figure 3-96. Deutz EMR 2 Engine Side Connection Diagram - Sheet 2 of 2

3-184 3121139




| Pin No. | Designation | Description |
|---------|--|---|
| 1 | Reserve | Reserve |
| 2 | Output: digital 3 | Digital output for solenoid 1) |
| 3 | Output: digital 4 | For heating flange (optional)/ glow plug (optional) |
| 4 | Input (optional) Temp 1 | Fuel temperature ²⁾ |
| 5 | Input (optional) Temp 2 | Charge air temperature |
| 6 | Input (optional) DigIn 5 | Coolant level / oil level |
| 7 | Output: PWM2/digital 6 | |
| 8 | GND | Reference potential for analog signal at pin 9 |
| 9 | Input: analog 7 | Analog input for Coolant temperature sensor (NTC) |
| 10 | GND | Reference potential for analog signal at pin 11 |
| 11 | Multi-function input: speed 2/DigIn 2 | Digital input second engine speed (crankshaft) (optional) and speed signal (optional) |
| 12 | GND | Reference potential for analog signal at pin 13 |
| 13 | Input: speed 1 | Digital input first engine speed (camshaft) |
| 14 | STG - | PWM output, signal for actuator coil |
| 15 | STG + | PWM output, signal for actuator coil |
| 16 | Screen | Screening regulating rod travel sensor (for lines 17, 18, 19) |
| 17 | RF - | General connection for reference and measuring coil |
| 18 | RF REF | Analog input, reference signal of the reference coil |
| 19 | RF MESS | Analog input, measuring signal of the measuring coil |
| 20 | GND | Reference potential for signal at pin 21 |
| 21 | Input: analog 4/digital 9 | Analog input 4 (sensor signal oil pressure sensor) or digital input 9 |
| 22 | +5 V REF | +5 V Reference voltage for signal at pin 21 (max. 15 mA) |
| 23 | GND | Reference potential for signal at pin 24 |
| 24 | Input: analog 2/digital 7 | Analog input 2 (sensor signal charge air) or digital input 7 |
| 25 | +5 V LDA | +5 V Reference potential for signal at pin 24 (max. 15 mA) |

¹⁾ For continuous power: < 4 A

Figure 3-97. EMR 2 Engine Plug Pin Identification

²⁾ Corresponds to special function"fuel temperature compensation at the EMR (0211 2571)



| Pin-No. | Designation | Description |
|---------|--|--|
| 1 | U Batt - | Negative pole at battery (clamp 31) |
| 2 | GND | Reference potential for signal |
| 3 | Output: digital 2 | PWM or digital output, various functions |
| 4 | Input / output: DigInOut | Fault lamp and diagnostic button |
| 5 | Output: PWM 1/Dig 1 | PWM or digital output, various functions |
| 6 | Multi-function input: DigIn 3 | Genset applications/gear shift/motor brake |
| 7 | Input: digital 10/velocity | Speed signal (tacho input) |
| 8 | NC | Not occupied |
| 9 | NC | Not occupied |
| 10 | L-line | Serial ISO 9141 interface |
| 11 | K-line | Serial ISO 9141 interface |
| 12 | CAN high | Interface for CAN-Bus |
| 13 | CAN low | Interface for CAN-Bus |
| 14 | U Batt + | Positive pole for battery (clamp 15) |
| 15 | Output: digital 5 | Digital output, various functions |
| 16 | Output: digital 7/Frequency | Frequency, PWM or digital output, various functions |
| 17 | Ground | Reference potential for signal at pins 18, 19 and 21 |
| 18 | Input: digital 1 / PWM 1 | PWM 1 or digital input 1, various functions |
| 19 | Multi-function input: DigIn 4 | Performance curve switching/genset applications |
| 20 | Multi-function input: digital 8 / analog 3 | Hand hand throttle/genset applications, Digital (8) or analog input (3) |
| 21 | Input: digital 2 / PWM 2 | PWM 2 or digital input 2, various functions |
| 22 | Screen | Screening (e.g. for lines hand throttle or PWG) |
| 23 | GND | Reference potential for signal at pin 24 |
| 24 | Input: analog 1 / digital 6 | Analog input 1 (pedal value sensor, PWG) or digital input 6 |
| 25 | +5 V REF | +5 V Reference voltage for signal at pin 24 |

Figure 3-98. EMR 2 Vehicle Plug Pin Identification

3-186 3121139

| Fault | Fault no. (in SERDIA) | Fault locality/ Fault description | NPN | EM . | Cause | Remarks | Help |
|------------------------|-----------------------------|--------------------------------------|--------|---------------|--|---|--|
| Zero error display | ı | No faults | 524287 | 31 | No active faults present | | |
| | 3 | | 0 | | Sensor failure. Distance from gear | Governor in emergency operation (if sensor 2 available). Emergency switch-off (if sensor 2 not available or failed). | Check distance. Check cable |
| Revolutions | . | Speed sensor 1 | 061 | ₂₀ | cob lat. Additional addit impulses. | Governor in emergency operation (with sensor 1) Emergency switch-off (if sensor 1 not available or failed). | comecuon. Check sensor and replace if required. |
| / speed acquisition | 03 | Speed sensor | 84 | ω | Tacho failed. Additional fault impulses. Cable connection interrupted. | Governor in emergency operation. | Check cable connection and Tacho. Replace if required. |
| | 2 | Excess speed switch- | Ç | - | Speed was/is in excess of limit.e. | Engine stop. | Check parameter (21). Check speed settings. |
| | 04 | off | 081 |) | Check PID setting, Check rods. Check incorrect speed). Check No. of teeth. | Check PID setting. Check rods. Check actuator and replace if required. Check cable to actuator (impulse on incorrect speed). Check No. of teeth. For vehicles check for possible thrust mode. | κ cable to actuator (impulse on node. |
| | 07 | Charge air pressure | 102 | 2 | | | |
| | 80 | Oil pressure | 100 | 2 | | | |
| Sensors | 60 | Coolant temperature | 110 | 0 | Fault at corresponding sensor entry (e.g. short circuit or cable break). | With failure of the sensor the associated monitoring function is de-activated. | Check sensor cable. Check sensor and replace if required. Check fault limits for sensor. |
| | 10 | Charge air temperature | 105 | 2 | | | |
| | 11 | Fuel temperature | 174 | 7 | | | |

NOTE: SID is equal to 512. To get SPN #, add 512 + number. For example, SID 254 would be 512+254 or an SPN of 766.

Figure 3-99. EMR2 Fault Codes - Sheet 1 of 5

| Fault group | Fault no. (in SERDIA) | Fault locality/ Fault description | SPN | FMI | Cause | Remarks | Help |
|---------------------|-----------------------------|--------------------------------------|---------|-----|---|---|--|
| | 30 | Oil pressure warning | 100 | - | Oil pressure below speed- dependent warning line characteristic | Fault message (disappears when oil pressure is again above recovery limit). After a delay time - fill limitation. | Check engine (oil level, oil pump). Check oil pressure sensor and cable. Check oil pressure warning line characteristic. |
| | 31 | Coolant temperature warning | 110 | 0 | Coolant temperature has exceeded warning level. | Fault message (disappears when coolant temperature again drops below recovery level). After a delay time - fill limitation. | Check coolant. Check coolant temperature sensor and cable. |
| Functional fault | 32 | Charge air temperature warning | 105 | 0 | Charge air temperature has exceeded warning level. | Fault message (disappears when charge air temperature gain drops below recovery level). After a delay time - fill limitation. | Check charge air. Check charge air-temperature sensor and cable. |
| warning | 34 | Coolant level warning | 111 | - | Switch input "Low coolant level" is active. | Fault message. | Check coolant level. Check coolant level sensor and cable. |
| | 35 | Speed warning (with thrust mode | SID 190 | 41 | revolutions was/is above (top) revolution speed limt. "Thrust mode" function is active. | | Check parameters. Check speed settings. |
| | | operation). | | | Check PID setting. Check rods. Check sensor (impulses on incorrect speed) | Check PID setting. Check rods. Check actuator and replace if required. Check cable to actuator Check speed sensor (impulses on incorrect speed). Check No. of teeth. For vehicles check for possible thrust mode. | cable to actuator. Check speed for possible thrust mode. |
| | 36 | Fuel temperature warning | 174 | 0 | Fuel-temperature has exceeded warning level. | Fault message (disappears when fuel temperature again drops below recovery level). | Check fuel. Check fuel temperature sensor and cable. |

NOTE: SID is equal to 512. To get SPN #, add 512 + number. For example, SID 254 would be 512+254 or an SPN of 766.

Figure 3-100. EMR2 Fault Codes - Sheet 2 of 5

3-188 3121139

| dleH | Check charge air. Check charge air-temperature sensor and cable. Check switch-off limit. | Check coolant level. Check coolant level sensor and cable. | Check actuator, replace if required. Check cable, check fault limits for "Confirmation". | Check actuator replace if required. Check cable, check fault limits for "Rifeness confirmation". | Check actuator/actuator rods / injection pump, replace if required. Check actuator cable. | Check actuator and replaced if required. Check feedback cable. Check fault limits and reference values of the feedback. Program the fault limits for feedback, save values. Switch ignition off and on again. Check again. If faulty, inform DEUTZ-Service and carry out automatic equalization again. Set fault limits again. |
|--------------------------------------|--|--|--|--|---|---|
| Remarks | Emergency stop | Emergency stop. Start lock. | Emorranov ewitch off Activity | cannot be operated. | Fault message (disappears when difference is < 10 %). | Engine stop / start lock. Governor cannot be taken into use. EDC actuator calibration required. |
| Cause | Charge air temperature has exceeded switch-off limit. | Switch input "Low coolant level" is active. | Antintor and nonnontal Equition | Actuator confirmation. | Injection pump/actuator jammed or not connected. Difference between nominal/actual control travel is > 10 % of the overall control path. | No automatic actuator equalization possible. Incorrect input of the actuator reference values. |
| Ε | 0 | - | 12 | 13 | 7 | 13 |
| NAS | 105 | 111 | SID 24 | SID 24 | SID 23 | SID 23 |
| Fault locality/ Fault description | Charge air temperature switch- off | Coolant level switch- off | Feedback | Reference feedback | Control travel difference | Auto calibration BOSCH-EDC pumps faulty operation |
| Fault no. (in SERDIA) | 42 | 44 | 20 | 52 | 53 | 59 |
| Fault | Functional fault, switch-off | | | | Actuator | |

NOTE: SID is equal to 512. To get SPN #, add 512 + number. For example, SID 254 would be 512+254 or an SPN of 766.

Figure 3-101. EMR2 Fault Codes - Sheet 3 of 5

| Help | Check cable of digital output | (מפוס מוסמים | | | | Check CAN connection, terminating resistor (see Chapter | 12.4), Check control unit. | Check CAN connection, cable connection. Check sensor and replace if required. | Switch ignition off and on again. Check again. If faulty inform | | Note values of parameters (3895 and 3896). Switch ignition off and on again. Check again. If faulty inform DEUTZ Service. |
|--------------------------------------|---|--|---------------------------------------|------------------|-----------------|--|---|---|---|---|---|
| Remarks | Driver level is switched off. | Fault message. | | | | Application-dependent. | | | | Emergency switch-off. engine cannot be started. | |
| Cause | Fault (short circuit / cable break) at | מפונים במולימי. | | | | CAN-controller for CAN-bus is faulty. Fault emoval despite re-initialising continuously not possible | Overflow in input buffer or a transmission cannot be placed on the bus. | | Fault in parameter programming in the governor fixed value memory. | Constant monitoring of program memory shows error (so-called "Flash-test"). | Constant monitoring of working memory shows error. |
| FMI | 2 | 2 | 9 | Ξ | 2 | 12 | 6 | 14 | 12 | 12 | 2 |
| SPN | SID 51 | SID 60 | SID 51 | 91 | 868 | SID 231 | SID 231 | SID 231 | SID 253 | SID 240 | SID 254 |
| Fault locality/ Fault description | Digital output 3 (Switch-off solenoid, pin M 2) | Digital output 6, pin M 7 | Excess voltage switch-off solenoid | Error Hand Setp1 | Error CAN Setp1 | CAN-Bus controller | CAN interface SAE J 1939 | Cable break, short circuit or bus-error | Parameter programming (write EEPROM) | Cyclic program test | Cyclic RAM test |
| Fault no. | 09 | 62 | 63 | 29 | 89 | 70 | 71 | 74 | 92 | 77 | 78 |
| Fault | | Hardware | outputs | I | I | | Communi- cation | | | Memory | |

NOTE: SID is equal to 512. To get SPN #, add 512 + number. For example, SID 254 would be 512+254 or an SPN of 766.

Figure 3-102. EMR2 Fault Codes - Sheet 4 of 5

3-190 3121139

| deH | when Switch ignition off and on again. Check again. If faulty inform ange). DEUTZ Service. | . Check voltage Supply. Switch | | Service. | when ange). | | Check data for correct settings. Save parameters. Switch ignition off and on again. Check again. If faulty inform DEUTZ Service. | Note parameters (3897 and 3898). Switch lightion off and on again. Check again. If faulty inform DEUTZ Service. | |
|--------------------------------------|--|--------------------------------|--|--------------------------|---|---|---|---|----------------|
| Remarks | Fault message (disappears when power again in the normal range) | : : | Fault message (disappears when power again in the normal range). Auxiliary value 5 V | | Fault message (disappears when power again in the normal range) | Fault message (disappears when power again in normal range). Atmospheric pressure monitoring function de-activated. | Engine cannot be started. | Emergency switch-off. Engine cannot be started. | |
| Cause | Power supply for actuator not in the permissible range. | | Reference voltage for actuator not in the permissible range. | | Internal temperature for control unit not in permissible range. | Atmospheric pressure not in permissible range. | No data found or checksum of data is faulty (note: fault only occurs during setting of parameter / saving or reset.). | Internal calculation fault (so-called "Stack overflow" fault). | |
| E E | 7 | 7 | 2 | 7 | 12 | 12 | 2 | 8 | 7 |
| NPN | SID 254 | SID 254 | SID 254 | SID 254 | 171 | 108 | SID 253 | SID 240 | SID 254 |
| Fault locality/ Fault description | Power supply (Actuator) | Reference voltage 1 | Reference voltage 2 | Reference voltage 4 | Internal temperature | Atmospheric pressure | Parameter fault (EEPROM retrieval or checksum faulty). | Stack overflow | Internal fault |
| Fault no. (in SERDIA) | 80 | 83 | 84 | 85 | 98 | 87 | 06 | 93 | 94 |
| Fault | | | : - | Control unit hardware | | | | Program logic | |

NOTE: SID is equal to 512. To get SPN #, add 512 + number. For example, SID 254 would be 512+254 or an SPN of 766.

Figure 3-103. EMR2 Fault Codes - Sheet 5 of 5

3.30 GM ENGINE GENERAL MAINTENANCE

Maintenance of the Drive Belt

The serpentine drive belt utilizes a spring loaded tensioner which keeps the belt properly adjusted. The drive belt is an integral part of the cooling and charging systems and should be inspected frequently.

When inspecting the belts check for:

- · Cracks or breaks
- · Chunking of the belt
- Splits
- Material hanging from the belt
- Glazing and hardening
- · Damaged or improperly aligned pulleys
- · Improperly performing tensioner

Check the belt tensioner by pressing down on the midway point of the longest stretch between pulleys. The belt should not depress beyond 1/2 in. (13mm). If the depression is more than allowable adjust the tension.

NOTICE

THE ENGINE MANUFACTURER DOES NOT RECOMMEND THE USE OF "BELT DRESSING" OR "ANTI SLIPPING AGENTS" ON THE DRIVE BELT.

Engine Electrical System Maintenance

The engine electrical system incorporates computers and microprocessors to control the engine ignition, fuel control, and emissions. Due to the sensitivity of the computers to good electrical connections periodic inspection of the electrical wiring is necessary. When inspecting the electrical system use the following:

- Check and clean the battery terminal connections and insure the connections are tight
- Check the battery for any cracks or damage to the case
- Check the Positive and Negative battery cables for any corrosion build up, rubbing or chafing, check connection on the chassis to insure they are tight
- Check the entire engine wire harness for rubbing chafing, cuts or damaged connections, repair if necessary
- Check all wire harness connectors to insure they are fully seated and locked

- Check ignition coil and spark plug cables for hardening, cracking, chafing, separation, split boot covers and proper fit
- Replace spark plugs at the proper intervals as prescribed in the engine manufacturer's manual
- Check to make sure all electrical components are fitted securely
- Check the ground and platform control stations to insure all warning indicator lights are functioning

Checking/Filling Engine Oil Level

NOTICE

AN OVERFILLED CRANKCASE (OIL LEVEL OVER THE SPECIFIED FULL MARK) CAN CAUSE AN OIL LEAK, A FLUCTUATION OR DROP IN THE OIL PRESSURE, AND ROCKER ARM "CLATTER" IN THE ENGINE.

NOTICE

CARE MUST BE TAKEN WHEN CHECKING THE ENGINE OIL LEVEL. OIL LEVEL MUST BE MAINTAINED BETWEEN THE "ADD" MARK AND "FULL" MARK ON THE DIPSTICK.

To ensure that you are not getting a false reading, make sure the following steps are taken to before check the oil level.

- 1. Stop the engine if in use.
- **2.** Allow sufficient time (approximately 5 minutes) for the oil to drain back into the oil pan.
- **3.** Remove the dipstick. Wipe with a clean cloth or paper towel and reinstall. Push the dipstick all the way into the dipstick tube.
- **4.** Remove the dipstick and note the oil level.
- 5. Oil level must be between the "FULL" and "ADD" marks.




Figure 3-104. Engine Oil Dip Stick

3-192 3121139

- **6.** If the oil level is below the "ADD" mark, proceed to Step 7 and 8 and reinstall the dipstick into the dipstick tube.
- Remove the oil filter cap from the valve rocker arm cover.
- **8.** Add the required amount of oil to bring the level up to but not over "FULL" mark on the dipstick.
- **9.** Reinstall the oil fill cap to the valve rocker cover and wipe away any excess oil.

Changing The Engine Oil

NOTICE

WHEN CHANGING THE OIL, ALWAYS CHANGE THE OIL FILTER. CHANGE OIL WHEN THE ENGINE IS WARM FROM OPERATION AS THE OILS WILL FLOW FREELY AND CARRY AWAY MORE IMPURITIES.

To change the oil use the following steps:

- Start the engine and run until it reaches normal operating temperature.
- 2. Stop the engine.
- **3.** Remove the drain plug and allow the oil to drain.
- 4. Remove and discard the oil filter and its sealing ring.
- 5. Coat the sealing ring on the filter with clean engine oil and wipe the sealing surface on the filter mounting surface to remove any dust, dirt and debris. Tighten the filter securely (follow the filter manufacturers instructions). Do not over tighten.
- **6.** Check the sealing ring on drain plug for any damage, replace if necessary, wipe the plug with a clean rag, and wipe the sealing surface on the pan and reinstall the pan plug. Do not over tighten.
- 7. Fill the crankcase with oil.
- 8. Start the engine and check for oil leaks.
- Stop the engine and check the oil level to insure the oil level is at "FULL".
- **10.** Dispose of the oil and filter in a safe manner.

Coolant Fill Procedure - Dual Fuel Engine

NOTICE

DAMAGE TO THE ENGINE COULD OCCUR IF NOT PROPERLY FILLED WITH COOLANT. LPG FUELED ENGINES ARE MOST PRONE TO CREATING AN AIR LOCK DURING A COOLANT FILL OPERATION DUE TO THE ELECTRONIC PRESSURE REGULATOR (EPR) BEING THE HIGHEST POINT IN THE COOLING SYSTEM. AN EPR THAT APPEARS TO HAVE FROST FORMING ON IT IS A SIGN THAT THE ENGINE COOLING SYSTEM CONTAINS AIR. THE APPEARANCE AND TEMPERATURE OF THE EPR SHOULD BE MONITORED DURING THE COOLANT FILL OPERATION. A WARM EPR IS AN INDICATION THAT THE COOLING SYSTEM IS PROPERLY FILLED AND FUNCTIONING.

A CAUTION

MAKE SURE ENGINE IS COOL BEFORE PERFORMING ANY MAINTENANCE WORK.

Loosen the worm gear clamp on the coolant line running into the EPR as shown below and remove the hose from the EPR. Place a rag under the hose to prevent coolant from running onto the engine/machine.



Remove the radiator cap. Fill the radiator with coolant until coolant starts to appear from the previously removed hose at the EPR. Reinstall the hose back onto the EPR and continue to fill radiator with coolant.



3. With the radiator cap still removed, start the engine and run until the thermostat opens. The thermostat opens at 170° F (77° C), which can be checked using the JLG handheld analyzer.

NOTICE

WHILE ENGINE IS RUNNING, AIR AND/OR STEAM MAY BE PRESENT COMING FROM THE RADIATOR. THIS IS NORMAL.

4. After running the engine for 5 minutes after it has reached operating temperature, shut the engine off and continue to step 5.

A CAUTION

WITH THE ENGINE RUNNING OR WHEN SHUTTING OFF THE ENGINE, SOME HEATED COOLANT MAY SPILL OUT DUE TO AIR "BURPING" OUT OF THE SYSTEM WITH THE RADIATOR CAP OFF.

5. Next, verify that the 2 coolant hoses on the EPR are warm. If they are not warm repeat step 3 and 4, otherwise continue to step 6.

NOTICE

A PROPERLY PURGED COOLING SYSTEM WILL YIELD A WARM UPPER RADIATOR HOSE AND A WARM EPR HOSE. IF THE UPPER RADIATOR HOSE AND/OR EPR HOSE ARE NOT WARM TO THE TOUCH AFTER THE ENGINE HAS RUN FOR 5-8 MINUTES AFTER REACHING OPERATING TEMPERATURE, THE SYSTEM MAY STILL CONTAIN AIR. IT MAY BE NECESSARY TO REPEAT THE ABOVE STEPS.

6. Fill radiator with coolant as needed and install the radiator cap. Next, remove the cap off the coolant recovery bottle and fill just below the HOT FULL line and reinstall the caps.



3.31 GM ENGINE DUAL FUEL SYSTEM

The Dual Fuel system allows the operator to operate the vehicle on either gasoline or LPG by positioning a selector switch in the operator's platform. When the operator places the selector switch in the gasoline mode the gasoline fuel pump is energized. While in the gasoline mode the LPG fuel lock-off is isolated and will not energize. In addition the gasoline injector circuit is enabled and injector pulses are provided to each injector and the ECM calibration for gasoline is also enabled. When the operator selects the LPG mode the Low Pressure LPG lock-off is energized and fuel from the LPG tank flows to the Electronic Pressure Regulator (EPR). The EPR receives an electronic signal to position the secondary lever for the start or run positions and when the engine begins to crank the mixer air valve will rise and fuel will begin flowing to engine. During this mode the gasoline fuel pump is isolated and will not be activated. The primary components of the gasoline dual fuel system are the gasoline tank, electric fuel pump and filter, fuel supply line, injector rail and injectors and the fuel pressure regulator. The primary components of the LPG dual fuel system are the LPG fuel tank, in-fuel filter, LPG Low Pressure lockoff, Electronic Pressure Regulator (EPR) and the fuel mixer module. The LPG fuel system operates at pressures which range from 14.0 in. (355.60 mm) of water column up to 312 psi (21.5 BAR).

Components which are shared by both systems include the Electronic Throttle Control and the ECM. The ECM contains a dual calibration; one controls the gasoline fuel system during gasoline operation and one controls the LPG fuel system during LPG operation.

3-194 3121139

Fuel Filter

Propane fuel like all other motor fuels is subject to contamination from outside sources. Refueling of the equipment's tank and removal of the tank from the equipment can inadvertently introduce dirt and other foreign matter into the fuel system. It is therefore necessary to filter the fuel prior to entering the fuel system components downstream of the tank. An inline fuel filter has been installed in the fuel system to remove the dirt and foreign matter from the fuel. The inline filter is replaceable as a unit only. Maintenance of the filter is critical to proper operation of the fuel system and should be replaced as Section 1. In severe operating condition more frequent replacement of the filter may be necessary.

Electric Lock Off

The Electric Lock Off device is an integrated assembly. When energized the solenoid opens the valve and allows the Propane fuel to flow through the device. The valve opens during cranking and run cycles of the engine. The lock off supply voltage is controlled by the engine control module (ECM).





Figure 3-105. Electric Fuel Lock Off

EPR Assembly

The EPR assembly is a combination Low Pressure Regulator and a Voice Coil Assembly. The Voice coil is an electronic actuator which is controlled by an internal microprocessor. The microprocessor provides output data to the ECM and receives input data over a CAN BUS connection. The internal microprocessor receives electrical signals from the Fuel Pressure Sensor FPS and the Fuel Temperature Pressure FTP and communicates the data to the ECM. The ECM uses the FPS and FTP data to calculate the location of the secondary lever in the LPR and sends that data back to the EPR via the CAN BUS. The internal microprocessor in the EPR will then output a signal, which causes the voice coil to move and position the secondary lever to the correct location.



- 1. Pressure Regulator Section
- Fuel Inlet
- Coolant Passage
- Primary Test Port
- Secondary Test Port
- Voice Coil Section

Figure 3-106. EPR Assembly

3121139 3-195

Low Pressure Regulator (LPR)

The LPR is a combination vaporizer, pressure regulating device. The LPR is a negative pressure, two stage regulator that is normally closed when the engine is not running. When the engine is cranking or running, a partial vacuum is created in the fuel line which connects the regulator to the mixer. This partial vacuum opens the regulator permitting fuel to flow to the mixer.

Propane fuel enters the primary port of the LPR and passes through the primary jet and into the primary/ exchanger chamber. As the propane passes through the heat exchanger the fuel expands and creates pressure inside the chamber. The pressure rises as the fuel expands when the pressure rises above 1.5 psi (10.34 kpa), sufficient pressure is exerted on the primary diaphragm to cause the diaphragm plate to pivot and press against the primary valve pin thus closing off the flow of fuel. This action causes the flow of fuel into the regulator to be regulated.

When the engine is cranking, sufficient vacuum will be introduced into the secondary chamber from the mixer drawing the secondary diaphragm down onto the spring loaded lever and opening the secondary valve allowing vaporized fuel to pass to the mixer. This mechanical action in conjunction with the EPR reactions causes the downward action on the secondary lever causing it to open wider allowing more fuel to flow to the mixer.

NOTICE

THE VOICE COIL SECTION OF THE EPR ASSEMBLY IS AN EMISSIONS CONTROL DEVICE AND CANNOT BE REBUILT. IF THE COIL ASSEMBLY FAILS TO OPERATE PROPERLY, REPLACE IT WITH AN OEM REPLACEMENT PART ONLY.




Figure 3-107. Low Pressure Regulators

Air Fuel Mixer

The air valve mixer is an air-fuel metering device and is completely self-contained. The mixer is an air valve design, utilizing a relatively constant pressure drop to draw fuel into the mixer from cranking to full load. The mixer is mounted in the air stream ahead of the throttle control device.

When the engine begins to crank, it draws in air with the air valve covering the inlet, negative pressure begins to build. This negative pressure signal is communicated to the top of the air valve chamber through 4 vacuum ports in the air valve assembly. A pressure/force imbalance begins to build across the air valve diaphragm between the air valve vacuum chamber and the atmospheric pressure below the diaphragm. The air valve vacuum spring is calibrated to generate from 4.0 in. (101.6 mm) of water column at start to as high as 14.0 in. (355.60 mm) of water column at full throttle. The vacuum being created is referred to as Air Valve Vacuum (AVV). As the air valve vacuum reaches 4.0 in. (101.6mm) of water column, the air valve begins to lift against the air valve spring. The amount of AVV generated is a direct result of the throttle position. At low engine speed the air valve vacuum is low and the air valve position is low thus creating a small venturi for the fuel to flow. As the engine speed increase the AVV increases and the air valve is lifted higher thus creating a much larger venturi. This air valve vacuum is communicated from the mixer venture to the LPR secondary chamber via the low pressure fuel supply hose. As the AVV increases in the secondary chamber the secondary diaphragm is drawn further down forcing the secondary valve lever to open wider.




Figure 3-108. Air Fuel Mixer

3-196 3121139

Electronic Throttle Control (ETC)

Engine speed and load control is maintained by an ETC device. Speed and load control are determined by the ECM. Defaults programmed into the ECM software and throttle position sensors allow the ECM to maintain safe operating control over the engine. The Electronic Throttle Control device or "throttle body assembly" is connected to the intake manifold of the engine. The electronic throttle control device utilizes an electric motor connected to the throttle shaft. When the engine is running electrical signals are sent from the equipment controls to the engine ECM when the operator depresses an equipment function switch. The ECM then sends an electrical signal to the motor on the electronic throttle control to increase or decrease the angle of the throttle blade thus increasing or decreasing the air/fuel flow to the engine.

The electronic throttle control device also incorporates two internal Throttle Position Sensors (TPS) which provide output signals to the ECM as to the location of the throttle shaft and blade. The TPS information is used by the ECM to correct speed and load control as well as emission control.




Figure 3-109. ETC throttle control device

Engine Control Module

To obtain maximum effect from the catalyst and accurate control of the air fuel ratio the emission certified engine is equipped with an onboard computer or Engine Control Unit (ECM). The ECM is a 32 bit controller which receives input data from sensors fitted to the engine and fuel system and then outputs various signals to control engine operation.

One specific function of the controller is to maintain "closed loop fuel control". Closed loop fuel control is accomplished when the exhaust gas oxygen sensor (HEGO) mounted in the exhaust system sends a voltage signal to the controller. The controller then calculates any correction that may need to be made to the air fuel ratio. The controller then outputs signals to the EPR to correct the amount of fuel being supplied to the mixer. At the same time the ECM may correct the throttle blade position to correct speed and load of the engine.

The controller also performs diagnostic functions on the fuel system and notifies the operator of malfunctions by turning on a Malfunction Indicator Light (MIL) mounted in the Ground Control Station and the Platform Control Station. Malfunctions in the system are identified by a Diagnostic Code number. In addition to notifying the operator of the malfunction in the system the controller also stores the information about the malfunction in its memory.




Figure 3-110. LPG Engine Control Unit (ECM)




Figure 3-111. ECM Assembly

Heated Exhaust Gas Oxygen Sensor

There are two Heated Exhaust Gas Oxygen Sensors (HEGO). The first HEGO is mounted in the exhaust system downstream of the engine. It is used to measure the amount of oxygen present in the exhaust stream and communicate that to the ECM via an electrical signal. The amount of oxygen present in the exhaust stream indicates whether the fuel/air ratio is too rich or too lean. If the HEGO sensor signal indicates that the exhaust stream is too rich the ECM will decrease or lean the fuel mixture during engine operation, if the mixture is too lean the ECM will richen the mixture. The ECM continuously monitors the HEGO sensor output. If a rich or lean condition is present for an extended period of time, and the ECM cannot correct the condition, the ECM will set a diagnostic code and turn on the MIL light in control box.

The second HEGO is mounted in the exhaust system after the muffler. It measures the amount of oxygen in the exhaust system after the catalyst treatment has been completed in the muffler. If the ECM detects that the catalytic action in the muffler is not sufficient and fuel correction cannot correct the malfunction the MIL light is illuminated in the control box and a DTC code will stored in the computer.

NOTICE

THE HEATED EXHAUST GAS OXYGEN SENSOR IS AN EMISSION CONTROL DEVICE. IF THE HEGO FAILS TO OPERATE, REPLACE IT WITH AN OEM REPLACEMENT PART. THE HEGO SENSOR IS SENSITIVE TO SILICONE OR SILICONE BASED PRODUCTS AND CAN BECOME CONTAMINATED. AVOID USING SILICONE SEALERS OR HOSES TREATED WITH SILICONE LUBRICANTS IN THE AIR STREAM OR FUEL LINES.



Figure 3-112. Heated Exhaust Gas Oxygen Sensor (HEGO)

Gasoline Multi Point Fuel Injection System (MPFI)

The primary components of the Gasoline Multi Point Fuel Injection (MPFI) fuel system are the fuel tank, electric fuel pump, fuel pressure and temperature sensor manifold, fuel filter and fuel rail.

Gasoline Fuel Pump

The Gasoline is stored as a liquid in the fuel tank and in drawn into the fuel system by an electric fuel pump. The fuel pump will receive a signal from the ECM to prime the fuel system for approximately 2 seconds prior to start. Priming of the fuel system provides for a quicker start, when the engine begins to crank

Gasoline Pressure And Temperature Sensor Manifold

This engine is equipped with a fuel injector rail that does not have a pressure regulator or a return circuit to the fuel tank. Fuel pressure for this engine is regulated by the engine's ECM. The ECM receive fuel pressure and temperature feedback from the gasoline fuel sensor manifold and uses this information to control the ground side of the fuel pump. Fuel pressure is regulated by the ECM pulse width modulating (PWM) the fuel pump. The fuel pressure and temperature sensor manifold has a return or "bleed" circuit that connects back to the fuel tank. This circuit is used to bleed off any vapor that develops in the line and return a small amount of fuel to the tank. The fuel comes from the fuel tank and passes through the fuel pump. Fuel exits the fuel pump, passes through the filter and then enters the fuel pressure and temperature manifold assembly. Fuel flows through the feed circuit and is delivered to the fuel injector rail. Fuel that enters the bleed circuits through they bypass valve in the manifold is returned to the fuel tank.




Figure 3-113. Gasoline Fuel Pressure and Temperature Manifold Assembly

3-198 3121139

Fuel Filter

After the fuel is drawn into the fuel pump, the fuel flows through the gasoline fuel filter. The fuel filter will trap small particles as the fuel passes through the filter to remove debris and prevents the fuel pressure and temperature manifold and fuel injectors from becoming damaged. Maintenance of the fuel filter is required as indicated in Section 1.

Fuel Injector Rail

Fuel flows from the fuel pressure and temperature manifold assembly to the fuel rails where the fuel is delivered to the fuel injectors. The fuel rail also contains a Schrader valve which is utilized to test the regulated pressure of the fuel system.

Fuel Injector

The fuel supply is maintained on the top of the injector from the injector rail. The injector is fed a "pulse" signal through the wire harness which causes the injector to open. During regular operating conditions the ECM controls the opening and duration of opening of the injector. During lower RPM operation the injector signals or "pulses" are less frequent then when the engine is operating at higher RPMs. The engine has been calibrated to deliver the precise amount of fuel for optimum performance and emission control.

3.32 GM ENGINE FUEL SYSTEM REPAIR

Propane Fuel System Pressure Relief

▲ CAUTION

THE PROPANE FUEL SYSTEM OPERATES AT PRESSURES UP TO 312 PSI (21.5 BAR). TO MINIMIZE THE RISK OF FIRE AND PERSONAL INJURY, RELIEVE THE PROPANE FUEL SYSTEM PRESSURE (WHERE APPLICABLE) BEFORE SERVICING THE PROPANE FUEL SYSTEM COMPONENTS.

To relieve propane fuel system pressure:

- Close the manual shut-off valve on the propane fuel tank.
- 2. Start and run the vehicle until the engine stalls.
- 3. Turn the ignition switch OFF.

NOTICE

RESIDUAL VAPOR PRESSURE WILL BE PRESENT IN THE FUEL SYSTEM. ENSURE THE WORK AREA IS WELL VENTILATED BEFORE DISCONNECTING ANY FUEL LINE.


Propane Fuel System Leak Test

▲ CAUTION

NEVER USE AN OPEN FLAME OF ANY TYPE TO CHECK FOR PROPANE FUEL SYSTEM LEAKS.

Always inspect the propane fuel system for leaks after performing service. Check for leaks at the fittings of the serviced or replaced component. Use a commercially available liquid leak detector or an electronic leak detector. When using both methods, use the electronic leak detector first to avoid contamination by the liquid leak detector.

Propane Fuel Filter Replacement



- Electric Lock Off Solenoid
- 2. Mounting Plate
- 3. Housing Seal
- 4. Filter Magnet
- 5. Filter Housing
- 6. Seal
- 7. Electrical Connector
- 8. Fuel Outlet
- 9. 0-ring
- 10. Filter
- 11. Fuel Inlet
- 12. Retaining Bolt
- 13. Ring

Figure 3-114. Filter Lock Assembly

REMOVAL

- **1.** Relieve the propane fuel system pressure. Refer to Propane Fuel System Pressure Relief.
- 2. Disconnect the negative battery cable.
- **3.** Slowly loosen the Filter housing retaining bolt and remove it.
- 4. Pull the filter housing from the Electric lock off assembly.
- 5. Locate Filter magnet and remove it.
- Remove the filter from the housing.
- 7. Remove and discard the housing seal.
- 8. Remove and discard the retaining bolt seal.
- Remove and discard mounting plate to lock off o-ring seal.

INSTALLATION


NOTICE

BE SURE TO REINSTALL THE FILTER MAGNET INTO THE HOUSING BEFORE INSTALLING NEW SEAL.

- 1. Install the mounting plate to lock off o-ring seal.
- 2. Install the retaining bolt seal.
- 3. Install the housing seal.
- 4. Drop the magnet into the bottom of the filter housing.
- 5. Install the filter into the housing.
- 6. Install the retaining bolt into the filter housing.
- 7. Install the filter up to the bottom of the electric lock off.
- 8. Tighten the filter retaining bolt to 106 in. lbs. (12 Nm).
- Open manual shut-off valve. Start the vehicle and leak check the propane fuel system at each serviced fitting Refer to Propane Fuel System Leak Test.

3-200 3121139

Electronic Pressure Regulator (EPR) Assembly Replacement



- 1. Pressure Regulator Section
- 2. Fuel Inlet
- 3. Coolant Passage
- 4. Primary Test Port
- 5. Secondary Test Port
- 6. Voice Coil Section

Figure 3-115. EPR Assembly

The EPR assembly is a made up of two separate components. The Voice Coil Section is not serviceable and can only be replaced as an assembly. The pressure regulator section is serviceable and will be detailed in this section.

REMOVAL

- Relieve the propane fuel system pressure. Refer to Propane Fuel System Pressure Relief.
- 2. Disconnect the negative battery cable.
- Slowly remove the fuel inlet fitting at the Electric Lock Off.

NOTE: Residual vapor pressure will be present in the fuel system.

- Disconnect the electrical connector to the Electric Lock off.
- **5.** Remove the Electric Lock Off from the regulator.
- **6.** Remove the lock pin from the vapor fitting on the regulator housing and remove the fitting and hose and retain the pin.
- Remove the lock pin from the pressure sensor on the regulator housing and remove the Sensor and retain the pin.
- **8.** Using a clamp pliers pinch off the hoses on the coolant lines to the regulator
- Remove the lock pin from both the water fittings on the regulator housing and remove the fittings and hoses and retain the pin

- 10. Disconnect the EPR electrical connector
- Remove the (3) three nuts from the EPR isolators and the EPR mounting bracket
- 12. Remove the EPR from the bracket
- **13.** Remove the (3) three mounting isolators

INSTALLATION

NOTICE

DO NOT USE TEFLON TAPE ON ANY FUEL FITTING. USE A LIQUID PIPE THREAD SEALANT WHEN INSTALLING FITTINGS.

CHECK ALL THE O-RINGS ON THE VAPOR AND WATER FITTINGS FOR ANY DAMAGE REPLACE IF NECESSARY.

LUBE ALL THE O-RINGS WITH AN O-RING LUBE BEFORE INSTALLING.

- Install the three (3) rubber isolators to the bottom of the EPR
- Install the EPR assembly to the bracket and tighten the retaining nuts.

NOTE: Do not over tighten the isolators and cause a separation of the isolators.

- **3.** Install the fuel temperature sensor into the regulator opening and lock in place with the locking pin, connect the electrical connector.
- **4.** Insert the fuel vapor line and fitting into the regulator port and lock in place with the locking pin.
- Install both the water hoses and fittings into the regulator and lock in place with the locking pin remove the clamp pliers from the hoses.
- Install the electric lock off into the regulator inlet and tighten into proper location, connect the electrical connector.
- Connect the fuel supply line and tighten until fully seated.
- 8. Connect the EPR electrical connector.
- 9. Open the manual valve.

 Start the vehicle and leak check the propane fuel system at each serviced fitting Refer to Propane Fuel System Leak Test.




Figure 3-116. Pressure Regulator Section

PRESSURE REGULATOR SECTION REMOVAL

- 1. Remove the EPR refer to EPR Removal Procedure.
- Remove the six (6) regulator to voice coil screws using the special tool and separate the regulator from the actuator.

NOTICE

DO NOT REMOVE THE SECONDARY DIAPHRAGM RETAINING PLATE AND DIAPHRAGM THIS WILL VOID THE WARRANTY OF THE ACTUATOR SECTION.

PRESSURE REGULATOR SECTION INSTALLATION

- Install the regulator to the actuator section using the six (6) retaining screws and tighten 70 in. lbs. (8 Nm).
- 2. Install the EPR refer to EPR Installation.

Temperature Manifold Absolute Pressure (TMAP) Sensor




Figure 3-117. (TMAP) Sensor & Electronic Throttle Control (ETC)

REMOVAL

- 1. Disconnect the TMAP electrical connector.
- 2. Remove the two retaining bolts.
- 3. Remove the TMAP.

INSTALLATION

NOTE: Apply a small amount of o-ring lubricant before installation.

- 1. Install in the TMAP.
- 2. Tighten retaining bolts to 62 lb-in (7 Nm).
- **3.** Start the vehicle and check for proper operation.

3-202 3121139

Electronic Throttle Control Replacement

See Figure 3-117.

REMOVAL

- 1. Disconnect the negative battery cable.
- 2. Remove the air intake duct.
- **3.** Release the hose clamp on the vapor fuel line and remove the vapor hose.
- 4. Disconnect the TMAP electrical connector.
- 5. Disconnect the electronic throttle control connector.
- **6.** Remove the manifold to throttle body adapter bolts and remove the throttle body mixer assembly.
- **7.** Pull the throttle body assembly from the adapter.
- 8. Remove electronic throttle control device.
- **9.** Remove the o-rings gasket and discard.

INSTALLATION

NOTICE

LIGHTLY LUBRICATE BOTH THROTTLE CONTROL DEVICE TO ADAPTER O-RINGS.

 Install the o-ring on throttle body. Press it down to the bottom of the surface.



Install the two quad seals. Install one seal at a time to insure the seal does not roll. The seal must sit flat on the throttle body.



3. Attach mixer and throttle body together. The two parts do not bolt together; they will be secured when you mount it on the intake. Notice the orientation of the air inlet and throttle body cover.



Place gasket on intake manifold and attach mixer/throttle assembly to manifold.




Figure 3-118. Mixer Assembly

Mixer Replacement

See Figure 3-118.

REMOVAL

- Remove the Throttle control device Refer to Electronic Throttle Body Replacement.
- Remove the four (4) bolts to the throttle control device to mixer adapter bolts.
- 3. Remove and discard the mixer to adapter gasket.

INSTALLATION

NOTICE

COVER THROTTLE BODY ADAPTER OPENING TO PREVENT DEBRIS FROM ENTERING ENGINE UNTIL REASSEMBLY.

- 1. Install Mixer to adapter gasket onto the mixer.
- Install the mixer to the throttle control device to mixer adapter and secure with the 4 retaining screws. Tighten 80 in. lbs. (9 Nm).
- **3.** Install Throttle body. Refer to Electronic Throttle Control Device Replacement.
- Start the engine and leak check all fittings and connections.

Coolant Hose Replacement

REMOVAL

- 1. Drain the coolant.
- Using hose clamp pliers, disconnect both hose clamps on each hose.
- **3.** Remove the hose from each of the fittings.

INSTALLATION

NOTE: Use hose material and lengths specified by JLG.

- Install the hose clamps to each hose and set the clamp back on each hose to make installation easier.
- 2. Fit the hose to the fittings.
- 3. Secure by positioning each of the clamps.

Vapor Hose Replacement

REMOVAL

- 1. Using hose clamp pliers disconnect both hose clamps.
- 2. Remove the vapor hose from each fitting.

INSTALLATION

NOTICE

THE VAPOR SUPPLY HOSE IS SPECIFICALLY DESIGNED, DO NOT USE HOSE MATERIAL OR LENGTH OTHER THAN JLG SPECIFIED PARTS.

- 1. Install hose clamps and set back on each hose.
- Reinstall the vapor hose to each fitting.
- 3. Reset clamps.
- 4. Start engine and check for leaks.

3-204 3121139

Engine Control Module Replacement

REMOVAL

- 1. Disconnect Negative battery cable.
- 2. Remove controller from mounting bracket.
- 3. Push connector lock back to unlock connector.
- **4.** Unplug controller and remove.

INSTALLATION

NOTICE

THE CONTROLLER IS CALIBRATED FOR EACH ENGINE VERIFY YOU HAVE THE CORRECT CONTROLLER

- 1. Plug connector into controller.
- 2. Push lock into place.
- 3. Mount controller into mounting bracket.
- **4.** Reconnect the battery cable.
- 5. Start engine.
- **6.** Check for any DTC codes and clear.
- Verify engine is in closed loop and no warning lights are illuminated.

Heated Exhaust Gas Oxygen Sensor Replacement

REMOVAL

- 1. Disconnect Negative battery cable.
- 2. Disconnect the O2 sensor electrical connector.
- **3.** Using an O2 Sensor socket, remove the O2 Sensor and discard.

INSTALLATION

NOTICE

BEFORE INSTALL THE 02 SENSOR LUBRICATE THREADS WITH ANTI-SEIZE COMPOUND GM P/N 5613695 or equivalent. Avoid getting compound on the sensor tip.

- 1. Install O2 sensor. Tighten to 30 lb-ft (41 Nm).
- 2. Start engine.
- 3. Check for any DTC codes and clear.
- **4.** Verify engine is in closed loop and no warning lights are illuminated.

3.33 GM ENGINE LPG FUEL SYSTEM DIAGNOSIS

Fuel System Description




Figure 3-119. EPR Assembly

To maintain fuel and emission control on the LPG fuel system the Engine Control Units (ECM) relies on numerous engine sensor and output data from the Electronic Pressure Regulator (EPR). The ECM will then determine the target fuel calibration and command the EPR to reposition the voice coil to the proper position which, subsequently reposition the secondary lever in the pressure regulator to maintain proper control. The EPR and ECM will continue to communicate back and forth during normal operation.

In the event that the EPR fails to communicate or the Communications Area Network (CAN) cable fails to transmit data the regulator will operate in an open loop configuration. As the air valve vacuum in the mixer venturi is communicated to the secondary chamber of the regulator the secondary diaphragm will be drawn in a downwards motion. This downward motion will cause the secondary lever to open thus allowing more fuel to enter the mixer.

In the (LPR) the fuel is vaporized and the pressure reduced in two stages. The first stage reduces the pressure to approximately 1.0 to 3.0 psi (6.8 to 20.6 kPa). The second stage reduces the pressure to approximately negative 1.5" of water column.

The fuel is then drawn from the secondary chamber of the LPR by the vacuum generated by air flowing through the mixer. This vacuum signal is also used to generate lift for the mixer air valve. This vacuum signal is most commonly referred to as air valve vacuum. In the mixer, the fuel mixes with the air entering the engine. This air/ fuel mixture is then drawn into the engine for combustion.

Diagnostic Aids

This procedure is intended to diagnose a vehicle operating on LPG. If the vehicle will not continue to run on LPG, refer to Hard Start for preliminary checks. Before proceeding with this procedure, verify that the vehicle has a sufficient quantity of fuel and that liquid fuel is being delivered to the LPR. Also, ensure that the manual shut off valve on the LPG tank is fully opened and that the excess flow valve has not been activated.

Tools Required:

- 7/16 Open end wrench (for test port plugs)
- DVOM (GM J 39200, Fluke 88 or equivalent).
- · 12 volt test light

Diagnostic Scan Tool

· Diagnostic Display tool.

Pressure Gauges

- · IMPCO ITK-2 Test kit
- Water Column Gauge / Manometer (GM 7333-6 or equivalent).
- 0-10 PSI Gauge

Test Description

The numbers below refer to step numbers on the diagnostic table.

- 5. This step determines if the LPR requires replacement
- 6. This step determines if the problems are in the mechanical side of the Pressure Regulator or the Electronic Voice Coil
- 10. This step determines if the Mixer requires replacement
- 14. This step determines if the Lock Off requires replacement
- 17. This step determines if the Fuel Filter requires replacement.

3-206 3121139

Table 3-14. LPF Fuel System Diagnosis

| STEP | ACTION | VALUE(S) | YES | NO |
|------|--|-----------------------|--|---------------|
| 1 | Were you referred to this procedure by a DTC diagnostic chart? | | Go to Step 3 | Go to Step 2 |
| 2 | Perform the On Board Diagnostic (OBD) System Check. Are any DTCs present in the ECM? | | Gotothe applicable DTC Table | Go to Step 3 |
| 3 | Verify that the LPG fuel tank has a minimum of 1/4 tank of fuel, that the manual valve is open and the tank quick connect is fully engaged Does the vehicle have fuel? | | Go to Step 4 | |
| 4 | 1. Connect a water column gauge or a manometer to the secondary test port of the low pressure regulator (LPR).2. Start the engine and allow it to reach operating temperature.Does the engine start and run? | | Go to Step 5 | Go to Step 8 |
| 5 | With the engine idling, observe the pressure reading for the LPR secondary pressure. Does the fuel pressure fluctuate rhythmically OUTSIDE the specified range? | -1.0" to -2.0" w.c | Go to Step 25 | Go to Step 6 |
| 6 | 1. Disconnect the EPR electrical connectors. NOTE: This action will cause a DTC to be set by the ECM 2. With the engine idling observe the pressure reading on the secondary test port. Is the fuel pressure WITHIN the specified range? | -1.0" to -2.0" w.c | Go to Fuel Control System Diagnosis | Go to Step 7 |
| 7 | I. Inspect the air intake stream between the mixer assembly and the throttle body for leaks. Inspect the fuel hose connection between the LPR and mixer assembly for damage or leakage. Inspect any vacuum hoses for leaks Was a problem found and corrected? | | Go to Step 26 | Go to Step 22 |
| 8 | 1. Connect a water column gauge or a manometer to the secondary test port of the low pressure regulator (LPR). 2. Crank the engine and observe the pressure reading for the LPR secondary pressure. Does the fuel pressure indicate a vacuum is present? | | Go to Step 12 | Go to Step 9 |
| 9 | Remove Air induction hose to the mixer Observe the air valve for movement while the engine is cranking. Note: Movement of the air valve will be minimal at cranking speeds. Does the air valve move when the engine is cranked? | | Go to Step 11 | Go to Step 10 |
| 10 | Inspect the air intake stream to the mixer assembly and the throttle body for vacuum leaks. Inspect the vacuum hoses from the mixer for proper connection and condition. Was a problem found and repaired? | | Go to Step 26 | Go to Step 24 |
| 11 | Inspect the fuel hose connection between the LPR and the mixer assembly for damage or leakage. Was a problem found and repaired? | | Go to Step 26 | Go to Step 12 |
| 12 | 1. Connect a 0-10 psi gauge to the primary test port of the low pressure regulator (LPR). 2. Crank the engine and observe the pressure reading for the LPR primary pressure. Is the fuel pressure ABOVE the specified value? | 1-3 PSI | Go to Step 22 | Go to Step 13 |
| 13 | 1. Turn OFF the ignition. 2. Disconnect the LPL connector. 3. Install a test light between the pins of the LPL connector. 4. Crank the engine. The test light should illuminate. Does the test light illuminate? | | Go to Step 14 | Go to Step 16 |
| 14 | Using a DVOM, check the resistance of the low pressure lock-off (LPL). Is the resistance within the specified range? | 12W-16W | Go to Step 15 | Go to Step 23 |

Table 3-14. LPF Fuel System Diagnosis

| STEP | ACTION | VALUE(S) | YES | NO |
|------|---|----------|---------------|---------------|
| 15 | 1. Turn the ignition OFF. 2. Close the manual shut-off valve on the LPG tank. CAUTION: When disconnecting LPG fuel lines, liquid LPG may be present. Perform this step in a well ventilated area. 3. Loosen the fuel inlet hose fitting at the inlet of the LPL. Was fuel present when the fitting was loosened? | 1 | Go to Step 23 | Go to Step 17 |
| 16 | 1. Turn OFF the ignition. 2. Connect the test light to chassis ground and probe pin A of the LPL connector. 3. Crank the engine. The test light should illuminate. Does the test light illuminate? | | Go to Step 20 | Go to Step 21 |
| 17 | 1. Remove the LPG fuel filter / LPL. 2. Remove the filter from the LPL. 3. Empty the contents of the inlet side of the LPG fuel filter onto a clean surface. 4. Inspect the contents of the LPG fuel filter for an excessive amount of foreign material or water. If necessary, locate and repair the source of contamination. 5. Verify the LPG fuel filter is not restricted or plugged. Was a problem found? | 1 | Go to Step 19 | Go to Step 18 |
| 18 | The fuel supply system or hoses are plugged or restricted, locate and repair the problem. Is the action complete? | | Go to Step 26 | |
| 19 | Replace the fuel filter. Refer to Fuel Filter Replacement. Is the action complete? | | Go to Step 26 | |
| 20 | Repair the open in the lock-off ground circuit. Is the action complete? | | Go to Step 26 | |
| 21 | Repair the open in the lock-off power circuit. Is the action complete? | | Go to Step 26 | |
| 22 | Replace the low pressure regulator (LPR). Refer to Low Pressure Regulator Replacement. Is the action complete? | | Go to Step 26 | |
| 23 | Replace the lock-off. Refer to Lock-off Replacement. Is the action complete? | | Go to Step 26 | |
| 24 | Replace the mixer assembly. Refer to Fuel Mixer Replacement. Is the action complete? | | Go to Step 26 | |
| 25 | The fuel supply system is operating normally, if a failure of the control solenoids is suspected. Refer to Fuel Control System Diagnosis. 1. Install the test plug in the LPR secondary chamber. 2. If you were sent to this routine by another diagnostic chart, return to the previous diagnostic procedure. Is the action complete? | | System OK | |
| 26 | 1. Disconnect all test equipment 2. Install the primary and secondary test port plugs. 3. Start the engine. 4. Using SNOOP or equivalent, leak check the test port plugs. Is the action complete? | | System OK | |

3-208 3121139

Table 3-15. Symptom Diagnosis

| Checks | Action |
|---|--|
| | Important Preliminary Checks |
| Before Using This Section | Before using this section, you should have performed On Board Diagnostic Check and determined that: 1. The Control Module and MIL (Malfunction Indicator Lamp) are operating correctly. 2. There are no Diagnostic Trouble Codes (DTCs) stored, or a DTC exists but without a MIL. |
| | Several of the following symptom procedures call for a careful visual and physical check. The visual and physical checks are very important. The checks can lead to correcting a problem without further checks that may save valuable time. |
| LPG Fuel System Check | 1. Verify the customer complaint. 2. Locate the correct symptom table. 3. Check the items indicated under that symptom. 4. Operate the vehicle under the conditions the symptom occurs. Verify HEGO switching between lean and rich. IMPORTANT! Normal HEGO switching indicates the LPG fuel system is in closed loop and operating correctly at that time. |
| Visual and Physical Checks | Check the ECM ground for being clean, tight and in its proper location. Check the ECM ground for being clean, tight and in its proper location. Check the vacuum hoses for splits, kinks and proper connections. Check thoroughly for any type of leak or restriction. Check for air leaks at all the mounting areas of the intake manifold sealing surfaces. Check for proper installation of the mixer module assembly. Check for air leaks at the mixer assembly. Check the ginition wires for the following conditions: - Cracking - Hardness - Proper routing - Carbon tracking Check the wiring for the following items: - Proper connections, pinches or cuts. The following symptom tables contain groups of possible causes for each symptom. The order of these procedures is not important. If the scan tool readings do not indicate the problems, then proceed in a logical order, easiest to check or most likely to cause first. |
| | Intermittent |
| DEFINITION: The problem may or may not | turn ON the Malfunction Indicator Lamp (MIL) or store a Diagnostic Trouble Code (DTC). |
| Preliminary Checks | Refer to Important Preliminary Checks. Do not use the DTC tables. If a fault is an intermittent, the use of the DTC tables may result in the replacement of good parts. |
| Faulty Electrical Connections or Wiring | Faulty electrical connections or wiring can cause most intermittent problems. Check the suspected circuit for the following conditions: - Faulty fuse or circuit breaker - Connectors poorly mated - Terminals not fully seated in the connector (backed out) - Terminals not properly formed or damaged - Terminal to wires poorly connected - Terminal tension insufficient Carefully remove all the connector terminals in the problem circuit in order to ensure the proper contact tension. If necessary, replace all the connector terminals in the problem circuit in order to ensure the proper contact tension. Checking for poor terminal to wire connections requires removing the terminal from the connector body. |
| Operational Test | If a visual and physical check does not locate the cause of the problem, drive the vehicle with a scantool. When the problem occurs, an abnormal voltage or scan reading indicates the problem may be in that circuit. |

Table 3-15. Symptom Diagnosis

| Table 3-13. Symptom Diagnosis | | |
|--|--|--|
| Checks | Action | |
| Intermittent Malfunction Indicator Lamp (MIL) | The following components can cause intermittent MIL and no DTC(s): A defective relay, Control Module driven solenoid, or a switch that can cause electrical system interference. Normally, the problem will occur when the faulty component is operating. The improper installation of electrical devices, such as lights, 2-way radios, electric motors, etc. The ignition secondary voltage shorted to a ground. The Malfunction Indicator Lamp (MIL) circuit or the Diagnostic Test Terminal intermittently shorted to ground. The Control Module grounds. | |
| Loss of DTC Memory | To check for the loss of the DTC Memory: 1. Disconnect the TMAP sensor. 2. Idle the engine until the Malfunction Indicator Lamp illuminates. The ECM should store a TMAP DTC. The TMAP DTC should remain in the memory when the ignition is turned OFF. If the TMAP DTC does not store and remain, the ECM is faulty. | |
| Additional Checks | | |
| | No Start No Start | |
| DEFINITION: The engine cranks OK ²² but doe | s not start. | |
| Preliminary Checks | Refer to Important Preliminary Checks. | |
| Control Module Checks | If a scan tool is available: Check for proper communication with both the ECM. Check the fuse in the ECM battery power circuit. Refer to Engine Controls Schematics. Check battery power, ignition power and ground circuits to the ECM. Refer to Engine Control Schematics. Verify voltage and/or continuity for each circuit. | |
| SensorChecks | Check the TMAP sensor. Check the Magnetic pickup sensor (RPM). | |
| Fuel System Checks | Important: A closed LPG manual fuel shut off valve will create a no start condition. Check for air intake system leakage between the mixer and the throttle body. Verify proper operation of the low pressure lock-off solenoids. Check the fuel system pressures. Refer to the LPG Fuel System Diagnosis. Check for proper mixer air valve operation. | |
| Ignition System Checks | Note: LPG being a gaseous fuel requires higher secondary ignition system voltages for the equivalent gasoline operating conditions. Check for the proper ignition voltage output with J 26792 or the equivalent. Verify that the spark plugs are correct for use with LPG (R42LTS) Check the spark plugs for the following conditions: - Wet plugs - Cracks - Wear - Improper gap - Burned electrodes - Heavy deposits Check for bare or shorted ignition wires. Check for loose ignition coil connections at the coil. | |
| Engine Mechanical Checks | Important: The LPG Fuel system works on a fumigation principle of fuel introduction and is more sensitive to intake manifold leakage than the gasoline fuel supply system. Check for the following: Vacuum leaks Improper valve timing Low compression Bent pushrods Worn rocker arms Broken or weak valve springs Worn camshaft lobes. | |

3-210 3121139

Table 3-15. Symptom Diagnosis

| Checks | Action | | | | |
|---|---|--|--|--|--|
| Exhaust System Checks | Check the exhaust system for a possible restriction: - Inspect the exhaust system for damaged or collapsed pipes - Inspect the muffler for signs of heat distress or for possible internal failure. Check for possible plugged catalytic converter. Refer to Restricted Exhaust System Diagnosis. | | | | |
| | Hard Start Hard Start | | | | |
| DEFINITION: The engine cranks OK, but doe | rs not start for a long time. The engine does eventually run, or may start but immediately dies. | | | | |
| Preliminary Checks | Refer to Important Preliminary Checks. Make sure the vehicle's operator is using the correct starting procedure. | | | | |
| SensorChecks | Check the Engine Coolant Temperature sensor with the scan tool. Compare the engine coolant temperature with the ambient air temperature on a cold engine. IF the coolant temperature reading is more than 5 degrees greater or less than the ambient air temperature on a cold engine, check for high resistance in the coolant sensor circuit. Refer to DTC 111 Check the Crankshaft Position (CKP) sensor. Check the Throttle position (TPS) sensor. | | | | |
| Fuel System Checks | Important: A closed LPG manual fuel shut off valve will create an extended crank OR no start condition. Verify the excess flow valve in the LPG manual shut-off valve is not tripped. Check mixer module assembly for proper installation and leakage. Verify proper operation of the low pressure lock-off solenoids. Verify proper operation of the EPR. Check for air intake system leakage between the mixer and the throttle body. Check the fuel system pressures. Refer to the Fuel System Diagnosis. | | | | |
| Ignition System Checks | Note: LPG being a gaseous fuel requires higher secondary ignition system voltages for the equivalent gasoline operating conditions. Check for the proper ignition voltage output with J 26792 or the equivalent. Verify that the spark plugs are correct for use with LPG (R42LTS). Check the spark plugs for the following conditions: - Wet plugs - Cracks - Wear - Improper gap - Burned electrodes - Heavy deposits Check for bare or shorted ignition wires. Check for moisture in the distributor capif applicable. Check for loose ignition coil connections. Important: 1. If the engine starts but then immediately stalls, Check the Crankshaft Position (CKP). 2. Check for improper gap, debris or faulty connections. | | | | |
| Engine Mechanical Checks | Important: The LPG Fuel system works on a fumigation principle of fuel introduction and is more sensitive to intake manifold leakage than the gasoline fuel supply system. Check for the following: - Vacuum leaks - Improper valve timing - Low compression - Bent pushrods - Worn rocker arms - Broken or weak valve springs - Worn camshaft lobes Check the intake and exhaust manifolds for casting flash. | | | | |
| Exhaust System Checks | Check the exhaust system for a possible restriction: -Inspect the exhaust system for damaged or collapsed pipesInspect the muffler for signs of heat distress or for possible internal failure. Check for possible plugged catalytic converter. Refer to Restricted Exhaust System Diagnosis or Exhaust System in the GM Base Engine Service Manual. | | | | |

Table 3-15. Symptom Diagnosis

| Checks | Action | | | |
|---|--|--|--|--|
| Additional Checks | | | | |
| Cuts Out, Misses | | | | |
| DEFINITION: A surging or jerking that follows engine speed, usually more pronounced as the engine load increases which is not normally felt above 1500 RPM. The exhaust has a steady spit-ting sound at idle, low speed, or hard acceleration for the fuel starvation that can cause the engine to cut-out. | | | | |
| Preliminary Checks | Refer to Important Preliminary Checks. | | | |
| Ignition System Checks | Start the engine. Wet down the secondary ignition system with water from a spray bottle, and look/listen for arcing or misfiring as you apply water. Check for proper ignition output voltage with spark tester J 26792. Check for a cylinder misfire. Verify that the spark plugs are correct for use with LPG (R42LTS) Remove the spark plugs in these cylinders and check for the following conditions: Insulation cracks Wear Improper gap Burned electrodes Heavy deposits Visually/Physically inspect the secondary ignition for the following: Ignition wires for arcing, cross-firing and proper routing | | | |
| Engine Mechanical Checks | Ignition coils for cracks or carbon tracking Perform a cylinder compression check. Check the engine for the following: - Improper valve timing - Bent pushrods - Worn rocker arms - Worn camshaft lobes - Broken or weak valve springs Check the intake and exhaust manifold passages for casting flash. | | | |
| Fuel System Checks | Check the fuel system - plugged fuel filter, low fuel pressure, etc. Refer to LPG Fuel System Diagnosis. Check the condition of the wiring to the low pressure lock-off solenoid. | | | |
| Additional Check | Check for Electromagnetic Interference (EMI). EMI on the reference circuit can cause a missing condition. Monitoring the engine RPM with a scan tool can detect an EMI. A sudden increase in the RPM with little change in the actual engine RPM, indicates EMI is present. If the problem exists, check the routing of the secondary wires and the ground circuit. | | | |
| | Hesitation, Sag, Stumble | | | |
| DEFINITION: The vehicle has a momentary la severe enough. | ack of response when depressing the accelerator. The condition can occur at any vehicle speed. The condition may cause the engine to stall if it's | | | |
| Preliminary Checks | Refer to Important Preliminary Checks. | | | |
| Fuel System Checks | Check the fuel pressure. Refer to LPG Fuel System Diagnosis. Check for low fuel pressure during a moderate or full throttle acceleration. If the fuel pressure drops below specification, there is possibly a faulty low pressure regulator or a restriction in the fuel system. Check the Manifold Absolute Pressure (MAP) sensor response and accuracy. Check LPL electrical connection. Check the mixer air valve for sticking or binding. Check the mixer module assembly for proper installation and leakage. Check the EPR electrical connections. | | | |

3-212 3121139

Table 3-15. Symptom Diagnosis

| Checks | Action |
|--|---|
| Ignition System Checks | Note: LPG being a gaseous fuel requires higher secondary ignition system voltages for the equivalent gasoline operating conditions. If a problem is reported on LPG and not gasoline, do not discount the possibility of a LPG only ignition system failure and test the system accordingly. Check for the proper ignition voltage output with J 26792 or the equivalent. Verify that the spark plugs are correct for use with LPG (R42LTS). Check for faulty spark plug wires. Check for fouled spark plugs. |
| Additional Check | Check for manifold vacuum or air induction system leaks. Check the generator output voltage. |
| | Backfire |
| DEFINITION: The fuel ignites in the intake r | nanifold, or in the exhaust system, making a loud popping noise. |
| Preliminary Check | Refer to Important Preliminary Checks. |
| Ignition System Checks | Important! LPG, being a gaseous fuel, requires higher secondary ignition system voltages for the equivalent gasoline operating conditions. The ignition system must be maintained in peak condition to prevent backfire. |
| Engine Mechanical Check | Check for the proper ignition coil output voltage using the spark tester J26792 or the equivalent. Check the spark plug wires by connecting an ohmmeter to the ends of each wire in question. If the meter reads over 30,000 ohms, replace the wires. Check the connection at each ignition coil. Check for deteriorated spark plug wire insulation. Check the spark plugs. The correct spark plugs for LPG are (R42LTS). Remove the plugs and inspect them for the following conditions: - Wet plugs - Cracks - Wear - Improper gap - Burned electrodes - Heavy deposits Important! The LPG Fuel system works on a fumigation principle of fuel introduction and is more sensitive to intake manifold leakage than a gasoline fuel supply system. Check the engine for the following: - Improper valve timing - Engine compression - Manifold vacuum leaks - Intake manifold gaskets - Sticking or leaking valves - Exhaust system leakage Check the intake and exhaust system for casting flash or other restrictions. |
| Fuel System Checks | Perform a fuel system diagnosis. Refer to LPG Fuel System Diagnosis. |
| | Lack of Power, Sluggishness, or Sponginess |
| DEFINITION: The engine delivers less than | expected power. There is little or no increase in speed when partially applying the accelerator pedal. |
| Preliminary Checks | Refer to Important Preliminary Checks. Refer to the LPG Fuel system OBD System Check. Compare the customer's vehicle with a similar unit. Make sure the customer has an actual problem. Do not compare the power output of the vehicle operating on LPG to a vehicle operating on gasoline as the fuels do have different drive feel characteristics. Remove the air filter and check for dirt or restriction. Check the vehicle transmission Refer to the OEM transmission diagnostics. |

Table 3-15. Symptom Diagnosis

| Checks | Action |
|---|---|
| Fuel System Checks | Check for a restricted fuel filter, contaminated fuel, or improper fuel pressure. Refer to LPG Fuel System Diagnosis. Check for the proper ignition output voltage with the spark tester J 26792 or the equivalent. Check for proper installation of the mixer module assembly. Check all air inlet ducts for condition and proper installation. Check for fuel leaks between the LPR and the mixer. Verify that the LPG tank manual shut-off valve is fully open. |
| c | Verify that liquid fuel (not vapor) is being delivered to the LPR. |
| SensorChecks | Check the Heated Exhaust Gas Oxygen Sensor (HEGO) for contamination and performance. Check for proper operation of the MAP sensor. Check for proper operation of the TPS sensor. |
| Exhaust System Checks | Check the exhaust system for a possible restriction: - Inspect the exhaust system for damaged or collapsed pipes Inspect the muffler for signs of heat distress or for possible internal failure Check for possible plugged catalytic converter. |
| Engine Mechanical Check | Check the engine for the following: Engine compression Valve timing Improper or worn camshaft. Refer to Engine Mechanical in the Service Manual. |
| Additional Check | Check the ECM grounds for being clean, tight, and in their proper locations. Check the generator output voltage. If all procedures have been completed and no malfunction has been found, review and inspect the following items: Visually and physically, inspect all electrical connections within the suspected circuit and/or systems. Check the scan tool data. |
| | Poor Fuel Economy |
| DEFINITION: Fuel economy, as mean shown by an by refueling records. | sured by refueling records, is noticeably lower than expected. Also, the economy is noticeably lower than it was on this vehicle at one time, as previously |
| Preliminary Checks | Refer to Important Preliminary Checks. Check the air cleaner element (filter) for dirt or being plugged. Visually (Physically) check the vacuum hoses for splits, kinks, and proper connections. Check the operators driving habits for the following items: - Is there excessive idling or stop and go driving? - Are the tires at the correct air pressure? - Are excessively heavy loads being carried? - Is their often rapid acceleration? Suggest to the owner to fill the fuel tank and to recheck the fuel economy. Suggest that a different operator use the equipment and record the results. |
| Fuel System Checks | Check the LPR fuel pressure. Refer to LPG Fuel System Diagnosis. Check the fuel system for leakage. |
| SensorChecks | Check the Temperature Manifold Absolute Pressure (TMAP) sensor. |
| Ignition System Checks | Verify that the spark plugs are correct for use with LPG (R42LTS) Check the spark plugs. Remove the plugs and inspect them for the following conditions: - Wet plugs - Cracks - Wear - Improper gap - Burned electrodes - Heavy deposits Check the ignition wires for the following items: - Cracking - Hardness - Proper connections |
| Cooling System Checks | Check the engine thermostat for always being open or for the wrong heat range |

3-214 3121139

Table 3-15. Symptom Diagnosis

| Checks | Action | | | |
|--|---|--|--|--|
| Additional Check | Check the transmission shift pattern. Refer to the OEM Transmission Controls section the Service Manual. Check for dragging brakes. | | | |
| | Rough, Unstable, or Incorrect Idle, Stalling | | | |
| DEFINITION: The engine runs unevenly at id engine. | DEFINITION: The engine runs unevenly at idle. If severe enough, the engine or vehicle may shake. The engine idle speed may vary in RPM. Either condition may be severe enough to stall the engine. | | | |
| Preliminary Check | Refer to Important Preliminary Checks. | | | |
| SensorChecks | Check for silicon contamination from fuel or improperly used sealant. The sensor will have a white powdery coating. The sensor will result in a high but false signal voltage (rich exhaust indication). The ECM will reduce the amount of fuel delivered to the engine causing a severe driveability problem. Check the Heated Exhaust Gas Oxygen Sensor (HEGO) performance: Check the Temperature Manifold Absolute Pressure (TMAP) sensor response and accuracy. | | | |
| Fuel System Checks | Check for rich or lean symptom that causes the condition. Drive the vehicle at the speed of the complaint. Monitoring the oxygen sensors will help identify the problem. Check for a sticking mixer air valve. Verify proper operation of the EPR. Perform a cylinder compression test. Refer to Engine Mechanical in the Service Manual. Check the LPR fuel pressure. Refer to the LPG Fuel System Diagnosis. Check mixer module assembly for proper installation and connection. | | | |
| Ignition System Checks | Check for the proper ignition output voltage using the spark tester J26792 or the equivalent. Verify that the spark plugs are correct for use with LPG (R42LTS) Check the spark plugs. Remove the plugs and inspect them for the following conditions: - Wet plugs - Cracks - Wear - Improper gap - Burned electrodes - Blistered insulators - Heavy deposits Check the spark plug wires by connecting an ohmmeter to the ends of each wire in question. If the meter reads over 30,000 ohms, replace the wires. | | | |
| Additional Checks | Important: The LPG Fuel system works on a fumigation principle of fuel introduction and is more sensitive to intake manifold leakage than the gasoline fuel supply system. Check for vacuum leaks. Vacuum leaks can cause a higher than normal idle and low throttle angle control command. Check the ECM grounds for being clean, tight, and in their proper locations. Check the battery cables and ground straps. They should be clean and secure. Erratic voltage may cause all sensor readings to be skewed resulting in poor idle quality. | | | |
| Engine Mechanical Check | Check the engine for the following: - Broken motor mounts - Improper valve timing - Low compression - Bent pushrods - Worn rocker arms - Broken or weak valve springs - Worn camshaft lobes | | | |
| Surges/Chuggles | | | | |
| | on under a steady throttle or cruise. The vehicle feels as if it speeds up and slows down with no change in the accelerator pedal. | | | |
| Preliminary Checks | Refer to Important Preliminary Checks. | | | |
| Sensor Checks | Check Heated Exhaust Gas Oxygen Sensor (HEGO) performance. | | | |

Table 3-15. Symptom Diagnosis

| Checks | Action |
|------------------------|--|
| Fuel System Checks | Check for Rich or Lean symptom that causes the condition. Drive the vehicle at the speed of the complaint. Monitoring the oxygen sensors will help identify the problem. Check the fuel pressure while the condition exists. Refer to LPG Fuel System Diagnosis. Verify proper fuel control solenoid operation. Verify that the LPG manual shut-off valve is fully open. Check the in-line fuel filter for restrictions. |
| Ignition System Checks | Check for the proper ignition output voltage using the spark tester J26792 or the equivalent. Verify that the spark plugs are correct for use with LPG (R42LTS). Check the spark plugs. Remove the plugs and inspect them for the following conditions: - Wet plugs - Cracks - Wear - Improper gap - Burned electrodes - Heavy deposits Check the Crankshaft Position (CKP) sensor |
| Additional Check | Check the ECM grounds for being clean, tight, and in their proper locations. Check the generator output voltage. Check the vacuum hoses for kinks or leaks. Check Transmission. |

3-216 3121139

Table 3-16. DTC to SPN/FMI Cross Reference Chart

| DTC | Description | SPN Code | FMI Code |
|-----|---------------------------------|----------|----------|
| 16 | Crank Never Synced at Start | 636 | 8 |
| 91 | Fuel Pump Low Voltage | 94 | 4 |
| 92 | Fuel Pump High Voltage | 94 | 3 |
| 107 | MAP Low Voltage | 106 | 4 |
| 108 | MAP High Pressure | 106 | 16 |
| 111 | IAT Higher Than Expected 1 | 105 | 15 |
| 112 | IAT Low Voltage | 105 | 4 |
| 113 | IAT High Voltage | 105 | 3 |
| 116 | ECT Higher Than Expected 1 | 110 | 15 |
| 117 | ECT Low Voltage | 110 | 4 |
| 118 | ECT High Voltage | 110 | 3 |
| 121 | TPS 1 Lower Than TPS 2 | 51 | 1 |
| 122 | TPS 1 Signal Voltage Low | 51 | 4 |
| 123 | TPS 1 Signal Voltage High | 51 | 3 |
| 127 | IAT Higher Than Expected 2 | 105 | 0 |
| 129 | BP Low Pressure | 108 | 1 |
| 134 | EGO 1 Open/Inactive | 724 | 10 |
| 154 | EGO 2 Open/Inactive | 520208 | 10 |
| 171 | Adaptive Learn High Gasoline | 520200 | 0 |
| 172 | Adaptive Learn Low Gasoline | 520200 | 1 |
| 182 | Fuel Temp Gasoline Low Voltage | 174 | 4 |
| 183 | Fuel Temp Gasoline High Voltage | 174 | 3 |
| 187 | Fuel Temp LPG Low Voltage | 520240 | 4 |
| 188 | Fuel Temp LPG High Voltage | 520240 | 3 |
| 217 | ECT Higher Than Expected 2 | 110 | 0 |
| 219 | Max Govern Speed Override | 515 | 15 |
| 221 | TPS 2 Signal Voltage Low | 51 | 0 |
| 222 | TPS 2 Signal Low Voltage | 520251 | 4 |
| 223 | TPS 2 Signal High Voltage | 520251 | 3 |
| 261 | Injector Driver 1 Open | 651 | 5 |
| 262 | Injector Driver 1 Shorted | 651 | 6 |
| 264 | Injector Driver 2 Open | 652 | 5 |
| 265 | Injector Driver 2 Shorted | 652 | 6 |
| 267 | Injector Driver 3 Open | 653 | 5 |
| 268 | Injector Driver 3 Shorted | 653 | 6 |
| 270 | Injector Driver 4 Open | 654 | 5 |
| 271 | Injector Driver 4 Shorted | 654 | 6 |
| 336 | Crank Sync Noise | 636 | 2 |
| 337 | Crank Loss | 636 | 4 |
| 341 | Cam Sync Noise | 723 | 2 |
| 342 | Cam Sensor Loss | 723 | 4 |
| 420 | Gasoline Cat Monitor | 520211 | 10 |
| 524 | Oil Pressure Low | 100 | 1 |

Table 3-16. DTC to SPN/FMI Cross Reference Chart

| DTC | Description | SPN Code | FMI Code |
|------|--------------------------------------|----------|----------|
| 562 | System Voltage Low | 168 | 17 |
| 563 | System Voltage High | 168 | 15 |
| 601 | Flash Checksum Invalid | 628 | 13 |
| 604 | RAM Failure | 630 | 12 |
| 606 | COP Failure | 629 | 31 |
| 642 | External 5V Reference Low | 1079 | 4 |
| 643 | External 5V Reference High | 1079 | 3 |
| 685 | Power Relay Open | 1485 | 5 |
| 686 | Power Relay Shorted | 1485 | 4 |
| 687 | Power Relay Short to Power | 1485 | 3 |
| 1111 | Fuel Rev Limit | 515 | 16 |
| 1112 | Spark Rev Limit | 515 | 0 |
| 1151 | Closed Loop Multiplier High LPG | 520206 | 0 |
| 1152 | Closed Loop Multiplier Low LPG | 520206 | 1 |
| 1155 | Closed Loop Multiplier High Gasoline | 520204 | 0 |
| 1156 | Closed Loop Multiplier Low Gasoline | 520204 | 1 |
| 1161 | Adaptive Learn High LPG | 520202 | 0 |
| 1162 | Adaptive Learn Low LPG | 520202 | 1 |
| 1165 | LPG Cat Monitor | 520213 | 10 |
| 1171 | LPG Pressure Higher Than Expected | 520260 | 0 |
| 1172 | LPG Pressure Lower Than Expected | 520260 | 1 |
| 1173 | EPR Comm Lost | 520260 | 31 |
| 1174 | EPR Voltage Supply High | 520260 | 3 |
| 1175 | EPR Voltage Supply Low | 520260 | 4 |
| 1176 | EPR Internal Actuator Fault | 520260 | 12 |
| 1177 | EPR Internal Circuitry Fault | 520260 | 12 |
| 1178 | EPR Internal Comm Fault | 520260 | 12 |
| 1612 | RTI 1 loss | 629 | 31 |
| 1613 | RTI2Loss | 629 | 31 |
| 1614 | RTI3Loss | 629 | 31 |
| 1615 | A/D Loss | 629 | 31 |
| 1616 | Invalid Interrupt | 629 | 31 |
| 1625 | Shutdown Request | 1384 | 31 |
| 1626 | CAN Tx Failure | 639 | 12 |
| 1627 | CAN Rx Failure | 639 | 12 |
| 1628 | CAN Address Conflict Failure | 639 | 13 |
| 1629 | Loss of TSC 1 | 639 | 31 |
| 2111 | Unable to Reach Lower TPS | 51 | 7 |
| 2112 | Unable to Reach Higher TPS | 51 | |
| 2135 | TPS 1/2 Simultaneous Voltages | 51 | 31 |
| 2229 | BP Pressure High | 108 | 0 |

3-218 3121139

SECTION 4. BOOM & PLATFORM

4.1 MAIN BOOM ASSEMBLY

Removal

1. Using suitable lifting equipment, adequately support boom assembly weight along entire length.

NOTICE


HYDRAULIC LINES AND PORTS SHOULD BE CAPPED IMMEDIATELY AFTER DISCONNECTING LINES TO AVOID ENTRY OF CONTAMINANTS INTO SYSTEM.

2. Tag and disconnect hydraulic lines from telescope cylinder. Use a suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.

Boom Disassembly

NOTE: The following procedure assumes the boom is removed from the machine.

- 1. Extend the boom approximately 2 ft (0.6 m). This will enable access to the bolts that secure the cable mount block to the boom fly section.
- 2. Remove hardware securing the telescope cylinder.
- **3.** Remove hardware securing the cover plate on the bottom front of the base boom section.




NOTE: Do not allow wire rope to rotate. This may damage the wire rope.


Clamp both threaded ends of wire rope to prevent rotation.

NOTE: Do not clamp on threads. Remove jam nuts and nuts which secure the wire rope adjustments to the bottom front of the base boom section.


5. Using a 3/8 drive extension approximately 4 ft (1.2 m) long, remove the bolts and washers securing the cable mount block to the boom fly section.



Remove the four bolts, shims, and attachment blocks that secure the telescope cylinder barrel to the boom mid section.



7. Remove the four bolts, shims, and mounting blocks that secure the telescope cylinder rod to the boom base section.




NOTICE

WHEN REMOVING THE TELESCOPE CYLINDER FROM THE BOOM, IT MAY BE NECESSARY AT SOME POINT TO TURN THE CYLINDER SLIGHTLY IN ORDER TO CLEAR ASSEMBLIES MOUNTED WITHIN THE BOOM. CARE MUST BE TAKEN TO MOVE THE CYLINDER SLOWLY FROM THE BOOM. DAMAGE TO COMPONENTS MAY RESULT FROM FORCIBLE IMPACT WITH THESE ASSEMBLIES.

NOTE: The telescope cylinder weighs approximately 600 lbs. (272 kg).

8. Using overhead cranes or other suitable lifting/supporting devices, carefully pull the telescope cylinder out from the back of the boom. At the same time, also pull the cable mount block out so the extension cables come out with the telescope cylinder and do not bind. The lifting/supporting devices will have to be repositioned to support the weight of the cylinder as it is drawn out of the boom.



4-2 3121139

This page left blank intentionally.




Figure 4-1. Boom Assembly Cutaway - Sheet 1 of 2

4-4 3121139




Figure 4-2. Boom Assembly Cutaway - Sheet 2 of 2




Figure 4-3. Boom Components - Sheet 1 of 2

4-6 3121139




Figure 4-4. Boom Components - Sheet 2 of 2

- **9.** Carefully remove the telescope cylinder and sheave assembly. Place telescope cylinder on a suitable trestle.
 - a. Remove hardware from the wear pads; remove wear pads from cylinder.
 - **b.** Remove hardware from the wire rope guard; remove guard from cylinder.
 - c. Remove hardware from the sheave pin; remove pin and sheave from cylinder.




Figure 4-5. Disassembly of Sheave Assembly

- 10. Remove hardware which secures the wear pads to the front of base boom section; remove wear pads from the top, sides and bottom of the base boom section.
- **11.** Using an overhead crane or suitable lifting device, remove mid and fly boom sections from base section.

NOTE: When removing mid and fly boom sections from base boom section, retract wire rope must be dragged along with boom sections.

- 12. Remove hardware which secures the wear pads to the rear end of mid boom section; remove the wear pads from the top, sides and bottom of the mid boom section.
- **13.** Remove hardware which secures the sheave guards and sheave assemblies to mid boom section, remove sheave assemblies from mid boom section.

- **14.** Remove hardware which secures the wear pads to the front of mid boom section; remove wear pads from the top, sides and bottom of the mid boom section.
- **15.** Using an overhead crane or suitable lifting device, remove fly boom section from mid section.

NOTE: When removing fly boom section from mid boom section, retract wire rope must be dragged along with fly boom section.

- **16.** Remove hardware which secures the wear pads to the rear end of fly boom section; remove wear pads from the top, sides and bottom of the fly boom section.
- **17.** When removing wire rope from fly boom section, push the cable into fly boom. Route wire rope back through holes in the side of the fly boom section.




Figure 4-6. Disassembly Wire Rope Routing Procedure

4-8 3121139

Inspection

NOTE: When inspecting pins and bearings Refer to the guidelines established in Section 2 - General.

 Inspect all sheaves (extend and retract wire ropes and telescope cylinder) for excessive groove wear, burrs or other damage. Replace sheaves as necessary.

NOTE: To check the size, contour and amount of wear, a groove gauge is used. Replace the sheave if worn as shown in the following drawing.




Figure 4-7. Dimension of Sheaves When New

- **2.** Inspect extend and retract wire rope sheave bearings for wear, scoring, or other damage, and for ovality.
- Inspect extend wire rope and retract wire rope sheave pins for scoring, tapering and ovality. Replace pins as necessary.
- **4.** Inspect telescope cylinder sheave pin for scoring, tapering and ovality. Replace pins as necessary.
- **5.** Inspect boom pivot pin for wear, scoring, tapering and ovality, or other damage. Replace pins as necessary.

- Inspect telescope cylinder attach point for scoring, tapering and ovality. Replace pins as necessary.
- Inspect upper lift cylinder attach pin for wear, scoring, tapering and ovality, or other damage. Ensure pin surfaces are protected prior to installation. Replace pins as necessary.
- **8.** Inspect inner diameter of boom pivot bushing for scoring, distortion, wear, or other damage. Replace bearing as necessary.
- Inspect all wear pads for excessive wear or other damage. Replace pads when worn to within 1/8 in. (3.2 mm) of threaded insert.
- Inspect extend and retract wire rope attach point components for cracks, stretching, distortion, or other damage. Replace components as necessary.
- Inspect all threaded components for damage such as stretching, thread deformation, or twisting. Replace as necessary.
- Inspect structural units of boom assembly for bending, cracking, separation of welds, or other damage. Replace boom sections as necessary.

Assembly

NOTE: When installing fly section wear pads, install same number and thickness of shims as were removed during disassembly.

- Measure inside dimensions of the base and mid sections to determine the number of shims required for proper lift.
- **2.** Measure inside dimensions of the mid section to determine the number of shims required for proper lift.
- Install side, top and bottom wear pads to the rear end of fly section; shim evenly to the measurements of the inside of mid section.




Figure 4-8. Proximity Switch Adjustment

4-10 3121139

Install retract wire ropes into rear end of fly section, route wire ropes through holes in side of fly boom section and pull into slot.




Figure 4-9. Routing Installation of Retract Wire Ropes

5. Install side, top and bottom wear pads to the rear end of mid section; shim evenly to the measurements of the inside of mid section.

NOTICE

WHEN ASSEMBLING BOOM SECTIONS, ENSURE THAT THE BOOM SLIDING TRAJECTORIES HAVE BEEN CLEARED OF CHAINS, TOOLS, AND OTHER OBSTRUCTIONS.

- **6.** Shim the insides of the boom sections for a total of 1/16 in. (1.52 mm) clearance (if the action is centered, there will be 1/32 clearance on each side).
- Slide fly boom section into the mid boom section. Shim boom, if necessary, for a total of 1/16 in. (1.52 mm) clearance.
- **8.** Install wear pads into the forward position of the mid boom section. Shim boom, if necessary, for a total of 2/10 in. (5.08 mm) clearance.


- **9.** Properly position the retraction wire rope sheaves assemblies at the rear end of the mid boom section; ensure all sheave-to-mounting block attachment holes align. Install the sheave pins and secure them with mounting hardware. Position retract wire ropes onto the sheaves.
- **10.** Install sheave guards to rear end of mid boom section and secure with mounting hardware.
- **11.** Slide mid boom section into the base boom section. Allow the retraction wire ropes to trail between the bottom surfaces of boom sections. Shim boom, if necessary, for a total of 1/16 in. (1.52 mm) clearance.
- **12.** Install wear pads into the forward position of the base boom section. Shim boom, if necessary, for a total of 2/10 in. (5.08 mm) clearance.
- 13. Install sheave block to bottom of base boom section and adjust block so that retract wire ropes do not come into contact with boom surfaces.
- **14.** Install wire rope threaded ends through attachment holes in the bottom of base boom section. Loosely install nuts and jam nuts onto the threaded ends of wire ropes.
- **15.** Pull the boom sections out to approximately where they were extended to for telescope cylinder removal.
- Install a new extend sheave on the end of the telescope cylinder.
- 17. Route new extend cables around the telescope cylinder. Loosely fasten the threaded end of the cables to the rod end of the telescope cylinder with the adjusting nuts and lock nuts. Install the opposite end of the cables in the cable mount block.
- **18.** Use tape or tie straps to fasten the cables to the telescope cylinder assembly. It is important that the tape or straps be strong enough to hold the cable in place yet weak enough to break and fall away when the cables are adjusted.

NOTICE


WHEN PUSHING THE TELESCOPE CYLINDER INTO THE BOOM, IT MAY BE NECESSARY AT SOME POINT TO TURN THE CYLINDER SLIGHTLY IN ORDER TO CLEAR ASSEMBLIES MOUNTED WITHIN THE BOOM. CARE MUST BE TAKEN TO MOVE THE CYLINDER SLOWLY INTO THE BOOM. DAMAGE TO COMPONENTS MAY RESULT FROM FORCIBLE IMPACT WITH THESE ASSEMBLIES.

NOTE: The telescope cylinder weighs approximately 600 lbs. (272 kg).


19. Using adequate lifting equipment, carefully push the telescope cylinder assembly and cables back into the boom.




20. Apply JLG Threadlocker P/N 0100011 to the bolts and fasten the telescope cylinder rod to the boom base section with the bolts, shims, mounting blocks.



21. Apply JLG Threadlocker P/N 0100011 to the bolts and fasten the telescope cylinder barrel to the boom mid section with the bolts, shims, mounting blocks.



22. Using a 3/8 drive extension approximately 4 ft (1.2 m) long, install the bolts and washers securing the cable mount block to the boom fly section. Tape the bolts to the socket at the end of the extension to prevent it from coming out of the socket before it engages the mounting threads.



- **23.** Connect all the hydraulic lines to the cylinder as tagged during the removal procedure.
- **24.** Adjust the boom cables as outlined under Section 4.8, Boom Rope Torquing Procedures.

4-12 3121139


Installation

- Using a suitable lifting device, position boom assembly on upright so that the pivot holes in both boom and upright are aligned.
- **2.** Install boom pivot pin, ensuring that location of hole in pin is aligned with attach point on upright.
- **3.** If necessary, gently tap pin into position with soft headed mallet. Secure pin mounting hardware.
- 4. Connect all wiring to the ground control box.
- **5.** Connect all hydraulic lines running along side of boom assembly.
- **6.** Using all applicable safety precautions, operate lifting device in order to position boom lift cylinder so that holes in the cylinder rod end and boom structure are aligned. Insert the lift cylinder pin, ensuring that location of hole in pin is aligned with attach point on boom.
- Align holes in boom structure with hole in master cylinder. Insert the master cylinder pin, ensuring that location of hole in pin is aligned with attach point on boom.
- **8.** Adjust retract and extend cables to the proper torque. Refer to Section 4.8, Boom Rope Torquing Procedures.
- **9.** Using all applicable safety precautions, operate machine systems and raise and extend boom fully, noting the performance of the extension cycle.
- Retract and lower boom, noting the performance of the retraction cycle.


Telescope Cylinder/Boom Cable Removal

- 1. Make sure the machine is on a firm, level surface.
- 2. Raise the boom to a horizontal position.
- **3.** Extend the boom approximately 2 ft (0.6 m). This will enable access to the bolts that secure the cable mount block to the boom fly section.
- **4.** Tag and disconnect all hydraulic hoses running to the telescope cylinder. Cap or plug all openings to prevent any foreign matter from entering the hydraulic system.


5. Using a 3/8 drive extension approximately 4 ft (1.2 m) long, remove the bolts and washers securing the cable mount block to the boom fly section.



6. Remove the four bolts, shims, and attachment blocks that secure the telescope cylinder barrel to the boom mid section.



Remove the four bolts, shims, and mounting blocks that secure the telescope cylinder rod to the boom base section.




NOTICE


WHEN REMOVING THE TELESCOPE CYLINDER FROM THE BOOM, IT MAY BE NECESSARY AT SOME POINT TO TURN THE CYLINDER SLIGHTLY IN ORDER TO CLEAR ASSEMBLIES MOUNTED WITHIN THE BOOM. CARE MUST BE TAKEN TO MOVE THE CYLINDER SLOWLY FROM THE BOOM. DAMAGE TO COMPONENTS MAY RESULT FROM FORCIBLE IMPACT WITH THESE ASSEMBLIES.

NOTE: The telescope cylinder weighs approximately 600 lbs. (272 kg).


8. Using overhead cranes or other suitable lifting/supporting devices, carefully pull the telescope cylinder out from the back of the boom. At the same time, also pull the cable mount block out so the extension cables come out with the telescope cylinder and do not bind. The lifting/supporting devices will have to be repositioned to support the weight of the cylinder as it is drawn out of the boom.



Push the boom fly sections back in to gain access to the boom retraction cable. **10.** Remove the screws securing the sheave guards to the boom mid section and remove the sheave guards.




11. Remove the adjusting nuts and lock nuts from the opposite end of the retraction cables at the front of the boom base section. To aid in installing new retraction cables, fasten a length of tie wire as long as the retraction cables to the ends of the cables.



4-14 3121139


12. Twist the ends of the retraction cables to remove the ends of the cables from the slots in the side of the boom fly section.




13. From the rear of the boom, pull out the boom retraction cables.

Telescope Cylinder/Boom Cable Installation

- 1. Attach the threaded end of the new retraction cables to the tie wires used in the removal procedure.
- 2. From the front of the boom, pull the retraction cables through the boom and through the attachment holes in the bottom of the boom base section. Loosely install the adjustment nuts and jam nuts.
- 3. Install new retract sheaves, then route the opposite end of the retraction cables around the sheaves. Push the ends of the cables through the slots in the side of the boom fly section.



4. Install the sheave guards and secure them in place with the retaining screws.




- **5.** Pull the boom sections out to approximately where they were extended to for telescope cylinder removal.
- Install a new extend sheave on the end of the telescope cylinder.
- 7. Route new extend cables around the telescope cylinder. Loosely fasten the threaded end of the cables to the rod end of the telescope cylinder with the adjusting nuts and lock nuts. Install the opposite end of the cables in the cable mount block.
- **8.** Use tape or tie straps to fasten the cables to the telescope cylinder assembly. It is important that the tape or straps be strong enough to hold the cable in place yet weak enough to break and fall away when the cables are adjusted.

NOTICE


WHEN PUSHING THE TELESCOPE CYLINDER INTO THE BOOM, IT MAY BE NECESSARY AT SOME POINT TO TURN THE CYLINDER SLIGHTLY IN ORDER TO CLEAR ASSEMBLIES MOUNTED WITHIN THE BOOM. CARE MUST BE TAKEN TO MOVE THE CYLINDER SLOWLY INTO THE BOOM. DAMAGE TO COMPONENTS MAY RESULT FROM FORCIBLE IMPACT WITH THESE ASSEMBLIES.

NOTE: The telescope cylinder weighs approximately 600 lbs. (272 kg).


Using adequate lifting equipment, carefully push the telescope cylinder assembly and cables back into the boom.




10. Apply JLG Threadlocker P/N 0100011 to the bolts and fasten the telescope cylinder rod to the boom base section with the bolts, shims, mounting blocks.



11. Apply JLG Threadlocker P/N 0100011 to the bolts and fasten the telescope cylinder barrel to the boom mid section with the bolts, shims, mounting blocks.



12. Using a 3/8 drive extension approximately 4 ft (1.2 m) long, install the bolts and washers securing the cable mount block to the boom fly section. Tape the bolts to the socket at the end of the extension to prevent it from coming out of the socket before it engages the mounting threads.




- **13.** Connect all the hydraulic lines to the cylinder as tagged during the removal procedure.
- **14.** Adjust the boom cables as outlined under Section 4.8, Boom Rope Torquing Procedures.
- **15.** Run the boom through all lift and telescope functions and check for proper operation or any leakage.

4-16 3121139

Lift Cylinder Removal

- Elevate the boom enough to gain access to the lift cylinder lower pivot pin.
- Use an adequate supporting device to support the weight of the boom and associated components as shown below.


NOTE: The supporting device must be able to support approximately 5350 lbs (2430 kg).




- Tag and disconnect the hydraulic hoses from the lift cylinder.
- Use an adequate lifting device to support the lift cylinder.

NOTE: The lift cylinder weighs approximately 618 lbs (280 kg).

Remove the bolt and keeper pin securing the upper lift cylinder pivot pin and remove the pivot pin.



Remove the bolt and keeper pin securing the lower lift cylinder pivot pin and remove the pivot pin.



- Using the lifting device, slide the lift cylinder back enough to allow the cylinder end to clear the attachment point on the boom.
- **8.** Slide the lift cylinder sideways enough to remove it from the machine.

Lift Cylinder Installation


NOTE: The lift cylinder weighs approximately 618 lbs (280 kg).

- Using an adequate lifting device, position the lift cylinder in the machine in the same manner that it was removed.
- 2. Install the lower pivot pin and secure it in place with the keeper pin and bolt.
- **3.** Connect the hydraulic lines to the cylinder as tagged during removal.
- Extend the cylinder rod until it aligns with the attachment point on the boom. Take care not to extend the cylinder rod too far.
- 5. Install the upper lift cylinder pivot pin and secure it in place with the keeper pin and bolt.
- Remove the supporting device and function check the boom to make sure the lift cylinder operates properly and there are no leaks.


4.2 PLATFORM

Platform Valve Removal

- **7.** Tag and disconnect the hydraulic lines from the platform control valve. Use suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.
- **8.** Remove hardware securing cover from the platform support. Remove cover.




- **9.** Remove hardware securing the mounting bracket to the platform support. Take out the mounting bracket along with platform control valve.
- Remove hardware securing the platform control valve to the mounting bracket. Remove platform control valve.




Platform Valve Installation

- 1. Install platform control valve onto the mounting bracket and secure using hardware.
- **2.** Install the mounting bracket onto the platform support and secure using hardware.



3. Install cover onto the platform support securing the hardware.



4. Remove tag and reconnect the hydraulic lines to the platform control valve.

4-18 3121139

Support Removal





Figure 4-10. Location of Components Platform Support


- 1. Disconnect electrical cables from control console.
- **2.** Remove the bolts securing the platform to the platform support, then remove the platform.

NOTE: The platform weighs approximately 203 lbs. (104 kg).




3. Using a suitable device, support the platform support.

4. Remove the bolts and locknuts securing the support to the rotator.



5. Using a suitable brass drift and hammer, remove the rotator center bolt, then remove the support from the rotator.




Support Installation


1. Using a suitable device, support the platform support and position it on the rotator.

NOTE: The platform support weighs approximately 77 lbs. (35 kg).

2. Install the rotator center bolt.




3. Apply JLG Threadlocker P/N 0100011 to the eight bolts and locknuts securing the support to the rotator and install the bolts and locknuts.




4. Torque the nut on the rotator center bolt to 586 ft. lbs. (795 Nm). Torque the retaining bolts to 40 ft. lbs. (55 Nm).

5. Position the platform on the platform support and install the bolts securing the platform to the platform support. Torque the bolts to 85 ft. lbs. (116 Nm).



6. Connect the electrical cables to the platform control console.

4-20 3121139



- A Torque to 40 ft.lbs. (55 Nm)
- B JLG Threadlocker P/N 0100011
- C Torque to 586 ft. lbs. (795 Nm)
- D Check torque every 150 hours of operation
- E Torque to 85 ft. lbs. (116 Nm)

Figure 4-11. Platform Support Torque Values

4.3 ROTATOR AND SLAVE CYLINDER

Removal

- **1.** Tag and disconnect hydraulic lines to rotator. Use suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.
- 2. Supporting the rotator, remove hardware from pin #1. Using a suitable brass drift and hammer remove pin #1 from the fly boom.
- **3.** Remove the hardware from pin #2. Using a suitable brass drift and hammer, remove pin #2 from the fly boom and remove the rotator.
- **4.** Telescope the fly section out approximately 20 in. (50 cm) to gain access to the slave leveling cylinder. (860 SJ only).
- **5.** Supporting the slave cylinder remove the hardware from pin #3. Using a suitable brass drift and hammer remove pin #3 from the fly boom.
- **6.** Tag and disconnect hydraulic lines to the slave leveling cylinder. Use a suitable container to retain any residual

hydraulic fluid. Cap hydraulic lines and ports. Remove the slave cylinder.




Figure 4-12. Reassembly of Components-Rotator and Leveling Cylinder

4.4 MAIN BOOM POWERTRACK

Removal

1. Disconnect wiring harness connectors located in tower upright.

NOTICE

HYDRAULIC LINES AND PORTS SHOULD BE CAPPED IMMEDIATELY AFTER DISCONNECTING LINES TO AVOID ENTRY OF CONTAMINANTS INTO SYSTEM.

- **2.** Tag and disconnect hydraulic lines from connectors at boom assembly. Use suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.
- **3.** Disconnect dual capacity indicator limit switch from side of boom section.
- Remove hydraulic lines and electrical cables from Powertrack.
- **5.** Using suitable lifting equipment, adequately support Powertrack weight along entire length.

6. Remove bolt #1 securing the push tube on the fly boom section.




Figure 4-13. Main Boom Powertrack Components

- **7.** Remove bolt #2 securing the push tube on the mid boom section.
- **8.** With Powertrack supported and using all applicable safety precautions, remove bolts #3, #4 and #5 securing rail to the base boom section. Remove Powertrack from boom section.

4-22 3121139




Figure 4-14. Powertrack Installation Main Boom - (Sheet 1 of 2)




Figure 4-15. Powertrack Installation Main Boom - (Sheet 2 of 2)

4-24 3121139

4.5 POWERTRACK MAINTENANCE

One Piece Bracket Maintenance

1. Place the powertrack on a workbench.



2. Remove the screws from the bars on one side of the powertrack on the first link.





3. Remove the screws from the flat bar on the other side of the powertrack.




4. Pull up on the loose side of the round bar to allow the poly roller to slide off.



5. Slide the poly roller off of the round bar.





6. Hold the round bar to remove the other screw.



7. Slide the flat bar out.





8. Remove the snap ring from one side of the bracket.



9. Remove the snap ring from the other side of the bracket.



4-26 3121139

10. Push down with slight pressure on the link and slide the bracket side up and over the extrusion on the link.



11. Repeat the previous step on the other side.




12. Slide the bracket off of the powertrack.




Two Piece Bracket Maintenance

1. Loosen the screw.



2. Slide the roller off the bar.



3. Hold the bar tightly and remove the other screw.



4. Hold the flat bar and remove the screws.



5. Remove the snap rings and pins.



6. Remove the screws from the bar. Remove the snap ring and pin.



7. Slide the link out.




4-28 3121139

Snap Rings and Screws


NOTICE

WHEN PERFORMING MAINTENANCE ON THE POWERTRACK, MAKE SURE TO DISCARD AND REPLACE ALL OLD SCREWS.

Make sure screws are tight and installed properly.




Make sure that all snap rings are closed and seated.



An open snap ring is shown below.



A snap ring that is not seated is shown below.



A seated and closed snap ring is shown below.



10-24 x 0.812 button torx socket head with blue locking patch:

- Tighten to 45-50 in.lbs. (5-5.6 Nm).
- Use T-25 torx bit.
- Do not reuse this screw. After removing replace with a new one.

4.6 BOOM CLEANLINESS GUIDELINES

The following are guidelines for internal boom cleanliness for machines that are used in excessively dirty environments.

- JLG recommends the use of the JLG Hostile Environment Package if available to keep the internal portions of a boom cleaner and to help prevent dirt and debris from entering the boom. This package reduces the amount of contamination which can enter the boom but does not eliminate the need for more frequent inspections and maintenance when used in these types of environments
- 2. JLG recommends that you follow all guidelines for servicing your equipment in accordance with the instructions outlined in the JLG Service & Maintenance Manual for your machine. Periodic maintenance and inspection is vital to the proper operation of the machine. The frequency of service and maintenance must be increased as environment, severity and frequency of usage requires.
- 3. Debris and foreign matter inside of the boom can cause premature failure of components and should be removed. Methods to remove debris should always be done using all applicable safety precautions outlined in the JLG Service & Maintenance Manuals.

- 4. The first attempt to remove debris from inside the boom must be to utilize pressurized air to blow the debris toward the nearest exiting point from the boom. Make sure that all debris is removed before operating the machine.
- 5. If pressurized air cannot dislodge the debris, then water with mild solvents applied via a pressure washer can be used. Again the method is to wash the debris toward the nearest exiting point from the boom. Make sure that all debris is removed, that no "puddling" of water has occurred, and that the boom internal components are dry prior to operating the machine. Make sure you comply with all federal and local laws for disposing of the wash water and debris.
- 6. If neither pressurized air nor washing of the boom dislodges and removes the debris, then disassemble the boom in accordance to the instructions outlined in the JLG Service & Maintenance Manual to remove the debris.

4-30 3121139

4.7 WIRE ROPE


Each day before using the machine:

- 1. Raise the main boom to approximately horizontal.
- 2. Extend and retract the boom sections.
- **3.** Check for delayed movement of the fly section, which indicates loose wire ropes.

Inspection


NOTE: The pictures in this paragraph are just samples to show the replacement criteria of the rope.

 Inspect ropes for broken wires, particularly valley wire breaks and breaks at end terminations.



Flexing a wire rope can often expose broken wires hidden in valleys between strands.


- 2. Inspect ropes for corrosion.
- 3. Inspect ropes for kinks or abuse.



A kink is caused by pulling down a loop in a slack line during improper handling, installation, or operation.

- **4.** Inspect sheaves for condition of bearings/pins. (See Dimension Of Sheaves for proper dimension.)
- **5.** Inspect sheaves for condition of flanges. (See Dimension Of Sheaves for proper dimension.)

Inspect sheaves with a groove wearout gauge for excessive wear.



Observe the groove so that it may be clearly seen whether the contour of the gauge matches the contour of the bottom of the groove.

7. Ropes passing inspection should be lubricated with wire rope lubricant before reassembly.

Three Month Inspection

- Remove boom covers and visually (with flashlight) inspect the ropes for rust, broken wires, frays, abuse, or any signs of abnormalities.
- Check rope tension by deflecting the ropes by hand...properly tensioned ropes should have little or no movement.

12 Year or 7000 Hour Replacement

1. Mandatory wire rope and sheave replacement.

Additional inspection required if:

- a. Machine is exposed to hostile environment or conditions.
- **b.** Erratic boom operation or unusual noise exists.
- c. Machine is idle for an extended period.
- d. Boom is overloaded or sustained a shock load.
- **e.** Boom exposed to electrical arc...wires may be fused internally.

Replacement Criteria

- 1. Sheaves and wire rope must be replaced as sets.
- 2. Rusted or corroded wire ropes.
- **3.** Kinked, "bird caged", or crushed ropes.
- 4. Ropes at end of adjustment range.
- 5. Sheaves failing wearout gage inspection.
- **6.** Ropes with 6 total broken wires in one rope lay, 3 in one strand in one rope lay, 1 valley break, or 1 break at any end termination.

4.8 BOOM ROPE TORQUING PROCEDURES

Torque Procedures

- 1. Position boom in fully down and fully retracted position.
- Clamp both threaded ends of wire rope to prevent rotation.

NOTE: Do not clamp on threads.




Figure 4-16. Clamping Wire Ropes

3. Install adjusting nuts (or remove nylon collar locknuts if re-adjusting) to both retract and extend wire ropes.

4. Torque retract adjusting nuts (platform end) to 15 ft. lbs. (20 Nm) alternating between the two wire ropes and keeping approximately the same amount of thread beyond the adjusting nut.

NOTE: Do not allow wire rope to rotate. This may damage the wire rope.


- **5.** Repeat the torque procedure in step #4 to the extend wire ropes (turntable end).
- **6.** Extend the boom 2 3 ft using the telescope function. Repeat step #4.
- 7. Retract the boom 1 2 ft using the telescope function. Do not bottom out telescope cylinder. Repeat step #5.
- **8.** Extend the boom approximately 2 3 ft again and check torque on the retract wire ropes.
- **9.** Retract the boom without bottoming out telescope cylinder and check torque on the extend wire ropes.

NOTE: Step #8 and #9 may need to be repeated to equalize the torque on all 4 wire ropes.

10. After all wire ropes have been properly torqued, install nylon collar locknuts. Remove all clamping devices and install all covers and guards. Check the boom for proper function.

4-32 3121139

4.9 ELEVATION & CAPACITY SWITCHES - 800S



| 1 | $Boom Capacity Length Switch to trip boom when it's 216" \pm 1" (5486mm \pm 25mm) from fully extended$ |
|---|--|
| 2 | $150.75" \pm 1" (3829 mm \pm 25 mm) position of boom sections to Trip Capacity Length Switch (ANSI Only)$ |
| | $18.25"\pm 1" (463.5mm\pm 25mm)\ position\ of\ boom\ sections\ to\ trip\ Transport\ Length\ Switch$ |
| 3 | $Boom Transport Length Switch to trip when boom is 18" \pm 1" from fully retracted$ |
| 4 | Boom Capacity Angle Switch to trip when upper boom is 50° to 55° above horizontal. 52° is the preferred trip angle |
| | $Boom Capacity Angle Switch to reset when upper boom is 59^{\circ} to 64^{\circ} above horizontal. 61^{\circ} is the preferred reset angle and the preferred angle and the preferred angle and the preferred angle and the preferred angle and the angle and the preferred angle and the angle angle$ |
| 5 | Boom Elevation Switch to trip when upper boom is 7° to 12° above horizontal. 9° is the preferred trip angle |
| | $Boom Elevation Switch to reset when upper boom is 3^{\circ} below horizontal to 2^{\circ} above horizontal . 0^{\circ} is the preferred reset angle and contact and $ |
| 6 | End of Stroke Switch should trip when boom is 5°-7° from end of extended cylinder stroke |

Figure 4-17. Elevation, Dual Capacity and Transport Switch Information - 800S





Figure 4-18. Elevation, Dual Capacity and Transport Switch Installation - 800S

4-34 3121139

4.10 ELEVATION, DUAL CAPACITY, & TRANSPORT SWITCH - 860SJ



| 1 | $Boom Capacity Length Switch to trip boom when it's 180" \pm 1" (4572 mm \pm 25 mm) from fully extended$ |
|---|---|
| 2 | $160.25" \pm 1" (4070 mm \pm 25 mm) \ position \ of boom \ sections \ to \ Trip \ Capacity \ Length \ Switch \ (ANSI \ Only)$ |
| | $18.25" \pm 1" (463.5 mm \pm 25 mm) \ position \ of boom \ sections \ to \ trip \ Transport \ Length \ Switch$ |
| 3 | $Boom Transport Length Switch to trip when boom is 18" \pm 1" from fully retracted$ |
| 4 | Boom Capacity Angle Switch to trip when upper boom is 44° to 49° above horizontal. 46° is the preferred trip angle |
| | $Boom Capacity Angle Switch to reset when upper boom is 52^{\circ} to 57^{\circ} above horizontal. 55^{\circ} is the preferred reset angle$ |
| 5 | Boom Elevation Switch to trip when upper boom is 9° to 14° above horizontal. 12° is the preferred trip angle |
| | $Boom Elevation Switch to reset when upper boom is 1^{\circ} below horizontal to 4^{\circ} above horizontal . 2^{\circ} is the preferred reset angle is 1^{\circ} below horizontal and below horizon$ |
| 6 | End of Stroke Switch should trip when boom is 5°-7° from end of extended cylinder stroke |

Figure 4-19. Elevation, Dual Capacity, and Transport Switch Information - 860SJ




Figure 4-20. Elevation, Dual Capacity, and Transport Switch Installation - 860SJ

4-36 3121139

4.11 ELECTRONIC PLATFORM LEVELING

Description

Electronic platform leveling replaces the conventional hydraulic method of platform leveling. The term "platform leveling" does not refer to the system maintaining the platform at level (or 0°) with respect to gravity, but instead refers to the controls automatically maintaining the platform within several degrees of a preset angle.

To control electronic platform leveling the platform is equipped with a pair of tilt sensors, one primary and one secondary, mounted to the non-rotating portion of the platform rotator, level up and level down valves that are used to provide proportional hydraulic flow for each directional function, and a control module that interprets the sensor readings and actuates the leveling valves.

PRIMARY AND SECONDARY TILT SENSOR INTERACTION

Two tilt sensors, mounted on each side of the platform support, are used to measure the incline of the platform with respect to gravity and control the automatic platform angle control function. The right one (as viewed from standing in the platform) is used as the primary sensor and the left one as a secondary backup sensor.

If a fault occurs with the primary sensor, control will revert to the secondary sensor (This is discussed in more detail in the error response section).

Because of the mounting orientation of the tilt sensors, the primary tilt sensor will output ascending voltage values with increases in positive platform tilt angle. The backup or secondary tilt sensor will output descending voltage values with increases in positive platform angle.




Figure 4-21. Level Switches - 800S

4-38 3121139




Figure 4-22. Level Switches - 860SJ

PLATFORM VALVES

The platform specific valves are located in a manifold at the platform

There are six valves that control various platform functions. Two control Platform Level up and down for the leveling function, two are used to rotate the platform, and two to control jib up and down.

All platform valves are Pulse Width Modulated (PWM'd). PWM is a method of setting the voltage across a valve, and therefore the flow through it, by varying the On/Off duty cycle of the control module output. PWMing permits proportional flow control.

There is also a Platform Dump Valve, located in the platform valve manifold, which is used to hydraulically isolate the control valves and to improve hydraulic response.

The Ground Module controls this valve to enable automatic platform leveling and to provide manual platform leveling in the event that the Platform Module is inoperable.

In ground mode, the platform dump valve is turned on whenever any platform or jib valve output is turned on. Whenever all platform and jib valves are turned off, the platform dump valve is turned off.

In platform mode, the platform dump valve is turned on whenever the footswitch is depressed.

Normal Operation

AUTOMATIC PLATFORM ANGLE CONTROL

The level system will assume a new fixed set point (fixed incline of the platform with respect to gravity) each time the control system is powered up (cycling of the EMS) and each time the footswitch is engaged.

Automatic platform angle control only functions while operating drive, telescope, lift or swing. It does not adjust the platform angle while operating any other function (e.g. rotate, jib, or steer). Furthermore, machines equipped with control system software P5.0 and later, automatic platform angle control for drive and swing may be disabled by using the analyzer. For this case, the platform angle setpoint is taken when the joystick moves from a non-leveling function (drive/swing) to a leveling function (lift/tele).

The machine controls attempt to maintain the angle of the platform to setpoint by providing a command proportional to the angular error from setpoint. Since the sensors used to measure the platform angle are fluid-filled, gravity-based sensors, reading the sensors in real time would cause constant correction of the platform position due to machine vibration and inertial changes of the boom. Therefore, the sensor readings are averaged over time, or filtered, in order to achieve a more uniform reading. This filtering has the advantage of providing smoother operation, but has the disadvantage of causing a lag (or sluggishness) in the system response. This lag may cause the platform to be several degrees from setpoint.

In order to provide a better system response, the controls also compute the rate of angular change of the platform position and set the leveling valve positions to achieve a matching velocity. The measured velocity is the average platform speed over the last 0.5 seconds. The desired valve command is computed by comparing the measured velocity to the desired velocity and setting the valve opening to correspond to the required amount of make-up angle. The amount the valve opens when making an automatic correction is proportional to and directly affected by:

- · Crackpoint setting
- Velocity error (proportional factor)
- · Sum of velocity errors over time (integral factor)

These three factors are summed together with appropriate gain factors to compute the resulting current to the valves. The operator does not have control over the latter two factors, but can affect the resulting current by adjusting the crackpoint. Increasing the crackpoint makes the valve current higher, resulting in quicker more aggressive control and larger amounts of overshoot. Decreasing the crackpoint will result in smoother operation but may not permit enough platform velocity to keep up with the boom (i.e., may get platform timeout alarms) in some multi-function operations. The platform controls are set up to provide smooth leveling operations for the majority of conditions and will perform best for steady operator command, as opposed to command values for function, that change frequently.

In order to obtain acceptable performance while performing all hydraulic functions, five sets of parameters are used. These "zones" allow compensation for differences in how the basket level changes when doing different functions. These zones are as follows:

- 1. Lift up
- 2. Lift down
- 3. Other boom functions
- 4. Drive
- 5. Auxiliary

The other boom functions zone includes Swing, Telescope, Jib swing (It is not necessary to level with jib lift, since the mechanical linkage keeps the basket level).

These zones are prioritized when multiple functions are active. The priorities are as follows.

- Auxiliary power and any other function, zone = auxiliary power
- 2. Drive and any other function, zone = Drive

4-40 3121139

- 3. Lift up and any other function, zone = Lift up
- **4.** Lift down and any other function, zone = Lift down
- **5.** Other boom functions, zone = Other boom functions

During the power-up procedure, function enable, in both Platform and Ground Mode, is delayed during the 1.5 second startup lamp test. During this 1.5 second startup period, the basket level up valve will be energized at 100% duty cycle for 0.5 second, and then the basket level down valve energized at 100% duty cycle for 0.5 second. This will help to keep the valves from sticking.

PLATFORM LEVEL MANUAL OVERRIDE

In addition to automatic platform angle control, the operator is able to manually adjust the platform level position by means of the level override switches located at the platform and ground control positions (similar to a Master/Slave hydraulic system).

If a command from the Platform Level Up and Down toggle switch on either the platform or the ground is received, automatic platform angle control will cease and the appropriate output will be commanded to turn on.

The duty cycle of the output shall be scaled from the pump potentiometer. When the toggle switch is released, after one second, the current filtered value of tilt angle will be taken as **the new set point**.

In other words the operator can chose a platform level incline other than level with gravity and the system will maintain the chosen platform angle within several degrees of setpoint.

Platform Leveling Fault

The JLG Control System takes a snapshot of the two sensor values and records the difference once on each power up. The Control system allows a ± 5 degree difference from those values. For example, if Sensor 1 is at 5 degrees and Sensor 2 is at 11 degrees, the difference is 6 degrees and the DTC is triggered when the sensors are 1 degree (or less) apart or 11 degrees (or more) apart.

If a fault occurs in the platform leveling system the following will occur:

- Automatic platform angle control will stop and the platform dump valve will be disabled (level, rotate, and jib functions disabled). The exception is when there is a fault in only one sensor automatic platform angle control will remain active as the control system will use the other sensor to control leveling.
- **2.** The level system fault lamp will flash (to indicate that the leveling function has been lost).
- 3. The platform alarm will sound.
- 4. A system fault will be logged.
- All function speeds (lift, swing, telescope and drive) will be placed in creep mode (except when the platform is in the transport position see below).

To reset the fault the emergency stop switch should be recycled.

NOTICE

IF THE LEVEL SYSTEM FAULT INDICATOR REMAINS ILLUMINATED, RETURN THE PLATFORM TO THE STOWED POSITION, SHUT DOWN THE MACHINE, AND REPAIR THE LEVELING SYSTEM.

ERROR RESPONSE

If basket level varies from the current **setpoint** by \pm 5.5° for more than 2 seconds for large variations from setpoint when the platform is not in the transport position, the controls assume the system is not properly set up or has degraded and initiate a fault.

When the unit is in the transport position and driving and the current setpoint varies by \pm 5.5° for more than 10 seconds the events 1,2,3 & 4 above will occur. (note function speeds will operate normally). Since the control system can not anticipate all conditions under which a machine is to be operated, these parameters have been chosen to provide reasonable performance and safe operation. If an error occurs, cycling the EMS will clear the fault. The operator should evaluate the operating situation and assess his machine to determine the source of the fault.

VALVE DRIVER ERRORS

There are three possible level valve driver errors, short to battery, short to ground, and open circuit.

- In the case of a short to ground or an open circuit, the platform valve cannot be turned on and the following will occur:
 - a. All interactions with platform leveling shall cease
 - **b.** The Electronic Leveling System Fault Lamp shall flash (to indicate that the leveling function has been lost).
 - c. The platform alarm will sound.
 - d. A system fault will be logged.
 - All function speeds (lift, swing, telescope and drive) will be placed in creep mode (except when the platform is in the transport position).
- In the case of a **short to battery** on one of the platform leveling valves, the valve cannot be turned off and the following will occur:
 - a. The platform dump valve will be turned off to prevent unintended tilting of the platform.
 - **b.** All interactions with platform leveling shall cease.
 - c. The Electronic Leveling System Fault Lamp shall flash (to indicate that the leveling function has been lost).
 - **d.** The platform alarm will sound.
 - e. A system fault will be logged.
 - **f.** All function speeds (lift, swing, telescope and drive) will be placed in creep mode (except when the platform is in the transport position).

- 3. In the case of a **short to battery on the platform dump valve**, the valve cannot be turned off. The controllability of the platform leveling function will be impaired and the following will occur:
 - a. All interactions with platform leveling shall cease.
 - b. The Electronic Leveling System Fault Lamp shall flash (to indicate that the leveling function has been lost).
 - c. The platform alarm will sound.
 - **d.** A system fault will be logged.
 - All function speeds (lift, swing, telescope and drive) will be placed in creep mode (except when the platform is in the transport position).

Lift, swing, drive and telescope will continue to operate

In each of the cases above it shall be necessary to re-cycle the EMS to clear the fault. Operable functions shall be in the creep mode except while below elevation.

TILT SENSOR ERRORS

If the secondary tilt sensor is faulty, the control system will continue to utilize information from the primary sensor.

If the primary sensor is faulty, the control system will switch to the backup sensor for control.

In both cases above the following will occur:

- The Electronic Leveling System Fault Lamp will flash (to indicate that there is a leveling fault).
- 2. The platform alarm will sound.
- **3.** A system fault will be logged.
- 4. All function speeds (lift, swing, telescope, jib and drive) will be placed in creep mode (except when the platform is in the transport position).
- **5.** Automatic platform angle control remains active.

Lift, swing, drive and telescope will continue to operate.

In each of the cases above it will be necessary to re-cycle the EMS to clear the fault. Operable functions shall be in the creep mode except while below elevation.

4-42 3121139

When both sensors appear to be working but have measurements that disagree by ±5.5° The following will occur:

- 1. All interactions with platform leveling shall cease.
- 2. The Electronic Leveling System Fault Lamp shall flash (to indicate that the leveling function has been lost).
- **3.** The platform alarm will sound.
- **4.** A system fault will be logged.
- All function speeds (lift, swing, telescope and drive) will be placed in creep mode (except when the platform is in the transport position).

At this point, the operator must use the level up and down toggle switch to manually level during descent. It shall be necessary to re-cycle the EMS to clear the fault.

CAN Errors

The Ground Module has two direct outputs dedicated to overriding the Platform Module's control of the leveling valves. The EPBC Ground Module "Platform Level Up/Down" outputs are used to control the platform level up and down valves.

When in ground mode, if the Ground Module reads a platform leveling switch command, the switch command is communicated over CAN to the Platform Module where it is handled normally.

If Ground Module determines that CAN communication is inoperable, it turns on the platform control valve and the appropriate platform leveling override outputs while the switch is engaged.

If the Platform Module is still running when CAN is down nothing will operate when in platform mode. When the operator switches to ground mode, the platform will not control any of its valve outputs and a CAN error message is signaled.

Replacing the Level Sensors

Earlier generations of this machine had three different generations of level sensors that were used on this machine. JLG P/N 4360503, P/N 4360528, and P/N 4360544. P/N 4360528 and 4360544 supersede P/N 4360503. If one of the 4360503 sensors fail, BOTH sensors must be replaced with two P/N 4360544 sensors. 4360503 Sensors can be identified by the code SSY0185-13 which is printed on the sensor. Otherwise, single 4360528 or 4360544 9999sensors may be replaced.

Additional Platform and Jib Valves

The high side drivers for the platform left and right and the jib up and down valves are be located in the Platform Module and are PWM'd. The control for these functions are the same as currently implemented for the EPBC except that the flow through the valves is individually controllable instead of controlled by single the flow control valve. The individually controlled duty cycle will be the same as would otherwise have been commanded to the flow control valve.

Only one platform or jib function is allowed at one time to limit the amount of current draw, minimizing the voltage drop on the supply to the PM.

The function is enabled first shall remain active until it is released. Any other function commanded while another function is active is ignored.

If only one other function is commanded when the active function is released, the other function will be activated.

If more than one function is commanded when the active function is released, only one function shall be activated.

Platform Leveling Calibration Procedure STEP 1: SETTING THE PLATFORM VALVE MINIMUMS

- 1. Put machine into "Ground Mode".
- 2. Start machine and plug in Analyzer.
- **3.** Go to the "Access Level 2" screen.
- 4. Enter "33271" to get into Access Level 1 mode.
- **5.** Go to the "Personalities" menu and adjust the following personalities. Refer to the Personality Ranges/Defaults table in Section 6 JLG Control System for proper setting values.

Basket Level Up Min Basket Level Up Max Basket Level Down Max Jib Up Min Jib Down Min

6. Recycle EMS.

STEP 2: CALIBRATING THE PLATFORM LEVEL SENSORS (FOR PLATFORM SOFTWARE PRIOR TO VERSION P3.4)

- 1. Put machine into "Ground Mode".
- 2. Start machine and plug in Analyzer.
- **3.** Manually level the platform with the switch on the MTB.
- 4. Go to the "Access Level 2" screen.
- 5. Enter "33271" to get into Access Level 1 mode.
- 6. Go to the "Calibrations" menu and hit ENTER.
- 7. Use RIGHT ARROW go to "Plat. Leveling" screen.
- 8. Hit ENTER. "Calibrate?" prompt should appear.
- 9. Hit ENTER again to calibrate level sensors.
- When calibration has been successful "Cal. Complete" should appear.
- 11. Cycle power to the machine.

STEP 3: BLEEDING THE PLATFORM VALVES

Start up the machine and exercise the following platform functions (from the ground) eight (8) to ten (10) times for 5 seconds in each direction.

Basket Rotate Basket Level Jib U/D (if configured)

STEP 4: CALIBRATING THE PLATFORM LEVEL UP AND DOWN VALVE CRACKPOINTS

NOTE: Since the valve position which allows minimum oil flow (crackpoint) is dependent on the oil pressure, verify the proper stand-by pressure as outlined in Section 5.3 prior to setting the crackpoints.

- 1. Put machine into "Ground Mode".
- 2. Start machine and plug in Analyzer.
- 3. Go to the "Access Level 2" screen.
- 4. Enter "33271" to get into Access Level 1 mode.
- 5. Go to the "Calibrations" menu and hit ENTER.
- **6.** Go to the "Basket U Crkpt" Screen. Hit ENTER.
- 7. "Calibrate?" prompt should appear. Hit ENTER again.

- 8. You will hear engine go to 1800 rpm.
- **9.** Using UP ARROW, increase the value until you see the basket up movement. (Typically from 275 425).
- **10.** Hit ENTER again. "Cal. Complete" message should appear
- 11. Engine should again return to idle.
- **12.** Hit ESC should return to "Basket U Crkpt" screen.
- **13.** Hit RIGHT ARROW to get to the "Basket D Crkpt" screen. Hit ENTER.
- **14.** "Calibrate?" prompt should appear. Hit ENTER again.
- 15. You will hear engine go to 1800 rpm.
- **16.** Using UP ARROW, increase the value until you see the basket down movement. (Typically from 275 425).
- Hit ENTER again. "Cal. Complete" message should appear.
- **18.** Engine should again return to idle.
- 19. Hit ESC to exit.
- 20. Cycle power to the machine.
- 21. The preceding steps will provide acceptable crackpoint settings for the majority of machines. However, if the operator can feel small jolts in the platform from the valve opening during a leveling operation, the crackpoint is likely too high for this machine. A high crackpoint may also lead to "over-leveling", causing the platform to drift beyond the set point. An example of this would be the platform tilting too far backwards during a Lift Up operation. Therefore, use the following guidelines to evaluate whether further crackpoint adjustment is required.
 - a. Telescope the machine halfway.
 - b. Perform Lift Up. If the basket leans backward (over compensates), the Level Down crackpoint is too high. If the basket leans forward or a BASKET LEVEL-ING SYSTEM TIMEOUT fault occurs, the Level Down crackpoint is too low.
 - c. Perform Lift Down. If the basket leans forward (over compensates), the Level Up crackpoint is too high. If the basket leans backwards or the Tilt Cutout Alarm comes on, the Level Up crackpoint is too low.


4-44 3121139

4.12 HELAC ROTARY ACTUATOR

Theory of Operation


The rotary actuator is a simple mechanism that uses the sliding spline operating concept to convert linear piston motion into powerful shaft rotation. Each actuator is composed of a housing with integrated gear teeth (01) and only two moving parts: the central shaft with integrated bearing tube and mounting flange (02), and the annular piston sleeve (03). Helical spline teeth machined on the shaft engage matching splines on the in-side diameter of the piston. The outside diameter of the piston carries a second set of splines, of opposite hand, which engage with matching splines in the housing. As hydraulic pressure is applied, the piston is displaced axially within the housing -similar to the operation of a hydraulic cylinder while the splines cause the shaft to rotate. When the control valve is closed, oil is trapped inside the actuator, preventing piston movement and locking the shaft in position.

The shaft is supported radially by the large upper radial bearing and the lower radial bearing. Axially, the shaft is separated from the housing by the upper and lower thrust washers. The end cap is adjusted for axial clearance and locked in position by set screws or pins.



NOTE: Bars indicate starting positions of piston and shaft. Arrows indicate direction they will rotate. The housing with integral ring gear remains stationary.

As fluid pressure is applied, the piston is displaced axially while the helical gearing causes the piston and shaft to rotate simultaneously. The double helix design compounds rotation: shaft rotation is about twice that of the piston.




Housing
 Shaft
 Piston Sleeve
 End Cap
 Lock Pin
 Cap Screw

200. T-Seal202. T-Seal204. 0-ring205. Cup Seal207. Backup Ring

302. Wear Guide 304. Thrust Washer 304.1. Wiper Seal 401. Counterbalance Valve 400. Stop Tube

Figure 4-23. Rotary Actuator (Exploded View)

4-46 3121139



1. 109. Lock Pin 302. Wear Guide Housing 304. Thrust Washer 2. Shaft 113. Cap Screw 200. T-Seal 304.1. WiperSeal 3. Piston Sleeve End Cap 400. Stop Tube (Optional) 4. 202. T-Seal 103.1. Screw (Optional) 204. 0-ring 420.1. Bushing 103.2. Washer (Optional) 205. Cup Seal 420.2. Bushing (Optional) 106.1. Port Plug 207. Backup Ring 421.1. Bushing (Optional) 106.2. Port Plug


Figure 4-24. Rotary Actuator (Cutaway View)

Tools Required for Assembly/Disassembly

Upon assembly and disassembly of the actuator there are basic tools required. The tools and their intended functions are as follows:

- Flashlight- helps examine timing marks, component failure and overall condition.
- Felt Marker- match mark the timing marks and outline troubled areas.
- 3. Allen wrench-removal of port plugs and setscrews.
- 4. Box knife- removal of seals.
- Seal tool- assembly and disassembly of seals and wear quides.
- Pry bar- removal of end cap and manual rotation of shaft.
- Rubber mallet- removal and installation of shaft and piston sleeve assembly.
- 8. Nylon drift-installation of piston sleeve.
- End cap dowel pins-removal and installation of end cap (sold with seal kit).





The seal tool is merely a customized standard flat head screw-driver. To make this tool you will need to heat the flat end with a torch. Secure the heated end of the screwdriver in a vise and physically bend the heated end to a slight radius. Once the radius is achieved round off all sharp edges of the heated end by using a grinder. There may be some slight modifications for your own personal preference.

Disassembly



 Remove the capscrews (113) over end caplock pins (109).



 Using a 1/8" (3.18mm) drill bit, drill a hole in the center of each lock pin to a depth of approximately 3/ 16" (4.76mm).



3. Remove the lock pins using an "Easy Out" (a size #2 is shown). If the pin will not come out with the "Easy Out", use 5/16" drill bit to a depth of 1/2" (12.7mm) to drill out the entire pin.

4-48 3121139



4. Install the end cap (4) removal tools provided with the Helac seal kit.




5. Using a metal bar, or something similar, unscrew the end cap (4) by turning it counter clockwise.



6. Remove the end cap (4) and set aside for later inspection.



7. Remove the stop tube if included. The stop tube is an available option to limit the rotation of the actuator.





8. Every actuator has timing marks for proper engagement.




9. Prior to removing the shaft, (2), use a felt marker to clearly indicate the timing marks between shaft and piston. This will greatly simplify timing during assembly.



10. Remove the shaft (2). It may be necessary to strike the threaded end of the shaft with a rubber mallet.



11. Before removing the piston (3), mark the housing (1) ring gear in relation to the piston O.D. gear. There should now be timing marks on the housing (1) ring gear, the piston (3) and the shaft (2).



12. To remove the piston (3) use a rubber mallet and a plastic mandrel so the piston is no damaged.



13. At the point when the piston gear teeth come out of engagement with the housing gear teeth, mark the piston and housing with a marker as shown.




14. Remove the o-ring (204) and backup ring (207) from end cap (4) and set aside for inspection.

4-50 3121139



15. Remove the wear guides (302) from the end cap (4) and shaft (2).



16. To remove the main pressure seals (205), it is easiest to cut them using a sharp razor blade being careful not to damage the seal groove.



17. Remove the thrust washers (304), from the end cap (4) and shaft (2).



18. Remove the wiper seal (304.1) from its groove in the end cap (4) and shaft (2).



19. Remove the piston O.D. seal (202).



20. Remove the piston I.D. seal (200). You may now proceed to the inspection process.

Inspection



1. Clean all parts in a solvent tank and dry with compressed air prior to inspecting. Carefully inspect all critical areas for any surface finish abnormalities: Seal grooves, bearing grooves, thrust surfaces, rod surface, housing bore and gear teeth.



2. Inspect the thrust washers (304) for rough or worn edges and surfaces. Measure it's thickness to make sure it is within specifications (Not less than 0.092" or 2.34 mm).



3. Inspect the wear guide condition and measure thickness (not less than 0.123" or 3.12 mm).

Assembly



1. Gather all the components and tools into one location prior to re-assembly. Use the cut away drawing to reference the seal orientations.



2. Install the thrust washer (304) onto shaft (2) and end cap (4).



3. Install the wiper seal (304.1/green o-ring) into it's groove on the shaft (2) and end cap (4) around the outside edge of the thrust washer (304).

4-52 3121139



4. Using a seal tool install the main pressure seal (205) onto shaft (2) and end cap (4). Use the seal tool in a circular motion.



5. Install the o-ring (204) and backup ring (207) into the inner seal groove on the end cap (4).



6. Install the wear guide (302) on the end cap (4) and shaft (2).



7. Install the inner T-seal (200) into the piston (3) using a circular motion. Install the outer T-seal (202) by stretching it around the groove in a circular motion. Each T-seal has 2 backup rings (see drawing for orientation).



Beginning with the inner seal (200) insert one end of b/u ring in the lower groove and feed the rest in using a circular motion. Make sure the wedged ends overlap correctly. Repeat this step for the outer seal (202).




8. Insert the piston (3) into the housing (1) as shown, until the outer piston seal (202) is touching inside the housing bore.


3121139 4-53



9. Looking from the angle shown, rotate the piston (3) until the marks you put on the piston and the housing (1) during disassembly line up as shown. Using a rubber mallet, tap the piston into the housing up to the point where the gear teeth meet.




10. Looking from the opposite end of the housing (1) you can see if your timing marks are lining up. When they do, tap the piston (3) in until the gear teeth mesh together. Tap the piston into the housing the rest of the way until it bottoms out.



11. Install the shaft (2) into the piston (3). Be careful not to damage the seals. Do not engage the piston gear teeth yet.




12. Looking from the view shown, use the existing timing marks to line up the gear teeth on the shaft (2) with the gear teeth on the inside of the piston (3). Now tap the flange end of the shaft with a rubber mallet until the gear teeth engage.



13. Install two bolts in the threaded holes in the flange. Using a bar, rotate the shaft in a clockwise direction until the wear guides are seated inside the housing bore.



AS THE SHAFT IS ROTATED, BE CAREFUL NOT TO DISENGAGE THE PISTON AND HOUSING GEARING.



4-54 3121139

14. Install the stop tube onto the shaft end. Stop tube is an available option to limit the rotation of an actuator.



15. Coat the threads on the end of the shaft with antiseize grease to prevent galling.



16. Thread the end cap (4) onto the shaft (2) end. Make sure the wear guide stays in place on the end cap as it is threaded into the housing (1).



17. Tighten the end cap (4). In most cases the original holes for the lock pins will line up.



18. Place the lock pins (109) provided in the Helac seal kit in the holes with the dimple side up. Then, using a punch, tap the lock pins to the bottom of the hole.



19. Insert the set screws (113) over the lock pins. Tighten them to 25 in. lbs. (2.825 Nm).

3121139 4-55

Installing Counterbalance Valve

Refer to Figure 4-25., Rotator Counterbalance Valve.

- **1.** Make sure the surface of the actuator is clean, free of any contamination and foreign debris including old Loctite.
- **2.** Make sure the new valve has the o-rings in the counterbores of the valve to seal it to the actuator housing.
- **3.** The bolts that come with the valve are grade 8 bolts. New bolts should be installed with a new valve. JLG Threadlocker P/N 0100011 should be applied to the shank of the three bolts at the time of installation.
- **4.** Torque the 1/4-in. bolts 110 to 120 in. lbs. (12.4 to 13.5 Nm). Do not torque over 125 in. lbs (14.1 Nm). Torque the 5/16-in. bolts 140 in. lbs. (15.8 Nm). Do not torque over 145 in. lbs. (16.3 Nm).




Figure 4-25. Rotator Counterbalance Valve

4-56 3121139

Testing the Actuator

If the equipment is available, the actuator should be tested on a hydraulic test bench. The breakaway pressure — the pressure at which the shaft begins to rotate — should be approximately 400 psi (28 bar). Cycle the actuator at least 25 times at 3000 psi (210 bar) pressure. After the 25 rotations, increase the pressure to 4500 psi (315 bar) to check for leaks and cracks. Perform the test again at the end of the rotation in the opposite direction.

TESTING THE ACTUATOR FOR INTERNAL LEAKAGE

If the actuator is equipped with a counterbalance valve, plug the valve ports. Connect the hydraulic lines to the housing ports. Bleed all air from the actuator (see Installation and Bleeding) Rotate the shaft to the end of rotation at 3000 psi (210 bar) and maintain pressure. Remove the hydraulic line from the non-pressurized side.

Continuous oil flow from the open housing port indicates internal leakage across the piston. Replace the line and rotate the shaft to the end of rotation in the opposite direction. Repeat the test procedure outlined above for the other port. If there is an internal leak, disassemble, inspect and repair.

Installation and Bleeding


After installation of the actuator on the equipment, it is important that all safety devices such as tie rods or safety cables are properly reattached.

To purge air from the hydraulic lines, connect them together to create a closed loop and pump hydraulic fluid through them. Review the hydraulic schematic to determine which hydraulic lines to connect. The linear feet and inside diameter of the hydraulic supply lines together with pump capacity will determine the amount of pumping time required to fully purge the hydraulic system.

Bleeding may be necessary if excessive backlash is exhibited after the actuator is connected to the hydraulic system. The following steps are recommended when a minimum of two gallons (8 liters) is purged.

1. Connect a 3/16" inside diameter x 5/16" outside diameter x 5 foot clear, vinyl drain tube to each of the two bleed nipples. Secure them with hose clamps. Place the vinyl tubes in a clean 5-gallon container to collect the

purged oil. The oil can be returned to the reservoir after this procedure is completed.



- 2. With an operator in the platform, open both bleed nipples 1/4 turn. Hydraulically rotate the platform to the end of rotation (either clockwise or counterclockwise), and maintain hydraulic pressure. Oil with small air bubbles will be seen flowing through the tubes. Allow a 1/2 gallon of fluid to be purged from the actuator.
- **3.** Keep the fittings open and rotate the platform in the opposite direction to the end position. Maintain hydraulic pressure until an additional 1/4 gallon of fluid is pumped into the container.
- **4.** Repeat steps 2 & 3. After the last 1/2 gallon is purged, close both bleed nipples before rotating away from the end position.

3121139 4-57

Troubleshooting

Table 4-1. Troubleshooting

| Problem | Cause | Solution |
|---|--|---|
| 1. Shaft rotates slowly or not at all | a. Insufficient torque output | a. Verify correct operating pressure. Do not exceed OEM's pressure specifications. Load may be above maximum capacity of the actuator. |
| | b. Low rate of fluid flow | b. Inspect ports for obstructions and hydraulic lines for restrictions and leaks. |
| | c. Control or counterbalance valve has internal leak | c. Disconnect hydraulic lines and bypass valve. Leave valve ports open and operate the actuator through housing ports (do not exceed OEM's operating pressure). The valve must be replaced if a steady flow of fluid is seen coming from the valve ports. |
| | d. Piston and/or shaft seal leak | d. Remove the plug and the housing's valve ports. Operate the actuator through the housing ports. Conduct the internal leakage test as described in the Testing section on page 24 of this manual. |
| | e. Corrosion build-up on the thrust surfaces | e. Re-build the actuator. Remove all rust then polish. Replacement parts may be needed. |
| | f. Swollen seals and composite bearings caused by incompatible hydraulic fluid | f. Re-build the actuator. Use fluid that is compatible with seals and bearings. |
| 2. Operation is erratic or not responsive | a. Airinactuator | a. Purge air from actuator. See bleeding procedures. |
| 3. Shaft will not fully rotate | a. Twisted or chipped gear teeth | a. Check for gear binding. Actuator may not be able to be rebuilt and may need to be replaced. Damage could be a result of overload or shock. |
| | b. Port fittings are obstructing the piston | b. Check thread length of port fittings. Fittings should during stroke not reach inside the housing bore. |
| 4. Selected position cannot be maintained | a. Control or counterbalance valve has internal leak | a. Disconnect hydraulic lines and bypass valve. Leave valve ports open and operate the actuator through housing ports (do not exceed OEM's operating pressure). The valve must be replaced if a steady flow of fluid is seen coming from the valve ports. |
| | b. Piston and/or shaft seal leak | b. Remove the plug and the housing's valve ports. Operate the actuator through the housing ports. Conduct the internal leakage test as described in the Testing section on page 24 of this manual. |
| | c. Airin actuator | c. Purge air from actuator. See bleeding procedures |

4-58 3121139

4.13 LOAD SENSING DEVICE

Calibrating the Load Sensor

NOTE: Refer to Section 6 - JLG Control System.

- 1. Place the boom in the following position.
 - a. Boom Stowed
 - **b.** Telescope In
 - c. Jib 0 Degrees
 - d. Swing 0 Degrees
 - e. Basket Level 0 Degrees
 - f. Basket Rotate 0 Degrees
 - g. Weight in Basket 0
 - h. Machine parked on firm, level surface
- **2.** Activate both emergency stop switches and turn the key switch to the platform position.
- Remove all loads from the platform, including the operator.
- **4.** Turn P1 clockwise (in) until the potentiometer begins to click
- **5.** Plug the analyzer into the port in the platform.
- 6. Select Access Level from Main Menu.
- 7. Enter 33271.

- 8. Select Machine Set-Up>Load Cell>1 Warn Only.
- Select Machine Diagnostics>System Load Cell on the Analyzer.
- **10.** Adjust P2 until the Load = 0%.
- 11. Place 525 lbs. (238 kg) in the center of the basket.
- **12.** Adjust P1 until the Load = 100%
- **13.** Verify that the overload indicator lights continuously and the alarm sounds continuously during an overload condition.
- **14.** Remove the weight from the platform.
- **15.** Adjust P2 until the Load = 0%.
- 16. Place 525 lbs. (238 kg) in the center of the basket.
- 17. Adjust P1 until the Load = 100%
- 18. Remove the weight from the basket.
- **19.** Seal the potentiometers with fingernail polish.

3121139 4-59




Figure 4-26. Load Sensing Device

4-60 3121139

SECTION 5. BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

5.1 LUBRICATING O-RINGS IN THE HYDRAULIC SYSTEM

When assembling connectors in the hydraulic that use o-ring fittings, it is necessary to lubricate all fittings with hydraulic oil prior to assembly. To lubricate the fittings, use one of the following procedures.

NOTE: All o-ring fittings must be pre-lubricated with hydraulic oil prior to assembly.

Cup and Brush

The following is needed to correctly oil the o-ring in this manner:

- · A small container for hydraulic oil
- · Small paint brush



1. Hold the fitting in one hand while using the brush with the other hand to dip into the container. Remove excess hydraulic oil from the brush so an even film of oil is applied on the o-ring.



2. Holding the fitting over the hydraulic oil container, brush an even film of oil around the entire o-ring in the fitting, making sure the entire o-ring is completely saturated.



3. Turn the o-ring on the other side of the fitting and repeat the previous step, ensuring the entire o-ring is coated with hydraulic oil.



Dip Method

NOTE: This method works best with Face Seal o-rings, but will work for all o-ring fitting types.

The following is needed to correctly oil the o-ring in this manner:

- · A small leak proof container
- · Sponge cut to fit inside the container
- A small amount of hydraulic oil to saturate the sponge.
- 1. Place the sponge inside the container and add hydraulic oil to the sponge until it is fully saturated.
- **2.** Dip the fitting into the sponge using firm pressure. Upon lifting the fitting, a small droplet will form and drip from the bottom of the fitting. This should signify an even coating of oil on the fitting.



3. O-ring Boss type fittings will require more pressure in able to immerse more of the fitting into the saturated sponge. This will also cause more oil to be dispersed from the sponge.



Spray Method

This method requires a pump or trigger spray bottle.

- 1. Fill the spray bottle with hydraulic oil.
- 2. Hold the fitting over a suitable catch can.
- Spray the entire o-ring surface with a medium coat of oil.



Brush-on Method

This method requires a sealed bottle brush.

- 1. Fill the bottle with hydraulic oil.
- **2.** Using slight pressure to the body of the spray bottle, invert the bottle so the brush end is in the downward position.
- **3.** Brush hydraulic oil on the entire o-ring, applying an even coat of oil.



5-2 3121139

5.2 CYLINDER REPAIR

Axle Lockout Cylinder

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

 Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

A WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

- Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
- **3.** Remove the counterbalance valves, plugs and bleeder valves from the cylinder port block. Discard o-rings.
- 4. Place the cylinder barrel into a suitable holding fixture.




Figure 5-1. Cylinder Barrel Support

Mark cylinder head and barrel with a center punch for easy realignment. Using an allen wrench, loosen the eight cylinder head retainer capscrews, and remove capscrews from cylinder barrel.




Figure 5-2. Capscrew Removal

6. Attach a suitable pulling device to the cylinder rod port block end or cylinder rod end, as applicable.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

7. With the barrel clamped securely, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.





Figure 5-3. Cylinder Rod Support

- **8.** Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
- **9.** Loosen and remove nut which attaches the piston to the rod, and remove the piston.



- 1. Barrel
- 2. Rod
- 3. Piston
- 4. Head
- 6. Bolt

- 5. Bushing
- 7. Counterbalance Valve
- 8. Bushing
- 9. Plug
- 10. Bleeder Valve
- 11. Wiper Seal
- 12. Rod Seal
- 13. 0-ring
 - 14. Backup Ring
 - 15. Wear Ring
 - 16. Wear Ring
 - 17. T-Seal
 - 18. 0-ring
- 19. Backup Ring
- 20. Washer Ring
- 21. Bolt
- 22. Bushing

Figure 5-4. Axle Lockout Cylinder

5-4 3121139

- **10.** Insert the capscrews in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the capscrews until the bushing is loose on the piston.
- 11. Remove the bushing from the piston.




Figure 5-5. Tapered Bushing Removal

- **12.** With the barrel clamped securely, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.
- **13.** Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
- **14.** Loosen and remove nut which attaches the piston to the rod, and remove the piston.
- **15.** Insert the capscrews in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the capscrews until the bushing is loose on the piston.
- **16.** Remove the bushing from the piston.
- **17.** Screw the piston by hand, and remove the piston from cylinder rod.
- **18.** Remove and discard the piston o-rings, seal rings, wear rings and backup rings.
- **19.** Remove the rod from the holding fixture. Remove the cylinder head gland. Discard the o-rings, backup rings, rod seals, wear rings and wiper seals.

Cleaning and Inspection

- Clean all parts thoroughly in an approved cleaning solvent.
- **2.** Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
- Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
- **4.** Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
- **5.** Inspect threaded portion of barrel for damage. Dress threads as necessary.
- **6.** Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
- Inspect threaded portion of piston for damage. Dress threads as necessary.
- **8.** Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
- **9.** Inspect cylinder head inside diameter for scoring or other damage and for ovality and tapering. Replace as necessary.
- **10.** Inspect threaded portion of head for damage. Dress threads as necessary.
- **11.** Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
- **12.** Inspect cylinder head outside diameter for scoring or other damage, ovality and tapering. Replace as necessary.
- **13.** If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - **a.** Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - **b.** Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - **c.** Lubricate inside of the steel bushing with WD40 prior to bearing installation.
 - **d.** Using an arbor of the correct size, carefully press the bearing into steel bushing.

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-6. Composite Bearing Installation

- **14.** If applicable, inspect port block fittings and holding valve. Replace as necessary.
- **15.** Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
- **16.** If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

Assembly

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

 A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-7. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-8. Cylinder Head Seal Installation

5-6 3121139

2. Use a soft mallet to tap a new wiper seal into the applicable cylinder head gland groove. Install a new wear ring into the applicable cylinder head gland groove.




Figure 5-9. Wiper Seal Installation

3. Place a new o-ring and backup ring in the applicable outside diameter groove of the cylinder head.




Figure 5-10. Installation of Head Seal Kit

- **4.** Install washer ring onto rod, carefully install the head gland on the rod, ensuring that the wiper and rod seals are not damaged or dislodged. Push the head along the rod to the rod end, as applicable.
- Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible.
- **6.** Place a new o-ring and backup rings in the inner piston diameter groove.
- 7. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible
- Carefully thread the piston on the cylinder rod hand tight, ensuring that the o-ring and backup rings are not damaged or dislodged.

NOTE: When installing the tapered bushing, piston and mating end of rod must be free of oil.

9. Install the bolts in tapered bushing.

10. Assemble the tapered bushing loosely into the piston and insert capscrews through the drilled holes in the bushing and into the tapped holes in the piston.




Figure 5-11. Tapered Bushing Installation

- **11.** Tighten the capscrews evenly and progressively in rotation to 9 ft.lbs. (12 Nm).
- **12.** After the screws have been torqued, tap the tapered bushing with a hammer (16 to 24 oz.) and brass shaft (approximately 3/4" in diameter) as follows:
 - a. Place the shaft against the cylinder rod and in contact with the bushing in the spaces between the capscrews.
 - **b.** Tap each space once; this means the tapered bushing is tapped 3 times as there are 3 spaces between the capscrews.




Figure 5-12. Seating the Tapered Bushing

- **13.** Rotate the capscrews evenly and progressively in rotation to 9 ft.lbs. (12 Nm).
- **14.** Remove the cylinder rod from the holding fixture.
- **15.** Place seals in the applicable outside diameter grooves of the cylinder piston. (See Figure 5-13., Piston Seal Kit Installation).

16. Place new seals in the outer piston diameter groove. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the solid seal).




Figure 5-13. Piston Seal Kit Installation

17. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

18. With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading o-ring and seal ring are not damaged or dislodged.

19. Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.




Figure 5-14. Rod Assembly Installation

- **20.** Apply JLG Threadlocker P/N 0100011 to the socket head bolts and secure the cylinder head gland using the washer ring and bolts. Torque bolts to 65 ft.lbs. (90 Nm).
- **21.** After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any holding valve or valves.
- **22.** If applicable, install the cartridge-type holding valve and fittings in the rod port block, using new o-rings as applicable.

5-8 3121139

Jib Lift Cylinder (860SJ Only)

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

A WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

- Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
- **3.** Remove the counterbalance holding valve and plugs from the cylinder port block. Discard o-rings.
- 4. Place the cylinder barrel into a suitable holding fixture.




Figure 5-15. Cylinder Barrel Support

5. Mark cylinder head and barrel with a center punch for easy realignment. Using an allen wrench, loosen the cylinder head retainer capscrews, and remove capscrews from cylinder barrel.




Figure 5-16. Capscrew Removal

6. Attach a suitable pulling device to the cylinder rod port block end or cylinder rod end, as applicable.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

7. With the barrel clamped securely, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.





Figure 5-17. Cylinder Rod Support



1. Barrel Head 3. **Washer Ring**

4. Bolt 5. Rod

Counterbalance Valve

7. Plug

Plug Capscrew

10. Piston 11. Tapered Bushing

12. Spacer Tube

13. Lock Ring

14. Piston Seal 15. 0-ring 16. Backup ring

17. 0-ring 18. Backup Ring 19. Rod Seal

20. Wiper Seal 21. Wear Ring

22. Bushing

23. Bushing

Figure 5-18. Jib Lift Cylinder (860SJ Only)

5-10 3121139

- **8.** Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
- **9.** Insert the capscrews in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the capscrews until the bushing is loose on the piston.
- **10.** Remove the bushing from the piston.




Figure 5-19. Tapered Bushing Removal

- **11.** Screw the piston counterclockwise, by hand, and remove the piston from cylinder rod.
- **12.** Remove and discard the piston o-rings, seal rings, and backup rings.
- **13.** Remove piston spacer, if applicable, from the rod.
- **14.** Remove the rod from the holding fixture. Remove the cylinder head gland. Discard the o-rings, backup rings, rod seals, wear rings and wiper seals.

CLEANING AND INSPECTION

- Clean all parts thoroughly in an approved cleaning solvent.
- Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
- **3.** Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
- Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
- Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
- **6.** Inspect threaded portion of piston for damage. Dress threads as necessary.
- Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
- **8.** Inspect cylinder head inside diameter for scoring or other damage and for ovality and tapering. Replace as necessary.
- **9.** Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
- Inspect cylinder head outside diameter for scoring or other damage and ovality and tapering. Replace as necessary.
- If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - **a.** Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - Lubricate inside of steel bushing prior to bearing installation.
 - **d.** Using an arbor of the correct size, carefully press the bearing into steel bushing.

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-20. Composite Bearing Installation

- **12.** If applicable, inspect port block fittings and holding valve. Replace as necessary.
- **13.** Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
- **14.** If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-21. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-22. Cylinder Head Seal Installation

5-12 3121139

2. Use a soft mallet to tap a new wiper seal into the applicable cylinder head gland groove. Install a new wear ring into the applicable cylinder head gland groove.




Figure 5-23. Wiper Seal Installation

3. Place a new o-ring and backup ring in the applicable outside diameter groove of the cylinder head.




Figure 5-24. Installation of Head Seal Kit

- **4.** Install washer ring onto rod, carefully install the head gland on the rod, ensuring that the wiper and rod seals are not damaged or dislodged. Push the head along the rod to the rod end, as applicable.
- **5.** Carefully slide the piston spacer on the rod.
- **6.** Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible.
- **7.** Place a new o-ring and backup rings in the inner piston diameter groove.
- **8.** Carefully thread the piston on the cylinder rod hand tight, ensuring that the o-ring and backup rings are not damaged or dislodged.
- **9.** Thread piston onto rod end and install the tapered bushing.

NOTE: When installing the tapered bushing, piston and mating end of rod must be free of oil.

- 10. Install the bolts in tapered bushing.
- **11.** Assemble the tapered bushing loosely into the piston and insert capscrews through the drilled holes in the bushing and into the tapped holes in the piston.




Figure 5-25. Tapered Bushing Installation

- **12.** Tighten the capscrews evenly and progressively in rotation to 5 ft.lbs. (7 Nm).
- **13.** After the screws have been torqued, tap the tapered bushing with a hammer (16 to 24 oz.) and brass shaft (approximately 3/4" in diameter) as follows:
 - a. Place the shaft against the cylinder rod and in contact with the bushing in the spaces between the capscrews.
 - **b.** Tap each space once; this means the tapered bushing is tapped 3 times as there are 3 spaces between the capscrews.




Figure 5-26. Seating the Tapered Bearing

- **14.** Rotate the capscrews evenly and progressively in rotation to 5 ft.lbs. (7 Nm).
- 15. Remove the cylinder rod from the holding fixture.

NOTICE

WHEN INSTALLING HYDROLOCK PISTON SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. REFER TO HYDROLOCKK PISTON SEAL INSTALLATION FOR CORRECT SEAL ORIENTATION. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-27. Hydrolock Piston Seal Installation

16. Place new hydrolock seal and guidelock rings in the outer piston diameter groove. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the solid seal).




Figure 5-28. Piston Seal Kit Installation

17. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

- **18.** With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading o-ring and seal ring are not damaged or dislodged.
- 19. Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.




Figure 5-29. Rod Assembly Installation

- **20.** Apply JLG Threadlocker P/N 0100011 to the socket head bolts and secure the cylinder head gland using the washer ring and bolts. Torque bolts to 20 ft.lbs. (27 Nm).
- **21.** After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any holding valve or valves.
- **22.** If applicable, install the cartridge-type holding valve and fittings in the rod port block, using new o-rings as applicable. Torque valves to 50-55 ft.lbs. (68-75 Nm).

5-14 3121139

Main Boom Lift Cylinder

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

- Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
- **3.** Remove the proportional valve, lift holding valve, relief valve, check valve, and plugs. Discard o-rings.
- 4. Place the cylinder barrel into a suitable holding fixture.




Figure 5-30. Cylinder Barrel Support

5. Mark cylinder head and barrel with a center punch for easy realignment. Using an allen wrench, loosen the cylinder head retainer capscrews, and remove capscrews from cylinder barrel.




Figure 5-31. Capscrew Removal

6. Attach a suitable pulling device to the cylinder rod port block end or cylinder rod end, as applicable.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

With the barrel clamped securely, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.





Figure 5-32. Cylinder Rod Support



1. Flatwasher 8. Rod 15. Wear Ring 22. Guidelock Ring 29. Relief Valve 2. Clamp 9. Plug 16. Rod Seal 23. Setscrew 30. Bolt 3. Bolt 10. Plug 17. Wiper Seal 24. Capscrew 31. Locknut 11. Plug 18. 0-ring Tapered Bushing 25. Spacer 32. Plate 5. Bushing 12. Piston 19. Backup ring 26. Check Valve 33. Check Valve 6. Head 13. 0-ring 20. Guidelock Ring 27. Lift Dump Proportional Solenoid Barrel 14. Backup Ring 28. Lift Holding Solenoid 7. 21. Seal

Figure 5-33. Main Boom Lift Cylinder

5-16 3121139

- **8.** Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
- **9.** Insert the capscrews in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the capscrews until the bushing is loosen on the piston.
- **10.** Remove the bushing from the piston.




Figure 5-34. Tapered Bushing Removal

- **11.** Screw the piston counterclockwise, by hand, and remove the piston from cylinder rod.
- Remove and discard the piston o-rings, seal rings, wear rings and backup rings.
- 13. Remove setscrew and piston spacer from the rod.
- **14.** Remove the rod from the holding fixture. Remove the cylinder head gland. Discard the o-rings, backup rings, rod seals, wear rings and wiper seals.

CLEANING AND INSPECTION

- Clean all parts thoroughly in an approved cleaning solvent.
- 2. Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
- **3.** Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
- Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
- Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
- **6.** Inspect threaded portion of piston for damage. Dress threads as necessary.
- **7.** Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
- **8.** Inspect cylinder head inside diameter for scoring or other damage and for ovality and tapering. Replace as necessary.
- Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
- Inspect cylinder head outside diameter for scoring or other damage and ovality and tapering. Replace as necessary.
- If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - **a.** Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - **b.** Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - Lubricate inside of steel bushing prior to bearing installation.
 - **d.** Using an arbor of the correct size, carefully press the bearing into steel bushing.

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-35. Composite Bearing Installation

- **12.** If applicable, inspect port block fittings and holding valve. Replace as necessary.
- **13.** Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
- **14.** If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-36. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-37. Cylinder Head Seal Installation

5-18 3121139

2. Use a soft mallet to tap a new wiper seal into the applicable cylinder head gland groove. Install a new wear ring into the applicable cylinder head gland groove.




Figure 5-38. Wiper Seal Installation

3. Place a new o-ring and backup ring in the applicable outside diameter groove of the cylinder head.




Figure 5-39. Installation of Head Seal Kit

- **4.** Install the head gland on the rod, ensuring that the wiper and rod seals are not damaged or dislodged. Push the head along the rod to the rod end, as applicable.
- **5.** Carefully slide the piston spacer on the rod and tighten the setscrew.
- 6. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible
- **7.** Place a new o-ring and backup rings in the inner piston diameter groove.
- Carefully thread the piston on the cylinder rod hand tight, ensuring that the o-ring and backup rings are not damaged or dislodged.
- **9.** Thread piston onto rod hand tight and install the tapered bushing.

NOTE: When installing the tapered bushing, piston and mating end of rod must be free of oil.

10. Assemble the tapered bushing loosely into the piston and insert capscrews through the drilled holes in the bushing and into the tapped holes in the piston.




Figure 5-40. Tapered Bushing Installation

- **11.** Tighten the capscrews evenly and progressively in rotation to 30 ft.lbs. (41 Nm).
- **12.** After the screws have been torqued, tap the tapered bushing with a hammer (16 to 24 oz.) and brass shaft (approximately 3/4" in diameter) as follows:
 - a. Place the shaft against the cylinder rod and in contact with the bushing in the spaces between the capscrews.
 - **b.** Tap each space once; this means the tapered bushing is tapped 3 times as there are 3 spaces between the capscrews.




Figure 5-41. Seating the Tapered Bearing

- **13.** Rotate the capscrews evenly and progressively in rotation to 30 ft.lbs. (41 Nm).
- 14. Remove the cylinder rod from the holding fixture.

NOTICE

WHEN INSTALLING HYDROLOCK PISTON SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. REFER TO HYDROLOCKK PISTON SEAL INSTALLATION FOR CORRECT SEAL ORIENTATION. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-42. Hydrolock Piston Seal Installation

15. Place new seal and wear rings in the outer piston diameter groove. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the solid seal).




Figure 5-43. Piston Seal Kit Installation

16. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

- 17. With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading o-ring and seal ring are not damaged or dislodged.
- **18.** Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.




Figure 5-44. Rod Assembly Installation

- **19.** Apply JLG Threadlocker P/N 0100011 to the socket head bolts and secure the cylinder head gland using the bolts. Torque bolts to 300 ft.lbs. (407 Nm).
- **20.** After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any holding valve or valves.
- **21.** Install the proportional valve, lift holding valve, relief valve, check valve and plugs, using new o-rings as applicable. Torque valves to 30-37 ft. lbs. (41-50 Nm).

5-20 3121139

Platform Level Cylinder

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

 Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

▲ WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

- Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
- **3.** Remove the cartridge valve and fittings from the cylinder port block. Discard o-rings.
- 4. Place the cylinder barrel into a suitable holding fixture.




Figure 5-45. Cylinder Barrel Support

5. Mark cylinder head and barrel with a center punch for easy realignment. Using an allen wrench, loosen the cylinder head retainer capscrews, and remove capscrews from cylinder barrel.




Figure 5-46. Capscrew Removal

6. Attach a suitable pulling device to the cylinder rod port block end or cylinder rod end, as applicable.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

7. With the barrel clamped securely, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.





Figure 5-47. Cylinder Rod Support



- 1. Capscrew
- Tapered Bushing
- 3. Bushing
- 4. Head
- 5. Rod
- Barrel 6.
- Plug 7.
- Plug 8.
- Piston
- 10. Backup Ring
- - 12. Wear Ring
 - 13. Backup Ring
 - 14. 0-ring
 - 15. 0-ring
- 16. Rod Seal
- 17. Wiper Seal
- 18. Seal
- 19. Washer Ring
- 20. Capscrew
- 21. Spacer
- 22. Cartridge Valve
- 23. Cartridge Valve

Figure 5-48. Platform Level Cylinder

5-22 3121139

- **8.** Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
- **9.** Insert the capscrews in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the capscrews until the bushing is loosen on the piston.
- **10.** Remove the bushing from the piston.




Figure 5-49. Tapered Bushing Removal

- **11.** Screw the piston counterclockwise, by hand, and remove the piston from cylinder rod.
- **12.** Remove and discard the piston o-rings, seal rings, lock rings and backup rings.
- **13.** Remove piston spacer from the rod.
- 14. Remove the rod from the holding fixture. Remove the cylinder head gland. Discard the o-rings, backup rings, rod seals, wear rings and wiper seals.

CLEANING AND INSPECTION

- Clean all parts thoroughly in an approved cleaning solvent.
- Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
- **3.** Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
- **4.** Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
- Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
- **6.** Inspect threaded portion of piston for damage. Dress threads as necessary.
- Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
- **8.** Inspect cylinder head inside diameter for scoring or other damage and for ovality and tapering. Replace as necessary.
- **9.** Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
- Inspect cylinder head outside diameter for scoring or other damage and ovality and tapering. Replace as necessary.
- If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - **a.** Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - Lubricate inside of steel bushing prior to bearing installation.
 - **d.** Using an arbor of the correct size, carefully press the bearing into steel bushing.

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-50. Composite Bearing Installation

- **12.** If applicable, inspect port block fittings and holding valve. Replace as necessary.
- **13.** Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
- **14.** If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-51. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-52. Cylinder Head Seal Installation

5-24 3121139

2. Use a soft mallet to tap a new wiper seal into the applicable cylinder head gland groove. Install a new wear ring into the applicable cylinder head gland groove.




Figure 5-53. Wiper Seal Installation

3. Place a new o-ring and backup ring in the applicable outside diameter groove of the cylinder head.




Figure 5-54. Installation of Head Seal Kit

- **4.** Install washer ring onto rod, carefully install the head gland on the rod, ensuring that the wiper and rod seals are not damaged or dislodged. Push the head along the rod to the rod end, as applicable.
- 5. Carefully slide the piston spacer on the rod.
- 6. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible
- **7.** Place a new o-ring and backup rings in the inner piston diameter groove.
- **8.** Carefully thread the piston on the cylinder rod hand tight, ensuring that the o-ring and backup rings are not damaged or dislodged.
- 9. Thread piston onto rod and install the tapered bushing.

NOTE: When installing the tapered bushing, piston and mating end of rod must be free of oil.

10. Assemble the tapered bushing loosely into the piston and insert capscrews through the drilled holes in the bushing and into the tapped holes in the piston.




Figure 5-55. Tapered Bushing Installation

- **11.** Tighten the capscrews evenly and progressively in rotation to 9 ft.lbs (12 Nm).
- **12.** After the screws have been torqued, tap the tapered bushing with a hammer (16 to 24 oz.) and brass shaft (approximately 3/4" in diameter) as follows:
 - a. Place the shaft against the cylinder rod and in contact with the bushing in the spaces between the capscrews.
 - **b.** Tap each space once; this means the tapered bushing is tapped 3 times as there are 3 spaces between the capscrews.




Figure 5-56. Seating the Tapered Bearing

- **13.** Rotate the capscrews evenly and progressively in rotation to 9 ft.lbs (81 Nm).
- 14. Remove the cylinder rod from the holding fixture.

NOTICE

WHEN INSTALLING HYDROLOCK PISTON SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. REFER TO HYDROLOCKK PISTON SEAL INSTALLATION FOR CORRECT SEAL ORIENTATION. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-57. Hydrolock Piston Seal Installation

15. Place new hydrolock seal and guidelock rings in the outer piston diameter groove. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the solid seal).




Figure 5-58. Piston Seal Kit Installation

16. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

- 17. With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading o-ring and seal ring are not damaged or dislodged.
- **18.** Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.




Figure 5-59. Rod Assembly Installation

- **19.** Apply JLG Threadlocker P/N 0100011 to the socket head bolts and secure the cylinder head gland using the washer ring and bolts. Torque bolts to 35 ft.lbs. (50 Nm).
- **20.** After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any holding valve or valves.
- **21.** If applicable, install the cartridge-type holding valve and fittings in the rod port block, using new o-rings as applicable. Torque valves to 50-55 ft.lbs. (68-75 Nm).

5-26 3121139

Steer Cylinder (Prior to SN 0300142665)

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

▲ WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

- **2.** Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
- 3. Place the cylinder barrel into a suitable holding fixture.




Figure 5-60. Cylinder Barrel Support

4. Using a hook spanner, loosen the spanner nut retainer, and remove spanner nut from cylinder barrel.




Figure 5-61. Spanner Nut Support

5. Attach a suitable pulling device to the cylinder rod port block end or cylinder rod end, as applicable.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

6. With the barrel clamped securely, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.





Figure 5-62. Cylinder Rod Support



1. Locknut

6. Rod

11. Rod Seal

- 2. Piston 3. Seal
- 7. Head
- 12. Spanner Nut

- 4. 0-ring
- 8. 0-ring
- 13. Wiper Seal

- 5.
- 9. Backup Ring
- 14. Bushing
- Barrel 10. Retainer Ring

Figure 5-63. Steer Cylinder (Prior to SN 0300142665)

5-28 3121139

- **7.** Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
- **8.** Loosen and remove nut which attaches the piston to the rod.
- **9.** Screw the piston counterclockwise, by hand, and remove the piston from cylinder rod.
- **10.** Remove and discard the piston o-rings, seal rings, and backup rings.
- Remove the rod from the holding fixture. Remove the cylinder head gland. Discard the o-rings, backup rings, rod seals, retainer ring and wiper seals.

CLEANING AND INSPECTION

- Clean all parts thoroughly in an approved cleaning solvent.
- Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
- **3.** Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
- **4.** Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
- Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
- **6.** Inspect threaded portion of piston for damage. Dress threads as necessary.
- Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
- **8.** Inspect cylinder head inside diameter for scoring or other damage and for ovality and tapering. Replace as necessary.
- **9.** Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
- Inspect cylinder head outside diameter for scoring or other damage and ovality and tapering. Replace as necessary.
- If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - **a.** Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - **c.** Lubricate inside of steel bushing with WD40 prior to bearing installation.
 - **d.** Using an arbor of the correct size, carefully press the bearing into steel bushing.

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-64. Composite Bearing Installation

- **12.** If applicable, inspect port block fittings and holding valve. Replace as necessary.
- **13.** Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
- **14.** If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-65. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-66. Cylinder Head Seal Installation

5-30 3121139

2. Use a soft mallet to tap a new wiper seal into the applicable cylinder head gland groove. Install a new wear ring into the applicable cylinder head gland groove.




Figure 5-67. Wiper Seal Installation

Place a new o-ring, backup seal and retainer ring in the applicable outside diameter groove of the cylinder head.




Figure 5-68. Installation of Head Seal Kit

- **4.** Install washer ring onto rod, carefully install the head gland on the rod, ensuring that the wiper and rod seals are not damaged or dislodged. Push the head along the rod to the rod end, as applicable.
- Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible
- Carefully thread the piston on the cylinder rod hand tight, ensuring that the o-ring and backup rings are not damaged or dislodged.
- **7.** Remove the cylinder rod from the holding fixture.
- **8.** Place a new o-ring in the inner piston diameter groove. (See Figure 5-69.)
- Place new seals in the outer piston diameter groove. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the solid seal). (See Figure 5-69.).




Figure 5-69. Piston Seal Kit Installation

10. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

- 11. With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading o-ring and seal ring are not damaged or dislodged.
- **12.** Secure Piston to the rod using nut.
- Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.
- **14.** Secure the cylinder head gland using the spanner nut.
- **15.** After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any holding valve or valves.

NOTE: *Steer cylinder spanner nut is tightened as per Spec. "CYR" Cylinder spanner nut tightening procedure. Pressurize cylinder on retract to 80/100 psi to push rod guide firmly against the round retaining ring. (Apply 1 drop of JLG Threadlocker P/N 0100011, 2 places, at 180° apart. Hand tighten nut, then tighten 1/4 turn with spanner wrench).

Steer Cylinder (SN 0300014266 through 0300182743, SN B300000100 through B300001091)

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

 Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

▲ WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

- Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
- 3. Place the cylinder barrel into a suitable holding fixture.




Figure 5-70. Cylinder Barrel Support




Figure 5-71. Spanner Nut Removal

- Using a hook Spanner, loosen the spanner nut retainer, and remove spanner nut from cylinder barrel.
- **5.** Attach a suitable pulling device to the cylinder rod port block end or cylinder rod end, as applicable.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

6. With the barrel clamped securely, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.





Figure 5-72. Cylinder Rod Support

5-32 3121139



- 1. Piston
- 2. Seal 3. Seal
- 4. Setscrew
- 5. Rod
- Barrel
- 7. Head
- 0-ring
- 9. Backup Ring
- 10. Retainer Ring
- 11. Spanner Nut
- 12. Seal
- 13. Wiper
- 14. Bushing

Figure 5-73. Steer Cylinder (SN 0300014266 through 0300182743, SN B300000100 through B300001091)

3121139 5-33

- Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
- **8.** Loosen and remove setscrew which attaches the piston to the rod.
- **9.** Screw the piston counterclockwise, by hand, and remove the piston from cylinder rod.
- 10. Remove and discard the piston o-rings, seal rings.
- Remove the rod from the holding fixture. Remove the cylinder head gland. Discard the o-rings, backup rings, rod seals, retainer ring and wiper seals.

CLEANING AND INSPECTION

- Clean all parts thoroughly in an approved cleaning solvent.
- Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
- Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
- **4.** Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
- Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
- **6.** Inspect threaded portion of piston for damage. Dress threads as necessary.
- Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
- Inspect cylinder head inside diameter for scoring or other damage and for ovality and tapering. Replace as necessary.
- **9.** Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
- Inspect cylinder head outside diameter for scoring or other damage and ovality and tapering. Replace as necessary.
- If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - **a.** Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - Lubricate inside of steel bushing with WD40 prior to bearing installation.
 - **d.** Using an arbor of the correct size, carefully press the bearing into steel bushing.

5-34 3121139

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-74. Composite Bearing Installation

- **12.** If applicable, inspect port block fittings and holding valve. Replace as necessary.
- **13.** Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
- **14.** If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-75. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-76. Cylinder Head Seal Installation

Use a soft mallet to tap a new wiper seal into the applicable cylinder head gland groove. Install a new wear ring into the applicable cylinder head gland groove.




Figure 5-77. Wiper Seal Installation

3. Place a new o-ring and backup seal in the applicable outside diameter groove of the cylinder head.




Figure 5-78. Installation of Head Seal Kit

- 4. Install washer ring onto rod, carefully install the head gland on the rod, ensuring that the wiper and rod seals are not damaged or dislodged. Push the head along the rod to the rod end, as applicable.
- Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible.
- **6.** Carefully thread the piston on the cylinder rod hand tight, ensuring that the o-ring and backup rings are not damaged or dislodged.
- 7. Remove the cylinder rod from the holding fixture.
- Place a new o-ring in the inner piston diameter groove. (See Figure 5-79.)
- Place new seals in the outer piston diameter groove. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the solid seal). (See Figure 5-79.).




Figure 5-79. Piston Seal Kit Installation (Prior to SN 0300142664)

10. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

- **11.** With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading o-ring and seal ring are not damaged or dislodged.
- 12. Secure Piston to the rod using nut.
- **13.** Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.
- 14. Secure the cylinder head gland using the spanner nut. Torque bolts to 275-300 ft.lbs (373- 407 Nm).
- **15.** After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any holding valve or valves.

NOTE: *Steer cylinder spanner nut is tightened as per Spec. "CYR" Cylinder spanner nut tightening procedure. Pressurize cylinder on retract to 80/100 psi to push rod guide firmly against the round retaining ring. (Apply 1 drop of JLG Threadlocker P/N 0100011, 2 places, at 180° apart. Hand tighten nut, then tighten 1/4 turn with spanner wrench).

5-36 3121139

Telescope Cylinder

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

- Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
- **3.** If applicable, remove the cartridge-type holding valve and fittings from the cylinder port block. Discard orings.
- **4.** Place the cylinder barrel into a suitable holding fixture.




Figure 5-80. Cylinder Barrel Support

5. Mark cylinder head and barrel with a center punch for easy realignment. Using an allen wrench, loosen the cylinder head retainer capscrews, and remove capscrews from cylinder barrel.




Figure 5-81. Capscrew Removal

6. Attach a suitable pulling device to the cylinder rod port block end or cylinder rod end, as applicable.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

7. With the barrel clamped securely, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.





Figure 5-82. Cylinder Rod Support



- 1. Bolt
- **Tapered Bushing** 2.
- 3. Head
- 4. Barrel
- 5. Rod
- Wear Ring

- WearRing 9.
- 10. 0-ring
- 11. 0-ring
- 12. Rod Seal
- 7. Backup Ring
 - **Backup Ring** 14. T-Seal
 - 15. O-ring Plug

13. Wiper

- 16. 0-ring Plug
- 17. Piston
- 18. Washer Ring
- 19. Capscrew
- 20. Capscrew
- 21. Capscrew
- 22. Spacer
- 23. Valve assembly
- 24. 0-ring
- 25. Capscrew
- 26. Assembly Valve
- 27. Cartridge Seal Kit
- 28. Cartridge Seal Kit

Figure 5-83. Telescopic Cylinder

5-38 3121139

- **8.** Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
- **9.** Insert the capscrews in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the capscrews until the bushing is loosen on the piston.
- **10.** Remove the bushing from the piston.




Figure 5-84. Tapered Bushing Removal

- **11.** Screw the piston counterclockwise, by hand, and remove the piston from cylinder rod.
- **12.** Remove and discard the piston o-rings, seal rings, wear rings and backup rings.
- **13.** Remove setscrew from the piston spacer. Remove spacer from the rod.
- 14. Remove the rod from the holding fixture. Remove the cylinder head gland. Discard the o-rings, backup rings, rod seals, wear rings and wiper seals.

CLEANING AND INSPECTION

- Clean all parts thoroughly in an approved cleaning solvent.
- Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
- **3.** Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
- **4.** Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
- Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
- **6.** Inspect threaded portion of piston for damage. Dress threads as necessary.
- Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
- Inspect cylinder head inside diameter for scoring or other damage and for ovality and tapering. Replace as necessary.
- **9.** Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
- Inspect cylinder head outside diameter for scoring or other damage and ovality and tapering. Replace as necessary.
- If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - **a.** Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - Lubricate inside of steel bushing prior to bearing installation.
 - **d.** Using an arbor of the correct size, carefully press the bearing into steel bushing.

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-85. Composite Bearing Installation

- Inspect spacer for burrs and sharp edges. If necessary, dress inside diameter surface with Scotch Brite or equivalent.
- **13.** If applicable, inspect port block fittings and holding valve. Replace as necessary.
- **14.** Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
- **15.** If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-86. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-87. Cylinder Head Seal Installation

5-40 3121139

2. Use a soft mallet to tap a new wiper seal into the applicable cylinder head gland groove. Install a new wear ring into the applicable cylinder head gland groove.




Figure 5-88. Wiper Seal Installation

3. Place a new o-ring and backup ring in the applicable outside diameter groove of the cylinder head.




Figure 5-89. Installation of Head Seal Kit

- **4.** Install washer ring onto rod, carefully install the head gland on the rod, ensuring that the wiper and rod seals are not damaged or dislodged. Push the head along the rod to the rod end, as applicable.
- **5.** Carefully slide the piston spacer on the rod. Install capscrew on the spacer.
- 6. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible.
- **7.** Place a new o-ring and backup rings in the inner piston diameter groove.
- **8.** Carefully thread the piston on the cylinder rod hand tight, ensuring that the o-ring and backup rings are not damaged or dislodged.
- **9.** Thread piston onto rod until it abuts the spacer end and install the tapered bushing.

NOTE: When installing the tapered bushing, piston and mating end of rod must be free of oil.

10. Assemble the tapered bushing loosely into the piston and insert capscrews through the drilled holes in the bushing and into the tapped holes in the piston.




Figure 5-90. Tapered Bushing Installation

- **11.** Tighten the capscrews evenly and progressively in rotation to 9 ft.lbs. (12 Nm).
- **12.** After the screws have been torqued, tap the tapered bushing with a hammer (16 to 24 oz.) and brass shaft (approximately 3/4" in diameter) as follows:
 - a. Place the shaft against the cylinder rod and in contact with the bushing in the spaces between the capscrews.
 - **b.** Tap each space once; this means the tapered bushing is tapped 3 times as there are 3 spaces between the capscrews.




Figure 5-91. Seating the Tapered Bearing

- **13.** Rotate the capscrews evenly and progressively in rotation to 9 ft.lbs. (12 Nm).
- 14. Remove the cylinder rod from the holding fixture.
- **15.** Place new T-seal and wear rings in the outer piston diameter groove. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the solid seal).




Figure 5-92. Piston Seal Kit Installation

16. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

- 17. With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading o-ring and seal ring are not damaged or dislodged.
- 18. Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.





Figure 5-93. Rod Assembly Installation

- **19.** Apply JLG Threadlocker P/N 0100011 to the socket head bolts and secure the cylinder head gland using the washer ring and bolts. Torque bolts to 55 ft.lbs. (75 Nm).
- **20.** After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any holding valve or valves.
- **21.** Install the valve assembly. Torque capscrews to 9 ft.lbs. (12 Nm).

5-42 3121139



- 1. Main Valve
- 2. Platform Valve Filter
- 3. Dual Flow Divider (4WD)
- 4. Auxiliary Pump
- 5. Jib Valve
 - . Platform Valve
- 7. Hydraulic Filter
- 3. Dual Select Valve
- 9. Flow Divider (2WD)

Figure 5-94. Control Valve Installation

5.3 PRESSURE SETTING PROCEDURE

Cold temperatures have a significant impact on pressure readings. JLG Industries Inc. recommends operating the machine until the hydraulic system has warmed to normal operating temperatures prior to checking pressures. JLG Industries Inc. also recommends the use of a calibrated gauge. Pressure readings are acceptable if they are within $\pm\,5\%$ of specified pressures.


To ensure all pressures are set correctly, the following procedures must be followed in order.

- All applicable steps in Section 5.4, Start Up Procedures must be followed.
- 2. Set up of the function pump.
- 3. Adjustments made at the main valve block.
- 4. Adjustments made at the platform valve.

Set Up of the Function Pump


STAND BY PRESSURE OR LOAD SENSE PRESSURE

 Install a low pressure gauge at port "M1" of the main valve block. A low pressure gauge capable of reading 500 psi.




2. Start the engine from the ground control. The gauge should read between 400-440 psi (27.5 to 30 Bar). To make an adjustment to this pressure, go to the engine compartment, locate the function pump.

- **3.** There are (2) adjustments at the top of the pump. They are located on the pump compensator which has (4) bolts mounting it to the pump. The stand by adjustment is at the top. To adjust this, a 4 mm and 6 mm allen wrench will be needed. The adjustment screw is facing the front of the pump, or toward the engine.
 - **a.** First, using the 4 mm wrench, loosen the set screw on the side of the compensator (facing you) which is in line with the adjustment screw. This is a jam nut screw which holds the main adjustment from turning. Loosen it 1 turn.




b. Next, using the 6 mm wrench adjust the main adjustment clockwise to increase or counter-clockwise to decrease. The pressure should read between 400-440 psi (27.5 to 30 Bar).



5-44 3121139

HIGH PRESSURE RELIEF


 Install a high pressure gauge at the "M1" port of the main valve block.



- 2. Activate telescope in. The gauge should read 2800 psi.
- **3.** To make an adjustment to this pressure, go back to the engine compartment to the function pump. The high pressure relief adjustment is the lower one of the (2) on the compensator. To adjust this, a 4 mm and 6 mm allen wrench will be needed. The adjustment screw is facing the front of the pump, or toward the engine.
 - **a.** First, using the 4 mm wrench, loosen the set screw on the side of the compensator (facing you) which is in line with the adjustment screw. This is a jam nut screw which holds the main adjustment from turning. Loosen it 1 turn.



b. Next, using the 6 mm wrench adjust the main adjustment clockwise to increase or counter-clockwise to decrease. This adjustment will be re-set at the end of this procedure to 2500 psi (172 Bar). This is the <u>maximum</u> relief pressure for all functions governed by this pump.



Adjustments Made at the Main Valve Block

TELESCOPE OUT

- Install a high pressure gauge at the "M3" port of the main valve block.
- **2.** Activate Telescope out. The gauge should read 2500 psi (172 Bar).
- **3.** The relief valve is located directly below the M3 port. Turn clockwise to increase, counterclockwise to decrease.

SWING LEFT AND RIGHT

- 1. Lock the Turn-table lock pin.
- 2. Install the hi-pressure gauge at M2.
- **3.** Activate swing, the gauge should read 1700 psi (117 Bar).
- The adjustment cartridge is located right above the M2 port. Turn clockwise to increase, counterclockwise to decrease.

STEER

- 1. Install a hi-pressure gauge at port M4. Activate steer left or right. The gauge should read 2500 psi (172 Bar).
- **2.** The relief valve is located right above port M4. Turn clockwise to increase, counterclockwise to decrease.

Adjustments Made at the Platform Valve Assembly

NOTE: When replacing the level up or level down cartridge, the function should be cycled, and then the crack pressure value calibrated.

PLATFORM LEVEL UP

- 1. Install a high pressure gauge at port "M1". Activate level up to the end of stroke, you should read 2600 psi (179 Bar).
- The level up relief valve is located to the right and above port M1. Turn clockwise to increase, counterclockwise to decrease.

PLATFORM LEVEL DOWN

- 1. Install a high pressure gauge at gauge port "M2", Activate level down to the end of stroke, you should read 1800 psi (124 Bar).
- The level down relief valve is located to the right and below port M2. Turn clockwise to increase, counterclockwise to decrease.


PLATFORM JIB UP AND DOWN

- 1. Install a high pressure gauge at port M3. Activate jib up or down, you should read 1700 psi (117.2 Bar).
- **2.** The up relief valve is located above port M3. Turn clockwise to increase, counterclockwise to decrease.

PUMP HI-PRESSURE RELIEF VALVE

Go back to the function pump and reset the hi-pressure from 2800 psi (193 Bar) back to 2500 psi (172 Bar).


5-46 3121139



- 1. Check Valve
- 2. Pilot Valve Lift
- 3. Check Valve (100 psi 6.9 Bar)
- 4. Tele Out Relief
- 5. Lift Up Dump
- 6. Swing Relief

- 7. Steer Relief
- 8. Steer Flow Regulator (6 gpm 22.7 lpm
- 9. Load Sense Steer
- 10. Load Sense Swing
- 11. Check Valve (60 psi 4.1 Bar
- 12. Steer Control
- 13. Swing Control
- 14. Proportional Valve Tele
- 15. Main Dump
- 16. Telescope Control

Figure 5-95. Main Valve Identification



- 1. Level Down Relief
- 2. Level Up Relief
- 3. Flow Regulator (0.5 gpm 1.9 lpm)
- 4. Check Valve (25 psi 1.7 Bar)
- 5. Platform Level

- 6. Pressure
- 7. Rotator
- 8. Flow Regulator (2 gpm 7.6 lpm)
- 9. Flow Regulator (0.2 gpm 0.75 lpm)
- 10. Load Sense

- 11. Jib Relief
- 12. Jib Control
- 13. Flow Regulator (2 gpm 7.6 lpm)
- 14. Filter

Figure 5-96. Platform Valve Identification

5-48 3121139




Table 5-1. Cartridge Torque Values

| | Ft-Lbs. | Nm |
|----|---------|--------|
| 1 | 18-20 | 24-27 |
| 2 | 33-37 | 45-50 |
| 3 | 19-21 | 26-28 |
| 4 | 50-55 | 68-75 |
| 5 | 19-21 | 26-28 |
| 6 | 50-55 | 68-75 |
| 7 | 24-26 | 33-35 |
| 8 | 70-80 | 95-108 |
| 9 | 19-21 | 26-28 |
| 10 | 50-55 | 68-75 |
| 11 | 24-26 | 33-35 |

Table 5-2. Coil Torque Values

| | Ft-Lbs. | Nm |
|---|---------|-----|
| Α | 5-7 | 7-9 |
| В | 5-7 | 7-9 |
| C | 5-7 | 7-9 |

Figure 5-97. Main Valve Cartridge Torque Values




Table 5-3. Cartridge Torque Values

| | Ft-Lbs. | Nm |
|----|---------|----|
| 1 | 20 | 27 |
| 2 | 20 | 27 |
| 3 | 20 | 27 |
| 4 | 20 | 27 |
| 5 | 20 | 27 |
| 6 | 25 | 34 |
| 7 | 20 | 27 |
| 8 | 20 | 27 |
| 9 | 20 | 27 |
| 10 | 20 | 27 |

Table 5-3. Cartridge Torque Values

| | Ft-Lbs. | Nm |
|----|---------|----|
| 11 | 20 | 27 |
| 12 | 20 | 27 |

Table 5-4. Coil Torque Values

| | Ft-Lbs. | Nm |
|---|---------|---------|
| Α | 10-12 | 14-16.8 |
| В | 5 | 7 |
| C | 5 | 7 |

Figure 5-98. Platform Valve Cartridge Torque Values

5-50 3121139

5.4 START UP PROCEDURES

Start Up After Overhaul or Replacement of Components

PRE-FILL OF BOTH THE DRIVE AND FUNCTION PUMP

Machine without oil cooler: When filling the oil tank, fill it to the very top of the tank. This will give you enough head pressure from the tank to gravity fill the case on both pumps. The excess oil will be used to fill the cylinders during start up. The top case port on the outside of the drive pump has a ¾" tee fitting. Remove the cap from the end of the tee. You should see oil in 1-2 minutes, tighten up the cap. The drive pump case is done. Next, go the function pump, using a 3/8" allen wrench remove the plug on the inside of the pump next to the turntable side sheet. When oil flows out of the pump, 2-3 minutes, re-install the plug. Both pumps are pre-filled. Not doing this causes the pumps to start dry, and reduces the efficiency of the pump and can cause premature failure.

Machine with oil cooler: When filling the oil tank, fill it to the very top of the tank. This will help give you enough head pressure from the tank to gravity fill the case on both pumps. The top case port on the outside of the pump has a ¾" tee fitting. Remove the cap from the center of the tee. You should see oil in 1-2 minutes. If not, depending on hose routing, the drive pump may not gravity feed. Oil has to flow through the oil cooler to get to the pump. Hose up an external hand pump to this tee fitting, and give it about (6) pumps after it has started pumping oil. This should be sufficient. Install the cap back onto the tee fitting. The drive pump is done. Next, go the function pump, using a 3/8" allen wrench remove the plug on the inside of the pump next to the turn-table side sheet. When oil flows out of the pump, 2-3 minutes, re-install the plug. Both pumps are pre-filled. Not doing this causes the pumps to start dry, and reduces the efficiency of the pump and can cause premature failure.

PURGING OF THE FUNCTION PUMP SUCTION HOSE.

Large pockets of air get trapped in this line and must be removed at low pressure. Head pressure from the tank is not enough. Here are (3) methods of purging the air from the hose at low pressure.

- 1. At the main control valve, remove the ³/₄" hose from port "P1", remove the 1" hose from port "T". Using a 12-16 connector, connect them together. Start the machine and let it run for approx. 10 seconds. Shut off the machine, remove the 12-16 adapter and re-hose.
- 2. Remove the ¾" hose from port "P1" and hold it into a 5 gallon bucket and start the machine. The air should purge very quickly, (seconds). Shut off the machine and re-hose.
- 3. Remove the ¾" hose from port "P1", using a #12 male union add approx. 30" of ¾" hose to it. Remove the return filter cap at the top of the tank, lift out the ele-

ment making sure the canister stays in the tank. Hold the hose end down in the canister and start the machine and let it run approx. 10 seconds. Re-install the filter and re-hose the machine.

NOTE: **If using a shop vac to create suction on the oil tank while doing maintenance, both steps "1" and "2" will need done.

NOTE: **If installing a new drive pump, step "1" will need done.

NOTE: **If installing a new function pump, step "1" and "2" will need done.

NOTE: **If installing a new function pump and the suction hose is capped without draining a lot of oil out of the hose, which creates a large air void, step "2" will not need to be done.

NOTE: **When operating a function such as Lift Up, if the function pump makes a loud noise and the lift up stops and starts, that is a sign of cavitation, air going through the pump at high pressure. This will in a short time destroy the pump and contaminate the entire system. Make sure all suction hoses are tight and free of leaks at the tank and pump. A suction hose does not leak when the engine is running, it will allow air to be drawn into the pump causing cavitation. After the machine is shut down, then you will see a very slow leak.




Figure 5-99. Hydraulic Schematic - Sheet 1 of 8

5-52 3121139




Figure 5-100. Hydraulic Schematic - Sheet 2 of 8




Figure 5-101. Hydraulic Schematic - Sheet 3 of 8

5-54 3121139




Figure 5-102. Hydraulic Schematic - Sheet 4 of 8




Figure 5-103. Hydraulic Schematic - Sheet 5 of 8

5-56 3121139




Figure 5-104. Hydraulic Schematic - Sheet 6 of 8




Figure 5-105. Hydraulic Schematic - Sheet 7 of 8

5-58 3121139




Figure 5-106. Hydraulic Schematic - Sheet 8 of 8

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

| NOTES: | |
|--------|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | - |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | - <u>- </u> |
| | |
| | - |
| | |
| | |
| | |
| | |
| | |
| | |

5-60 3121139

SECTION 6. JLG CONTROL SYSTEM

6.1 JLG CONTROL SYSTEM ANALYZER KIT INSTRUCTIONS

Introduction

NOTICE

WHEN INSTALLING A NEW POWER MODULE CONTROLLER ON THE MACHINE, IT WILL BE NECESSARY TO PROGRAM THE CONTROLLER FOR THE PROPER MACHINE CONFIGURATION. INCLUDING OPTIONS.

NOTICE

IT IS A GOOD PRACTICE TO AVOID PRESSURE-WASHING ELECTRICAL/ELECTRONIC COMPONENTS. SHOULD PRESSURE-WASHING BE UTILIZED TO WASH AREAS CONTAINING ELECTRICAL/ELECTRONIC COMPONENTS, JLG INDUSTRIES, INC. RECOMMENDS A MAXIMUM PRESSURE OF 750 PSI (52 BAR) AT A MINIMUM DISTANCE OF 12 IN. (30.5 CM) AWAY FROM THESE COMPONENTS. IF ELECTRICAL/ELECTRONIC COMPONENTS ARE SPRAYED, SPRAYING MUST NOT BE DIRECT AND BE FOR BRIEF TIME PERIODS TO AVOID HEAVY SATURATION.

The JLG designed Control System is a 12 Volt based control unit installed on the boom lift.

The JLG Control System has reduced the need for exposed terminal strips, diodes and trimpots and provides simplicity in

viewing and adjusting the various personality settings for smooth control of: acceleration, deceleration, creep, min speed, and maximum speed for all boom, drive, and steering functions.

The main lift, swing, and drive are controlled by individual joysticks, with steering being controlled by a rocker switch built into the top the drive joystick. To activate Drive, Lift, and Swing simply pull up on the slide lock location on the joystick and move the handle into the direction desired.

The control system will control the voltage output to the valves and pump, as programmed for smooth operation and maximum cycle time. Ground control speeds for all boom functions can also be programmed into the control system.

The JLG Control System controller has a built in LED to indicate any faults. The system stores recent faults which may be accessed for troubleshooting. Optional equipment includes a soft touch system, head and tail lights, and ground alarm. These options may be added later but must be programmed into the control system when installed.

The Control System may be accessed utilizing a custom designed, hand held analyzer (Analyzer Kit, JLG part no. 2901443) which will display two lines of information at a time, by scrolling through the program.




Figure 6-1. Hand Held Analyzer

3121139 6-1

To Connect the JLG Control System Analyzer


- Connect one end of the cable, supplied with the analyzer, to the correct four pin connector on the motor control unit; there will be only one connector which correctly fits the cable.
- 2. Connect the other end of the cable to the analyzer.

NOTE: The ends of the cable are identical and can be reversed; the cable end can only be inserted one way into the matching connector.

3. Power up the vehicle by turning the key to the platform or ground position and pulling the emergency stop buttons on; this will power the "SMART System" and the analyzer.

Using the Analyzer

The analyzer will display the current top level menu item, for example::



MENU: DIAGNOSTICS

Press LEFT & RIGHT (g, e) to move between menu items; press ENTER to select the displayed menu item.

When a top level menu item is selected, a new set of menu

items may be offered; press **LEFT** & **RIGHT** arrows then **ENTER** again to select the required item.

To cancel a selected menu item, press **ESCAPE**; then a different menu item can be chosen.

The available menu items will vary depending on the vehicle; check the vehicle manual for more information.


6-2 3121139

Changing the Access Level of the Hand Held Analyzer


When the analyzer is first connected, its access level ensures that most configurations cannot be changed; this ensures that a setting cannot be accidentally altered.


To change the access level, a PASSWORD must be entered; the password must be known.

To enter a password, first find the appropriate top level menu item:



MENU: ACCESS LEVEL 3





When the correct password is displayed, press **ENTER** to confirm it; the access level will change to match the password

(If not, press **ENTER** to check and correct the password).

The correct passwords will vary depending on the vehicle; check the vehicle manual for more information.

3121139 6-3


Adjusting Configuration Using the Hand Held Analyzer

When a personality item is selected, press **UP**



Y

arrows to adjust its value, for example:



PERSONALITIES: DRIVE ACCEL 1.0s

There will be a maximum and minimum for the value to

ensure safe operation; the value will not increase if **UP** is pressed when at the maximum, or if DOWN is pressed when at the minimum.


If the value does not change when **UP** is pressed, check the access level.



Machine Setup

When a machine digit item is selected, press **UP**





GROUND ALARM: 2 = DRIVE

The effect of the machine digit value is displayed along with its value; there will only be certain settings allowed to ensure safe operation.

If the value does not change when **UP** or **DOWN** is pressed, check the access level.

The available personality and machine digit items will vary depending on the vehicle; check the vehicle manual for more information.


6-4 3121139

Level Vehicle Description

A NEW TILT MODULE WILL ACT AS IF IT IS TILTED ALL OF THE TIME UNTIL THE FOLLOWING PROCEDURE IS PERFORMED.

▲ WARNING

DO NOT CALIBRATE THE LEVEL SENSOR EXCEPT ON A LEVEL SURFACE.



Place machine in stowed position with the boom between the rear wheels.

To level machine chose:

CALIBRATION: TILT SENSOR

Press ENTER

When prompted, swing machine 180°



Table 6-1. Analyzer Abbreviations

| Table 6-1. Analyzer Abbreviations | | | | | |
|-----------------------------------|--------------------------------|--|--|--|--|
| ABBREVIATION | MEANING | | | | |
| ACCEL | ACCELERATE | | | | |
| ACT | ACTIVE | | | | |
| A/D | ANALOG DIGITAL CONVERTER COUNT | | | | |
| AMB. | AMBIENT | | | | |
| ANG | ANGLE | | | | |
| AUX | AUXILIARY | | | | |
| BCS | BOOM CONTROL SYSTEM | | | | |
| BM | BOOM LENGTH ANGLE MODULE | | | | |
| BLAM | BOOM LENGTH ANGLE MODULE | | | | |
| BR | BROKEN | | | | |
| BSK | BASKET | | | | |
| CAL | CALIBRATION | | | | |
| CL | CLOSED | | | | |
| CM | CHASSIS MODULE | | | | |
| CNTL | CONTROL | | | | |
| CNTRL | CONTROL | | | | |
| C/O | CUTOUT | | | | |
| CONT(S) | CONTRACTOR(S) | | | | |
| COOR | COORDINATED | | | | |
| CRKPT | CRACK POINT | | | | |
| CRP | CREEP | | | | |
| CUT | СИТОИТ | | | | |
| CYL | CYLINDER | | | | |
| DECEL | DECELERATE | | | | |
| D | DOWN | | | | |
| DN | DOWN | | | | |
| DWN | DOWN | | | | |
| DEG. | DEGREE | | | | |
| DOS | DRIVE ORIENTATION SYSTEM | | | | |
| DRV | DRIVE | | | | |
| E | ERROR | | | | |
| E&T | ELEVATED & TILTED | | | | |
| ELEV | ELEVATION | | | | |
| ENG | ENGINE | | | | |
| EXT | EXTEND | | | | |
| F | FRONT | | | | |
| FL | FLOW | | | | |
| FNT | FRONT | | | | |
| FOR | FORWARD | | | | |
| FWD | FORWARD | | | | |
| FSW | F00T SWITCH | | | | |
| FUNC | FUNCTION | | | | |
| | | | | | |

Table 6-1. Analyzer Abbreviations

| ABBREVIATION | MEANING |
|--------------|----------------------------|
| G | GROUND |
| GND | GROUND |
| GRN | GREEN |
| GM | GROUND MODULE |
| Н | HOURS |
| HW | HARDWARE |
| HWFS | HARDWARE FAILSAFE |
| 1 | IN or CURRENT |
| JOY | JOYSTICK |
| L | LEFT |
| LB | POUND |
| LEN | LENGTH |
| LIM | LIMIT |
| LT | LEFT |
| LVL | LEVEL |
| М | MINUTES |
| MIN | MINIMUM |
| MAX | MAXIMUM |
| М | MAIN |
| MN | MAIN |
| NO | NORMALLY OPEN or NO |
| NC | NORMALLY CLOSED |
| 0 | OUT |
| 0/C | OPEN CIRCUIT |
| OP | OPEN |
| O/R | OVERRIDE or OUTRIGGER |
| 0//R | OVERRIDE |
| OSC | OSCILLATING |
| OVRD | OVERRIDE |
| P | PLATFORM |
| P | PRESSURE |
| PCV | PROPORTIONAL CONTROL VALVE |
| PLAT | PLATFORM |
| PLT | PLATFORM |
| PM | PLATFORM MODULE |
| POT | POTENTIOMETER |
| PRES | PRESSURE |
| PRS | PRESSURE |
| PT | POINT |
| R | REAR or RIGHT |
| REV | REVERSE or REVISION |
| RET | RETRACT |
| ROT. | ROTATE |

Table 6-1. Analyzer Abbreviations

| luble o 1. Allulyzel Abbleviations | | | | | |
|------------------------------------|--------------------|--|--|--|--|
| ABBREVIATION | MEANING | | | | |
| RT | RIGHT | | | | |
| S/C | SHORT CIRCUIT | | | | |
| SEL | SELECTOR | | | | |
| SN | SERIAL NUMBER | | | | |
| SPD | SPEED | | | | |
| STOW | STOWED | | | | |
| STOWD | STOWED | | | | |
| SW | SWITCH or SOFTWARE | | | | |
| TELE | TELESCOPE | | | | |
| TEMP | TEMPERATURE | | | | |
| TORQ. | TORQUE | | | | |
| TRN | TRANSPORT | | | | |
| T/T | TURNTABLE | | | | |
| T | TOWER | | | | |
| TURNTBL | TURNTABLE | | | | |
| TWR | TOWER | | | | |
| U | UPPER or UP | | | | |
| V | VOLT | | | | |
| VER | VERSION | | | | |
| VLV | VALVE | | | | |
| WIT | WITNESS | | | | |
| YEL | YELLOW | | | | |

6-6 3121139




Figure 6-2. ADE Block Diagram

Table 6-2. Machine Configuration Programming Information Prior to Software Version P5.3

| Configuration Digit | Number | Description | Default Number |
|--|--------|---|----------------|
| MODEL NUMBER: | 1 | 400S | 1 |
| 1 | 2 | 450A | |
| | 3 4 | 510A 600S | |
| | 5 | 600A | |
| | 6 | 600SC | |
| | 7 | 6015 | |
| | 8 | 740A | |
| | 9 10 | 800A 800S | |
| | 10 | | |
| MARKET: | 0 | ANSIUSA | 0 |
| 2 | 1 | ANSIEXPORT | O . |
| | 2 | CSA | |
| | 3 | CE | |
| | 4 | AUSTRALIA | |
| | 5 | JAPAN | |
| | _ | | |
| ENGINE: 3* | 1 | FORD EFI GAS: Ford LRG425 EFI Gas (Tier 1) | 11 |
| * Engine selections vary depending on model selection. | 2 | FORD EFI D/F: Ford LRG425 EFI dual fuel (Tier 1) | |
| ucpenumy ommoder serection. | 3 | DEUTZF4TIER1: DeutzF4M1011F Diesel (Tier1) | |
| | 4 | DEUTZF3TIER1: DeutzF3M1011F Diesel (Tier1) | |
| | 5 | CAT. 3024C: CAT 3024C Diesel (Tier 2) | |
| | 6 | CAT. 3044C: CAT 3044C Diesel (Tier 2) | |
| | 7 | DEUTZ F4TIER2: Deutz F4M2011 Diesel (Tier 2) | |
| | 8 | DEUTZ F3 TIER2: Deutz F3M2011 Diesel (Tier 2) | |
| | 9 | FORD GASTIER2: Ford LRG425 EFI Gas (Tier 2) | |
| | 10 | FORD D/FTIER2: Ford LRG425 EFI Dual Fuel (Tier 2) | |
| | 11 | DEUTZ ECM: Engine Control Module - ECM | |
| | | | |
| FLYWHEEL TEETH: 4* | 0 | 133 TEETH: 133 flywheel teeth. | 1 |
| *This menu item is only visible if Deutz engine selections 3 or 4 are selected. | 1 | 110 TEETH: 110 flywheel teeth. | |
| | | | |
| | | | |

6-8 3121139

Table 6-2. Machine Configuration Programming Information Prior to Software Version P5.3

| Configuration Digit | Number | Description | Default Number |
|---|--------|---|----------------|
| GLOW PLUG: | 0 | NO GLOW PLUGS: No glow plugs installed. | 1 |
| 5 | 1 | W/O STARTER LOCK: Automatic pre-glow time determined by ambient air temperature; engine start can be attempted at any time during pre-glow. | |
| | 2 | W/STARTERLOCK: Automatic pre-glow time determined by ambient air temperature; engine start is NOT permitted until pre-glow is finished. | |
| | | | |
| ENGINE SHUTDOWN: 6 | 0 | DISABLED: No engine shutdown. | 1 |
| | 1 | ENABLED: Shutdown engine when coolant temperature is greater than 110 deg. Cor the oil pressure is less than 8 psi. | |
| | | | |
| TILT: 7* | 1 | 5 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 5 degrees and above elevation; also reduces drive speed to creep. | 1 |
| *Certainmarketselections will limit tilt options. | 2 | 4 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also reduces drive speed to creep. | |
| | 3 | 3 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also reduces drive speed to creep. | |
| | 4 | 4 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up. | |
| | 5 | 3 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up. | |
| | | Note: Any of the selections above will light the tilt lamp when a tilted condition occurs and will sound the platform alarm when the machine is also above elevation. | |
| | | | |
| JIB: | 0 | NO: No jib installed. | 0 |
| * Only visible under certain model selections | 1 | YES: Jib installed which has up and down movements only. | |
| | | | |
| 4WHEELSTEER: | 0 | NO: No four-wheel steer installed. | 0 |
| 9* * Only visible under certain model selections. | 1 | YES: Four-wheel steer installed. | |
| | | | |
| SOFT TOUCH: | 0 | NO: No soft touch system installed. | 0 |
| 10* *Only visible under certain model selections. | 1 | YES: Soft touch system installed. | |

Table 6-2. Machine Configuration Programming Information Prior to Software Version P5.3

| Configuration Digit | Number | Description | Default Number |
|---|--------|---|----------------|
| | | | |
| GEN SET/WELDER: | 0 | NO: No generator installed. | 0 |
| | 1 | BELT DRIVE: Belt driven setup. | |
| | | | |
| GEN SET CUTOUT: 12* | 0 | MOTION ENABLED: Motion enabled when generator is ON. | 0 |
| * Only visible if Gen Set / Welder Menu selection is not 0. | 1 | MOTION CUTOUT: Motion cutout in platform mode only. | |
| | | | |
| H&TLIGHTS: 13 | 0 | NO: No head and tail lights installed. | 0 |
| 13 | 1 | YES: Head and tail lights installed. | |
| | | | |
| CABLE SWITCH: 14* | 0 | NO: No broken cable switch installed. | 0 |
| * Only visible under certain model selections. * Certain market and model selections will alter the default setting. | 1 | YES: Broken cable switch installed. | |
| | | | |
| LOAD SYSTEM: | 0 | NO: No load sensor installed. | 0 |
| 15* *Only visible under certain | 1 | WARN ONLY: Functions in creep, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF). | |
| model selections. * Certain market selections will limit load system options or alter | 2 | CUTOUT PLATFORM: All functions cutout, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF). | |
| default setting. | 2 | CUTOUT ALL: All functions cutout, flash overload light (500mS on, 500mS off), platform alarm beeps (5 sec ON, 2 sec OFF). | |
| | 3 | SPECIAL 1: Functions in creep, overload lamp lit, disables main telescope out & main lift up, platform | |
| | 4 | alarm beeps (5 sec ON, 2 sec OFF). | |
| | | | |
| LOAD SENSOR: 16* | 0 | 1 ON ROTATOR: Use the on-board load sensor for all models except those which use the Leveling Platform Module. | 1 |
| * Only visible if Load Sensor Menu selection is not 0. * Market selections will limit certain load sensor options. | 1 | 4 UNDER PLATFORM: Use the EIM for load sensing. | |
| | | | |

6-10 3121139

 Table 6-2. Machine Configuration Programming Information Prior to Software Version P5.3

| Configuration Digit | Number | Description | Default Number |
|---|--------|--|----------------|
| FUNCTION CUTOUT: 17* | 0 | NO: No drive cutout. | 0 |
| *Only visible under certain | 1 | BOOM CUTOUT: Boom function cutout while driving above elevation. | |
| market selections. * Certain market selections will | 2 | DRIVE CUTOUT: Drive cutout above elevation. | |
| limit function cutout options or alter default setting. | 3 | DRIVE CUT E&T: Drive cutout above elevation and tilted. | |
| <u> </u> | | | |
| GROUND ALARM: | 0 | NO: No ground alarm installed. | 0 |
| 18* *Certain market selections will alter | 1 | DRIVE: Travel alarm sounds when the drive function is active (Option). | |
| default setting. | 2 | DESCENT: Descent alarm sounds when lift down is active (Option). | |
| | 3 | MOTION: Motion alarm sounds when any function is active (Option). | |
| | | | |
| DRIVE: 19* | 0 | 4WD: Four wheel drive. | 0 |
| * Only visible under certain model | 1 | 2WD: Two wheel drive. | |
| selections. | 2 | 2WD W/2-SPEED: Two wheel drive with 2-speed valve. | |
| | | | |
| TEMPERATURE: 20 | 0 | CELSIUS: Celsius unit selection. | 1 |
| 20 | 1 | FAHRENHEIT: Fahrenheit unit selection. | |
| | | | |
| LEVELING MODE: 21* | 0 | ALL FUNCTIONS: Platform level with all functions. | 0 |
| * Only visible on 800S models. | 1 | LEVEL LIFT/TELESCOPE: Platform level on lift and telescope only. | |
| | | | |

4150364-14

Table 6-3. Machine Configuration Programming Information Software Version P5.3 to P6.1

| Configuration Label/Digit | Number | Description | Default Number |
|---------------------------|--------|-------------|----------------|
| MODEL NUMBER: | 1 | 400S | 1 |
| 1 | 2 | 450A | |
| | 3 | 510A | |
| | 4 | 600S | |
| | 5 | 600A | |
| | 6 | 600SC | |
| | 7 | 601S | |
| | 8 | 740A | |
| | 9 | 800A | |
| | 10 | 800S | |
| | | | |
| MARKET: | 0 | ANSIUSA | 0 |
| 2 | 1 | ANSI EXPORT | |
| | 2 | CSA | |
| | 3 | Œ | |
| | 4 | AUSTRALIA | |
| | 5 | JAPAN | |
| | | | |

6-12 3121139

Table 6-3. Machine Configuration Programming Information Software Version P5.3 to P6.1

| Configuration Label/Digit | Number | Description | Default Number |
|---|--------|---|----------------|
| ENGINE: 3* | 1 | FORD EFI GAS: Ford LRG425 EFI Gas (Tier 1) | 7 |
| * Engine selections vary | 2 | FORD EFI D/F: Ford LRG425 EFI dual fuel (Tier 1) | |
| depending on model selection. | 3 | DEUTZF4TIER1: DeutzF4M1011F Diesel (Tier1) | |
| | 4 | DEUTZF3TIER1: DeutzF3M1011F Diesel (Tier 1) | |
| | 5 | CAT. 3024C: CAT 3024C Diesel (Tier 2) | |
| | 6 | CAT. 3044C: CAT 3044C Diesel (Tier 2) | |
| | 7 | PERKINS 404C (Tier 2) | |
| | 8 | DEUTZF4TIER2: DeutzF4M2011 Diesel (Tier 2) | |
| | 9 | DEUTZF3TIER2: DeutzF3M2011 Diesel (Tier2) | |
| | 10 | FORD GAS TIER2: Ford LRG425 EFI Gas (Tier 2) | |
| | 11 | FORD D/FTIER2: Ford LRG425 EFI Dual Fuel (Tier 2) | |
| | 12 | DEUTZ ECM: Engine Control Module - ECM | |
| | 13 | DUAL FUEL ECM: GM/PSI 3.0L Dual Fuel (Tier 2) | |
| | | | |
| FLYWHEELTEETH: 4* | 0 | 133 TEETH: 133 flywheel teeth. | 1 |
| *This menu item is only visible if Deutz engine selections 3 or 4 are selected. | 1 | 110 TEETH: 110 flywheel teeth. | |
| | | | |
| GLOW PLUG: | 0 | NO GLOW PLUGS: No glow plugs installed. | 2 |
| 3 | 1 | AIR INTAKE: Glow plugs installed in the air intake on the manifold. | |
| | 2 | IN-CYLINDER: Glow plugs installed in each cylinder. | |
| | | | |
| STARTER LOCKOUT: 6 | 0 | DISABLED: Automatic pre-glow time determined by ambient air temperature; engine start can be attempted at any time during pre-glow. | 0 |
| | 1 | ENABLED: Automatic pre-glow time determined by ambient air temperature; engine start is NOT permitted until pre-glow is finished. | |
| | | | |
| ENGINE SHUTDOWN: | 0 | DISABLED: No engine shutdown. | 1 |
| , | 1 | ENABLED: Shutdown engine when coolant temperature is greater than 110 deg. C or the oil pressure is less than 8 PSI. | |

Table 6-3. Machine Configuration Programming Information Software Version P5.3 to P6.1

| 1 | | |
|---|---|--|
| 1 | | |
| | 5 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 5 degrees and above elevation; also reduces drive speed to creep. | 1 |
| 2 | 4DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also reduces drive speed to creep. | |
| 3 | 3 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also reduces drive speed to creep. | |
| 4 | 4 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up. | |
| 5 | 3 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up. | |
| | | |
| 0 | NO: No jib installed. | 0 |
| 1 | YES: Jib installed which has up and down movements only. | |
| | | |
| 0 | NO: No four-wheel steer installed. | 0 |
| 1 | YES: Four-wheel steer installed. | |
| | | |
| 0 | NO: No soft touch system installed. | 0 |
| 1 | YES: Soft touch system installed. | |
| | | |
| 0 | NO: No generator installed. | 0 |
| 1 | BELT DRIVE: Belt driven setup. | |
| | | |
| 0 | MOTION ENABLED: Motion enabled when generator is ON. | 0 |
| 1 | MOTION CUTOUT: Motion cutout in platform mode only. | |
| | 4 5 0 1 0 1 0 1 | 3 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also reduces drive speed to creep. 4 |

6-14 3121139

Table 6-3. Machine Configuration Programming Information Software Version P5.3 to P6.1

| Configuration Label/Digit | Number | Description | Default Number |
|---|----------|---|----------------|
| H&TLIGHTS: | 0 | NO: No head and tail lights installed. | 0 |
| 14 | 1 | YES: Head and tail lights installed. | |
| | <u> </u> | | |
| CABLESWITCH: 15* | 0 | NO: No broken cable switch installed. | 0 |
| *Only visible under certain | 1 | YES: Broken cable switch installed. | |
| model selections. * Certain market and model | | | |
| selections will alter the default setting. | | | |
| | | | |
| LOAD SYSTEM: | 0 | NO: No load sensor installed. | 0 |
| 16* * Only visible under certain mar- | 1 | WARN ONLY: Functions in creep, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF). | |
| ket selections. * Certain market selections will | 2 | CUTOUT PLATFORM: All functions cutout, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF). | |
| limit load system options or alter default setting. | 3 | CUTOUT ALL: All functions cutout, flash overload light (500mS on, 500mS off), platform alarm beeps (5 | |
| defaultsetting. | , | sec ON, 2 sec OFF). | |
| | 4 | SPECIAL 1: Functions in creep, overload lamp lit, disables main telescope out & main lift up, platform alarm beeps (5 sec ON, 2 sec OFF). | |
| | | | |
| LOAD SENSOR: 17* | 0 | 1 ON ROTATOR: Use the on-board load sensor for all models except those which use the Leveling Platform Module. | 1 |
| *Only visible if Load Sensor Menu selection is not 0 and | 1 | 4 UNDER PLATFORM: Use the EIM for load sensing. | |
| under certain market selections. * Certain market selections will limit load sensor options. | | | |
| | | | <u> </u> |
| FUNCTION CUTOUT: | 0 | NO: No drive cutout. | 0 |
| 18* *Only visible under certain mar- | 1 | BOOM CUTOUT: Boom function cutout while driving above elevation. | |
| ket selections. * Certain market selections will | 2 | DRIVE CUTOUT: Drive & steer cutout above elevation. | |
| limit function cutout options or alter default setting. | 3 | DRIVE CUT E&T: Drive & steer cutout above elevation and tilted. | |
| | | | |

Table 6-3. Machine Configuration Programming Information Software Version P5.3 to P6.1

| Configuration Label/Digit | Number | Description | Default Number |
|--|--------|--|----------------|
| GROUND ALARM: 19* | 0 | NO: No ground alarm installed. | 3 |
| * Certain market selections will | 1 | DRIVE: Travel alarm sounds when the drive function is active (Option). | |
| alter default setting. | 2 | DESCENT: Descent alarm sounds when lift down is active (Option). | |
| | 3 | MOTION: Motion alarm sounds when any function is active (Option). | |
| | | | |
| DRIVE: 20* | 0 | 4WD: Four wheel drive. | 0 |
| * Only visible under certain | 1 | 2WD: Two wheel drive. | |
| model selections. | 2 | 2WD W/2-SPEED: Two wheel drive with 2-speed valve. | |
| | | | |
| TEMPERATURE: 21* | 0 | CELSIUS: Celsius unit selection. | 1 |
| *Certain market selections will alter default setting. | 1 | FAHRENHEIT: Fahrenheit unit selection. | |
| | | | |
| LEVELING MODE: | 0 | ALL FUNCTIONS: Platform level with all functions. | 0 |
| 22* * Only visible on 800S models. | 1 | LEVEL LIFT/TELESCOPE: Platform level on lift and telescope only. | |
| | | | |

4150364-18

6-16 3121139

Table 6-4. Machine Configuration Programming Information Software Version P6.1 to Present

| Configuration Label/Digit | Number | Description | Default Number |
|---------------------------|--------|-------------|----------------|
| MODEL NUMBER: | 1 | 400S | 1 |
| | 2 | 450A | |
| | 3 | 510A | |
| | 4 | 600S | |
| | 5 | 600A | |
| | 6 | 600SC | |
| | 7 | 601S | |
| | 8 | 740A | |
| | 9 | 800A | |
| | 10 | 800S | |
| | | | |
| MARKET: | 0 | ANSIUSA | 0 |
| 2 | 1 | ANSI EXPORT | |
| | 2 | CSA | |
| | 3 | Œ | |
| | 4 | AUSTRALIA | |
| | 5 | JAPAN | |
| | | | |

Table 6-4. Machine Configuration Programming Information Software Version P6.1 to Present

| Configuration Label/Digit | Number | Description | Default Number |
|---|--------|---|----------------|
| ENGINE: 3* | 1 | FORDEFIGAS: Ford LRG425 EFI Gas (Tier 1) | 14 |
| *Engine selections vary depending on model selection. | 2 | FORDEFID/F: Ford LRG425 EFI dual fuel (Tier 1) | |
| depending of moder selection. | 3 | DEUTZF4TIER1: DeutzF4M1011F Diesel (Tier1) | |
| | 4 | DEUTZF3 TIER1: DeutzF3M1011F Diesel (Tier1) | |
| | 5 | CAT. 3024C: CAT 3024C Diesel (Tier 2) | |
| | 6 | CAT. 3044C: CAT 3044C Diesel (Tier 2) | |
| | 7 | PERKINS 404C (Tier 2) | |
| | 8 | DEUTZF4TIER2: DeutzF4M2011 Diesel (Tier 2) | |
| | 9 | DEUTZF3 TIER2: DeutzF3M2011 Diesel (Tier 2) | |
| | 10 | FORD GAS TIER2: Ford LRG425 EFI Gas (Tier 2) | |
| | 11 | FORD D/F TIER2: Ford LRG425 EFI Dual Fuel (Tier 2) | |
| | 12 | DEUTZ ECM: Engine Control Module - ECM (Tier 2 and Tier 3) | |
| | 13 | DUAL FUEL ECM: GM/PSI 3.0L Dual Fuel (Tier 2) | |
| | 14 | PERKINSECM | |
| | 15 | CATECM | |
| | | | |
| FLYWHEELTEETH: 4* | 0 | 133 TEETH: 133 flywheel teeth. | 1 |
| *This menuitem is only visible if Deutz engine selections 3 or 4 | 1 | 110 TEETH: 110 flywheel teeth. | |
| are selected. | | | |
| | | | |
| GLOW PLUG: 5 | 0 | NO GLOW PLUGS: No glow plugs installed. | 2 |
| 3 | 1 | AIR INTAKE: Glow plugs installed in the air intake on the manifold. | |
| | 2 | IN-CYLINDER: Glow plugs installed in each cylinder. | |
| | | | |
| STARTER LOCKOUT: 6 | 0 | DISABLED: Automatic pre-glow time determined by ambient air temperature; engine start can be attempted at any time during pre-glow. | 0 |
| | 1 | ENABLED: Automatic pre-glow time determined by ambient air temperature; engine start is NOT permitted until pre-glow is finished. | |
| | | | |

6-18 3121139

Table 6-4. Machine Configuration Programming Information Software Version P6.1 to Present

| Configuration Label/Digit | Number | Description | Default Number |
|---|--------|---|----------------|
| ENGINE SHUTDOWN: | 0 | DISABLED: No engine shutdown. | 1 |
| 7 | 1 | ENABLED: Shutdown engine when coolant temperature is greater than 110 deg. C or the oil pressure is less than 8 PSI. | |
| | | | |
| TILT: 8* * Certain market selections will | 1 | 5 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 5 degrees and above elevation; also reduces drive speed to creep. | 1 |
| limit tilt options and alter default setting. | 2 | 4 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also reduces drive speed to creep. | |
| Note: Any of the selections above will light the tilt lamp | 3 | 3 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also reduces drive speed to creep. | |
| when a tilted condition occurs and will sound the platform alarm when the machine is also above elevation. | 4 | 4 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up. | |
| | 5 | 3 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up. | |
| | | | |
| JIB: 9* | 0 | NO: No jib installed. | 0 |
| *Only visible under certain model selections. | 1 | YES: Jib installed which has up and down movements only. | |
| | | | |
| 4 WHEEL STEER: 10* | 0 | NO: No four-wheel steer installed. | 0 |
| * Only visible under certain model selections. | 1 | YES: Four-wheel steer installed. | |
| | | | |
| SOFT TOUCH: 11* | 0 | NO: No soft touch system installed. | 0 |
| *Only visible under certain model selections. | 1 | YES: Soft touch system installed. | |
| | | | |
| GENSET/WELDER: | 0 | NO: No generator installed. | 0 |
| 12 | 1 | BELT DRIVE: Belt driven setup. | |
| | | | |
| GENSET CUTOUT: | 0 | MOTION ENABLED: Motion enabled when generator is ON. | 0 |
| 13* * Only visible if Gen Set / Welder Menu selection is not 0. | 1 | MOTION CUTOUT: Motion cutout in platform mode only. | |

Table 6-4. Machine Configuration Programming Information Software Version P6.1 to Present

| Configuration Label/Digit | Number | Description | Default Number |
|---|--------|---|----------------|
| | | | |
| H&TLIGHTS: 14 | 0 | NO: No head and tail lights installed. | 0 |
| 14 | 1 | YES: Head and tail lights installed. | |
| | | | |
| CABLESWITCH: 15* | 0 | NO: No broken cable switch installed. | 0 |
| *Only visible under certain | 1 | YES: Broken cable switch installed. | |
| model selections. * Certain market and model | | | |
| selections will alter the default setting. | | | |
| | | | |
| LOAD SYSTEM: | 0 | NO: No load sensor installed. | 0 |
| 16* * Only visible under certain mar- | 1 | WARN ONLY: Functions in creep, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF). | |
| ket selections. * Certain market selections will | | CUTOUT PLATFORM: All functions cutout, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF). | |
| limit load system options or alter default setting. | 2 | CUTOUT ALL: All functions cutout, flash overload light (500mS on, 500mS off), platform alarm beeps (5 | |
| | 3 | sec ON, 2 sec OFF). | |
| | | SPECIAL 1: Functions in creep, overload lamp lit, disables main telescope out & main lift up, platform alarm beeps (5 sec ON, 2 sec OFF). | |
| | 4 | | |
| | | | |
| LOAD SENSOR: 17* * On horizith a if Load Conson | 0 | 1 ON ROTATOR: Use the on-board load sensor for all models except those which use the Leveling Platform Module. | 1 |
| * Only visible if Load Sensor Menu selection is not 0 and | 1 | 4 UNDER PLATFORM: Use the EIM for load sensing. | |
| under certain market selections. * Certain market selections will | | | |
| limit load sensor options. | | | |
| | | | |
| FUNCTION CUTOUT: 18* | 0 | NO: No drive cutout. | 0 |
| * Only visible under certain mar- ket selections. | 1 | BOOM CUTOUT: Boom function cutout while driving above elevation. | |
| * Certain market selections will limit function cutout options or | 2 | DRIVE CUTOUT: Drive & steer cutout above elevation. | |
| alter default setting. | 3 | DRIVE CUT E&T: Drive & steer cutout above elevation and tilted. | |
| | | | |

6-20 3121139

Table 6-4. Machine Configuration Programming Information Software Version P6.1 to Present

| Configuration Label/Digit | Number | Description | Default Number |
|---|--------|---|----------------|
| GROUND ALARM: 19* | 0 | NO: No ground alarm installed. | 3 |
| *Certain market selections will | 1 | DRIVE: Travel alarm sounds when the drive function is active (Option). | |
| alter default setting. | 2 | DESCENT: Descent alarm sounds when lift down is active (Option). | |
| | 3 | MOTION: Motion alarm sounds when any function is active (Option). | |
| | , | | |
| DRIVE: 20* | 0 | 4WD: Four wheel drive. | 0 |
| *Only visible under certain | 1 | 2WD: Two wheel drive. | |
| model selections. | 2 | 2WDW/2-SPEED: Two wheel drive with 2-speed valve. | |
| | | | |
| TEMPERATURE: 21* | 0 | CELSIUS: Celsius unit selection. | 1 |
| * Certain market selections will alter default setting. | 1 | FAHRENHEIT: Fahrenheit unit selection. | |
| | , | | |
| LEVELING MODE: 22* | 0 | ALL FUNCTIONS: Platform level with all functions. | 0 |
| *Only visible on 800S models. | 1 | LEVEL LIFT/TELESCOPE: Platform level on lift and telescope only. | |
| | | | |
| DRIVE CONTROL: 23 | 0 | NORMAL: Drive coils are energized from the Ground Module. | 2 |
| 23 | 1 | PROPULSION: Drive coils are energized from the Propulsion Module. | |
| | 2 | ENHANCED: Drive coils are energized from the Ground Module and the ground side of the drive coils are brought back to current feedback returns. | |
| | | | |
| CLEARSKY: | 0 | NO: Clearsky (telematics) option is disabled. | 0 |
| 24 | 1 | YES: Clearsky (telematics) option is enabled. | |
| | | | |
| CRIBBING OPTION: 25 | 0 | NO: Cribbing Option is disabled. | 0 |
| 23 | 1 | YES: Cribbing Option is enabled. | |
| | | | |

4150364-19

Table 6-5. Machine Configuration Programming Information

| Configuration Digit | Number | Description | Default Number |
|---------------------|--|--|-----------------------------|
| ity settings fi | configuratior rst and then c lefault values. | n must be completed before any personality settings can be changed. Changing th hanging the model number of the machine configuration will cause the personal | e personal- ity settings |
| MODEL NUMBER: | 1 | 4005 | 1 |
| I | 2 | 450A | |
| | 3 | 510A | |
| | 4 | 600S | |
| | 5 | 600A | |
| | 6 | 600SC | |
| | 7 | 6015 | |
| | 8 | 740A | |
| | 9 | 800A | |
| | 10 | 800S | |
| | | | |
| MARKET: | 0 | ANSI USA | 0 |
| 2 | 1 | ANSI EXPORT | |
| | 2 | CSA | |
| | 3 | CE | |
| | 4 | AUSTRALIA | |
| | 5 | JAPAN | |
| | 6 | GB | |
| | ı | | |

6-22 3121139

Table 6-5. Machine Configuration Programming Information

| Number | Description | Default Number |
|--------|--|--|
| 1 | FORD EFI GAS: Ford LRG425 EFI Gas (Tier 1) | 14 |
| 2 | FORD EFI D/F: Ford LRG425 EFI dual fuel (Tier 1) | |
| 3 | DEUTZF4TIER1: DeutzF4M1011F Diesel (Tier1) | |
| 4 | DEUTZF3TIER1: DeutzF3M1011F Diesel (Tier1) | |
| 5 | CAT. 3024C: CAT 3024C Diesel (Tier 2) | |
| 6 | CAT. 3044C: CAT 3044C Diesel (Tier 2) | |
| 7 | PERKINS 404C (Tier 2) | |
| 8 | DEUTZF4TIER2: DeutzF4M2011 Diesel (Tier 2) | |
| 9 | DEUTZF3TIER2: DeutzF3M2011 Diesel (Tier 2) | |
| 10 | FORD GAS TIER2: Ford LRG425 EFI Gas (Tier 2) | |
| 11 | FORD D/FTIER2: Ford LRG425 EFI Dual Fuel (Tier 2) | |
| 12 | DEUTZ ECM: Engine Control Module - ECM (Tier 2 and Tier 3) | |
| 13 | DUAL FUEL ECM: GM/PSI 3.0L Dual Fuel (Tier 2) | |
| 14 | PERKINSECM | |
| 15 | CATECM | |
| 16 | DEUTZ EMR4: Deutz Engine Control Module (Tier 4 Final) | |
| 17 | FORD DUAL FUEL | |
| | | |
| 0 | 133 TEETH: 133 flywheel teeth. | 1 |
| 1 | 110TEETH: 110flywheel teeth. | |
| | 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 | FORD EFI GAS: Ford LRG425 EFI Gas (Tier 1) FORD EFI D/F: Ford LRG425 EFI Gas (Tier 1) DEUTZ F4 TIER1: Deutz F4M1011F Diesel (Tier 1) CAT. 3024C: CAT 3024C Diesel (Tier 2) CAT. 3024C: CAT 3024C Diesel (Tier 2) PERKINS 404C (Tier 2) DEUTZ F4 TIER2: Deutz F4M2011 Diesel (Tier 2) DEUTZ F4 TIER2: Deutz F4M2011 Diesel (Tier 2) FORD GAS TIER2: Ford LRG425 EFI Gas (Tier 2) FORD D/F TIER2: Ford LRG425 EFI Dual Fuel (Tier 2) DEUTZ F4 TIER2: Deutz F4M2011 Diesel (Tier 2) PERKINS ECM DEUTZ F4 TIER2: Ford LRG425 EFI Dual Fuel (Tier 2) TO FORD D/F TIER2: Ford LRG425 EFI Dual Fuel (Tier 2) DEUTZ F4 TIER2: Deutz F4M2011 Diesel (Tier 2) TO FORD D/F TIER2: Ford LRG425 EFI Dual Fuel (Tier 2) TO DEUTZ ECM: Engine Control Module - ECM (Tier 2 and Tier 3) DUAL FUEL ECM: GM/PSI 3.0L Dual Fuel (Tier 2) THE PERKINS ECM TO THE PARK THE |

Table 6-5. Machine Configuration Programming Information

| Configuration Digit | Number | Description | Default Number |
|---|--------|---|-------------------|
| GLOW PLUG: | 0 | NO GLOW PLUGS: No glow plugs installed. | 2 |
| 5 | 1 | AIR INTAKE: Glow plugs installed in the air intake on the manifold. | |
| | 2 | IN-CYLINDER: Glow plugs installed in each cylinder. | |
| | | | |
| STARTER LOCKOUT: 6 | 0 | DISABLED: Automatic pre-glow time determined by ambient air temperature; engine start can be attempted at any time during pre-glow. | 0 |
| | 1 | ENABLED: Automatic pre-glow time determined by ambient air temperature; engine start is NOT permitted until pre-glow is finished. | |
| | | | |
| FUEL CUTOUT | 0 | RESTART: Engine allowed to be restarted multiple times when very low fuel level is reached. | 0 |
| 7 *This menuitem is only vis- | 1 | ONE RESTART: Engine allowed to be restarted once for 2 minutes when very low fuel level is reached. | |
| ible if non dual fuel engines are selected. | 2 | ENGINE STOP: Engine not able to restart when very low fuel level is reached. | |
| | | | |
| ENGINE SHUTDOWN: | 0 | DISABLED: No engine shutdown. | 1 |
| o | 1 | ENABLED: Shutdown engine when coolant temperature is greater than 110 deg. Cor the oil pressure is less than 8 PSI. | |
| | | | |
| TILT: 9* *Certain market selections | 1 | 5 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 5 degrees and above elevation; also reduces drive speed to creep. | 1 |
| will limit tilt options and alter default setting. | 2 | 4 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also reduces drive speed to creep. | |
| Note: Any of the selections above will light the tilt | 3 | 3 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also reduces drive speed to creep. | |
| lamp when a tilted condition occurs and will sound the platform alarm when the machine is also above elevation. | 4 | 4 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up. | |
| | 5 | 3 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up. | |
| | 6 | 5 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 5 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up. | |

6-24 3121139

Table 6-5. Machine Configuration Programming Information

| Configuration Digit | Number | Description | Default Number |
|--|--------|--|-------------------|
| JIB: 10* | 0 | NO: No jib installed. | 0 |
| *Only visible under certain model selections. | 1 | YES: Jib installed which has up and down movements only. | |
| | | | |
| 4 WHEEL STEER: 11* | 0 | NO: No four-wheel steer installed. | 0 |
| *Only visible under certain model selections. | 1 | YES: Four-wheel steer installed. | |
| | | | |
| STTOUCH/SKYGUARD: | 0 | NONE: No soft touch or skyguard system installed. | 0 |
| 12 | 1 | SOFTTOUCH - Soft touch only installed. | |
| | 2 | SKYGUARD - Skyguard only installed. | |
| | 3 | BOTH (CUTOUT) - Soft touch and Skyguard installed. | |
| | | | |
| GEN SET/WELDER: | 0 | NO: No generator installed. | 0 |
| 13 | 1 | BELT DRIVE: Belt driven setup. | |
| | | | |
| GEN SET CUTOUT: 14* | 0 | MOTION ENABLED: Motion enabled when generator is ON. | 0 |
| *Only visible if Gen Set / Welder Menu selection is | 1 | MOTION CUTOUT: Motion cutout in platform mode only. | |
| not 0. | | | |
| | | | |
| H&TLIGHTS: 15 | 0 | NO: No head and tail lights installed. | 0 |
| | 1 | YES: Head and tail lights installed. | |
| | | | |
| CABLE SWITCH: 16* | 0 | NO: No broken cable switch installed. | 0 |
| * Only visible under certain model selections. | 1 | YES: Broken cable switch installed. | |
| *Certain market and model selections will alter the default setting. | | | |
| | | | |

Table 6-5. Machine Configuration Programming Information

| Configuration Digit | Number | Description | Default Number |
|---|--------|---|-------------------|
| LOAD SYSTEM: | 0 | NO: No load sensor installed. | 0 |
| 17* *Only visible under certain | 1 | WARN ONLY: Functions in creep, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF). | |
| market selections. *Certain market selections | 2 | CUTOUT PLATFORM: All functions cutout, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF). | |
| will limit load system options or alter default set- | 3 | CUTOUT ALL: All functions cutout, flash overload light (500mS on, 500mS off), platform alarm beeps (5 | |
| ting. *LOAD SYSTEM will not be | | sec ON, 2 sec OFF). | |
| visible in CE and defaulted to CUTOUT ALL for machines equipped with MSSO. | 4 | SPECIAL 1: Functions in creep, overload lamp lit, disables main telescope out & main lift up, platform alarm beeps (5 sec ON, 2 sec OFF). | |
| | | | |
| LOAD SENSOR: 18* | 0 | 1 ON ROTATOR: Use the on-board load sensor for all models except those which use the Leveling Platform Module. | 1 |
| *Only visible if Load Sensor | | AUNDED DI ATTODIA II-a da FIM faul a dannin | |
| Menu selection is not 0 and under certain market selec- | 1 | 4 UNDER PLATFORM: Use the EIM for load sensing. | |
| tions. *Certain market selections | | | |
| will limit load sensor options. | | | |
| | | | |
| FUNCTION CUTOUT: | 0 | NO: No drive cutout. | 0 |
| 19* *Only visible under certain | 1 | BOOM CUTOUT: Boom function cutout while driving above elevation. | |
| market selections. *Certain market selections | 2 | DRIVE CUTOUT: Drive & steer cutout above elevation. | |
| will limit function cutout options or alter default setting. | 3 | DRIVE CUT E&T: Drive & steer cutout above elevation and tilted. | |
| | | | |
| GROUND ALARM: 20* | 0 | NO: No ground alarm installed. | 3 |
| *Certain market selections | 1 | DRIVE: Travel alarm sounds when the drive function is active (Option). | |
| will alter default setting. | 2 | DESCENT: Descent alarm sounds when lift down is active (Option). | |
| | 3 | MOTION: Motion alarm sounds when any function is active (Option). | |

6-26 3121139

Table 6-5. Machine Configuration Programming Information

| Configuration Digit | Number | Description | Default Number |
|--|--------|---|-------------------|
| DRIVE: 21* | 0 | 4WD: Four wheel drive. | 0 |
| *Only visible under certain | 1 | 2WD: Two wheel drive. | |
| model selections. | 2 | 2WD W/2-SPEED: Two wheel drive with 2-speed valve. | |
| | | | |
| DISPLAY UNITS: 22* | 0 | IMPERIAL: DEGF, PSI, LBS. | 0 |
| *Certain market selections will alter default setting. | 1 | METRIC: DEG C, KPA, KGS | |
| | | | |
| LEVELING MODE: 23* | 0 | ALL FUNCTIONS: Platform level with all functions. | 0 |
| * Only visible on 800S models. | 1 | LEVEL LIFT/TELESCOPE: Platform level on lift and telescope only. | |
| | | | |
| DRIVE CONTROL: 24 | 0 | NORMAL: Drive coils are energized from the Ground Module. | 2 |
| 24 | 1 | PROPULSION: Drive coils are energized from the Propulsion Module. | |
| | 2 | ENHANCED: Drive coils are energized from the Ground Module and the ground side of the drive coils are brought back to current feedback returns. | |
| | | | |
| DRIVE PUMP 25 | 0 | SAUER DANFOSS: Machine equipped with Sauer Danfoss drive pump | 0 |
| *Only visible on 600A, | 1 | EATON: Machine equipped with Eaton drive pump | |
| 600S, and 800S models. | 2 | M46 - XXXX: Machine equipped with M46 - XXXX drive pump | |
| | 3 | 830XXXXX: Machine equipped with 830XXXXX: drive pump | |
| | | | |
| BOOM CONTROL: | 0 | NORMAL: Boom function coils are energized from the Ground Module. | 0 |
| 26 | 1 | ENHANCED: Boom function are energized from the Ground Module and the ground side of the drive coils and brought back to current feedback returns. | |
| | | | |
| FUNCTION SPEED KNOB 27 | 0 | YES: Machine is equipped with Function Speed Knob. | 0 |
| LI | 1 | NO: Machine is equipped with Operation Speed Switch. | |
| | | | |

Table 6-5. Machine Configuration Programming Information

| Configuration Digit | Number | Description | Default Number |
|--|--------|---|-------------------|
| CLEARSKY: | 0 | NO: Clearsky (telematics) option is disabled. | 0 |
| 28 | 1 | YES: Clearsky (telematics) option is enabled. | |
| | | | |
| CRIBBING OPTION: | 0 | NO: Cribbing Option is disabled. | 0 |
| 25 | 1 | YES: Cribbing Option is enabled. | |
| | | | |
| FUEL TANK SIZE: | 0 | 31 Gallon Tank | 0 |
| 30 | 1 | 52 Gallon Tank | |
| | | | |
| ALARM/HORN: 31 | 0 | SEPERATE: Separate alarm and horn. | 0 |
| 31 | 1 | COMBINED: Combination alarm / horn. | |
| | | | |
| ALERT/BEACON: 32 | 0 | OFF FOR CREEP: Alert beacon will not flash while in Creep. | 0 |
| 32 | 1 | 20FPS FOR CREEP: Alert beacon will flash at 20FPS while in Creep. | |
| | | | |
| TEMP CUTOUT: | 0 | NO: Temp Cutout is Disabled | 0 |
| 33 | 1 | YES: Temp Cutout is Enabled | |
| | | | |
| PLAT LVL OVR CUT: 34 | 0 | NO: Platform Level Override will always be functional. | 0 |
| T | 1 | YES: Platform Level Override will only be functional when In Transport. | |
| | | | |
| WATER IN FUEL SENSOR 35 | 0 | No: Water in Fuel Sensor Disabled. | 0 |
| *This menu item is only vis- ibleif Deutz EMR 4 engine is selected. *Only visible under certain market selections. | 1 | YES: Water in Fuel Sensor Enabled. | |

4150364-R

6-28 3121139

Table 6-6. 800S Machine Configuration Programming Settings

| | | _ | etting | | | | |
|-----------------|---------|-------------|--------|----|-----------|-------|----------------|
| 800 S | ANSIUSA | ANSI Export | CSA | U | Australia | Japan | g _B |
| Model Number | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| Market | 0 | 1 | 2 | 3 | 4 | 5 | 3 |
| Engine | 12 | 12 | 12 | 12 | 12 | 12 | 12 |
| Flywheel Teeth | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Glow Plugs | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Starter Lockout | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Fuel Cutout | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Engine Shut- | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| down | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Tilt | 1 | 1 | 1 | Χ | Χ | 1 | Χ |
| | 2 | 2 | 2 | Χ | 2 | 2 | Χ |
| | 3 | 3 | 3 | Χ | 3 | 3 | Χ |
| | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 5 | 5 | 5 | 5 | 5 | 5 | 5 |
| | 6 | 6 | 6 | Χ | Χ | 6 | Χ |
| Jib | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 4 Wheel Steer | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Soft Touch/ | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Skyguard | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| Gen Set / | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Welder | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Gen Set Cutout | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Head & Tail- | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| lights | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Cable Break | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Switch | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Load System | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Χ | 1 | Χ | Х | Х | 1 | Χ |
| | Χ | 2 | Χ | 2 | 2 | 2 | 2 |
| | Χ | 3 | Χ | 3 | Χ | 3 | 3 |
| | Χ | 4 | Χ | Χ | Χ | 4 | Χ |
| Load Sensor | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |

Table 6-6. 800S Machine Configuration Programming Settings

| 800 S | ANSI USA | ANSI Export | CSA | Œ | Australia | Japan | GB |
|------------------|----------|-------------|-----|---|-----------|-------|----|
| Function Cut- | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| out | Χ | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | Χ | 2 | 2 | 2 |
| | Χ | 3 | 3 | Χ | 3 | 3 | 3 |
| Ground Alarm | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| Drive Type | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Display Units | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Leveling Mode | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Drive Control | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Drive Pump | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | Χ | χ | Χ | χ | Χ | Х | Χ |
| | χ | χ | Х | χ | χ | Х | χ |
| Boom Control | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Function Speed | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Knob | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Clearsky | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Cribbing | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Option | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Fuel Tank Size | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Alarm/Horn | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Alert Beacon | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Temp Cutout | Χ | 0 | Χ | 0 | Χ | Χ | 0 |
| | Χ | 1 | Χ | 1 | Χ | Х | 1 |
| Plat Lvl Ovr Cut | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |

Table 6-6. 800S Machine Configuration Programming Settings

| 800 S | ANSI USA | ANSI Export | CSA | CE | Australia | Japan | GB |
|---------------|----------|-------------|-----|----|-----------|-------|----|
| Water in Fuel | Χ | 0 | χ | Χ | Χ | Χ | 0 |
| Sensor | Χ | 1 | Χ | Χ | χ | χ | 1 |

BOLD BLUE text indicates the default setting. Plain text indicates another available selection. *RED ITALIC* text indicates the default when option is factory installed. SHADED CELLS indicate hidden menu or selection.

Table 6-7. 860SJ Machine Configuration Programming Settings

| 860 SJ | ANSI USA | ANSI Export | CSA | Ð | Australia | Japan | g _B |
|-----------------|----------|-------------|-----|----|-----------|-------|----------------|
| Model Number | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| Market | 0 | 1 | 2 | 3 | 4 | 5 | 3 |
| Engine | 12 | 12 | 12 | 12 | 12 | 12 | 12 |
| Flywheel Teeth | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Glow Plugs | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Starter Lockout | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Fuel Cutout | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Engine Shut- | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| down | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Tilt | 1 | 1 | 1 | Χ | Χ | 1 | Χ |
| | 2 | 2 | 2 | Χ | 2 | 2 | X |
| | 3 | 3 | 3 | Χ | 3 | 3 | Χ |
| | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 5 | 5 | 5 | 5 | 5 | 5 | 5 |
| | 6 | 6 | 6 | χ | Χ | 6 | Χ |
| Jib | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 4 Wheel Steer | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Soft Touch/ | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Skyguard | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| Gen Set / | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Welder | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Gen Set Cutout | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Head & Tail- | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| lights | 1 | 1 | 1 | 1 | 1 | 1 | 1 |

Table 6-7. 860SJ Machine Configuration Programming Settings

| 860 SJ | ANSI USA | ANSI Export | CSA | Œ | Australia | Japan | GB |
|------------------|----------|-------------|-----|---|-----------|-------|----|
| Cable Break | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Switch | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Load System | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Χ | 1 | Χ | χ | χ | 1 | χ |
| | Χ | 2 | Χ | 2 | 2 | 2 | 2 |
| | Χ | 3 | Χ | 3 | χ | 3 | 3 |
| | Χ | 4 | Χ | χ | χ | 4 | Χ |
| Load Sensor | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Function Cut- | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| out | χ | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | χ | 2 | 2 | 2 |
| | χ | 3 | 3 | Χ | 3 | 3 | 3 |
| Ground Alarm | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| Drive Type | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Display Units | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Leveling Mode | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| . | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Drive Control | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Drive Pump | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Jiire: ump | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | Х | Х | Х | Х | Х | Χ | χ |
| | Х | Х | Х | Х | Х | Х | χ |
| Boom Control | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 500111 20111101 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Function Speed | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Knob | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Clearsky | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| cicuisky | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Cribbing | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Option | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Fuel Tank Size | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| ו עכו ומווא אובכ | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Alarm/Horn | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| riaiiii/ MUIII | | | | | | | |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |

6-30 3121139

Table 6-7. 860SJ Machine Configuration Programming Settings

| | | | <u> </u> | | | | |
|------------------|----------|-------------|----------|----|-----------|-------|----|
| 860 SJ | ANSI USA | ANSI Export | CSA | CE | Australia | Japan | GB |
| Alert Beacon | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Temp Cutout | Χ | 0 | Χ | 0 | Χ | Χ | 0 |
| | Χ | 1 | Χ | 1 | Χ | Х | 1 |
| Plat Lvl Ovr Cut | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Water in Fuel | Χ | 0 | Χ | Χ | Χ | Χ | 0 |
| Sensor | Χ | 1 | Χ | Χ | Χ | Х | 1 |

BOLD BLUE text indicates the default setting. Plain text indicates another available selection. *RED ITALIC* text indicates the default when option is factory installed. SHADED CELLS indicate hidden menu or selection.

6.2 MACHINE PERSONALITY SETTINGS AND FUNCTION SPEEDS

NOTE: Personality settings can be adjusted within the adjustment range in order to achieve optimum machine performance.

Table 6-8. Machine Personality Settings

| FUNCTION | PERSONALITY | RANGE | DEFAULTS-800S | DEFAULTS-860SJ |
|-----------|---------------------------|--------------|---------------|----------------|
| DRIVE | ACCELeration | 0.1 to 5.0 s | 2.0 | 2.0 |
| | DECELeration | 0.1 to 3.0 s | 2.0 | 2.0 |
| | FORward MINimum speed | 0 to 35%% | 4 | 4 |
| | FORward MAXimum speed | 0 to 100% | 30 | 30 |
| | REVerse MINimum speed | 0 to 35% | 4 | 4 |
| | REVerse MAXimum speed | 0 to 100% | 30 | 30 |
| | ELEVATED MAXimum speed | 0 to 50% | 20 | 20 |
| | CREEP MAXimum speed | 0 to 50% | 20 | 20 |
| | Engine RPM | 800 to 2900 | 1800 | 1800 |
| | | | | |
| STEER | MAXimum speed | 0 to 100% | 100 | 100 |
| | Engine RPM | 800 to 2900 | 1800 | 1800 |
| | | | <u> </u> | |
| MAIN LIFT | ACCELeration | 0.1 to 5.0s | 2.5 | 2.5 |
| | DECELeration | 0.1 to 3.0s | 1.5 | 1.5 |
| | MINimum UP speed | 0 to 60% | 15 | 15 |
| | MAXimum UP speed | 0 to 100% | 80 | 80 |
| | CREEP maximum UP speed | 0 to 65% | 30 | 30 |
| | MINimum DOWN speed | 0 to 60% | 15 | 15 |
| | MAXimum DOWN speed | 0 to 100% | 80 | 80 |
| | CREEP maximum DOWN speed | 0 to 75% | 30 | 30 |
| | Engine RPM | 800 to 2900 | 1800 | 1800 |
| | | | | |
| TOWERLIFT | ACCELeration | 0.1 to 5.0s | N/A | N/A |
| | DECELeration | 0.1 to 3.0s | N/A | N/A |
| | MINimum UP speed | 0 to 60% | N/A | N/A |
| | MAXimum UP speed | 0 to 100% | N/A | N/A |
| | MINimum DOWN speed | 0 to 60% | N/A | N/A |
| | MAXimum DOWN speed | 0 to 100% | N/A | N/A |
| | Engine RPM | 800 to 2900 | N/A | N/A |
| | | | | |
| SWING | ACCELeration | 0.1to 5.0s | 2.8 | 2.8 |
| | DECELeration | 0.1 to 3.0s | 1.7 | 1.7 |
| | MINimum LEFT speed | 0 to 50% | 14 | 14 |
| | MAXimum LEFT speed | 0 to 100% | 65 | 65 |
| | CREEP maximum LEFT speed | 0 to 65% | 43 | 43 |
| | MINimum RIGHT speed | 0 to 50% | 14 | 14 |
| | MAXimum RIGHT speed | 0 to 100% | 68 | 68 |
| | CREEP maximum RIGHT speed | 0 to 65% | 49 | 49 |
| | Engine RPM | 800 to 2900 | 1800 | 1800 |

6-32 3121139

Table 6-8. Machine Personality Settings

| FUNCTION | PERSONALITY | RANGE | DEFAULTS-800S | DEFAULTS-860SJ |
|-----------------|---------------------|--------------|---------------|----------------|
| | | | | |
| MAINTELESCOPE | ACCELeration | 0.1 to 5.0s | 3.5 | 3.5 |
| | DECELeration | 0.1 to 3.0s | 1.0 | 1.0 |
| | MINimum IN speed | 0 to 65% | 24 | 24 |
| | MAXimum IN speed | 0 to 100% | 63 | 63 |
| | MINimum OUT speed | 0 to 65% | 26 | 26 |
| | MAXimum OUT speed | 0 to 100% | 65 | 65 |
| | Medium Speed | 0.01 to 1.00 | 0.50 | 0.50 |
| | Engine RPM | 800 to 2900 | 1800 | 1800 |
| | | | · · · | |
| TELESCOPE TOWER | ACCELeration | 0.1 to 5.0s | N/A | N/A |
| | DECELeration | 0.1to 3.0s | N/A | N/A |
| | MINimum IN speed | 0 to 65% | N/A | N/A |
| | MAXimum IN speed | 0 to 100% | N/A | N/A |
| | MINimum OUT speed | 0 to 65% | N/A | N/A |
| | MAXimum OUT speed | 0 to 100% | N/A | N/A |
| | Engine RPM | 800 to 2900 | N/A | N/A |
| | | | <u> </u> | |
| PLATFORM LEVEL | ACCELeration | 0.1to 5.0s | 0.1 | 0.1 |
| | DECELeration | 0.1to 3.0s | 0.1 | 0.1 |
| | MINimum UP speed | 0 to 65% | 48 | 48 |
| | MAXimum UP speed | 0 to 100% | 100 | 100 |
| | MINimum DOWN speed | 0 to 65% | 48 | 48 |
| | MAXimum DOWN speed | 0 to 100% | 100 | 100 |
| | Medium Speed | 0.01 to 1.00 | 0.10 | 0.10 |
| | Engine RPM | 800 to 2900 | 1800 | 1800 |
| | | | | |
| PLATFORM ROTATE | ACCELeration | 0.1to 5.0s | 0.1 | 0.1 |
| | DECELeration | 0.1to 3.0s | 0.1 | 0.1 |
| | MINimum LEFT speed | 0 to 65% | 69 | 69 |
| | MAXimum LEFT speed | 0 to 100% | 90 | 90 |
| | MINimum RIGHT speed | 0 to 65% | 69 | 69 |
| | MAXimum RIGHT speed | 0 to 100% | 90 | 90 |
| | Medium Speed | 0.01 to 1.00 | 0.30 | 0.30 |
| | Engine RPM | 800 to 2900 | 1800 | 1800 |

Table 6-8. Machine Personality Settings

| FUNCTION | PERSONALITY | RANGE | DEFAULTS-800S | DEFAULTS-860SJ |
|------------------|-----------------------------|--------------|---------------|----------------|
| | | | | |
| JIB LIFT | Lift ACCELeration | 0.1 to 5.0s | N/A | 3.3 |
| | Lift DECELeration | 0.1 to 3.0s | N/A | 0.8 |
| | MINimum UP speed | 0 to 65% | N/A | 43 |
| | MAXimum UP speed | 0 to 100% | N/A | 80 |
| | MINimum down | 0 to 65% | N/A | 40 |
| | MAXimum Down | 0 to 100% | N/A | 75 |
| | Medium Speed | 0.01 to 1.00 | N/A | 0.60 |
| | Engine RPM | 800 to 2900 | N/A | 1800 |
| | <u> </u> | | <u> </u> | |
| GROUND MODE | Tower LIFT UP speed | 0 to 100% | N/A | N/A |
| | Tower LIFT DOWN speed | 0 to 100% | N/A | N/A |
| | Main LIFT UP speed | 0 to 100% | 63 | 63 |
| | Main LIFT DOWN speed | 0 to 100% | 63 | 63 |
| | SWING speed | 0 to 100% | 64 | 64 |
| | Main TELEscope speed | 0 to 100% | 62 | 62 |
| | Tower TELEscope speed | 0 to 100% | N/A | N/A |
| | BASKET ROTATE speed | 0 to 100% | 89 | 89 |
| | BASKET LEVEL speed | 0 to 100% | 99 | 99 |
| | Jib LIFT (UP/DOWN) speed | 0 to 100% | N/A | 79 |
| | Jib LIFT (LEFT/RIGHT) speed | 0 to 100% | N/A | N/A |
| | <u> </u> | | <u> </u> | |
| EXTENDABLE AXLES | REAR Axle Extend | 0 to 100% | N/A | N/A |
| | REAR Axle Retract | 0 to 100% | N/A | N/A |
| | REAR Jack Extend | 0 to 100% | N/A | N/A |
| | REAR Jack Retract | 0 to 100% | N/A | N/A |
| | FRONT Axle Extend | 0 to 100% | N/A | N/A |
| | FRONT Axle Retract | 0 to 100% | N/A | N/A |
| | FRONT Jack Extend | 0 to 100% | N/A | N/A |
| | FRONT Jack Retract | 0 to 100% | N/A | N/A |
| | Engine RPM | 800 to 2900 | N/A | N/A |

6-34 3121139

6.3 MACHINE ORIENTATION WHEN DOING SPEED TESTS

Lift: Telescope Retracted. Lift Up, Record Time, Lift Down, Record Time.

Swing: Boom at Full Elevation. Telescope Retracted. Swing the Turntable 360 degrees, Record Time. Swing the Opposite Direction, Record Time.

Telescope: Boom at Full Elevation; Telescope Retracted; Telescope Out, Record Time. Telescope In, Record Time.

Drive (Forward/Reverse): Test should be done on a smooth level surface. Drive Select Switch should be set to High Engine. Results should be recorded for a 200 ft. course. Drive Forward, Record Time. Drive Reverse, Record Time.

Drive (Elevated): Test should be done on a smooth level surface. Drive Select Switch should be set to High Engine. Results should be recorded for a 50 ft. course. Drive Forward, Record Time. Drive Reverse, Record Time.

Platform Rotate: Platform level and completely rotated one direction. Rotate the opposite direction, Record Time. Rotate the other direction, Record Time.

Articulating Jib: Platform level and centered with the boom. Start with the Jib down. Jib Up, Record Time. Jib Down, Record Time.

Test Notes

- 1. Stop watch should be started with the function, not with the controller or switch.
- **2.** All speed tests are run from the platform. These speeds do not reflect the ground control operation.
- **3.** The platform speed knob control must be at full speed (turned clockwise completely).
- **4.** Function speeds may vary due to cold, thick hydraulic oil. Test should be run with the oil temperature above 100° F (38° C).
- **5.** Some flow control functions may not work with the speed knob clicked into the creep position.

Table 6-9. Function Speeds (In Seconds)

| Function | 800S | 860SJ | | | | |
|---|----------------|---------------|--|--|--|--|
| Lift Up | 59-75 | 56-73 | | | | |
| Lift Down | 57-75 | 56-75 | | | | |
| Swing Right & Left* | 110-135 | 110-135 | | | | |
| NOTE: No more than 10% difference swing right. | ence between s | wing left and | | | | |
| Telescope Out | 59-65 | 56-65 | | | | |
| Telescope In | 45-57 | 44-60 | | | | |
| Platform Rotate Right & Left** | 18-30 | 18-30 | | | | |
| NOTE: No more than 15% different rotate right. | | | | | | |
| Jib Up | N/A | 33-47 | | | | |
| Jib Down | N/A | 29-39 | | | | |
| Drive (Forward) | 33-45 | 33-45 | | | | |
| Drive (Reverse) | 33-45 | 33-45 | | | | |
| Drive (Elevated) | 46-75 | 46-75 | | | | |

6.4 CANBUS COMMUNICATIONS

CANbus: CAN (Control Area Network) is a two wire differential serial link between the Platform Module, Jib Module, Ground Module, Boom Length Angle Module and the Chassis Module providing bi-directional communications.

Two-wire: One wire (red) is driven high (5v) and the other low (black) (0v) to send a signal; both wires "float" (2.5v) when no signal is being sent.

Differential: Any electrical line noise can affect the high or the low wires but never both, so communications is not corrupted.

Serial Link: Messages are being sent bit by bit along the wires; the high bus speed allow all modules to be constantly updated around 20 times per second. Typical traffic is 300 - 500 messages per second.

A complete CANbus circuit is approximately 60 ohms, which can be verified at the "T" fitting inside the ground station or below the BLAM. Each individual circuit from the modules is approximately 120 ohms.

The GROUND MODULE (UGM) is the master system controller. Most functions are dispatched and coordinated from this module. The PLATFORM MODULE handle sub-tasks. All characterized information (values) are stored into the ground module (i.e., Personalities or Calibrations).

Interlocks: Any device that sends an electrical input. (For an example a limit switch, proximity switch, etc).


Platform Level: The GROUND MODULE stores the default values and handles interlocks. The PLATFORM MODULE reads the sensors mounted on the platform assembly and controls the Level Up / Down valves to maintain setpoint sent from the GROUND MODULE.

Steer: The GROUND MODULE stores crack points and sends desired drive direction, steering mode and axle extend/retract commands. The PLATFORM MODULE reports the steering switch position to the GROUND MODULE.

Drive: The GROUND MODULE stores crack points, sends commands for each drive pump. (Command is computed from drive joystick input, interlocks, wheel angle, etc).

Lift, Tele, & Swing: The GROUND MODULE stores default values and handles interlocks and calibration information. Lift, Telescope and Swing commands are dependent upon interlocks through out the machine. Boom angle, length and swing are controlled by the GROUND MODULE.

6-36 3121139



NOTE: Some screens may not be available depending upon machine configuration

Figure 6-3. Analyzer Flow Chart, Prior to Version 5.X Software - Sheet 1 of 4

3121139 6-37




Figure 6-4. Analyzer Flow Chart, Prior to Version 5.X Software - Sheet 2 of 4

6-38 3121139




Figure 6-5. Analyzer Flow Chart, Prior to Version 5.X Software - Sheet 3 of 4





Figure 6-6. Analyzer Flow Chart, Prior to Version 5.X Software - Sheet 4 of 4

6-40 3121139



NOTE: Some screens may not be available depending upon machine configuration.

Figure 6-7. Analyzer Flow Chart, Version 5.X Software - Sheet 1 of 4

| PERSONALITIES: SWING | | | | | | | |
|----------------------|-----------------|------------------|-----------------|------------------|----------------|----------------------------------|-----------------|
| PERSONALITIES: | PERSONALITIES: | PERSONALITIES: | PERSONALITIES: | PERSONALITIES: | PERSONALITIES: | PERSONALITIES: | PERSONALITIES: |
| TOWER LIFT | MAIN TELESCOPE | TOWER TELESCOPE | PLATFORM LEVEL | PLATFORM ROTATE | JIB LIFT | GROUND MODE | GEN SET/WELDER |
| TOWER LIFT: | MAIN TELESCOPE: | TOWER TELESCOPE: | PLATFORM LEVEL: | PLATFORM ROTATE: | JIB LIFT: | GROUND MODE: | GEN SET/WELDER: |
| ACCEL X.XS | ACCEL X.XS | ACCEL X.XS | ACCEL X.XS | ACCEL X.XS | ACCEL X.XS | MAIN UP: XXX% | ENGINE 1800 RPM |
| TOWER LIFT: | MAIN TELESCOPE: | TOWER TELESCOPE: | PLATFORM LEVEL: | PLATFORM ROTATE: | JIB LIFT: | GROUND MODE: | |
| DECEL X.XS | DECEL X.XS | DECEL X.XS | DECEL X.XS | DECEL X.XS | DECEL X.XS | MAIN DOWN: XXX% | |
| TOWER LIFT: | MAIN TELESCOPE: | TOWER TELESCOPE: | PLATFORM LEVEL: | PLATFORM ROTATE: | JIB LIFT: | GROUND MODE: | |
| MIN UP X% | MIN IN X% | MIN IN X% | MIN UP X% | MIN LEFT X% | MIN UP X% | SWING: XX% | |
| TOWER LIFT: | MAIN TELESCOPE: | TOWER TELESCOPE: | PLATFORM LEVEL: | PLATFORM ROTATE: | JIB LIFT: | GROUND MODE: | |
| MAX UP X% | MAX IN X% | MAX IN X% | MAX UP X% | MAX LEFT X% | MAX UP X% | PLT LEVEL: XXX% | |
| TOWER LIFT: | MAIN TELESCOPE: | TOWER TELESCOPE: | PLATFORM LEVEL: | PLATFORM ROTATE: | JIB LIFT: | GROUND MODE: | |
| MIN DOWN X% | MIN OUT X% | MIN OUT X% | MIN DOWN X% | MIN RIGHT X% | MIN DOWN X% | PLT ROTATE: XXX% | |
| TOWER LIFT: | MAIN TELESCOPE: | TOWER TELESCOPE: | PLATFORM LEVEL: | PLATFORM ROTATE: | JIB LIFT: | GROUND MODE: | |
| MAX DOWN X% | MAX OUT X% | MAX OUT X% | MAX DOWN X% | MAX RIGHT X% | MAX DOWN X% | MAIN TELE: XXX% | |
| | | | | | | GROUND MODE: TOWER TELE: XXX% | |
| | | | | | | GROUND MODE: TOWER UP: XXX% | |
| | | | | | | GROUND MODE: TOWER DOWN: XXX% | |
| | | | | | | GROUND MODE: JIB LIFT: XXX% | |

Figure 6-8. Analyzer Flow Chart, Version 5.X Software - Sheet 2 of 4

6-42 3121139




Figure 6-9. Analyzer Flow Chart, Version 5.X Software - Sheet 3 of 4




Figure 6-10. Analyzer Flow Chart, Version 5.X Software - Sheet 4 of 4

6-44 3121139





Figure 6-11. Fault Code Light and module Location



PLATFORM CONNECTION



GROUND CONTROL CONNECTION

Figure 6-12. Analyzer Connecting Points

6-46 3121139




Figure 6-13. Ground Control Module - Sheet 1 of 3




Figure 6-14. Ground Control Module - Sheet 2 of 3

6-48 3121139




Figure 6-15. Ground Control Module - Sheet 3 of 3




Figure 6-16. Platform Control Module - Sheet 1 of 2

6-50 3121139




Figure 6-17. Platform Control Module - Sheet 2 of 2

Analyzer Diagnostics Menu Structure

In the following structure descriptions, an intended item is selected by pressing ENTER; pressing ESC steps back to the next outer level. The LEFT /RIGHT arrow keys




Table 6-10. ADJUSTMENTS - Personality Descriptions

| DRIVE | |
|--------------|--|
| ACCEL | Displays/adjusts drive acceleration |
| DECEL | Displays/adjusts drive deceleration |
| MINFORWARD | Displays/adjusts minimum forward drive speed |
| MAXFORWARD | Displays/adjusts maximum forward drive speed |
| MINREVERSE | Displays/adjusts minimum reverse drive speed |
| MAX REVERSE | Displays/adjusts maximum reverse drive speed |
| ELEVATED MAX | Displays/adjusts maximum drive speed NOTE: used when elevation cutout switches are limiting maximum speed |
| CREEP MAX | Displays/adjusts maximum drive speed NOTE: used when creep switch on pump pot is active |
| STEERMAX | Displays/adjusts the maximum steer speed |
| LIFT | |
| ACCEL | Displays/adjusts upper lift acceleration |
| DECEL | Displays/adjusts upper lift deceleration |
| MINUP | Displays/adjusts minimum upper lift up speed |
| MAXUP | Displays/adjusts maximum upper lift up speed |
| CREEP UP | Displays/adjusts maximum upper lift up speed NOTE: used when creep switch on pump pot is active |
| MINDOWN | Displays/adjusts minimum upper lift down speed |
| MAXDOWN | Displays/adjusts maximum upper lift down speed |
| CREEP DOWN | Displays/adjusts maximum upper lift down speed NOTE: used when creep switch on pump pot is active |
| SWING | |
| ACCEL | Displays/adjusts swing acceleration |
| DECEL | Displays/adjusts swing deceleration |
| MINLEFT | Displays/adjusts minimum swing left speed |
| MAXLEFT | Displays/adjusts maximum swing left speed |

6-52 3121139

Table 6-10. ADJUSTMENTS - Personality Descriptions

| CREEPLEFT | Displays/adjusts maximum swing left speed NOTE: used when creep switch on pump pot is active |
|---------------|--|
| MINRIGHT | Displays/adjusts minimum swing right speed |
| MAXRIGHT | Displays/adjusts maximum swing right speed |
| CREEP RIGHT | Displays/adjusts maximum swing right speed NOTE: used when creep switch on pump pot is active |
| MAINTELESCOPE | |
| ACCEL | Displays/adjusts telescope acceleration |
| DECEL | Displays/adjusts telescope deceleration |
| MININ | Displays/adjusts minimum telescope in speed |
| MAXIN | Displays/adjusts maximum telescope in speed |
| MINOUT | Displays/adjusts minimum telescope out speed |
| MAXOUT | Displays/adjusts maximum telescope out speed |
| BASKETLEVEL | |
| ACCEL | Displays/adjusts basket level acceleration |
| DECEL | Displays/adjusts basket level deceleration |
| MINUP | Displays/adjusts minimum basket level up speed |
| MAXUP | Displays/adjusts maximum basket level up speed |
| MIN DOWN | Displays/adjusts minimum basket level down speed |
| MAXDOWN | Displays/adjusts maximum basket level down speed |
| BASKET ROTATE | |
| ACCEL | Displays/adjusts basket rotate acceleration |
| DECEL | Displays/adjusts basket rotate deceleration |
| MINLEFT | Displays/adjusts minimum basket rotate left speed |
| MAXLEFT | Displays/adjusts maximum basket rotate left speed |
| MIN RIGHT | Displays/adjusts minimum basket rotate right speed |
| MAXRIGHT | Displays/adjusts maximum basket rotate right speed |
| JIBLIFT | Not displayed if JIB = NO |
| ACCEL | Displays/adjusts jib acceleration |
| DECEL | Displays/adjusts jib deceleration |
| MINUP | Displays/adjusts minimum jib up speed |
| MAXUP | Displays/adjusts maximum jib up speed |
| MIN DOWN | Displays/adjusts minimum jib down speed |
| | |

Table 6-10. ADJUSTMENTS - Personality Descriptions

| MAXDOWN | Displays/adjusts maximum jib down speed | |
|--------------|--|--|
| MINLEFT | Displays/adjusts minimum jib left speed | |
| MAXLEFT | Displays/adjusts maximum jib left speed | |
| MINRIGHT | Displays/adjusts minimum jib right speed | |
| MAXRIGHT | Displays/adjusts maximum jib right speed | |
| STEER | | |
| MAXSPEED | Displays/adjusts maximum steer speed, which applies when vehicle speed is at minimum | |
| GROUND MODE | | |
| LIFTUP | Displays/adjusts fixed lift up speed | |
| LIFT DOWN | Displays/adjusts fixed lift down speed | |
| SWING | Displays/adjusts fixed swing speed | |
| TELE | Displays/adjusts fixed telescope speed | |
| BASKETLEVEL | Displays/adjusts fixed basket level speed | |
| BASKETROTATE | Displays/adjusts fixed basket rotate speed | |
| JIB (U/D) | Displays/adjusts jib lift speed Not displayed if JIB = NO | |
| JIB (L/R) | Displays/adjusts jib swing speed Not displayed if JIB = NO | |

6-54 3121139

Table 6-11. Diagnostic Menu Descriptions

| Page 6-11. Diagnostic Menu Descriptions | | | | | |
|---|---|--|--|--|--|
| DRIVE | | | | | |
| DRIVEFOR | Displays drive joystick direction & demand | | | | |
| STEER | Displays steer switch direction & demand NOTE: steer demand is inversely proportional to vehicle speed | | | | |
| BRAKES | Displays brake control system status | | | | |
| CREEP | Displays pump pot creep switch status | | | | |
| TWO SPEED | Displays two speed switch status | | | | |
| 2 SPEED MODE | Displays status of two speed valve | | | | |
| HIGHENGINE | Displays high engine switch status | | | | |
| воом | | | | | |
| ULIFTUP | Displays lift joystick direction & demand | | | | |
| SWING LEFT | Displays swing joystick direction & demand | | | | |
| LEVEL UP | Displays basket level switch direction & demand NOTE: demand is controlled by the pump pot | | | | |
| ROT. LEFT | Displays basket rotate switch direction & demand NOTE: demand is controlled by the pump pot | | | | |
| UTELEIN | Displays telescope switch direction & demand NOTE: demand is controlled by the pump pot | | | | |
| JIBUP | Displays jib lift switch direction & demand NOTE: demand is controlled by the pump pot Not displayed if JIB = NO | | | | |
| JIBLEFT | Displays jib swing switch direction & demand NOTE: demand is controlled by the pump pot Not displayed if JIB = NO | | | | |
| PUMP POT | Displays pump pot demand | | | | |
| ENGINE | | | | | |
| START | Displays start switch status | | | | |
| AIRFILTER | Displays air filter status | | | | |
| BATTERY | Displays measured battery voltage | | | | |
| COOLANT | Displays coolant temperature | | | | |
| OIL PRS | Displays oil pressure status | | | | |
| FUEL SELECT | Displays selected fuel (Dual Fuel only) | | | | |
| FUELLEVEL | Displays fuel level status | | | | |
| RPM | Displays Engine RPM | | | | |
| GM BATTERY | Displays battery voltage at ground module | | | | |
| | | | | | |

Table 6-11. Diagnostic Menu Descriptions

| PM BATTERY | Displays battery voltage at platform module | | | | |
|-------------------|--|--|--|--|--|
| TEMP | Displays ground module temperature | | | | |
| ELEV.CUTOUT | Displays elevation cutout switch status | | | | |
| FUNC. CUTOUT | Displays function cutout switch status | | | | |
| CREEP | Displays creep switch status | | | | |
| TILT | Displays measured vehicle tilt | | | | |
| AUX POWER | Displays status of auxiliary power switch | | | | |
| HORN | Displays status of horn switch | | | | |
| RFILTER | Displays status of return filter switch | | | | |
| CFILTER | Displays status of charge pump filter | | | | |
| LOAD LENGTH | Displays length switch status | | | | |
| ANGLE | Displays angle switch status | | | | |
| LOAD | Displays load sensor value NOTE: Not displayed if load = 0. | | | | |
| DATALOG | | | | | |
| ON | Displays total controller on (EMS) time | | | | |
| ENGINE | Displays engine run time | | | | |
| DRIVE | Displays total controller drive operation time | | | | |
| LIFT | Displays total controller lift operation time | | | | |
| SWING | Displays total controller swing operation time | | | | |
| TELE | Displays total controller tele operation time | | | | |
| MAX.TEMP | Displays maximum measured heatsink temp. | | | | |
| MIN.TEMP | Displays minimum measured heatsink temp. | | | | |
| MAX.VOLTS | Displays maximum measured battery voltage | | | | |
| RENTAL | Displays total controller operation time NOTE: can be reset | | | | |
| ERASE RENTAL | Not available at password level 2 | | | | |
| YES:ENTER, NO:ESC | ENTER resets rental datalog time to zero | | | | |
| VERSIONS | | | | | |
| GROUND | Displays ground module software version | | | | |
| PLATFORM | Displays platform module software version | | | | |
| ANALYSER | Displays Analyzer software version | | | | |

6-56 3121139

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC | Flash Code | Sequence | Fault Message | Fault Description | Check |
|------|------------|----------|--|--|--|
| 001 | 00 | 1 | EVERYTHING OK | The normal help message in Platform Mode. | No response required for this DTC. |
| 002 | 00 | 2 | GROUND MODE OK | The normal help message in Platform Mode. | No response required for this DTC. |
| 0010 | 00 | 10 | RUNNING AT CUTBACK - OUT OF TRANSPORT POSITION | Drive speed is limited to "ELEVATED MAX" while the vehicle is out of transport position. The normal help message in Ground Mode. | Response described in Drive Modes section. |
| 000 | 00 | 0 | <<< HELP COMMENT>>> | | |
| 0011 | 00 | 11 | FSW OPEN (Foot switch open) | A drive / boom function was selected with the Footswitch open. | The UGM shall not Enable the Machine. |
| 0012 | 00 | 12 | RUNNING AT CREEP - CREEP SWITCH OPEN | All functions at creep while the Creep Switch is open. | The UGM shall limit the machine to Creep speed. |
| 0013 | 00 | 13 | RUNNING AT CREEP - TILTED AND ABOVE ELEVATION | All functions at creep while the Platform is elevated and the Chassis is tilted. | |
| 0014 | 00 | 14 | CHASSIS TILT SENSOR OUT OF RANGE | The Chassis is tilted > 19 degrees for more then 4 seconds. | Not reported during power- up. |
| 0015 | 00 | 15 | LOAD SENSOR READING UNDER WEIGHT | The Load Sensing System indicates > 20% under calibrated zero point. | |
| 0031 | 00 | 31 | FUEL LEVEL LOW - ENGINE SHUTDOWN | Engine Shutdown has occurred due to Fuel Level = EMPTY condition. | Response described in Fuel Shutdown section. |
| 0035 | 00 | 35 | APU ACTIVE | Auxiliary Power/Emergency Descent Mode is active. | Response described in Auxiliary Power/Emergency Descent Mode section. |
| 0039 | 00 | 39 | SKYGUARD ACTIVE-FUNCTIONS CUTOUT | Response described in Auxiliary Power/ Emergency Descent Mode section. | Response described in Sky- Guard section. |
| 0040 | 00 | 40 | RUNNING AT CREEP - CREEP SWITCH CLOSED | All Function speeds are limited to creep because the creep switch is closed. | |
| 210 | 21 | 0 | <<< POWER-UP>>> | | |
| 211 | 21 | 1 | POWERCYCLE | The normal help message is issued at each power cycle. | |
| 212 | 21 | 2 | KEYSWITCH FAULTY | Both Platform and Ground modes are selected simultaneously. | The UGM shall assume a station selection of Ground. |
| 213 | 21 | 3 | FSWFAULTY | Both Footswitches are closed for more then one second. | The UGM shall not Enable the Machine. |
| 220 | 22 | 0 | <<< PLATFORM CONTROLS >>> | | |
| 227 | 22 | 7 | STEER SWITCHES FAULTY | Both Steer Left and Steer Right inputs are closed simultaneously. | The UGM shall prohibit Steer; The UGM shall limit Drive to Creep The Steer Left switch input = Low; The Steer Right switch input = Low; Steer and full Drive speed permitted after controls are initialized. |
| 2211 | 22 | 11 | FSW INTERLOCK TRIPPED | The Footswitch was closed for more then seven seconds. | Can be reported during power- up. |

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC | Flash Code | Sequence | Fault Message | Fault Description | Check |
|------|------------|----------|---|--|---|
| 2212 | 22 | 12 | DRIVE LOCKED - JOYSTICK MOVED BEFORE FOOTSWITCH | A drive function was selected with Footswitch open. | Can be reported during power-up. |
| 2213 | 22 | 13 | STEER LOCKED - SELECTED BEFORE FOOTSWITCH | A steer function was selected with Footswitch open. | The UGM shall not Enable the Machine. |
| 2214 | 22 | 14 | DRIVE/STEER LOCKED - JOYSTICK MOVED BEFORE ENABLE | Drive/Steer was selected before Enable switch activated. | |
| 2216 | 22 | 16 | D/S JOY. OUT OF RANGE HIGH | The D/S Joystick reference voltage is > 8.1V. | Resistive joysticks. If the reference voltage is > 7.7V then the reference voltage is out of tolerance of a short to battery has occurred. |
| 2217 | 22 | 17 | D/S JOY. CENTER TAP BAD | The D/S Joystick center tap voltage is <3.08V or > 3.83V. | Resistive joysticks There is a +/1V range. around these values due to resistor tolerances. |
| 2219 | 22 | 19 | L/SJOY. OUT OF RANGE HIGH | The L/S Joystick reference voltage is > 8.1V. | Resistive joysticks If the reference voltage is > 7.7V then the reference voltage is out of tolerance of a short to battery has occurred. |
| 2220 | 22 | 20 | L/SJOY. CENTER TAP BAD | The L/S Joystick center tap voltage is < 3.08V or > 3.83V. | Resistive joysticks There is a +/1V range. around these values due to resistor tolerances. |
| 2221 | 22 | 21 | LIFT/SWING LOCKED - JOYSTICK MOVED BEFORE FOOTSWITCH | A lift / swing function was selected with Footswitch open. | If triggered by the Lift and/or Swing joystick not being in the neutral position at Startup, the UGM shall prohibit Lift and Swing. If triggered by Lift and/or Swing joystick is not in the neutral position when Footswitch becomes active or while DTC 2212, 2213 or 2223 is active, the UGM shall not Enable the Machine. |
| 2222 | 22 | 22 | WAITING FOR FSW TO BE OPEN | The Footswitch was closed during Platform selection. | Can be reported during power- up. |
| 2223 | 22 | 23 | FUNCTION SWITCHES LOCKED - SELECTED BEFORE ENABLE | A boom function was selected with Footswitch open. | The UGM shall not Enable the Machine. |
| 2224 | 22 | 24 | FOOTSWITCH SELECTED BEFORE START | The Footswitch was closed during engine start. | The UGM shall prohibit Engine Start. |
| 2269 | 22 | 69 | FUNCTION PROBLEM - HIGH SPEED & CREEP ACTIVE TOGETHER | | |

6-58 3121139

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC | Flash Code | Sequence | Fault Message | Fault Description | Check |
|-------|------------|----------|---|--|---|
| 234 | 23 | 4 | FUNCTION SWITCHES FAULTY - CHECK DIAGNOSTICS/BOOM | A boom function has both directions selected together. | Disable whichever boom functions whose boom control inputs are triggering the fault. If Engine Start/Aux at fault, disable Engine Start but per- mit Auxiliary Power/ Emergency Descent. |
| 235 | 23 | 5 | FUNCTION SWITCHES LOCKED - SELECTED BEFORE AUX POWER | A boom function was selected before aux power. | |
| 236 | 23 | 6 | FUNCTION SWITCHES LOCKED - SELECTED BEFORE START SWITCH | A boom function was selected before engine start. | |
| 237 | 23 | 7 | START SWITCH LOCKED - SELECTED BEFORE KEYSWITCH | The Start Switch was closed during power- up. | The UGM shall prohibit Engine Start. |
| 23163 | 23 | 163 | FUNCTION PROBLEM - MSSO PERMANENTLY SELECTED | The MSSO switch input = Low at Startup. | No response required for this DTC Power Cycled. |
| 240 | 24 | 0 | << <other controls="">>></other> | | |
| 241 | 24 | 1 | AMBIENT TEMPERATURE SENSOR - OUT OF RANGE LOW | MACHINE SETUP > TEMP CUTOUT = YES; Ambient Temperature sensor reading - 50C. | The UGM shall set Low Temperature Cutout state = Faulty If the Machine is in Platform Mode and if the Boom is Above Elevation; The UGM shall suspend motion; If the Machine is in Ground Mode; No response required for this DTC. |
| 242 | 24 | 2 | AMBIENT TEMPERATURE SENSOR - OUT OF RANGE HIGH | Ambient Temperature sensor reading ≥ 85C. | Check Ambient Temperature sensor reading < 85C. |
| 250 | 25 | 0 | <<< FUNCTION PREVENTED >>> | | |
| 259 | 25 | 9 | MODEL CHANGED - HYDRAULICS SUSPENDED - CYCLEEMS | The model selection has been changed. | Disable all machine and engine functions (i.e., command engine shutdown and do not permit start). |
| 2513 | 25 | 13 | GENERATOR MOTION CUTOUT ACTIVE | Driving is not possible while the vehicle generator is running AND is configured to prevent drive. | The UGM shall not Enable the Machine. |
| 2514 | 25 | 14 | BOOM PREVENTED - DRIVE SELECTED | Boom functions are not possible while the vehicle is being driven AND is configured to not allow simultaneous drive & boom operation. | The UGM shall prohibit all boom functions. |
| 2516 | 25 | 16 | DRIVE PREVENTED - ABOVE ELEVATION | Driving is not possible while Boom functions are selected AND is configured to not allow simultaneous drive & boom operation. | The UGM shall prohibit Drive and Steer. |
| 2517 | 25 | 17 | DRIVE PREVENTED - TILTED & ABOVE ELEVATION | Driving is not possible while the vehicle is tilted and above elevation AND is configured to prevent drive while tilted and above elevation. | The UGM shall prohibit Drive and Steer. |

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC | Flash Code | Sequence | Fault Message | Fault Description | Check |
|------|------------|----------|---|---|---|
| 2518 | 25 | 18 | DRIVE PREVENTED - BOOM SELECTED | MACHINE SETUP > FUNCTION CUTOUT = BOOM CUTOUT The boom is Above Elevation Any boom function is already active The operator attempts to activate Drive or Steer. | The UGM shall prohibit Drive and Steer. |
| 2519 | 25 | 19 | DRIVE PREVENTED - TILTED & EXTENDED OR HIGH ANGLE | Drive Selected while tilted and extended and tilt is configured to cutout drive. | |
| 2520 | 25 | 20 | FUNCTIONS LOCKED OUT - CONSTANT DATA VERSION IMPROPER | | |
| 2530 | 25 | 30 | UMS SENSOR FORWARD LIMIT REACHED | The Upright angle relative to the turntable is less than -4.0 degree. | |
| 2531 | 25 | 31 | UMS SENSOR OUT OF USABLE RANGE | Both the turntable tilt sensor and the UMS sensor read greater then +/-10 degree in the same direction. | |
| 2532 | 25 | 32 | UMS SENSOR BACKWARD LIMIT REACHED | The Upright angle relative to the turntable is greater than +2.5 degree. | |
| 2563 | 25 | 63 | SKYGUARD SWITCH - DISAGREEMENT | MACHINE SETUP > SKYGUARD = YES; Machine is in Platform Mode; [(SkyGuard input #1 Platform Module J7- 18) ≠ (SkyGuard input #2 Platform Module J1-23)] > 160ms | Response detailed in Sky- Guard section. |
| 2568 | 25 | 68 | TEMPERATURE CUTOUT ACTIVE - AMBIENT TEMPERATURE TOO LOW | Low Temperature Cutout = Active | If the Boom is Above Elevation; The UGM shall suspend motion; The UGM shall limit the machine to Creep speed after controls initialized If the Machine is in Platform Mode and if the Boom is not Above Elevation. |
| 2576 | 25 | 76 | PLATFORM LEVEL PREVENTED - ABOVE ELEVATION | Platform Level Override Cutout = Enabled; The Platform Level Up or Down switch input = High; Footswitch is active. | The UGM shall suspend Plat- form Level Up and Down commands; The UGM shall prohibit Plat- form Level Up and Down |
| 2577 | 25 | 77 | DRIVE PREVENTED - START BATTERY CONNECTED | Start battery is connected | Check the battery. |
| 330 | 33 | 0 | <<< GROUND OUTPUT DRIVER>>> | | |
| 331 | 33 | 1 | BRAKE - SHORT TO BATTERY | There is a Short to Battery to the Brake Valve. | Check Harness for damage. |
| 332 | 33 | 2 | BRAKE-OPEN CIRCUIT | There is an Open Circuit to the Brake Valve. | Check Harness for damage. |
| 3311 | 33 | 11 | GROUND ALARM - SHORT TO BATTERY | There is a Short to Battery to the Ground Alarm. | Ground Alarm equipped vehicles only. |
| 3336 | 33 | 36 | ALTERNATOR POWER - SHORT TO GROUND | There is a Short to Ground to the Alternator/ECM. | Check Harness for damage. |
| 3340 | 33 | 40 | AUX POWER - SHORT TO GROUND | There is a Short to Ground to the Auxiliary Power Pump Relay. | Check Harness for damage. |
| 3341 | 33 | 41 | AUX POWER - OPEN CIRCUIT | There is an Open Circuit to the Auxiliary Power Pump Relay. | Check Harness for damage. |
| 3342 | 33 | 42 | AUX POWER - SHORT TO BATTERY | There is a Short to Battery to the Auxiliary Power Pump Relay. | Check Harness for damage. |

6-60 3121139

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC | Flash Code | Sequence | Fault Message | Fault Description | Check |
|------|------------|----------|-------------------------------------|--|---------------------------|
| 3346 | 33 | 46 | ELECTRIC FAN - SHORT TO GROUND | There is a short to ground to the Electric Fan. | Check Harness for damage. |
| 3347 | 33 | 47 | ELECTRIC FAN - OPEN CIRCUIT | There is an Open Circuit to the Electric Fan. | Check Harness for damage. |
| 3348 | 33 | 48 | ELECTRICFAN - SHORT TO BATTERY | There is a Short to Battery to the Electric Pump. | Check Harness for damage. |
| 3349 | 33 | 49 | ELECTRIC PUMP - SHORT TO GROUND | There is a Short to Ground to the Pump Relay. | Check Harness for damage. |
| 3350 | 33 | 50 | ELECTRIC PUMP - OPEN CIRCUIT | There is an Open Circuit to the Pump Relay. | Check Harness for damage. |
| 3351 | 33 | 51 | ELECTRIC PUMP - SHORT TO BATTERY | There is a Short to Battery to the Pump Relay. | Check Harness for damage. |
| 3352 | 33 | 52 | LPLOCK-SHORT TO GROUND | There is an Open Circuit to the LP Lock. | Check Harness for damage. |
| 3353 | 33 | 53 | LPLOCK-OPEN CIRCUIT | There is an Open Circuit to the LP Lock. | Check Harness for damage. |
| 3354 | 33 | 54 | LP LOCK - SHORT TO BATTERY | There is a short to Battery to the LP Lock. | Check Harness for damage. |
| 3355 | 33 | 55 | LP START ASSIST - SHORT TO GROUND | There is a short to ground to the LP Start Assist. | Check Harness for damage. |
| 3356 | 33 | 56 | LP START ASSIST - OPEN CIRCUIT | There is an Open Circuit to the LP Start Assist. | Check Harness for damage. |
| 3357 | 33 | 57 | LP START ASSIST - SHORT TO BATTERY | There is a short to battery to the LP Start Assist. | Check Harness for damage. |
| 3358 | 33 | 58 | MAIN DUMP VALVE - SHORT TO GROUND | There is a Short to Ground to the Main Dump Valve. | Check Harness for damage. |
| 3359 | 33 | 59 | MAIN DUMP VALVE - OPEN CIRCUIT | There is an Open Circuit to the Main Dump Valve. | Check Harness for damage. |
| 3360 | 33 | 60 | MAIN DUMP VALVE - SHORT TO BATTERY | There is a Short to Battery to the Main Dump Valve. | Check Harness for damage. |
| 3361 | 33 | 61 | BRAKE-SHORT TO GROUND | There is a Short to Ground to the Brake Valve. | Check Harness for damage. |
| 3362 | 33 | 62 | START SOLENOID - SHORT TO GROUND | There is a Short to Ground to the Start Relay. | Check Harness for damage. |
| 3363 | 33 | 63 | START SOLENOID - OPEN CIRCUIT | There is an Open Circuit to the Start Relay. | Check Harness for damage. |
| 3364 | 33 | 64 | START SOLENOID - SHORT TO BATTERY | There is a Short to Battery to the Start Relay. | Check Harness for damage. |
| 3365 | 33 | 65 | STEER DUMP VALVE - SHORT TO GROUND | There is a Short to Ground to the Steer Dump Valve. | Check Harness for damage. |
| 3366 | 33 | 66 | STEER DUMP VALVE - OPEN CIRCUIT | There is an Open Circuit to the Steer Dump Valve. | Check Harness for damage. |
| 3367 | 33 | 67 | STEER DUMP VALVE - SHORT TO BATTERY | There is a Short to Battery to the Steer Dump Valve. | Check Harness for damage. |
| 3368 | 33 | 68 | TWO SPEED VALVE - SHORT TO GROUND | There is a Short to Ground to the Two Speed Valve. | Check Harness for damage. |
| 3369 | 33 | 69 | TWO SPEED VALVE - OPEN CIRCUIT | There is an Open Circuit to the Two Speed Valve. | Check Harness for damage. |
| 3370 | 33 | 70 | TWO SPEED VALVE - SHORT TO BATTERY | There is a Short to Battery to the Two Speed Valve. | Check Harness for damage. |

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC | Flash Code | Sequence | Fault Message | Fault Description | Check |
|-------|------------|----------|--|---|---------------------------|
| 3371 | 33 | 71 | GROUND ALARM - SHORT TO GROUND | There is a Short to Ground to the Ground Alarm. | Check Harness for damage. |
| 3372 | 33 | 72 | GROUND ALARM - OPEN CIRCUIT | There is an Open Circuit to the Ground Alarm. | Check Harness for damage. |
| 3373 | 33 | 73 | GEN SET/WELDER - SHORT TO GROUND | There is a Short to Ground to the Generator Relay. | Check Harness for damage. |
| 3374 | 33 | 74 | GEN SET/WELDER-OPEN CIRCUIT | There is an Open Circuit to the Generator Relay. | Check Harness for damage. |
| 3375 | 33 | 75 | GEN SET/WELDER - SHORT TO BATTERY | There is a Short to Battery to the Generator Relay. | Check Harness for damage. |
| 3376 | 33 | 76 | HEAD TAIL LIGHT - SHORT TO GROUND | There is a Short to Ground to the Head Light Relay. | Check Harness for damage. |
| 3377 | 33 | 77 | HEAD TAIL LIGHT - OPEN CIRCUIT | There is an Open Circuit to the Head Light Relay. | Check Harness for damage. |
| 3378 | 33 | 78 | HEAD TAIL LIGHT - SHORT TO BATTERY | There is a Short to Battery to the Head Light Relay. | Check Harness for damage. |
| 3379 | 33 | 79 | HOUR METER-SHORT TO GROUND | There is a Short to Ground to the Hour Meter. | Check Harness for damage. |
| 3382 | 33 | 82 | PLATFORM LEVEL UP VALVE - SHORT TO GROUND | There is a Short to Ground to the Platform Level Up Valve | Check Harness for damage. |
| 3383 | 33 | 83 | PLATFORM LEVEL UP VALVE - OPEN CIRCUIT | There is an Open Circuit to the Platform Level Up Valve. | Check Harness for damage. |
| 3384 | 33 | 84 | PLATFORM LEVEL UP VALVE - SHORT TO BATTERY | There is a Short to Battery to the Platform Level Up Valve | Check Harness for damage. |
| 3388 | 33 | 88 | PLATFORM LEVEL DOWN VALVE - SHORT TO GROUND | There is a Short to Ground to the Platform Level Down Valve | Check Harness for damage. |
| 3389 | 33 | 89 | PLATFORM LEVEL DOWN VALVE - OPEN CIRCUIT | There is an Open Circuit to the Platform Level Down Valve. | Check Harness for damage. |
| 3390 | 33 | 90 | PLATFORM LEVEL DOWN VALVE - SHORT TO BATTERY | There is a Short to Battery to the Platform Level Down Valve | Check Harness for damage. |
| 3394 | 33 | 94 | PLATFORM ROTATE LEFT VALVE - SHORT TO GROUND | There is a Short to Ground to the Platform Rotate Left Valve. | Check Harness for damage. |
| 3395 | 33 | 95 | PLATFORM ROTATE LEFT VALVE - OPEN CIRCUIT | There is an Open Circuit to the Platform Rotate Left Valve. | Check Harness for damage. |
| 3396 | 33 | 96 | PLATFORM ROTATE LEFT VALVE - SHORT TO BATTERY | There is a Short to Battery to the Platform Rotate Left Valve. | Check Harness for damage. |
| 3397 | 33 | 97 | PLATFORM ROTATE RIGHT VALVE - SHORT TO GROUND | There is a Short to Ground to the Platform Rotate Right Valve. | Check Harness for damage. |
| 3398 | 33 | 98 | PLATFORM ROTATE RIGHT VALVE - OPEN CIRCUIT | There is an Open Circuit to the Platform Rotate Right Valve. | Check Harness for damage. |
| 3399 | 33 | 99 | PLATFORM ROTATE RIGHT VALVE - SHORT TO BATTERY | There is a Short to Battery to the Platform Rotate Right Valve. | Check Harness for damage. |
| 33100 | 33 | 100 | JIB LIFT UP VALVE - SHORT TO GROUND | There is a Short to Ground to the JIB Lift Up Valve. | Check Harness for damage. |
| 33101 | 33 | 101 | JIB LIFT UP VALVE - OPEN CIRCUIT | There is an Open Circuit to the JIB Lift Up Valve. | Check Harness for damage. |
| 33102 | 33 | 102 | JIB LIFT UP VALVE - SHORT TO BATTERY | There is a Short to Battery to the JIB Lift Up Valve. | Check Harness for damage. |

6-62 3121139

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC | Flash Code | Sequence | Fault Message | Fault Description | Check |
|-------|------------|----------|--|---|---------------------------|
| 33103 | 33 | 103 | JIB LIFT DOWN VALVE - SHORT TO GROUND | There is a Short to Ground to the JIB Lift Down Valve. | Check Harness for damage. |
| 33104 | 33 | 104 | JIB LIFT DOWN VALVE-OPEN CIRCUIT | There is an Open Circuit to the JIB Lift Down Valve. | Check Harness for damage. |
| 33105 | 33 | 105 | JIB LIFT DOWN VALVE - SHORT TO BATTERY | There is a Short to Battery to the JIB Lift Down Valve. | Check Harness for damage. |
| 33106 | 33 | 106 | TOWER LIFT UP VALVE - SHORT TO GROUND | There is a Short to Ground to the Tower Lift Up Valve. | Check Harness for damage. |
| 33107 | 33 | 107 | TOWER LIFT UP VALVE - OPEN CIRCUIT | There is an Open Circuit to the Tower Lift Up Valve. | Check Harness for damage. |
| 33108 | 33 | 108 | TOWER LIFT UP VALVE - SHORT TO BATTERY | There is a Short to Battery to the Tower Lift Up Valve. | Check Harness for damage. |
| 33109 | 33 | 109 | TOWER LIFT DOWN VALVE - SHORT TO GROUND | There is a Short to Ground to the Tower Lift Down Valve. | Check Harness for damage. |
| 33110 | 33 | 110 | TOWER LIFT DOWN VALVE - OPEN CIRCUIT | There is an Open Circuit to the Tower Lift Down Valve. | Check Harness for damage. |
| 33111 | 33 | 111 | TOWER LIFT DOWN VALVE - SHORT TO BATTERY | There is a Short to Battery to the Tower Lift Down Valve. | Check Harness for damage. |
| 33112 | 33 | 112 | TOWER TELESCOPE IN VALVE - SHORT TO GROUND | There is a Short to Ground to the Tower Telescope In Valve. | Check Harness for damage. |
| 33113 | 33 | 113 | TOWER TELESCOPE IN VALVE - OPEN CIRCUIT | There is an Open Circuit to the Tower Telescope In Valve. | Check Harness for damage. |
| 33114 | 33 | 114 | TOWER TELESCOPE IN VALVE - SHORT TO BATTERY | There is a Short to Battery to the Tower Telescope In Valve. | Check Harness for damage. |
| 33115 | 33 | 115 | TOWER TELESCOPE OUT VALVE - SHORT TO GROUND | There is a Short to Ground to the Tower Telescope Out Valve. | Check Harness for damage. |
| 33116 | 33 | 116 | TOWER TELESCOPE OUT VALVE - OPEN CIRCUIT | There is an Open Circuit to the Tower Telescope Out Valve. | Check Harness for damage. |
| 33117 | 33 | 117 | TOWER TELESCOPE OUT VALVE - SHORT TO BATTERY | There is a Short to Battery to the Tower Telescope Out Valve. | Check Harness for damage. |
| 33118 | 33 | 118 | SWING RIGHT VALVE - SHORT TO GROUND | There is a Short to Ground to the Swing Right Valve. | Check Harness for damage. |
| 33119 | 33 | 119 | SWING RIGHT VALVE - OPEN CIRCUIT | There is an Open Circuit to the Swing Right Valve. | Check Harness for damage. |
| 33120 | 33 | 120 | TELESCOPE IN VALVE - SHORT TO BATTERY | There is a Short to Battery to the Main Telescope In Valve. | Check Harness for damage. |
| 33121 | 33 | 121 | SWING RIGHT VALVE - SHORT TO BATTERY | There is a Short to Battery to the Swing Right Valve. | Check Harness for damage. |
| 33122 | 33 | 122 | SWING LEFT VALVE - SHORT TO GROUND | There is a Short to Ground to the Swing Left Valve. | Check Harness for damage. |
| 33123 | 33 | 123 | TELESCOPE OUT VALVE - SHORT TO BATTERY | There is a Short to Battery to the Main Telescope Out Valve. | Check Harness for damage. |
| 33130 | 33 | 130 | THROTTLE ACTUATOR - SHORT TO GROUND | There is a Short to Ground to the Throttle Actuator. | Check Harness for damage. |
| 33131 | 33 | 131 | THROTTLE ACTUATOR - OPEN CIRCUIT | There is an Open Circuit to the Throttle Actuator. | Check Harness for damage. |
| 33132 | 33 | 132 | THROTTLE ACTUATOR - SHORT TO BATTERY | There is a Short to Battery to the Throttle Actuator. | Check Harness for damage. |

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC 33170 | Flash Code | Sequence | Fault Message | Fault Description | |
|------------------|------------|----------|---|---|--|
| | 33 | 170 | LIFT DOWN VALVE - OPEN CIRCUIT | There is a Short to Ground to the Lift Down Valve. | Check Check Harness for damage. |
| 33171 | 33 | 171 | LIFT DOWN VALVE - SHORT TO BATTERY | There is an Open Circuit to the Lift Down Valve. | Check Harness for damage. |
| 33172 | 33 | 172 | LIFT DOWN VALVE - SHORT TO GROUND | There is a Short to Battery to the Lift Down Valve. | Check Harness for damage. |
| 33175 | 33 | 175 | JIB ROTATE LEFT VALVE - OPEN CIRCUIT | There is an Open Circuit to the JIB Rotate Left Valve. | Check Harness for damage. |
| 33176 | 33 | 176 | JIB ROTATE LEFT VALVE - SHORT TO BATTERY | There is a Short to Battery to the JIB Rotate Left Valve. | Check Harness for damage. |
| 33177 | 33 | 177 | JIB ROTATE LEFT VALVE - SHORT TO GROUND | There is a Short to Ground to the JIB Rotate Left Valve. | Check Harness for damage. |
| 33178 | 33 | 178 | JIB ROTATE RIGHT VALVE - OPEN CIRCUIT | There is an Open Circuit to the JIB Rotate Right Valve. | Check Harness for damage. |
| 33179 | 33 | 179 | JIB ROTATE RIGHT VALVE - SHORT TO BATTERY | There is a Short to Battery to the JIB Rotate Right Valve. | Check Harness for damage. |
| 33180 | 33 | 180 | JIB ROTATE RIGHT VALVE - SHORT TO GROUND | There is a Short to Ground to the JIB Rotate Right Valve. | Check Harness for damage. |
| 33182 | 33 | 182 | LIFT VALVES - SHORT TO BATTERY | There is a Short to Battery to the Lift Valves. | Check Harness for damage. |
| 33186 | 33 | 186 | TELESCOPE OUT VALVE - OPEN CIRCUIT | There is an Open Circuit to the Main Telescope Out Valve. | Check Harness for damage. |
| 33188 | 33 | 188 | TELESCOPE OUT VALVE - SHORT TO GROUND | There is a Short to Ground to the Main Telescope Out Valve. | Check Harness for damage. |
| 33189 | 33 | 189 | TELESCOPE IN VALVE - OPEN CIRCUIT | There is an Open Circuit to the Main Telescope In Valve. | Check Harness for damage. |
| 33190 | 33 | 190 | TELESCOPE IN VALVE - SHORT TO GROUND | There is a Short to Ground to the Main Telescope In Valve. | Check Harness for damage. |
| 33207 | 33 | 207 | HORN-OPEN CIRCUIT | There is an Open Circuit to the Horn. | Check Harness for damage. |
| 33208 | 33 | 208 | HORN - SHORT TO BATTERY | There is a Short to Battery to the Horn. | Check Harness for damage. |
| 33209 | 33 | 209 | HORN-SHORT TO GROUND | There is a Short to Ground to the Horn. | Check Harness for damage. |
| 33279 | 33 | 279 | GLOWPLUG-OPEN CIRCUIT | There is an Open Circuit to the Glow Plugs. | Check Harness for damage. |
| 33280 | 33 | 280 | GLOWPLUG-SHORT TO BATTERY | There is a Short to Battery to the Glow Plugs. | Check Harness for damage. |
| 33281 | 33 | 281 | GLOWPLUG - SHORT TO GROUND | There is a Short to Ground to the Glow Plugs. | Check Harness for damage. |
| 33287 | 33 | 287 | LIFT - CURRENT FEEDBACK READING TOO LOW | The Engine State = ENGINE RUNNING; The UGM commanded current > 250mA; The difference between the commanded current and the measured feedback current > [the larger of (125mA) or (15% of the commanded function Max)] for longer than 1 second. | The UGM shall suspend Lift Up and Down command and revert to Open Loop Current control for Lift; The UGM shall limit Lift Up and Down to Creep speed after controls initialized. |
| 33295 | 33 | 295 | SWING LEFT VALVE - OPEN CIRCUIT | There is an Open Circuit to the Swing Left Valve. | Check Harness for damage. |

6-64 3121139

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC | Flash Code | Sequence | Fault Message | Fault Description | Check |
|-------|------------|----------|--|---|--|
| 33306 | 33 | 306 | SWING LEFT VALVE - SHORT TO BATTERY | There is short to Battery to the Swing Left Valve. | Check Harness for damage. |
| 33314 | 33 | 314 | FLOW CONTROL VALVE - OPEN CIRCUIT | There is an Open Circuit to the Flow Control Valve. | Check Harness for damage. |
| 33315 | 33 | 315 | FLOW CONTROL VALVE - SHORT TO BATTERY | There is short to Battery to the Flow Control Valve | Check Harness for damage. |
| 33316 | 33 | 316 | FLOW CONTROL VALVE - SHORT TO GROUND | There is short to Ground to the Flow Control Valve | Check Harness for damage. |
| 33317 | 33 | 317 | DRIVEFORWARD VALVE - OPEN CIRCUIT | There is an Open Circuit to the Drive Forward Valve. | Check Harness for damage. |
| 33318 | 33 | 318 | DRIVEFORWARD VALVE - SHORT TO BATTER | There is short to Battery to the Drive Forward Valve. | Check Harness for damage. |
| 33319 | 33 | 319 | DRIVEFORWARD VALVE-SHORT TO GROUND | There is short to Ground to the Drive Forward Valve. | Check Harness for damage. |
| 33320 | 33 | 320 | DRIVE REVERSE VALVE - OPEN CIRCUIT | There is an Open Circuit to the Drive Reverse Valve. | Check Harness for damage. |
| 33321 | 33 | 321 | DRIVE REVERSE VALVE - SHORT TO BATTERY | There is a short to Battery to the Drive Reverse Valve. | Check Harness for damage. |
| 33322 | 33 | 322 | DRIVE REVERSE VALVE - SHORT TO GROUND | There is a short to Ground to the Drive Reverse Valve. | Check Harness for damage. |
| 33323 | 33 | 323 | LIFT UP VALVE - OPEN CIRCUIT | There is an Open Circuit to the Lift Up Valve. | Check Harness for damage. |
| 33324 | 33 | 324 | LIFT UP VALVE - SHORT TO BATTERY | There is a short to Battery to the Lift Up Valve. | Check Harness for damage. |
| 33325 | 33 | 325 | LIFT UP VALVE - SHORT TO GROUND | There is a Short to Ground to the Lift Up Valve. | Check Harness for damage. |
| 33331 | 33 | 331 | DRIVE-CURRENT FEEDBACK READING TOO LOW | The Engine State = ENGINE RUNNING; The UGM commanded current > 250mA; The difference between the commanded current and the measured feedback current > [the larger of (125mA) or (15% of the commanded function Max)] for longer than 1 second. | The UGM shall suspend Drive Forward and Reverse com- mand and revert to Open Cur- rent loop control for Drive; The UGM shall limit Drive For- ward and Reverse to Creep speed after controls initial- ized. |
| 33410 | 33 | 410 | DRIVE-CURRENT FEEDBACK READING LOST | Measured feedback current < 225mA while PWM output > 40% for a period of 100ms. | The UGM shall suspend Drive Forward and Reverse command and revert to Open Current loop control for Drive; The UGM shall limit Drive Forward and Reverse to Creep speed after controls initialized. |
| 33412 | 33 | 412 | SWING VALVES - SHORT TO BATTERY | There is a short to Battery to the Swing Valves. | Check Harness for damage. |
| 33414 | 33 | 414 | SWING-CURRENT FEEDBACK READING TOO LOW | Current feedback into controller is below threshold value. | Check wiring and coil. |

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC | Flash Code | Sequence | Fault Message | Fault Description | Check |
|-------|------------|----------|--|---|--|
| 33415 | 33 | 415 | FLOW CONTROL VALVE - CURRENT FEEDBACK READING TOO LOW | The Engine State = ENGINE RUNNING; The UGM commanded current > 250mA; The difference between the commanded current and the measured feedback current > [the larger of (125mA) or (15% of the commanded function Max)] for longer than 1 second. | The UGM shall suspend Flow Control and revert to Open Current loop control for Flow Control. |
| 33417 | 33 | 417 | LIFT - CURRENT FEEDBACK READING LOST | Measured feedback current < 225mA while PWM output > 40% for a period of 100ms. | The UGM shall suspend Lift Up and Down command and revert to Open Loop Current control for Lift; The UGM shall limit Lift Up and Down to Creep speed after controls initialized. |
| 33418 | 33 | 418 | SWING-CURRENT FEEDBACK READING LOST | Current feedback into controller not detected. | Check wiring and coil. |
| 33419 | 33 | 419 | FLOW CONTROL VALVE - CURRENT FEEDBACK READING LOST | Measured feedback current < 225mA while PWM output > 40% for a period of 100ms. | The UGM shall suspend Flow Control and revert to Open Current loop control for Flow Control. |
| 33488 | 33 | 488 | SWING FLOW CONTROL VALVE - SHORT TO GROUND | There is a short to the Ground to the Swing Flow Control Valve. | Check Harness for damage. |
| 33575 | 33 | 575 | ECM PULL DOWN RESISTOR - OPEN CIRCUIT | There is an Open Circuit to the ECM Pull Down Resistor. | Check Harness for damage. |
| 340 | 34 | 0 | <<< PLATFORM OUTPUT DRIVER>>> | | |
| 341 | 34 | 1 | PLATFORM LEVEL UP VALVE - OPEN CIRCUIT | There is an Open Circuit to the Platform Level Up Valve. | Check Harness for damage. |
| 342 | 34 | 2 | PLATFORM LEVEL UP VALVE-SHORT TO BATTERY | There is a Short to Battery to the Platform Level Up Valve. | Check Harness for damage. |
| 343 | 34 | 3 | PLATFORM LEVEL UP VALVE - SHORT TO GROUND | There is a Short to Ground to the Platform Level Up Valve. | Check Harness for damage. |
| 344 | 34 | 4 | PLATFORM LEVEL UP VALVE - SHORT TO BATTERY OR OPEN CIRCUIT | There is a Short to Battery or an Open Circuit to the Platform Level Up Valve. | Check Harness for damage. |
| 345 | 34 | 5 | PLATFORM LEVEL DOWN VALVE - OPEN CIRCUIT | There is an Open Circuit to the Platform Level Down Valve. | Check Harness for damage. |
| 346 | 34 | 6 | PLATFORM LEVEL DOWN VALVE - SHORT TO BATTERY | There is a short to Battery to the Platform Level Down Valve. | Check Harness for damage. |
| 347 | 34 | 7 | PLATFORM LEVEL DOWN VALVE - SHORT TO GROUND | There is a short to the Ground to the Platform Level Down Valve. | Check Harness for damage. |
| 348 | 34 | 8 | PLATFORM LEVEL DOWN VALVE-SHORT TO BATTERY OR OPEN CIRCUIT | There is a Short to Battery or an Open Circuit to the Platform Level Down Valve. | Check Harness for damage. |
| 349 | 34 | 9 | PLATFORM ROTATE LEFT VALVE - OPEN CIRCUIT | There is an Open Circuit to the Platform Rotate Left Valve. | Check Harness for damage. |
| 3410 | 34 | 10 | PLATFORM ROTATE LEFT VALVE - SHORT TO BATTERY | There is a short to Battery to the Platform Rotate Left Valve. | Check Harness for damage. |
| 3411 | 34 | 11 | PLATFORM ROTATE LEFT VALVE - SHORT TO GROUND | There is a short to Ground to the Platform Rotate Left Valve. | Check Harness for damage. |
| 3412 | 34 | 12 | PLATFORM ROTATE RIGHT VALVE - OPEN CIRCUIT | There is an Open Circuit to the Platform Rotate Right Valve. | Check Harness for damage. |

6-66 3121139

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC | Flash Code | Sequence | Fault Message | Fault Description | Check |
|------|------------|----------|--|---|---|
| 3413 | 34 | 13 | PLATFORM ROTATE RIGHT VALVE - SHORT TO BATTERY | There is a short to Battery to the Platform Rotate Right Valve. | Check Harness for damage. |
| 3414 | 34 | 14 | PLATFORM ROTATE RIGHT VALVE - SHORT TO GROUND | There is a short to Ground to the Platform Rotate Right Valve. | Check Harness for damage. |
| 3415 | 34 | 15 | JIB LIFT UP VALVE - OPEN CIRCUIT | There is an Open Circuit to the JIB Lift Up Valve. | Check Harness for damage. |
| 3416 | 34 | 16 | JIB LIFT UP VALVE - SHORT TO BATTERY | There is a Short to Battery to the JIB Lift Up Valve. | Check Harness for damage. |
| 3417 | 34 | 17 | JIB LIFT UP VALVE - SHORT TO GROUND | There is a short to Ground to the JIB Lift Up Valve. | Check Harness for damage. |
| 3418 | 34 | 18 | JIB LIFT DOWN VALVE - OPEN CIRCUIT | There is an Open Circuit to the JIB Lift Down Valve. | Check Harness for damage. |
| 3419 | 34 | 19 | JIB LIFT DOWN VALVE - SHORT TO BATTERY | There is a Short to Battery to the JIB Lift Down Valve. | Check Harness for damage. |
| 3420 | 34 | 20 | JIB LIFT DOWN VALVE - SHORT TO GROUND | There is a Short to Ground to the JIB Lift Down Valve. | Check Harness for damage. |
| 3421 | 34 | 21 | JIB ROTATE LEFT VALVE - OPEN CIRCUIT | There is an Open Circuit to the JIB Rotate Left Valve. | Check Harness for damage. |
| 3422 | 34 | 22 | JIB ROTATE LEFT VALVE - SHORT TO BATTERY | There is a Short to Battery to the JIB Rotate Left Valve. | Check Harness for damage. |
| 3423 | 34 | 23 | JIB ROTATE LEFT VALVE - SHORT TO GROUND | There is a Short to Ground to the JIB Rotate Left Valve. | Check Harness for damage. |
| 3424 | 34 | 24 | JIB ROTATE RIGHT VALVE - OPEN CIRCUIT | There is an Open Circuit to the JIB Rotate Right Valve. | Check Harness for damage. |
| 3425 | 34 | 25 | JIB ROTATE RIGHT VALVE - SHORT TO BATTERY | There is a Short to Battery to the JIB Rotate Right Valve. | Check Harness for damage. |
| 3426 | 34 | 26 | JIB ROTATE RIGHT VALVE - SHORT TO GROUND | There is a Short to Ground to the JIB Rotate Right Valve. | Check Harness for damage. |
| 430 | 43 | 0 | << <engine>>></engine> | | |
| 431 | 43 | 1 | FUEL SENSOR - SHORT TO BATTERY OR OPEN CIRCUIT | The Fuel Sensor reading is > 4.3V. | Energize fuel sensor per System Indicators |
| 432 | 43 | 2 | FUEL SENSOR - SHORT TO GROUND | The Fuel Sensor reading is < 0.2V. | Energize fuel sensor per Sys- tem Indicators |
| 433 | 43 | 3 | OIL PRESSURE - SHORT TO BATTERY | The Oil Pressure Sensor reading is > 6.6V. | Deutz engine only. |
| 434 | 43 | 4 | OIL PRESSURE - SHORT TO GROUND | The Oil Pressure Sensor reading is < 0.1V for more then 5 seconds. | Deutz engine only Not reported during engine start. |
| 435 | 43 | 5 | COOLANT TEMPERATURE - SHORT TO GROUND | The Coolant Temperature Sensor reading is < 0.1 V. | Deutz engine only. |
| 436 | 43 | 6 | FORD FAULT CODE ## | All ford fault codes except 63 are simply passed through from the Ford ECM. They only occur if a Ford Engine is selected in the machine configuration digits. Can be reported during power-up sequence. | |

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC | Flash Code | Sequence | Fault Message | Fault Description | Check |
|------|------------|----------|--|---|--|
| 437 | 43 | 7 | ENGINETROUBLECODE | Displays engine SPN FMI code. | Report and log in Help If [(MACHINE SETUP > DEUTZ EMR2) or (MACHINE SETUP > DEUTZ EMR4) and SPN:FMI = 535:7], prohibit engine cranking. |
| 438 | 43 | 8 | HIGHENGINETEMP | (Ford engine only) The engine temperature is > 117 C. (Deutz engine only) The engine temperature is > 130 C. | Ford / Deutz engine only. |
| 439 | 43 | 9 | AIR FILTER BYPASSED | The Air Filter is clogged. | Check Airfilter for clogging |
| 4310 | 43 | 10 | NO ALTERNATOR OUTPUT | Battery voltage is < 11.5 volts for more then 15 seconds after engine start. | Activate the No Charge indicator J4-26 per System Indicators. |
| 4311 | 43 | 11 | LOW OIL PRESSURE | (Ford engine only) The ECM has reported a low oil pressure fault. (Deutz engine only) Oil pressure is < 8 PSI for more then 10 seconds after engine start. | Ford / Deutz engine only. |
| 4312 | 43 | 12 | 485 COMMUNICATIONS LOST | This fault only occurs with a Ford Engine. It occures when no response are received from the ECM for 2.5 seconds. Can be reported during power-up sequence. | |
| 4313 | 43 | 13 | THROTTLE ACTUATOR FAILURE | The engine RPM is > XXX for more then XX seconds. | |
| 4314 | 43 | 14 | WRONG ENGINE SELECTED - ECM DETECTED | A ECM was detected with a non-ECM type engine selected. | |
| 4322 | 43 | 22 | LOSS OF ENGINE SPEED SENSOR | The engine RPM sensor indicates 0 RPM AND the Oil Pressure Sensor indicates > 8 PSI for three seconds. | Diesel engine only. |
| 4323 | 43 | 23 | SPEED SENSOR READING INVALID SPEED | The engine RPM sensor indicates > 4000 RPM. | Diesel engine only. |
| 4331 | 43 | 31 | SOOT LOAD WARNING - LOW | SPN/FMI 3719/16 3703/31 | Check Engine. |
| 4332 | 43 | 32 | SOOT LOAD WARNING-HIGH | SPN/FMI 3719/0 3714/31 | Check Engine. |
| 4333 | 43 | 33 | SOOT LOAD WARNING - SEVERE | SPN/FMI 3715/31 | Check Engine. |
| 4334 | 43 | 34 | ENGINE COOLANT - LOW LEVEL | MACHINE SETUP > ENGINE = DEUTZEMR4; ECM transmits a J1939 DM1 message for an engine coolant low level fault (SPN:FMI 111:1) on CAN2 or uses the J1939 Transport Protocol every one second to send this information if multiple engine faults exist. | MACHINE SETUP > ENGINE SHUTDOWN = ENABLED then shutdown the engine; Activate High Engine Temper- ature indicator J4-28. |
| 440 | 44 | 0 | <<< BATTERY SUPPLY>>> | | |
| 441 | 44 | 1 | BATTERY VOLTAGE TOO LOW - SYSTEM SHUTDOWN | Battery voltage is < 9V. | |
| 442 | 44 | 2 | BATTERY VOLTAGE TOO HIGH - SYSTEM SHUTDOWN | Battery voltage is > 16V. | |
| 445 | 44 | 5 | BATTERY VOLTAGE LOW | Battery voltage is < 11V for more then 5 seconds. | |

6-68 3121139

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC | Flash Code | Sequence | Fault Message | Fault Description | Check |
|------|------------|----------|--|--|---|
| 660 | 66 | 0 | << <communication>>></communication> | | |
| 662 | 66 | 2 | CANBUS FAILURE - PLATFORM MODULE | Platform Module CAN communication lost. | |
| 664 | 66 | 4 | CANBUS FAILURE - ACCESSORY MODULE | The accessory module is not receiving CAN messages. This is probably due to wiring problem. | Check the Wiring. |
| 666 | 66 | 6 | CANBUS FAILURE - ENGINE CONTROLLER | Engine Control Module CAN | ECM equipped engine only. |
| 6620 | 66 | 20 | CANBUS FAILURE - UMS SENSOR | communication lost. | |
| 6622 | 66 | 22 | CANBUS FAILURE - TCU MODULE | Machine Setup/Telematics = YES, No device heartbeat for 30 sec | |
| 6623 | 66 | 23 | CANBUS FAILURE - GATEWAY MODULE | Machine Setup/Telematics = YES, No device heartbeat for 30 sec | |
| 6629 | 66 | 29 | CANBUS FAILURE - TELEMATICS CANBUS LOADING TOO HIGH | | |
| 6657 | 66 | 57 | CANBUS FAILURE - TEMPERATURE SENSOR | MACHINE SETUP > TEMP CUTOUT = YES; UGM does not receive any CAN messages from the Ambient Temperature sensor in 250ms | The UGM shall set Low Temperature Cutout state = Faulty If the Machine is in Platform Mode and if the Boom is Above Elevation; The UGM shall suspend motion; The UGM shall limit the machine to Creep speed after controls initialized If the Machine is in Platform Mode and if the Boom is not Above Elevation. |
| 671 | 67 | 1 | ACCESSORY FAULT | | |
| 680 | 68 | 0 | << <telematics>>></telematics> | | |
| 681 | 68 | 1 | REMOTE CONTRACT MANAGEMENT OVERRIDE - ALL FUNCTIONS IN CREEP | | |
| 810 | 81 | 0 | << <tilt sensor="">>></tilt> | | |
| 813 | 81 | 3 | CHASSIS TILT SENSOR NOT CALIBRATED | The Chassis Tilt Sensor has not been calibrated. | |
| 815 | 81 | 5 | CHASSIS TILT SENSOR DISAGREEMENT | | |
| 816 | 81 | 6 | UMS SENSOR NOT CALIBRATED | The Control System detects a sensor out of range condition or a not calibrated fault with UMS angle sensor | |
| 817 | 81 | 7 | UMS SENSOR FAULT | The system detects that the UMS sensor frequency outside the 100Hz+/-5Hz range or the duty cycle is outside 50% +/-21% Range. | |
| 820 | 82 | 0 | <<< PLATFORM LOAD SENSE >>> | | |
| 825 | 82 | 5 | LSS HAS NOT BEEN CALIBRATED | The Load Sensing System Module has not been calibrated. | UGM to set Platform Load State = Overloaded. |

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC | Flash Code | Sequence | Fault Message | Fault Description | Check |
|------|------------|----------|--|--|--|
| 826 | 82 | 6 | RUNNING AT CREEP - PLATFORM OVERLOADED | All functions at creep, the Load Sensing System indicates the Platform is overloaded AND is configured to warn only while the Platform is overloaded. | |
| 827 | 82 | 7 | DRIVE & BOOM PREVENTED - PLATFORM OVERLOADED | Driving and boom functions are not possible while the Load Sensing System indicates the Platform is overloaded AND is configured to prevent drive and boom functions while the Platform is overloaded. | |
| 828 | 82 | 8 | LIFT UP & TELE OUT PREVENTED - PLATFORM OVERLOADED | Lift up and telescope out are not possible while the Load Sensing System indicates the Platform is overloaded AND is configured to prevent Lift up and telescope out while the Platform is overloaded. | |
| 8639 | 86 | 39 | FRONT LEFT STEER VALVE - OPEN CIRCUIT | There is an open circuit to the Front Left Steer Valve | Check Harness for damage. |
| 8640 | 86 | 40 | FRONT LEFT STEER VALVE - SHORT TO BATTERY | There is a short to Battery to the Front Left Steer Valve | Check Harness for damage. |
| 8641 | 86 | 41 | FRONT LEFT STEER VALVE - SHORT TO GROUND | There is a short to Ground to the Front Left Steer Valve | Check Harness for damage. |
| 8642 | 86 | 42 | FRONT RIGHT STEER VALVE - OPEN CIRCUIT | There is an open circuit to the Front Right Steer Valve | Check Harness for damage. |
| 8643 | 86 | 43 | FRONT RIGHT STEER VALVE - SHORT TO BATTERY | There is a short to Battery to the Front Right Steer Valve | Check Harness for damage. |
| 8644 | 86 | 44 | FRONT RIGHT STEER VALVE - SHORT TO GROUND | There is a short to Ground to the Front Right Steer Valve | Check Harness for damage. |
| 8645 | 86 | 45 | REAR LEFT STEER VALVE - OPEN CIRCUIT | There is an open circuit to the Rear Left Steer Valve | Check Harness for damage. |
| 8646 | 86 | 46 | REAR LEFT STEER VALVE - SHORT TO BATTERY | There is a short to Battery to the Rear Left Steer Valve | Check Harness for damage. |
| 8647 | 86 | 47 | REAR LEFT STEER VALVE - SHORT TO GROUND | There is a short to Ground to the Rear Left Steer Valve | Check Harness for damage. |
| 8648 | 86 | 48 | REAR RIGHT STEER VALVE - OPEN CIRCUIT | There is an open circuit to the Rear Right Steer Valve | Check Harness for damage. |
| 8649 | 86 | 49 | REAR RIGHT STEER VALVE - SHORT TO BATTERY | There is a short to Battery to the Rear Right Steer Valve | Check Harness for damage. |
| 8650 | 86 | 50 | REAR RIGHT STEER VALVE - SHORT TO GROUND | There is a short to Ground to the Rear Right Steer Valve | Check Harness for damage. |
| 871 | 87 | 1 | RETURN FILTER BYPASSED | Hydraulic Return Filter Clogged | Check Hydraulic Return Filter. |
| 872 | 87 | 2 | CHARGE PUMP FILTER BYPASSED | Charge Pump Filter Clogged | Check Charge Pump Filter. |
| 873 | 87 | 3 | MACHINE SAFETY SYSTEM OVERRIDE OCCURRED | MSS0 = Active | Response described in MSSO Influence on Machine Opera- tion section. |

6-70 3121139

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC | Flash Code | Sequence | Fault Message | Fault Description | Check |
|------|------------|----------|--|---|---|
| 998 | 99 | 8 | EEPROM FAILURE - CHECK ALL SETTINGS | The Ground Module has reported an EEPROM failure. | Disable all machine and engine functions (i.e., command engine shutdown and do not permit start); reset the section of EEPROM where the failure occurred to defaults. |
| 9910 | 99 | 10 | FUNCTIONS LOCKED OUT - PLATFORM MODULE SOFTWARE VERSION IMPROPER | The Platform Module software version is not compatible with the rest of the system. | Activate the platform alarm continuously Creep mode is active If Platform Mode is active, disable all Drive, Steer, and Boom functions and do not permit Machine Enable. |
| 9914 | 99 | 14 | PLATFORM MODULE SOFTWARE UPDATE REQUIRED | The Platform Module software requires an update. | |
| 9915 | 99 | 15 | CHASSIS TILT SENSOR NOT GAIN CALIBRATED | The Chassis Tilt Sensor gain calibration has been lost. | |
| 9916 | 99 | 16 | CHASSIS TILT SENSOR GAIN OUT OF RANGE | The Chassis Tilt Sensor gain calibration has become corrupted. | |
| 9919 | 99 | 19 | GROUND SENSOR REF VOLTAGE OUT OF RANGE | The Ground Module has reported that its sensor reference voltage is outside acceptable range. | Not reported during power- up. |
| 9920 | 99 | 20 | PLATFORM SENSOR REF VOLTAGE OUT OF RANGE | The Platform Module has reported that its sensor reference voltage is outside acceptable range. | Not reported during power- up. |
| 9921 | 99 | 21 | GROUND MODULE FAILURE - HIGH SIDE DRIVER CUTOUT FAULTY | The Ground Module has reported that its high side driver cutout failed. | |
| 9922 | 99 | 22 | PLATFORM MODULE FAILURE - HWFS CODE 1 | The Platform Module has reported that the V(Low) FET has failed. | |
| 9923 | 99 | 23 | GROUND MODULE FAILURE - HWFS CODE 1 | The Ground Module has reported that the V(Low) FET has failed. | |
| 9924 | 99 | 24 | FUNCTIONS LOCKED OUT - MACHINE NOT CONFIGURED | The machine is powered up and no model has been selected yet in the MACHINE SETUP menu. | Display ??? or NO MODEL at Analyzer MACHINE SETUP menu MACHINE SETUP- > MODEL NUMBER Do not report any other faults Disable all machine and engine functions (i.e., command engine shutdown and do not permit start). |
| 9944 | 99 | 44 | CURRENT FEEDBACK GAINS OUT OF RANGE | The factory set current feedback gains are out of range. | A gain of 1 is used for the factory gain (s) that was out of range; all functions shall be placed in Creep mode. |

Table 6-12. Diagnostic Trouble Code Chart (DTC)

| DTC | Flash Code | Sequence | Fault Message | Fault Description | Check |
|------|------------|----------|--|--|---|
| 9945 | 99 | 45 | CURRENT FEEDBACK CALIBRATION CHECKSUM INCORRECT | The factory set current feedback checksum is not correct. | |
| 9979 | 99 | 79 | FUNCTIONS LOCKED OUT - GROUND MODULE SOFTWARE VERSION IMPROPER | Temporary fault for the telematics project. The model needs to be a 600S or 1350S if not this fault will be generated and Platform controls will be prevented. This fault was to ensure that the software will only work for these two models. | Disable all machine and engine functions (i.e., command engine shutdown and do not permit start). |

6-72 3121139

SECTION 7. BASIC ELECTRICAL INFORMATION & SCHEMATICS

7.1 GENERAL

This section contains basic electrical information and schematics to be used for locating and correcting most of the operating problems which may develop. If a problem should develop which is not presented in this section or which is not corrected by listed corrective actions, technically qualified guidance should be obtained before proceeding with any maintenance.

NOTE: Some of the procedures/connectors shown in this section may not be applicable to all models.

7.2 MULTIMETER BASICS

A wide variety of multimeters or Volt Ohm Meters (VOM) can be used for troubleshooting your equipment. This section shows diagrams of a common, digital VOM configured for several different circuit measurements. Instructions for your VOM may vary. Please consult the meter operator's manual for more information.

Grounding

"Grounding the meter" means to take the black lead (which is connected to the COM (common) or negative port) and touch it to a good path to the negative side of the Voltage source.

Backprobing

To "backprobe" means to take the measurement by accessing a connector's contact on the same side as the wires, the back of the connector. Readings can be done while maintaining circuit continuity this way. If the connector is the sealed type, great care must be taken to avoid damaging the seal around the wire. It is best to use probes or probe tips specifically designed for this technique, especially on sealed connectors. Whenever possible insert probes into the side of the connector such that the test also checks both terminals of the connection. It is possible to inspect a connection within a closed connector by backprobing both sides of a connector terminal and measuring resistance. Do this after giving each wire a gentle pull to ensure the wires are still attached to the contact and contacts are seated in the connector.

Min/Max

Use of the "Min/Max" recording feature of some meters can help when taking measurements of intermittent conditions while alone. For example, you can read the Voltage applied to a solenoid when it is only operational while a switch, far from the solenoid and meter, is held down.

Polarity

Getting a negative Voltage or current reading when expecting a positive reading frequently means the leads are reversed. Check what reading is expected, the location of the signal and that the leads are connected to the device under test correctly. Also check that the lead on the "COM" port goes to the Ground or negative side of the signal and the lead on the other port goes to the positive side of the signal.

Scale

M = Mega = 1,000,000 * (Displayed Number)

k = kilo = 1,000 * (Displayed Number)

m = milli = (Displayed Number) / 1,000

 $\mu = micro = (Displayed Number) / 1,000,000$

Example: 1.2 kW = 1200 WExample: 50 mA = 0.05 A

Voltage Measurement




Figure 7-1. Voltage Measurement (DC)

- If meter is not auto ranging, set it to the correct range (See multimeter's operation manual)
- · Use firm contact with meter leads

3121139 7-1

Resistance Measurement




Figure 7-2. Resistance Measurement

- First test meter and leads by touching leads together.
 Resistance should read a short circuit (very low resistance).
- Circuit power must be turned OFF before testing resistance.
- Disconnect component from circuit before testing.
- If meter is not auto ranging, set it to the correct range (See multimeter's operation manual).
- Use firm contact with meter leads.

Continuity Measurement




Figure 7-3. Continuity Measurement

- Some meters require a separate button press to enable audible continuity testing.
- Circuit power must be turned OFF before testing continuity.
- · Disconnect component from circuit before testing.
- Use firm contact with meter leads.
- First test meter and leads by touching leads together.
 Meter should produce an audible alarm, indicating continuity.

7-2 3121139

Current Measurement




Figure 7-4. Current Measurement (DC)

- · Set up the meter for the expected current range.
- Be sure to connect the meter leads to the correct jacks for the current range you have selected.
- If meter is not auto ranging, set it to the correct range (See multi meter's operation manual).
- · Use firm contact with meter leads.

7.3 CHECKING SWITCHES

Basic Check

The following check determines if the switch is functioning properly, not the circuit in which the switch is placed. A switch is functioning properly when there is continuity between the correct terminals or contacts only when selected.

- 1. De-energize the circuit.
- 2. Isolate the switch from the rest of the circuit if possible. If not possible, keep in mind it may affect readings.
- **3.** Access the terminals to the switch.
- 4. If the switch has two terminals:
 - a. Measure resistance across the terminals.
 - **b.** Change the switch position.
 - c. Measure resistance again with the leads in the same positions. If the meter was reading short, it should read an open. If the meter was reading open it should read short.
- 5. If the switch has more than two terminals, consult the schematic or switch diagram to determine what terminals will be connected. The test is similar to testing a switch with two terminals.
 - **a.** Place one meter lead on the common contact and the other on a different contact in the same circuit.
 - **b.** Cycle through all positions of the switch. The meter should read short only when the switch connects the two terminals and open otherwise.
 - **c.** If the switch has more than one common contact repeat the process for that circuit.

Limit Switches

Limit switches are used to control movement or indicate position. Mechanical limit switches are just like manually operated switches except that the moving object operates the switch. These switches can be tested the same way as a standard switch by manually operating the sensing arm.

Another type of limit switch used by JLG is the inductive proximity switch, also referred to as a "prox switch". Inductive proximity switches are actuated only by ferrous metal (metal that contains Iron, such as steel) near the switch. They do not require contact, and must be energized to actuate. These types of switches can be used to detect boom or platform position, for example. These switches have a sensing face where the switch can detect ferrous metal close to it. To find the sensing face, take note how the switch is mounted and how the mechanisms meet the switch. Test this type of switch as follows:

3121139 7-3

- 1. Remove prox switch from its mount.
- Reconnect harness if it was disconnected for step a, and turn on machine.
- Hold switch away from metal and observe switch state in the control system diagnostics using the Analyzer. See vehicle or control system documentation on how to do this.
- **4.** Place sensing face of switch on the object to be sensed by the switch. If that is not available, use a piece of ferrous metal physically similar to it. The switch state in the control system diagnostics should change.
- **5.** When reinstalling or replacing switch be sure to follow mounting instructions and properly set the gap between the switch and object sensed.

Automatic Switches

If the switch is actuated automatically, by temperature or pressure for example, find a way to manually actuate the switch to test it. Do this either by applying heat or pressure, for example, to the switch. These switches may need to be energized to actuate.

- Connect instrumentation to monitor and/or control the parameter the switch is measuring.
- Observe switch state in control system with the Analyzer. See vehicle or control system documentation on how to do this.
- Operate system such that the switch actuates. This could be going over a certain pressure or temperature, for example. The state indicated in the control system should change.

Switch Wiring - Low Side, High Side

When controlling a load, a switch can be wired between the positive side of the power source and the load. This switch is called a "high side" switch. The switch supplies the power to the load. When a switch is wired between the negative side of the power source and the load, it is a "low side" switch. The switch provides the ground to the load.

A low side switch will allow voltage to be present on the load. No power is applied because the switch is stopping current flow. This voltage can be seen if the measurement is taken with one test lead on the load and the other on the battery negative side or grounded to the vehicle. What is actually being measured is the voltage drop across the switch. This could mislead a technician into thinking the load is receiving power but not operating. To produce an accurate picture of power or voltage applied to the load, measure voltage across the load's power terminals. Also, the technician can measure the voltage at both power terminals with respect to battery ground. The difference between those two measurements is the voltage applied to the load.

7.4 APPLYING SILICONE DIELECTRIC COMPOUND TO ELECTRICAL CONNECTIONS

NOTE: This section is not applicable for battery terminals.

NOTICE

JLG P/N 0100048 DIELECTRIC GREASE (NOVAGARD G661) IS THE ONLY MATERIAL APPROVED FOR USE AS A DIELECTRIC GREASE.

NOTE: Do NOT apply dielectric grease to the following connections:

- · Main Boom Rotary sensor connections (on Celesco Sensor),
- · LSS Modules connections,
- · Deutz EMR 2 ECM connection.

Silicone Dielectric Compound must be used on all electrical connections except for those mentioned above for the following reasons:

- To prevent oxidation at the mechanical joint between male and female pins.
- To prevent electrical malfunction caused by low level conductivity between pins when wet.

Use the following procedure to apply Silicone Dielectric Compound to the electrical connectors. This procedure applies to all plug connections not enclosed in a box. Silicone grease should not be applied to connectors with external seals.

 To prevent oxidation, silicone grease must be packed completely around male and female pins on the inside of the connector prior to assembly. This is most easily achieved by using a syringe.

NOTE: Over a period of time, oxidation increases electrical resistance at the connection, eventually causing circuit failure.

2. To prevent shorting, silicone grease must be packed around each wire where they enter the outside of the connector housing. Also, silicone grease must be applied at the joint where the male and female connectors come together. Any other joints (around strain reliefs, etc.) where water could enter the connector should also be sealed.

NOTE: This condition is especially common when machines are pressure washed since the washing solution is much more conductive than water.

7-4 3121139

3. Anderson connectors for the battery boxes and battery chargers should have silicone grease applied to the contacts only.

NOTE: Curing-type sealants might also be used to prevent shorting and would be less messy, but would make future pin removal more difficult.


When applied to electrical connections, dielectric grease helps to prevent corrosion of electrical contacts and improper conductivity between contacts from moisture intrusion. Open and sealed connectors benefit from the application of dielectric grease.

Dielectric grease shall be applied to all electrical connectors at the time of connection (except those noted under Exclusions).

Installation of Dielectric Grease

Before following these instructions, refer to excluded connector types (See Exclusions below).

- 1. Use dielectric grease in a tube for larger connection points or apply with a syringe for small connectors.
- 2. Apply dielectric grease to the female contact (fill it approximately ½ full; see example below)
- **3.** Leave a thin layer of dielectric grease on the face of the connector
- **4.** Assemble the connector system immediately to prevent moisture ingress or dust contamination
- **5.** Pierce one of the unused wire seals prior to assembly if the connector system tends to trap air (i.e. AMP Seal) and then install a seal plug.



Deutsch HD, DT, DTM, DRC Series

The Deutsch connector system is commonly used for harsh environment interconnect. Follow the installation instructions.



AWP Seal

The AMP Seal connector system is used on the Control ADE Platform and Ground Modules.

Apply dielectric grease to the female contact. If trapped air prevents the connector from latching, pierce one of the unused wire seals. After assembly, install a seal plug (JLG #4460905) in that location to prevent moisture ingress.

Note that seal plugs may be installed by the wire harness manufacturer if an unused wire seal becomes compromised (wire inserted in the wrong cavity during assembly and then corrected).



Figure 7-5. Application to Female Contacts



Figure 7-6. Use of Seal Plugs

AMP Mate-N-Lok

This connector system is widely used inside enclosures for general-purpose interconnect. Follow the installation instructions.



DIN Connectors

This connector is typically used on hydraulic valves. Follow the installation instructions.



Exclusions

A limited number of connectors do not benefit from dielectric grease, or may be permanently damaged by application. Dielectric grease may not be required in properly sealed enclosures.

7-6 3121139

BRAD HARRISON / PHOENIX CONTACT M12

The connector uses gold contact material to resist corrosion and an o-ring seal for moisture integrity. If dielectric grease is mistakenly applied to this connector system, the low-force contacts cannot displace the grease to achieve electrical contact. Once contaminated, there is no practical way to remove the dielectric grease (replacement of female contacts required). The JLG Load Sensing System and 1250AJP Rotary Angle Sensors are examples of components with the M12 connector system.





AMP JUNIOR TIMER

This type of connector uses back-seals for moisture integrity. However, the low-force contacts cannot displace dielectric grease and create electrical contact. It is possible to use solvents (i.e. contact cleaner or mineral spirits) for the removal of improperly applied dielectric grease. The EMR2 engine control module from Deutz employs this connector system (for example).



7.5 AMP CONNECTOR

Assembly

Check to be sure the wedge lock is in the open, or as-shipped, position (See Figure 7-7.). Proceed as follows:




Figure 7-7. Connector Assembly Figure 1

1. To insert a contact, push it straight into the appropriate circuit cavity as far as it will go (See Figure 7-9.).

2. Pull back on the contact wire with a force of 1 or 2 lbs. to be sure the retention fingers are holding the contact (See Figure 7-9.).




Figure 7-8. AMP Connector

7-8 3121139




Figure 7-9. Connector Assembly Figure 2

3. After all required contacts have been inserted, the wedge lock must be closed to its locked position. Release the locking latches by squeezing them inward (See Figure 7-10.).




Figure 7-10. Connector Assembly Figure 3

4. Slide the wedge lock into the housing until it is flush with the housing (See Figure 7-11.).




Figure 7-11. Connector Assembly Figure 4




Figure 7-12. Connector Disassembly

Disassembly

- 1. Insert a 4.8 mm (3/16") wide screwdriver blade between the mating seal and one of the red wedge lock tabs.
- 2. Pry open the wedge lock to the open position.
- **3.** While rotating the wire back and forth over a half turn (1/4 turn in each direction), gently pull the wire until the contact is removed.

NOTE: The wedge lock should never be removed from the housing for insertion or removal of the contacts.

Wedge Lock

The wedge lock has slotted openings in the forward, or mating end. These slots accommodate circuit testing in the field, by using a flat probe such as a pocket knife. DO NOT use a sharp point such as an ice pick.

Service - Voltage Reading



DO NOT PIERCE WIRE INSULATION TO TAKE VOLTAGE READINGS.

It has been common practice in electrical troubleshooting to probe wires by piercing the insulation with a sharp point. This practice should be discouraged when dealing with the AMPSEAL plug assembly, or any other sealed connector system. The resulting pinholes in the insulation will allow moisture to invade the system by traveling along the wire strands. This nullifies the effectiveness of the connector seals and could result in system failure.

7-10 3121139




Figure 7-13. Connector Installation

7.6 DEUTSCH CONNECTORS

DT/DTP Series Assembly




Figure 7-14. DT/DTP Contact Installation

- Grasp crimped contact about 25mm behind the contact harrel
- **2.** Hold connector with rear grommet facing you.
- Push contact straight into connector grommet until a click is felt. A slight tug will confirm that it is properly locked in place.
- **4.** Once all contacts are in place, insert wedgelock with arrow pointing toward exterior locking mechanism. The wedgelock will snap into place. Rectangular wedges are not oriented. Thy may go in either way.

NOTE: The receptacle is shown - use the same procedure for plug.

DT/DTP Series Disassembly




Figure 7-15. DT/DTP Contact Removal

- **5.** Remove wedgelock using needle nose pliers or a hook shaped wire to pull wedge straight out.
- 6. To remove the contacts, gently pull wire backwards, while at the same time releasing the locking finger by moving it away from the contact with a screwdriver.
- **7.** Hold the rear seal in place, as removing the contact may displace the seal.

7-12 3121139

HD30/HDP20 Series Assembly




Figure 7-16. HD/HDP Contact Installation

- **8.** Grasp contact about 25mm behind the contact crimp barrel.
- **9.** Hold connector with rear grommet facing you.
- 10. Push contact straight into connector grommet until a positive stop is felt. A slight tug will confirm that it is properly locked in place.

LOCKING FINGERS




Figure 7-17. HD/HDP Locking Contacts Into Position

NOTE: For unused wire cavities, insert sealing plugs for full environmental sealing

HD30/HDP20 Series Disassembly




Figure 7-18. HD/HDP Contact Removal

- **11.** With rear insert toward you, snap appropriate size extractor tool over the wire of contact to be removed.
- **12.** Slide tool along into the insert cavity until it engages contact and resistance is felt.
- **13.** Pull contact-wire assembly out of connector.




Figure 7-19. HD/HDP Unlocking Contacts

NOTE: Do Not twist or insert tool at an angle.




Figure 7-20. Electrical Components Installation (WITHOUT UGM) (Prior to SN 0300085332) - Sheet 1 of 2

7-14 3121139




Figure 7-21. Electrical Components Installation (WITHOUT UGM) (Prior to SN 0300085332) - Sheet 2 of 2




Figure 7-22. Electrical Components Installation (WITHOUT UGM) (SN 0300085332 through 0300140000) - Sheet 1 of 2

7-16 3121139





Figure 7-23. Electrical Components Installation (WITHOUT UGM) (SN 0300085332 through 0300140000) - Sheet 2 of 2



Electrical Components Installation (WITH UGM) (Prior to SN 0300140000) - Sheet 1 of 2

7-18 3121139




Figure 7-24. Electrical Components Installation (WITH UGM) (Prior to SN 0300140000) - Sheet 2 of 2




Figure 7-25. Electrical Components Installation (WITH UGM) (SN 0300140000 through 0300182743 and SN B300000100 through B300001091) - Sheet 1 of 2

7-20 3121139




Figure 7-26. Electrical Components Installation (WITH UGM) (SN 0300140000 through 0300182743 and SN B300000100 through B300001091) - Sheet 2 of 2

7.7 ELECTRICAL SCHEMATICS




Figure 7-27. Electrical Schematics Caterpillar, Deutz EMR2 and GM (Prior to SN 0300139080) - Sheet 1 of 6

7-22 3121139




Figure 7-28. Electrical Schematics Caterpillar, Deutz EMR2 and GM (Prior to SN 0300139080) - Sheet 2 of 6




Figure 7-29. Electrical Schematics Caterpillar, Deutz EMR2 and GM (Prior to SN 0300139080) - Sheet 3 of 6

7-24 3121139




Figure 7-30. Electrical Schematics Caterpillar, Deutz EMR2 and GM (Prior to SN 0300139080) - Sheet 4 of 6




Figure 7-31. Electrical Schematics Caterpillar, Deutz EMR2 and GM (Prior to SN 0300139080) - Sheet 5 of 6

7-26 3121139




Figure 7-32. Electrical Schematics Caterpillar, Deutz EMR2 and GM (Prior to SN 0300139080) - Sheet 6 of 6




Figure 7-33. Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 and SN B300000100 through B300000639)- Sheet 1 of 10

7-28 3121139




Figure 7-34. Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 and SN B300000100 through B300000639) - Sheet 2 of 10




Figure 7-35. Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 and SN B300000100 through B300000639) - Sheet 3 of 10

7-30 3121139




Figure 7-36. Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 and SN B300000100 through B300000639) - Sheet 4 of 10




Figure 7-37. Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 and SN B300000100 through B300000639) - Sheet 5 of 10

7-32 3121139




Figure 7-38. Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 and SN B300000100 through B300000639) - Sheet 6 of 10




Figure 7-39. Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 and SN B300000100 through B300000639) - Sheet 7 of 10

7-34 3121139




Figure 7-40. Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 and SN B300000100 through B300000639) - Sheet 8 of 10




Figure 7-41. Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 and SN B300000100 through B300000639) - Sheet 9 of 10

7-36 3121139




Figure 7-42. Electrical Schematics Caterpillar, Deutz EMR2 and GM (SN 0300139080 through 0300161729 and SN B300000100 through B300000639) - Sheet 10 of 10




Figure 7-43. Electrical Schematic (SN 0300161730 through 0300182743 and B300000640 through B300001091) - Sheet 1 of 10

7-38 3121139




Figure 7-44. Electrical Schematic (SN 0300161730 through 0300182743 and B300000640 through B300001091)- Sheet 2 of 10




Figure 7-45. Electrical Schematic (SN 0300161730 through 0300182743 and B300000640 through B300001091)- Sheet 3 of 10

7-40 3121139




Figure 7-46. Electrical Schematic (SN 0300161730 through 0300182743 and B300000640 through B300001091)- Sheet 4 of 10




Figure 7-47. Electrical Schematic (SN 0300161730 through 0300182743 and B300000640 through B300001091)- Sheet 5 of 10

7-42 3121139




Figure 7-48. Electrical Schematic (SN 0300161730 through 0300182743 and B300000640 through B300001091)- Sheet 6 of 10




Figure 7-49. Electrical Schematic (SN 0300161730 through 0300182743 and B300000640 through B300001091)- Sheet 7 of 10

7-44 3121139




Figure 7-50. Electrical Schematic (SN 0300161730 through 0300182743 and B300000640 through B300001091)- Sheet 8 of 10




Figure 7-51. Electrical Schematic (SN 0300161730 through 0300182743 and B300000640 through B300001091)- Sheet 9 of 10

7-46 3121139




Figure 7-52. Electrical Schematic (SN 0300161730 through 0300182743 and B300000640 through B300001091)- Sheet 10 of 10




Figure 7-53. Electrical Schematic GM - Sheet 1 of 2

7-48 3121139




Figure 7-54. Electrical Schematic GM - Sheet 2 of 2

7-50 3121139

PROPOSITION 65 WARNING

- Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm.
- Batteries also contain other chemicals known to the State of California to cause cancer.
- ·Wash hands after handling.

⚠ WARNING: **⚠**

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

1702961







An Oshkosh Corporation Company

Corporate Office JLG Industries, Inc. 1 JLG Drive McConnellsburg PA. 17233-9533 USA

(717) 485-5161(Corporate)(877) 554-5438(Service)(717) 485-6417

JLG Worldwide Locations

JLG Industries 358 Park Road Regents Park NSW 2143 Sydney 2143 Australia

** +6 (12) 87186300 +6 (12) 65813058 Email: techservicesaus@jlg.com JLG Ground Support Oude Bunders 1034 Breitwaterstraat 12A 3630 Maasmechelen Belgium

** +32 (0) 89 84 82 26 Email: emeaservice@jlg.com JLG Latino Americana LTDA Rua Antonia Martins Luiz, 580 Distrito Industrial Joao Narezzi Indiaatuba-SP 13347-404 Brasil

Oshkosh-JLG (Tianjin) Equipment Technology LTD Shanghai Branch No 465 Xiao Nan Road Feng Xian District Shanghai 201204 China

****** +86 (21) 800 819 0050

JLG Industries Dubai Jafza View PO Box 262728, LB 19 20th Floor, Office 05 Jebel Ali, Dubai

** +971 (0) 4 884 1131 +971 (0) 4 884 7683 Email: emeaservice@jlg.com JLG France SAS Z.I. Guillaume Mon Amy 30204 Fauillet 47400 Tonniens France

+33 (0) 553 84 85 86 +33 (0) 553 84 85 74 Email: pieces@jlg.com JLG Deutschland GmbH Max Planck Str. 21 27721 Ritterhude - Ihlpohl Germany

+49 (0) 421 69350-0 +49 (0) 421 69350-45 Email:german-parts@jlg.com JLG Equipment Services Ltd. Rm 1107 Landmark North 39 Lung Sum Avenue Sheung Shui N. T. Hong Kong

+(852) 2639 5783 +(852) 2639 5797

JLG Industries (Italia) S.R.L. Via Po. 22 20010 Pregnana Milanese (MI)

20010 Pregnana Milanese (MI Italy

** +39 (0) 2 9359 5210 +39 (0) 2 9359 5211 Email: ricambi@jlg.com JLG EMEA B.V. Polaris Avenue 63 2132 JH Hoofdorf The Netherlands

+31 (0) 23 565 5665 Email: emeaservice@jlg.com JLG NZ Access Equipment & Services 2B Fisher Cresent Mt Wellington 1060 Auckland, New Zealand

** +6 (12) 87186300 +6 (12) 65813058 Email:techservicesaus@jlg.com JLG Industries Vahutinskoe shosse 24b. Khimki Moscow Region 141400 Russia Federation

** +7 (499) 922 06 99 +7 (499) 922 06 99

Oshkosh-JLG Singapore Technology Equipment Pte Ltd. 35 Tuas Avenue 2 Jurong Industrial Estate Singapore 639454

+65 6591 9030 +65 6591 9045 Email: SEA@jlg.com JLG Iberica S.L. Trapadella, 2 Pol. Ind. Castellbisbal Sur 08755 Castellbisbal Barcelona Spain

+34 (0) 93 772 47 00 +34 (0) 93 771 1762 Email:parts_iberica@jlg.com JLG Sverige AB Enkopingsvagen 150 176 27 Jarfalla Sweden

** +46 (0) 8 506 595 00 +46 (0) 8 506 595 27 Email: nordicsupport@jlg.com JLG Industries (UK) Ltd. Bentley House Bentley Avenue Middleton, Greater Manchester M24 2GP United Kingdom

+44 (0) 161 654 1000 +44 (0) 161 654 1003 Email: ukparts@jlg.com